

**DEPARTMENT OF VETERANS AFFAIRS  
MASTER SPECIFICATIONS**

**TABLE OF CONTENTS  
Section 00 01 10**

**DIVISION 00 - SPECIAL SECTIONS**

00 01 15 List of Drawing Sheets

**DIVISION 01 - GENERAL REQUIREMENTS**

01 00 00	General Requirements	06-09
01 32 16.15	Project Schedules	
01 33 23	Shop Drawings, Product Data, and Samples	11-08
01 42 19	Reference Standards	
01 45 29	Testing Laboratory Services	
	<b>DIVISION 07 -THERMAL AND MOISTURE PROTECTION</b>	
07 81 00	Applied Fireproofing	
07 84 00	Firestopping	
	<b>DIVISION 08 - DOORS AND WINDOWS</b>	
08 90 00	Louvers and Vents	
	<b>DIVISION 09 - FINISHES</b>	
09 91 00	Painting	
	<b>DIVISION 21 - FIRE SUPPRESSION</b>	
21 05 11	Common Work Results for Fire Suppression	
21 13 13	Wet Pipe Sprinkler System	
	<b>DIVISION 22 - PLUMBING</b>	
22 11 00	Facility Water Distribution	
	<b>DIVISION 23 - HEATING, VENTILATING, AND AIR CONDITIONING (HVAC)</b>	
23 05 11	Common Work Results for HVAC and Steam Generation	12-07M
23 05 12	General Motor Requirements for HVAC Equipment	05-03M
23 05 41	Noise and Vibration Control for HVAC Piping and Equipment	12-06M
23 05 93	Testing, Adjusting, and Balancing for HVAC	12-06M
23 07 11	HVAC, Plumbing, Insulation	12-06M
23 09 23	Direct-Digital Control System for HVAC	09-08M
23 21 13	Hydronic Piping	12-06M
23 21 23	Hydronic Pumps	06-07M
23 22 13	Steam and Condensate Heating Piping	12-06M
23 31 00	HVAC Ducts and Casings	10-04M
23 34 00	HVAC Fans	06-04M

The "M" after the date denotes that the document is now in dual Metric/English.

23 40 00	HVAC Air Cleaning Devices	03-06M
23 72 00	Air-to-Air Energy Recovery Equipment	10-07M
23 73 00	Indoor Central-Station Air-Handling Units	04-03M
23 82 16	Air Coils	12-04M
23 82 18	Clean Steam Generators	
	<b>DIVISION 26 - ELECTRICAL</b>	
26 05 11	Requirements for Electrical Installations	05-05M
26 05 21	Low-Voltage Electrical Power Conductors and Cables (600 Volts and Below)	12-05M
26 05 26	Grounding and Bonding for Electrical Systems	10-06M
26 05 33	Raceway and Boxes for Electrical Systems	12-05M
26 29 11	Motor Starters	4-09
26 29 21	Disconnect Switch	03-03M
26 51 00	Interior Lighting	04-09