



CONTRACTOR IS RESPONSIBLE FOR SEALING PENETRATIONS RESULTING FROM THE INSTALLATION OF THEIR WORK.




BLDG#49 - EMERGENCY
GENERATOR EXHAUST

© SCALE: NTS



BLDG#49 - EMERGENCY GENERATOR
INTAKE AIR DAMPER

① SCALE: NTS



BLDG#49 - EMERGENCY GENERATOR
DAMPER OPERATION AND CONTROL

SCALE: NTS

BLDG#49 – EMERGENCY GENERATOR
FUEL OIL PIPING DIAGRAM

② SCALE: NTS

BLDG#49 - EMERGENCY GENERATOR
SECTION VIEW

① SCALE: NTS

GENERAL NOTE:

ALL CONTRACTORS AND SUBCONTRACTORS SHALL VERIFY ALL DIMENSIONS BY MEASUREMENT AT THE BUILDING AND/OR

CONSTRUCTION DOCUMENT SUBMISSION

[illegible]