



1
5-4

SILL AT PRECAST NO SCALE (REVISED)

1. INSTALL A VERTICAL TERMINATION BAR WITH WATERBLOCK BEHIND MEMBRANE INTO PRECAST AT STEP DOWN BETWEEN REGLET FLASHING AND THROUGH-WALL FLASHING. ALL METAL COMPONENTS MUST BE NEATLY COPED TO FIT.
2. ENSURE REGLET COUNTERFLASHES END DAM OF THROUGH-WALL FLASHING PRIOR TO INSTALLING BRICK.