

C3-61

Tap into existing medium pressure duct in break room w/ 6" round tap. Run 6" dia duct into IT closet and install manual volume damper in space above closet. Provide 1" duct wrap insulation. Set initial flow to 250 cfm. Install 24" x 5" security louver 12" above bottom edge of door.

