



- 1 TRANSITION 2838 SS EA TO NEGROPSY TABLE OUTLET FIELD VERIFY EXACT LOCATION DUCTWORK EA TO 2838 GYM.
 - 2 REBARANCE X-14V TO 1230 CFM MAX, 1230 CFM MIN.
 - 3 REBARANCE SUPPLY AIR DIFFUSER TO 815 GYM.
 - 4 CUT AND PATCH WALL AS REQUIRED IN ORDER TO ROUTE DUCTWORK, FINE STOP PENETRATION.
 - 5 X-5A DUCT MOUNTED AT 16'-0" AFF (BOTTOM).
 - 6 REMOVE AND REINSTALL X-14X14 SA AND X-16X8 RA RISERS IN ORDER TO ACCOMMODATE INSTALLATION OF NEW 2X4.2 SS EA.
 - 7 ROUTE 12X2 SS EA UP THROUGH CEILING UP TO ROUTE SUPPORT DUCT VERTICALLY FROM ADJACENT WALLS WITH UNDISTURBED FRAMING.
 - 8 ROUTE 2838 SS EA ELONG EXISTING CEILING, SLOPE HORIZONTAL DUCT BACK TOWARDS NEGROPSY TABLE, EXTEND HANGERS FROM STRUCTURE, CUT AND PATCH SURFACES TO MATCH EXISTING FINISH.
 - 9 ROUTE 2838 SS EA ABOVE CORRIOR CEILING, REMOVE AND REPLACE CEILING TILE AND GRID AS REQUIRED, GELING (RUE R-07).