

1. REFER TO GENERAL AND EXECUTION NOTES ON SHEET P-000.
2. COORDINATE WITH OWNER'S TIME SCHEDULE. MINIMIZE TIMING OF SERVICE DISRUPTION.
3. INDICATE EXTENT OF ABANDONED PIPING ON FOUNDATION RECORD DRAWING.

- 1 REMOVE SHORT SECTION OF SANITARY BRANCH PIPING AND CAP PIPE 6" BELOW FLOOR SURFACE. PATCH HOLES IN FLOOR AND WALLS.
- 2 REMOVE FLOOR DRAIN AND RELATED FLOOR CLEANOUTS. CAP PIPE 6" BELOW FLOOR SURFACE AND CAP VENT.
- 3 REMOVE SUPPLY, SANITARY AND VENT ASSOCIATED WITH REMOVED AUTOPSY TABLES AND CAP PIPES 6" BELOW FLOOR SURFACE.
- 4 DISCONNECT SANITARY BUILDING BRANCH AND CAP. LEAVE LOW END OF ABANDONED BRANCH OPEN.
- 5 REMOVE ENTIRE SANITARY BRANCH.
- 6 IN BASEMENT OF D-WING, REMOVE SAN. BRANCH PIPING SHOWN HERE WITH BOLD LINES AND CAP.

SAWCUT CONCRETE FLOOR IN SHADED AREAS AS REQUIRED TO REMOVE PLUMBING PIPING AS CALLED OUT IN THE PLUMBING KEY NOTES. NEW CONCRETE FLOOR SLAB SHALL BE INSTALLED, CURED, AND PREPARED AS REQUIRED FOR NEW FLOOR FINISH. SEE STRUCTURAL DRAWING FOR CONCRETE PATCHING SPEC.

1

----- PIPING TO BE REMOVED

..... PIPING TO BE ABANDONED

$$1/4'' = 1' - 0''$$

KEYPLAN

1" = 100'

TRUE NORTH

PLAN NORTH

AREA OF WORK


D-WING

A-WING

C-WING

B-WING

Project Title		
RENOVATE MORGUE		
Location		
WILLIAM S. MIDDLETON VA HOSPITAL, MADISON, WISCONSIN		
Date	Checked	Drawn
01/11/16	SPS	WERS

Project Number 607-14-114	Office of Construction and Facilities Management
Building Number 1	
Drawing Number PD-101	 Department of Veterans Affairs