


OFFICE OF
CONSTRUCTION
AND FACILITIES
MANAGEMENT

VA |  U.S. Department
of Veterans Affairs

- ① RELOCATE VARIABLE VOLUME BOXES AS NECESSARY FOR NEW PIPING.
- ② OFFSET 6" DUCT DOWN AS LOW AS POSSIBLE TO ROUTE NEW PIPING TO CHASE. COORDINATE THE SCOPE OF REMOVAL AND OFFSETTING OF DUCT FOR NEW LOCATION OF NEW PIPING.
- ③ ADD 7" END CAP.
- ④ NEW VARIABLE VOLUME BOX AND THERMOSTAT CONTROL. SEE SCHEDULE.
- ⑤ AFTER DEMOLITION OF EXISTING DUCT, ADD TWO 10" DIFFUSERS AND DUCT.