



- NOTES
- 1. REMOVE (E) YELLOW TRUNCATED DOME PAD
 - 2. INSTALL NEW RECESSED W/ REPLACEABLE PANELS
 - 3. INSTALL NEW TRUNCATED PADS WITH ADHESIVE AND CONCRETE FASTENERS

LEGEND

NEW TRUNCATED DOME

ADMINISTRATION BUILDING