



Notes;

Exam Rooms 237 and Toilet room E236
 Exam Room 252 and Toilet room E 251
 Teamlet room 259

1. Remove existing countertop carefully without damaging the surface to be relocated
2. Existing countertop relocated . Attach to existing wall. Provide backing plate. Provide data and power for computers.
3. (New) power and outlet /data for computers.
4. Patch and match existing wall. Paint wall.
5. Patch and match existing wall. Provide ceramic tile to match existing wall tile and pattern.
6. Cut opening in wall to receive new 42" wide door, frame and hardware. Match existing height of door.
7. Remove (e) door and frame. Infill door opening with metal stud and 5/8" type x gypsum board wall. Provide handrail. install tile and pattern to match existing.
8. Modify cubicle curtaintrack and to accommodate installation of new door.
9. Modify handrail and replace as needed. Provide backing plate as needed to install.
10. Provide solid surface wall.
11. Provide FRP panels at corridor under handrails
11. Convert room 262 into Exam room . Currently room is used as teamlet room. Relocate furniture from room E259 into room 262.
12. Provide power at 4'-6" aff
13. Convert E259 exam room into teamlet room. Move teamlet furniture from room 262 into E 259.

 **1** FLOOR PLAN
 SCALE: 1/4"=1'-0"

B164 2ND AND 3RD FLOOR
 WOMENS PRIVACY
 LONG BEACH, CA.

