

Keyed Work Notes:

1. Saw cut concrete and demo.
2. Install a new concrete L-shaped trench drain complete with, but not limited to, perimeter stainless steel angle (1-1/4 x 1-1/4 x 1/4 type 304) - embedded and anchored (stainless steel type 304 anchors) frame, 12 inch wide stainless steel bar grating trench cover (McNichols type 304 stainless steel, GW 100 (1 x 1 x 3/16) with load banding and uniform stubs – or equal), type 304 stainless steel collection box with removable type 304 stainless steel lint strainer basket over new 8 inch drain pipe inlet.
3. Install new 8 inch CPVC drain piping.
4. Patch concrete.

