

	I	10
	GENERAL NOT 1. INSTALL NEW DOOR W ADD CLEAR FINISH. REU HINGES. 2. REFER TO APPENDIX 4 INSTRUCTIONS. 3. DEMOLISH ALL PADDIN	ITTH NEW LOCKSET SE EXISTING I FOR DEMOLITION IG FROM WALLS.
	<ol> <li>INSTALL NEW FLOOR N TO BATHROOM.</li> <li>INSTALL NEW WALL MC COVERS OVER PLUMBIN ACCESSIBILITY REQUIRE</li> <li>INSTALL GRAB BARS.</li> <li>REMOVE CAMERA AND</li> </ol>	OUNTED SINK WITH G FOR MENTS.
	GOVERNMENT. 8. INSTALL CODE REQUIN 9. INSTALL TILE IN ACCO MURACTURER'S SPECIF RECOMMENDED ADHESIT FOUR FEET AF.F. WITH E 10. USE RECOMMENDED ACCORDANCE TO MANUF SPECIFICATION, TO BE N GROUT LINE.	RED SIGNAGE. RDANCE TO ICCATION. USE VE. TILE WALLS TO POXY GROUT. EPOXT GROUT IN FACTURER'S
	11. PRIME AND PAINT ALL ON DRAWINGS. 12. DEMOLSH CURRENT PREPARATION OF NEW F INSTALLATION. 13. ALL ANCILLARY PROD TO BE PROVIDED BY THE BY THE CONTRACTOR.	FLOORING IN FLOORING -
[		1
		I.
B		
	ect Tille MERGENCY DEPARTMENT SAFE R	OM Building Number BLDG 200 Drawing Number