



NOTES:

1. L_d = DEVELOPMENT LENGTH
2. WHEN SPlicing BARS OF DIFFERENT SIZE, USE LAP SPICE LENGTH OF LARGER BAR, U.O.N.
3. STAGGER SPICES AS INDICATED ON DRAWINGS.
4. MULTIPLY THE ABOVE LENGTHS BY 1.5 FOR EPOXY COATED REINF.

