

DRAWINGS NOTES FOR SHEET T130

DRAWING NOTES:

- 1 DISCONNECT EXISTING 400 PAIR TELEPHONE CABLE FROM EXISTING SPLICE IN TELECOM CLOSET C012A AND PULLBACK AND REROUTE TO NEW IDF ROOM TERMINATE ON NEW 110 WALL FIELD.
- 2 DISCONNECT EXISTING 600 PAIR TELEPHONE CABLE FROM EXISTING SPLICE IN TELECOM CLOSET C012A AND PULLBACK AND REROUTE TO NEW IDF ROOM TERMINATE ON NEW 110 WALL FIELD.
- 3 PROVIDE NEW 400 PAIR TELEPHONE CABLE FROM NEW IDF WALL TERMINATION FIELD TO NEW TELEPHONE CASE SPLICE IN TELECOM CLOSET C102A.
- 4 PROVIDE NEW 600 PAIR TELEPHONE CABLE FROM NEW IDF WALL TERMINATION FIELD TO NEW TELEPHONE CASE SPLICE IN TELECOM CLOSET C102A.
- 5 PROVIDE NEW 110 WALL TERMINATION FIELD AS REQUIRED TO TERMINATE AND CROSSCONNECT ALL CABLING INCLUDING 20% SPARE.
- 6 PROVIDE NEW TELEPHONE SPLICE CASE. PROVIDE COMPLETE SPLICE FROM EXISTING TO NEW TELEPHONE CABLING. DISCONNECT AND REMOVE EXISTING TELEPHONE SPLICE CASE. REUSED EXISTING TELEPHONE CABLING.
- 7 EXISTING TELEPHONE CABLING SHALL REMAIN.
- 8 PROVIDE NEW 600 PAIR OUTSIDE PLANT TELEPHONE CABLING TO SERVE NEW CLC BUILDING.