



- ①. DRILL THROUGH FLOOR AND INSTALL FLOOR DRAIN
- ②. CORE DRILL THROUGH CONCRETE
- ③. INSTALL UNDERGROUND AS PER SPECIFICATIONS
- ④. CONNECT TO EXISTING DRAIN; IF REQUIRED INSTALL NEW AND/OR LARGER DRAIN. SUBMIT TO THE GOVT FOR APPROVAL.
- ⑤. INSTALL SINK
- ⑥. INSTALL CASEWORK
- ⑦. INSTALL REFRIGERATOR (STAINLESS STEEL PROVIDE CONTRACTOR. COORDINATE WITH COR.
- ⑧. INSTALL WALL LOCKERS
- ⑨. NEW FLOOR, WALL, AND CEILING APPLICATION SEE FLOOR/WALLSCHEDULE
- ⑩. CUT TRENCH IN EXISTING FLOOR TO INSTALL NEW DRAIN FOR SINK
- ⑪. BRICK WORK TO BE RED RANGE WIRE CUT AS PER ASTM C-216 GRADE SW TYPE FBS.
BRICK WORK TO BE INTERLOCKING WITH EXISTING AND MORTAR TO MATCH IN COLOR AND THICKNESS. COORDINATE WITH COR.
- ⑫. DRILL THROUGH FLOOR/WALL AND CONNECT TO EXISTING PLUMBING FOR SINK INSTALLATION CONNECTION.