

DOOR TRANSITION STRIP SCHEDULE

DR #	DOOR TRANSITION	NOTES
A-634	CONCRETE	1, 2, 3
A-637	CONCRETE	1, 2, 3
A-641	CARPET	1, 2, 3
A-644	CONCRETE	1, 2, 3
A-645	CONCRETE	1, 2, 3
A-646	CONCRETE	1, 2, 3
B-703	VINYL	1, 2, 3
B-703	VINYL	1, 2, 3
B-705	CERAMIC TILE	1, 2, 3
B-709	CARPET	1, 2, 3
B-721	VINYL	1, 2, 3
B-724	VINYL	1, 2, 3
B-726	CARPET	1, 2, 3
A-837	VINYL	1, 2, 3
A-838	VINYL	1, 2, 3
A-839	VINYL	1, 2, 3
A-842	VINYL	1, 2, 3
A-843	CARPET	1, 2, 3
A-844	VINYL	1, 2, 3
A-846	VINYL	1, 2, 3
A-849	VINYL	1, 2, 3

HALLS AND WALLS 2013

603-13-701

25 MARCH 2013

Addendums:

A1 - 9 MAY 2013

NOTES:

1. INSTALL VT-2 AT DOOR THRESHOLDS BENEATH CLOSED DOOR TO MATCH AND REFLECT DOOR WIDTH.

2. NEW TRANSITION STRIPS SHALL BE BLACK AND EQUAL TO ROPPE "ADAPTER & TRANSITIONS" LINE OF PRODUCTS.

3. TRANSITION STRIPS SHALL BE USED FOR VINYL TILE TO VINYL TILE TRANSITIONS AT DOORWAYS WHERE THERE ARE DIFFERENCES IN FLOOR ELEVATIONS AND IN ADDITION TO THE VT-2 THRESHOLD.