



- 1. Pave cracks in all lots and roadways
- 2. All lot #11 at a minimum of 2' stone subgrade surface. Provide 4' new base course, and 2' new wear course
- 3. Re-slope lot #11 according to drawing

2' Stone Course
4' Stone Course

Site Plan - Lot 11 Resurfacing and
site-wide crack repairs 4/8/13