DOOR SCHEDULE

| MARK | DOOR TYPE: SINGLE – HOLLOW METAL – SWING | SINGLE – ALUMINUM – SWING | SINGLE – WOOD – SWING | SINGLE – ALUMINUM – SLIDER | DOUBLE – HOLLOW METAL – SWING | DOUBLE – ALUMINUM – SWING | DOUBLE – ALUMINUM – BI-FOLD | DOUBLE – ALUMINUM – SLIDER | FRAME TYPE: HOLLOW METAL | HOLLOW METAL – STATIONARY LEAF | ALUMINUM | ALUMINUM – SIDELITE | WOOD | LATCHING DEVICE: NONE | EXISTING PANIC RIM DEVICE | EXISTING PANIC MORTISE DEVICE | EXISTING PANIC VERTICAL ROD | EXISTING PANIC MORTISE & VERTICAL ROD | EXISTING PANIC RIM DEVICE W/ ELECTRIC LATCH | EXISTING LEVER | VON DUPRIN 33A PANIC RIM DEVICE | VON DUPRIN EL9827NL PANIC VERTICAL ROD DEVICE W/ RG27 | VON DUPRIN 9827EO PANIC VERTICAL ROD DEVICE W/ RG27 | VON DUPRIN EL3327ANL PANIC VERTICAL ROD DEVICE W/ RG27 | VON DUPRIN 3327AEO PANIC VERTICAL ROD DEVICE W/ RG27 | BEST 93KTD150S3 626 EXIT LEVER | VON DUPRIN 98NL RIM DEVICE | VON DUPRIN EL9847NL CONCEALED PANIC VERTICAL ROD DEVICE | STRIKE: NONE | EXISTING STRIKE | VON DUPRIN 299 TOP STRIKE & 304L BOTTOM STRIKE | VON DUPRIN 6300 ELECTRIC STRIKE | VON DUPRIN 6210 ELECTRIC STRIKE | VON DUPRIN 6223 ELECTRIC STRIKE | VON DUPRIN 6112 ELECTRIC STRIKE | VON DUPRIN 6221 ELECTRIC STRIKE | POWER: VON DUPRIN EPT10 POWER TRANSFER | VON DUPRIN PS914 POWER SUPPLY | EXISTING | CLOSER: EXISTING STANDARD CLOSER | EXISTING AUTOMATIC CLOSER | STANLEY D1651 STANDARD CLOSER | STANLEY D1651H CLOSER W/ HOLD OPEN | DEMOLITION: REMOVE ALL EXISTING KEYPADS – PREPARE WALL FOR NEW KEY PAD AND/OR PATCH WALL TO MATCH EXIST. STRUCTURE – CAP/REWORK WIRING AS REQ'D | REMOVE KEY SWITCHES – PATCH WALL TO MATCH EXIST. STRUCTURE – CAP/REWORK WIRING AS REQ'D | REMOVE PUSH TO EXIT BUTTON – PATCH WALL TO MATCH EXIST. STRUCTURE – CAP REWORK WIRING AS REQ'D | REMOVE MOTION SENSORS – CAP/REWORK WIRING AS REQ'D | REMOVE MAGNETIC HOLD OPENS – PATCH WALL TO MATCH EXIST. STRUCTURE – CAP/REWORK WIRING AS REQ'D | REMOVE PANIC DEVICE ON ONE LEAF – PATCH AND REPAIR DOOR TO RECEIVE NEW LATCHING DEVICE | REMOVE PUSH/PULL HARDWARE – PATCH AND REPAIR DOOR TO RECEIVE NEW LATCHING DEVICE | REMOVE MAGNETIC LOCK AND POWER SUPPLY – CAP/REWORK WIRING AS REQ'D | REMOVE EXISTING PANIC DEVICE – PREPARE DOOR TO RECEIVE NEW PANIC DEVICE | NOTES: REVERSE DOOR AND FRAME – REINSTALL WITH DOOR SWINGING IN OPPOSITE DIRECTION – SEE PLAN | DOOR CONTACT AND ALARM SYSTEM TO REMAIN | MOTION SENSOR AND ALARM SYSTEM TO REMAIN | PROVIDE LATCHING DEVICE, POWER SUPPLY, AND POWER TRANSFER @ EA. LEAF | INSTALL SOLENOID CARRAGE LOCK IN THE OPERATOR | MOUNT CARD READER ON A NEW PEDESTAL – VERIFY FINAL LOCATION W/ OWNER | OPERATION – SEE NARRATIVE |
|---|---|---