
1 UNIT SUBSTATION USD
2-E248 BASEMENT LEVEL
SERVES RISERS D & E
1 RISER D
2-E248 BD=PIPE BASEMENT
1D=LEVEL 1 FUNCTIONAL
3D=LEVEL 3 FUNCTIONAL
5D=LEVEL 5 FUNCTIONAL
7D=FUTURE N.I.C.
9D=FUTURE N.I.C.
11D=FUTURE N.I.C.
13D=FUTURE N.I.C.
1 RISER E
2-E248 BE=PIPE BASEMENT
1E=LEVEL 1 FUNCTIONAL
3E=LEVEL 3 FUNCTIONAL
5E=LEVEL 5 FUNCTIONAL
SERVICE BAY - 4
SERVICE BAY - 5
SERVICE BAY - 6
SERVICE BAY - 7
SERVICE BAY - 2
SERVICE BAY - 3
USA
USB
1 USC
2-E247 BASEMENT LEVEL
SERVES RISER C
WEST GENERATORS
BASEMENT LEVEL
SERVES CLINIC ADDITION
2 USF
2-E249 BASEMENT LEVEL
SERVES RISERS F & G
1 RISER C
2-E247 BC=PIPE BASEMENT
1C=LEVEL 1 FUNCTIONAL
3C=LEVEL 3 FUNCTIONAL
5C=LEVEL 5 FUNCTIONAL
7C=FUTURE N.I.C.
9C=FUTURE N.I.C.
11C=FUTURE N.I.C.
2 UNIT SUBSTATION USR
2-E250 BASEMENT LEVEL
SERVES RADIOLOGY
1 RISER F
2-E249 BF=PIPE BASEMENT
1F=LEVEL 1 FUNCTIONAL
3F=LEVEL 3 FUNCTIONAL
5F=LEVEL 5 FUNCTIONAL
2 RISER G
2-E249 BG=PIPE BASEMENT
1G=LEVEL 1 FUNCTIONAL
3G=LEVEL 3 FUNCTIONAL
5G=LEVEL 5 FUNCTIONAL