



SEE SHT SF-101B
SEE SHT SF-101A

NOTES:

1. ANCHORS MAY NOT BE INSTALLED DIRECTLY BENEATH WINDOWS TO AVOID DAMAGE TO EXTERIOR FACADE RELIEF. ADJUST SPACING BUT MAINTAIN TOTAL NUMBER OF ANCHORS IN ACCORDANCE WITH LENGTH OF WALL.

[illegible]