



- NOTES:**
1. COORDINATE WIRE TYPES, SIZES AND QUANTITIES WITH THE MANUFACTURER'S SPECIFICATIONS. ALL WIRING TO BE INSTALLED IN NOT LESS THAN 3/4" CONDUIT, AS PER NEC.
 2. PROVIDE AND INSTALL ANY AND ALL COMPONENTS AND WIRING NEEDED FOR CORRECT CONNECTION AND SWITCHING OF THE FUSE, FIDELITY, AND SPRINKLER RELEASE BY THE FIRE ALARM PANEL, INCLUDING ALL EXTERNAL RELAYS AND CURRENT SENSORS.
 3. PROVIDE AND INSTALL ANY AND ALL COMPONENTS AND WIRING NEEDED FOR CORRECT CONNECTION OF THE ZONE ALARM MODULE.
 4. UNLESS OTHERWISE NOTED, ALL DEVICES SHALL BE FED FROM PANELBOARD DESIGNATED "PP1".

Revisions		Date	
</			