



1010 Kings Highway South  
Building Two – 2nd Floor  
Cherry Hill, NJ 08034

Phone: 856-429-4000  
Fax: 856-429-5002  
E-mail: office@miller-remick.com

## Request for Information

**Contractor RFI No.:** 1

**Request Date:** 12/18/14

**Contractor/Supplier:** Johnson Controls

**M-R RFI Log No.:** 10

**Response Date:** 00/00/14

**VA Project No.:** 528-13-C-0179

**M-R Project No.:** 3-0499-0046

**Project Name:** Renovate 6B Ward Syracuse VAMC

**RFI:** (Attachments ☐ Yes ☒ No)

(Q) The specified room pressure monitors or equals are not manufactured to operate BACNET over IP. They are manufactured as BACNET mstp devices only. The current devices frequently used at the VA are BACNET mstp devices.

Please provide an alternate recommendation or clarification on the requirement.

Thank You,  
Todd Mancuso  
Branch Installation Manager  
Johnson Controls, Inc.  
Rochester & Syracuse, NY

(A) Where an HVAC device is not available with BACnet/IP communication, provide a BACnet/IP to BACnet/MSTP converter located adjacent to the device with excess Ethernet cable to support direct IP connection in the future.

**Michael Arnold- VA Energy Engineer**