

# Department of Veterans Affairs

PROJECT LOCATION:

## JESSE BROWN VA MEDICAL CENTER

820 S. DAMEN AVENUE CHICAGO, ILLINOIS 60612 312.569.8387

PROJECT TITLE:

SITE PREP OP RADIOLOGY ROOM - 1379 TASK ORDER #08

**BUILDING NUMBER:** 

11B

VA FORM 08-6231


ARCHITECTS + ENGINEERS:


## BANCROFT ARCHITECTS + ENGINEERS

700 NICHOLAS BLVD. SUITE 403 ELK GROVE VILLAGE, ILLINOIS 60007 847.952.9362 www.bancroft-ae.com

## PROJECT NUMBERS:

IDIQ NO. VA69D-13-D-0019 CONTRACT NO. VA69D-14-J-2293 STATION PROJECT NO. 537-14-120 BANCROFT-AE PROJECT NO. 12-126-08






| DRAWING<br>NUMBER | PDF PAGE<br>  NUMBER | DRAWING TITLE  |
|-------------------|----------------------|--|
| G-000             | 01                   | COVER  |
| G-001             | 02                   | GENERAL NOTES AND SYMBOLS                                    |
| G-101             | 03                   | PARTIAL FIRST FLOOR LIFE SAFETY PLAN AND CODE INFORMATION    |
|                   | •                    | STRUCTURAL   |
| SD-131            | 04                   | PARTIAL FIRST FLOOR - STRUCTURAL DEMOLITION CEILING PLAN     |
| S-131             | 05                   | PARTIAL FIRST FLOOR — STRUCTURAL CEILING PLAN                |
| SF-101            | 06                   | PARTIAL FIRST FLOOR - STRUCTURAL FRAMING PLAN                |
|                   | •                    | ARCHITECTURAL  |
| AD-101            | 07                   | PARTIAL FIRST FLOOR - DEMOLITION PLAN                        |
| AD-131            | 08                   | PARTIAL FIRST FLOOR - DEMOLITION REFLECTED CEILING PLAN      |
| AD-301            | 09                   | DEMOLITION BUILDING SECTION                                  |
| AD-302            | 10                   | DEMOLITION BUILDING SECTION                                  |
| A-101             | 11                   | PARTIAL FIRST FLOOR — CONSTRUCTION PLAN                      |
| A-131             | 12                   | PARTIAL FIRST FLOOR — REFLECTED CEILING PLAN                 |
| A-201             | 13                   | ROOM ELEVATIONS  |
| A-202             | 14                   | ROOM ELEVATIONS AND MILLWORK DETAILS                         |
| A-601             | 15                   | DOOR HARDWARE SCHEDULES AND DETAILS                          |
|                   |                      | INTERIORS  |
| I-101             | 16                   | PARTIAL FIRST FLOOR — INTERIOR FINISHES PLAN                 |
|                   |                      | FIRE PROTECTION  |
| FPD-101           | 17                   | PARTIAL FIRST FLOOR - FIRE PROTECTION DEMOLITION PLAN        |
| FP-101            | 18                   | PARTIAL FIRST FLOOR - FIRE PROTECTION PLAN                   |
|                   |                      | MECHANICAL   |
| MD-101            | 19                   | PARTIAL FIRST FLOOR - MECHANICAL VENTILATION DEMOLITION PLAN |
| M-101             | 20                   | PARTIAL FIRST FLOOR - MECHANICAL VENTILATION PLAN            |
|                   |                      | ELECTRICAL   |
| ED-101            | 21                   | PARTIAL FIRST FLOOR - ELECTRICAL POWER DEMOLITION PLAN       |
| ED-131            | 22                   | PARTIAL FIRST FLOOR ELECTRICAL LIGHTING DEMOLITION PLAN      |
| E-101             | 23                   | PARTIAL FIRST FLOOR ELECTRICAL POWER PLAN                    |
| E-131             | 24                   | PARTIAL FIRST FLOOR ELECTRICAL LIGHTING PLAN                 |
| E-501             | 25                   | PARTIAL SINGLE LINE DIAGRAM                                  |
| E-601             | 26                   | ELECTRICAL LAYOUT DETAILS AND WIRING DETAILS                 |
| E-602             | 27                   | ELECTRICAL PANEL SCHEDULE                                    |

|                 | DRAWING INDEX   |
|-----------------|---|
| SHEET<br>NUMBER | DRAWING TITLE   |
| RADIOLOGY       | SITE PLANNING DRAWING INDEX (COORDINATE WITH JBVA FOR DRAWINGS) |
| C1              | SITE READINESS  |
| A1              | EQUIPMENT LAYOUT  |
| S1              | STRUCTURAL LAYOUT   |
| S2              | STRUCTURAL DETAILS  |
| E1              | ELECTRICAL LAYOUT   |
| E2              | ELECTRICAL SPECIFICATIONS                                       |
| E3              | ELECTRICAL DETAILS  |
| E4              | ELECTRICAL DETAILS  |
| D1              | EQUIPMENT DETAILS   |

THE "RAD SITE PLANNING" DRAWINGS ARE FOR REFERENCE ONLY. ALL CONTRACTORS SHALL REVIEW THES DOCUMENTS TO BECOME FAMILIAR WITH THE EQUIPMENT AND RELATED COMPONENTS.

IDIQ NO. VA69D-13-D-0019 CONTRACT NO. VA69D-14-J-2293

Drawing Title Project Title ARCHITECT + ENGINEERS: SITE PLAN: ENGINEERS + CONSULTANTS: Office of COVER SITE PREP 537-14-120 OP RADIOLOGY ROOM 1379 Construction **Building Number** and Facilities 100% CONSTRUCTION DOCUMENT - ISSUE FOR BID 04/17/2015 Approved: Project Director 700 Nicholas Blvd. Suite 403 Drawing Number Location 100% CONSTRUCTION DOCUMENT - REV. 1 Management Elk Grove Village, IL 60007 CHICAGO, IL 95% CONSTRUCTION DOCUMENT 02/12/2015 T:**847.952.9362** F:**847.952.9403** G-000 11/24/2014 75% CONSTRUCTION DOCUMENT Checked BANCROFT ARCHITECTS + ENGINEERS www.bancroft-ae.com Department of Veterans Affairs 35% SCHEMATIC DESIGN - MODIFICATION 10/24/2014 Bancroft-AE Project No. 12-126-08 JS, CM EM 04/17/2015



ENGINEERS + CONSULTANTS:

SITE PLAN:

TAYLOR STREET

03/17/2015

02/12/2015

11/24/2014

10/24/2014

100% CONSTRUCTION DOCUMENT - ISSUE FOR BID 04/17/2015

100% CONSTRUCTION DOCUMENT - REV. 1

35% SCHEMATIC DESIGN - MODIFICATION

95% CONSTRUCTION DOCUMENT

75% CONSTRUCTION DOCUMENT

VA FORM 08-6231

\_\_\_

— .


RADIUS ACOUSTICAL CEILING TILE LAMINATE EACH RESILIENT BASE LAVATORY **ADJACENT EXPANSION JOINT** RCP REFLECTED CEILING PLAN LIGHT EMITTING DIODE ABOVE FINISHED FLOOR ELEVATION REC RECESSED AIR HANDLING UNIT LINEAR FEET (FOOT) **ELECTRIC** RECEPTACLE ALTERNATE LEAD LINED ELEV ELEVATOR REINF REINFORCED ALUMINUM REQD **ENCLOSURE** REQUIRED AMOUNT EQUAL ROOM RMAPPROXIMATE MATERIAL EQUIPMENT ROUGH OPENING AUTOMATIC  $\mathsf{MAX}$ MAXIMUM EWC ELECTRIC WATER COOLER AUXILIARY MECHANICAL EXH EXHAUST AUDIO VISUAL MANUFACTURER **EXIST** EXISTING SANITARY AVERAGE MINIMUM **EXPOSED** SCHED SCHEDULE MISCELLANEOUS EXT EXTERIOR SQUARE FOOT (FEET) MILLWORK SHT BD SHEET BOARD MASONRY OPENING FIRE ALARM SIM SIMILAR BUILDING MOISTURE RESISTANT FD FLOOR DRAIN **SPECIFICATION** BLK BLOCKING MOUNTED FDN FOUNDATION SPKLR BEAM SPRINKLER MOUNTING FIRE EXTINGUISHER SPKR SPEAKER BY OWNER METAL FIRE EXTINGUISHER CABINET SQUARE FURNITURE, FIXTURE, AND EQUIPMENT CEMENT STAINLESS STEEL FHC FIRE HOSE CABINET CONTROL JOINT STANDARD NOT APPLICABLE FIGURE STOR STORAGE CENTER LINE NATURAL FINISH SUSPEND SUSP CEILING NOT IN CONTRACT FIXTURE CLR CLEAR SHEET VINYL NUMBER FLOOR CMU CONCRETE MASONRY UNIT NOT TO SCALE FACE OF COL COLUMN TONGUE AND GROOVE FIRE PROTECTION OR FIREPROOF TEMP CONC TEMPERED CONCRETE **OVERALL** CONT TERR **TERRAZZO** CONTINUOUS ON CENTER FTG FOOTING COORD THK THICK COORDINATE OPPOSITE HAND CORR CORRIDOR TOP OF \_\_\_\_ GENERAL CONTRACTOR **TSTAT THERMOSTAT** CARPET OPTIONAL GLASS TYP CERAMIC TILE TYPICAL GYPSUM BOARD CTR CENTER PAT PATTERN CTRL UNLESS NOTED OTHERWISE CONTROL PLATE HAZARDOUS MATERIALS PLASTIC LAMINATE HARDWARE PLAS PLASTER OR PLASTIC HMHOLLOW METAL DBL DOUBLE VINYL COMPOSITION TILE PAIR HEIGHT DEG DEGREE VENTILATION **PREFINISHED** DEMO DEMOLITION VERIFY IN FIELD PREPARATION INCL INCLUDED DEPT DEPARTMENT VOL VOLUME **PROVIDE** FURNISH AND INSTALL INSUL INSULATION VINYL WALL COVERING DRINKING FOUNTAIN PAINT INTERIOR DIAMETER PAINT TO MATCH EXISTING PTME **DIFFUSER** WEST PARTITION **JANITOR** DIM DIMENSION WITH PWR POWER JOIST DN DOWN WITHOUT JOINT DOOR QUARRY TILE WALL COVERING J-BOX JUNCTION BOX DTL DWG DETAIL QUARTER WOOD QTR DRAWING QTY QUANTITY WDW WINDOW


**ABBREVIATIONS** 


IDIQ NO. VA69D-13-D-0019 CONTRACT NO. VA69D-14-J-2293


WELDED WIRE FABRIC


Drawing Title Project Title **Project Number** ARCHITECT + ENGINEERS: Office of SITE PREP GENERAL NOTES AND SYMBOLS 537-14-120 OP RADIOLOGY ROOM 1379 Construction **Building Number** and Facilities 700 Nicholas Blvd. Suite 403 Approved: Project Director Drawing Number Location Management Elk Grove Village, IL 60007 CHICAGO, IL T:847.952.9362 F:847.952.9403 G-001 Checked www.bancroft-ae.com BANCROFT ARCHITECTS + ENGINEERS Department of Veterans Affairs Bancroft-AE Project No. 12-126-08 04/17/2015 EM














\_\_\_\_




А п

\_\_\_







\_\_\_



А п



\_\_\_\_



VA FORM 08-6231

ROOM ELEVATION NOTES

- 1. EXISTING WOOD DOORS SHALL BE REFINISHED. REFER TO DRAWING A-601 FOR SPECIFICATIONS.
- 2. INDICATES 4" HIGH RUBBER WALL BASE. ALL WALL BASE SHALL HAVE A COVE
- 3. CONTRACTOR SHALL PATCH ALL EXISTING WALL FACES PRIOR TO FINISH PAINTING SCOPE OF WORK. FURNISH AND INSTALL 1/16" THICK LEAD MATERIAL AT ALL
- ABANDONED HOLES WITHIN GYPSUM BOARD WALL PANELS. 4. INDICATES EXISTING LEAD VEST CUBBY ENCLOSURE. PAINT EXPOSED GYPSUM BOARD WALLS WITHIN THIS ENCLOSURE.
- 5. EXISTING LEAD GLASS VISION PANEL. PROVIDE WINDOW SHADE SYSTEM AS SPECIFIED.
- 6. CONTRACTOR SHALL INFILL VOID SPACE AT ABANDONED LIGHTING CONTROL WALL BOX. REFER TO LEAD LINE GYPSUM BOARD PATCHING DETAIL.
- 7. EXISTING WALL MOUNTED NEEDLE DISPENSER UNIT TO REMAIN.
- 8. EXISTING PAPER TOWEL DISPENSER TO REMAIN.
- 9. EXISTING WALL HUNG LAVATORY TO REMAIN. CONTRACTOR SHALL TIGHTEN ALL MOUNTED BOLTS AT PROJECT COMPLETION PHASE.
- 10. EMERGENCY SHUT-OFF SWITCH. REFER TO ELECTRICAL DRAWINGS
- 11. INDICATES SURFACE MOUNTED METAL ELECTRICAL RACEWAY SYSTEM.
- 12. INDICATES ELECTRICAL METAL RACEWAY SYSTEM MOUNTED FLUSH WITH FLOOR
- LINE. REFER TO ELECTRICAL DRAWINGS.
- 13. INDICATES EXISTING WALL MOUNTED THERMOSTAT TO REMAIN.
- 14. INDICATES WALL LIGHT SWITCH LOCATION.
- 15. INDICATES EXISTING WALL MOUNTED DUPLEX ELECTRICAL OUTLETS TO REMAIN.
- 16. INDICATES EXISTING VOICE/DATA OUTLET LOCATIONS.
- 17. DIGITAL CHEST UNIT. REFER TO GE DRAWINGS
- 18. ELEVATING TABLE.
- 19. TETHER INTERFACE BOX
- 20. COAT HOOKS
- 21. EXISTING LAVATORY
- 22. EXISTING SOAP DISPENSER

IDIQ NO. VA69D-13-D-0019 CONTRACT NO. VA69D-14-J-2293


Office of

Construction


and Facilities

Management


Drawing Title Project Title Project Number SITE PLAN: ENGINEERS + CONSULTANTS: ARCHITECT + ENGINEERS: SITE PREP ROOM ELEVATIONS 537-14-120 OP RADIOLOGY ROOM 1379 **(2) Building Number** 100% CONSTRUCTION DOCUMENT - ISSUE FOR BID 04/17/2015 700 Nicholas Blvd. Suite 403 Elk Grove Village, IL 60007 Approved: Project Director Drawing Number Location 100% CONSTRUCTION DOCUMENT - REV. 1 03/17/2015 CHICAGO, IL 95% CONSTRUCTION DOCUMENT 02/12/2015 T:847.952.9362 F:847.952.9403 A-201 75% CONSTRUCTION DOCUMENT Checked 11/24/2014 BANCROFT ARCHITECTS + ENGINEERS www.bancroft-ae.com Department of Veterans Affairs 35% SCHEMATIC DESIGN - MODIFICATION 10/24/2014 Bancroft-AE Project No. 12-126-08 04/17/2015 EM Revisions: TAYLOR STREET




#### DOOR SCHEDULE DOOR INFORMATION FRAME INFORMATION **HARDWARE - COMMERCIAL GRADE CLOSERS** DOOR PLATES DOOR DOOR EDGING STOP DOOR FUNCTIONS **AUTOMATIC** HARDWARE SETS **OPERATORS** DRESSING ROOM 1380 1 COR-1380-A 3'-6" 7'-0" 1 3/4" WOOD H.M. N/A 110 RHR H.M. A 4 3 1 5/A601 6/A601 N/A CGH-1 PS/LS-1 WB-1 AP-1 DE-1 WS-1 2426-A |DB-1 |ES-1 | ADO-1 AP-1 DE-1 WS-1 2428-A 7/A601 6/A601 N/A CGH-1 PS/LS-1 DRESSING ROOM 1382 1 COR-1382-A 3'-6" 7'-0" 1 3/4" WOOD H.M. N/A 110 RHR H.M. A 4 3 1 DB-1 ES-1 ADO-1



\_\_\_






Revisions:

VA FORM 08-6231





#### DOOR AND FRAME NOTES

DOOR MANUFACTURES SHALL BE EITHER VT INDUSTRIES "HERITAGE", CECO OR ALGOMA. EXTRA HEAVY DUTY, 1 3 /4 " WOOD VENEER, BONDED PARTICLE BOARD CORE, 5-PLY CONSTRUCTION, PROVIDE BLOCKING AT DOOR HEAD, HB-1, DOOR BOTTOM RAIL, HB-2 AND LOCK BLOCK, HB-4

1. FINISH TYPE: WDMA TR-8. (UV CURED URETHANE) PRE-FINISHED.

- 2. VENEER MATCH: NOT REQUIRED
- 3. CUTOUTS: VERIFY WITH FINAL HARDWARE SCHEDULE
- 4. STANDARD BEVEL 1/8"
- 5. CLEARANCES: 1/8" TOP EDGE, 1/8" LOCK AND HINGE SIDE STILES.BOTTOM CLEARANCE 3 / 4" MAXIMUM, STC RATING 33

#### B. <u>DOOR HARDWARE</u>

- 1. <u>CONTINUOUS GEARED HINGES / CGH-1</u>: PEMKO MANUFACTURING, STANLEY OR ROTON. CONTINUOUS GEARED HINGES. OFF-SET FULL MORTISE HINGE, FINISH SHALL BE CLEAR ANODIZED, WIDTH SHALL BE 1 9/16" x HEIGHT 2 27/32". HEAVY DUTY RATING.
- 2. PASSAGE SET/LOCK SET / PS-LS-1: CORBIN RUSSWIN 2900 SERIES, SARGENT MANUFACTURING OR SCHLAGE MORTISE LOCK WITH ELECTRIC STRIKE AND PUSH/PULL PADDLE TRIM, HEAVY DUTY DESIGN AND ANSI/BHMA GRADE 1 STRENGTH. KEYING FEATURE INTERCHANGEABLE CORE, PROVIDE MASTER KEYING. MEETS ANSI A156.13 SERIES 1000, OPERATIONAL AND SECURITY GRADE 1. MEETS A117.1 ACCESSIBILITY CODE. MEETS FEDERAL FF-H-106C. AUXILIARY LATCH BOLT 9/16" (14mm) EFFECTIVE THROW AND 3/8" (10 mm) EFFECTIVE AUXILIARY LATCH DEADLOCKING. VERIFY OPTIONAL STRIKE, LIP LENGTHS AND ANSI WROUGHT STRIKE BOX.ELECTRICAL SPECIFICATIONS (FAIL SAFE/FAIL SECURE) 12 VAC/VDC @ 800mA OR 24 VAC/VDC @ 390mA, CONTINUOUS DUTY SOLENOID. MONITOR SWITCH RATING: 4amp @ 250 VAC, NOTE OPERATING VOLTAGE NOT TO EXCEED +/- 10%. MOUNT PADDLES HORIZONTAL (UP AND DOWN). VERIFY MORTISE CYLINDER TYPE PRIOR TO ORDERING.
- 3. ARMOR PLATE / AP-1: ROCKWOOD, TRIMCO OR IVES. METAL DOOR PLATE HEAVY DUTY, 0.062" THICK STAINLESS STEEL. FASTENERS  $\#6 \times 5/8$ " OH SMS. NOMINAL 36" HIGH x 40" WIDE x US32D/630. MEETS ANSI J101-METAL ARMOR PLATE REQUIREMENTS. SQUARE EDGES-ALL FOUR SIDES, CSK (COUNTER SUNK HOLES), CUTOUTS FOR SPECIFIED DOOR HARDWARE.
- 4.  $\underline{\text{DOOR}}$   $\underline{\text{EDGING}}$   $\underline{\text{DE}-1}$ : ROCKWOOD, TRIMCO OR IVES. NON-MORTISE DOOR EDGE. MATERIAL SHALL BE 0.05" THICK STAINLESS STEEL, FASTENERS  $\#6 \times 5/8$ " FH SMS. NOMINAL 84" HEIGHT, WOOD DOORS. FURNISH WITH FACTORY CUT-OUTS FOR LOCK STRIKES AND DEAD BOLT LATCH.
- 5. AUTOMATIC DOOR OPERATOR / ADO-1: NORTON, LCN OR HORTON. LOW ENERGY POWER OPERATOR. ELECTRICAL DATA: POWER INPUT 120 VAC, 60 Hz, CURRENT DRAW 0.9 A, AUXILIARY OUTPUT 24 VDC @ 1.3 A, SPDT RELAY FOR CONTROLLING ELECTRIC STRIKE.. ETL TESTED TO UL STANDARDS FOR AUTOMATIC DOORS USED ON FORE AND SMOKE BARRIER DOORS. ANSI / BHMA A 156.19 CERTIFIED. MEETS REQUIREMENTS FOR U.L. 10C FOR POSITIVE PRESSURE. 1—YEAR WARRANTY. UNIT SHALL HAVE THREE-POSITION SELECTOR MODE SWITCH THAT WILL PERMIT THE UNIT TO BE SWITCHED "ON' TO MONITOR FOR FUNCTION INPUTS, SWITCHED "H/O" FOR INDEFINITE HOLD OPEN FUNCTION OR SWITCHED "OFF" WHICH WILL DISABLE FUNCTION INPUTS ALLOWING UNIT TO BE USED AS A MANUAL DOOR CLOSER. TYPE OF APPLICATION WILL BE PULL SIDE OF DOOR,
- 6. <u>DEADBOLT / DB-1:</u> SARGENT MANUFACTURING COMPANY, CORBIN RUSSWIN, SARGENT MANUFACTURING OR SCHLAGE. HIGH GRADE CYLINDRICAL DEAD BOLT WHICH MEETS ANSI A156.6 GRADE 1. FINISH 26D. DEADBOLT BY KEY FROM OUTSIDE. INSIDE TURN LEVER RETRACTS BOLT.

#### DOOR REFINISHING NOTES

1. FOR DOOR NUMBERS 3, 4 AND 5, CONTRACTOR SHALL REMOVE ALL EXISTING HARDWARE. LIGHTLY SAND ALL FACES. CLEAN WOOD FACES PRIOR TO FINISH APPLICATION. FOLLOW WRITTEN SPECIFICATIONS SECTION 09 91 00 - PAINTING FOR DOOR FINISH REQUIREMENTS.

> IDIQ NO. VA69D-13-D-0019 **CONTRACT NO. VA69D-14-J-2293**


> > Office of

Construction

and Facilities

Management

Project Title Drawing Title Project Number ARCHITECT + ENGINEERS: SITE PLAN: ENGINEERS + CONSULTANTS: SITE PREP DOOR HARDWARE SCHEDULES AND DETAILS 537-14-120 OP RADIOLOGY ROOM 1379 **© Building Number** 100% CONSTRUCTION DOCUMENT - ISSUE FOR BID 04/17/2015 Approved: Project Director 700 Nicholas Blvd. Suite 403 Drawing Number 100% CONSTRUCTION DOCUMENT - REV. 1 Location 03/17/2015 Elk Grove Village, IL 60007 CHICAGO, IL 95% CONSTRUCTION DOCUMENT 02/12/2015 T:**847.952.9362** F:**847.952.9403** A-601 11/24/2014 75% CONSTRUCTION DOCUMENT Checked www.bancroft-ae.com BANCROFT ARCHITECTS + ENGINEERS Department of Veterans Affairs 35% SCHEMATIC DESIGN - MODIFICATION 10/24/2014 Bancroft-AE Project No. 12-126-08 04/17/2015 EM JS, EM TAYLOR STREET



**(** 

TAYLOR STREET

02/12/2015

11/24/2014

10/24/2014

100% CONSTRUCTION DOCUMENT - ISSUE FOR BID 04/17/2015

100% CONSTRUCTION DOCUMENT - REV. 1

35% SCHEMATIC DESIGN - MODIFICATION

95% CONSTRUCTION DOCUMENT

75% CONSTRUCTION DOCUMENT

VA FORM 08-6231

|             |                              |                |       |          |       | RC              | MO     | FIN   | ISH S           | SCH          | EDU   | ILE             |            |       |                 |        |       |       |        |
|-------------|------------------------------|----------------|-------|----------|-------|-----------------|--------|-------|-----------------|--------------|-------|-----------------|------------|-------|-----------------|--------|-------|-------|--------|
| ROOM<br>NO. | ROOMNAME                     | FLC            | OOR   | ВА       | SE    |                 | NORTH  |       |                 | WALI<br>WEST |       |                 | ALLS SOUTH |       |                 | EAST   |       |       | LING   |
| NO.         |                              | Material       | Color | Material | Color | Material        | Finish | Color | Material        | Finish       | Color | Material        | Finish     | Color | Material        | Finish | Color | Туре  | Height |
| 1376A       | CORRIDOR                     | SHEET<br>VINYL | WSF-1 | RUBBER   | RB-1  | EXIST<br>GYP BD | PAINT  | P-1   | EXIST<br>GYP BD | PAINT        | P-1   | EXIST<br>GYP BD | PAINT      | P-1   | EXIST<br>GYP BD | PAINT  | P-1   | EXIST | 9-1"   |
| 1381        | CONTROL ROOM                 | SHEET<br>VINYL | WSF-1 | RUBBER   | RB-1  | GYP BD          | PAINT  | P-1   | GYP BD          | PAINT        | P-1   | GYP BD          | PAINT      | P-1   | GYP BD          | PAINT  | P-1   | ACT-1 | 9'-1"  |
| 1379        | OUTPATIENT<br>RADIOLOGY EXAM | SHEET<br>VINYL | WSF-1 | RUBBER   | RB-1  | GYP BD          | PAINT  | P-1   | GYP BD          | PAINT        | P-1   | GYP BD          | PAINT      | P-1   | GYP BD          | PAINT  | P-2   | ACT-1 | 9'-1"  |
| 1382        | DRESSING ROOM                | EXIST          | EXIST | EXIST    | EXIST | EXIST<br>GYP BD | PAINT  | P-1   | EXIST<br>GYP BD | PAINT        | P-1   | EXIST<br>GYP BD | PAINT      | P-1   | EXIST<br>GYP BD | PAINT  | P-1   | EXIST |        |
| 1380        | DRESSING ROOM                | EXIST          | EXIST | EXIST    | EXIST | EXIST<br>GYP BD | PAINT  | P-1   | EXIST<br>GYP BD | PAINT        | P-1   | EXIST<br>GYP BD | PAINT      | P-1   | EXIST<br>GYP BD | PAINT  | P-1   | EXIST |        |

| Key   | Material                   | Manufacturer                         | Product Properties   | Style/Color  | Contact                           |
|-------|----------------------------|--------------------------------------|--|--|-----------------------------------|
| FLOO  | RING                       |                                      | •  | · · · · · · · · · · · · · · · · · · ·  |                                   |
| NSF-1 | SHEET VINYL                | MANNINGTON COMMERCIAL<br>FLOORING ** | HOMOGENEOUS/BIOSPEC<br>MD/ANTIMICROBIAL AGENTS/6'W/.080<br>THICKNESS | HOMOGENEOUS SHEET FLOORING - TOASTED<br>SESAME 15333                                     |                                   |
| ΓS-1  | TRANSITION<br>STRIP        | JOHNSONITE**                         | VINYL/5/8" PROFILE   | SLT-80-B/.080" SHEET VINYL TO 1/8" EXISTING VINYL TILE/COLOR: FAWN                       | CAROL KOTEL-LYNE<br>224-659-4107  |
| ΓS-2  | TRANSITION<br>STRIP        | JOHNSONITE**                         | VINYL/5/8" PROFILE   | SLT-80-C/.080" SHEET VINYL TO 1/4" CARPET OR CERAMIC TILE/COLOR: FAWN                    | CAROL KOTEL-LYNE<br>224-659-4107  |
| ΓS-3  | TRANSITION<br>STRIP        | JOHNSONITE**                         | VINYL/2" PROFILE   | RRS-80-B/.080" SHEET VINYL TO EXISTING CONCRETE FLOORING/COLOR: FAWN                     | CAROL KOTEL-LYNE<br>224-659-4107  |
| ΓS-4  | WED ROD                    | MANNINGTON COMMERCIAL<br>FLOORING**  | MANUFACTURE STANDARD   | WELD ROD - COLOR: CAMOUFLAGE ROD<br>415133   |                                   |
| BASE  |                            |                                      |  |  |                                   |
| RB-1  | RUBBER<br>BASE             | ROPPE**                              | 4" - 1/8" GAUGE WITH TOE -<br>VULCANIZED SBR RUBBER                  | 4" HEIGHT - TS RP140   | MARY COTEY<br>847-340-2775        |
| WALL  | FINISH                     |                                      | _ I  |  |                                   |
| P-1   | PAINT                      | SHERWIN-WILLIAMS**                   | WATERBORNE DTM ACRYLIC-EGG<br>SHELL                                  | MATCH COLOR: GLIDDEN -JUST PEACHY 20YY 67/216 ORDER #A0723 - WALLS + HOLLOW METAL FRAMES | CARSON CRADDUCK<br>312-953-0775   |
| P-2   | PAINT                      | SHERWIN-WILLIAMS**                   | WATERBORNE DTM ACRYLIC-EGG<br>SHELL                                  | COLOR INTUITIVE - FN18 - SW 6017 - ACCENT WALL   | CARSON CRADDUCK<br>312-953-0775   |
| CEILI | NG                         |                                      |  |  |                                   |
| ACT-1 | ACOUSTICAL<br>TILE CEILING | ARMSTRONG**                          | MINERAL FIBER-WET FORMED- TYPE III -<br>15/16" EXPOSED TEE           | - CIRRUS-SQUARE LAY-IN -574-24" X 24" X 3/4" - White                                     | ROBERT RUBENSTEIN<br>630-723-7396 |
| MILLW | ORK                        |                                      |  |  |                                   |
| SS-1  | SOLID<br>SURFACE           | WILSONART**                          | ACRYLIC RESINS - 13MM  | GIBRALTAR - CHICORY CREAM MELANGE 9047ML   | KATHY WALKER<br>630-487-1642      |
|       | BRACE                      | FAST CAP**                           | A-36 STEEL PLATE-12 GAUGE-0.1046"<br>THICK                           | 15" X 18" - WHITE - SB-15X18WH   | 888-443-3748                      |
|       | GROMMET                    | DOUG MOCKETT & CO**                  | PLASTIC  | 3" DIA. XG3-95 - WHITE   | 800-523-1269                      |

NOTE: MANNINGTON - WELD ROD - COLOR: CAMOUFLAGE ROD 415133 \*\* SEE CHART "MATERIAL PERFORMANCE DATA" FOR OTHER MANUFACTURERS

#### MATERIAL PERFORMANCE DATA SHEET VINYL MANNINGTON - BIOSPEC MD, OR ECORE - PEARLAZZO PUR OR ARMSTRONG -MEDINTECH - HOMOGENEOUS SHEET VINYL. URETHANE ALUMINUM OXIDE TOPCOAT, 6'-0" WIDTH, .080 INCHES WEARLAYER THICKNESS. 30-68 SQ. YDS PER ROLL, RANDOM REPEAT.

TRANSITION STRIPS

JOHNSONITE, FLEXCO OR VPI-RESILIENT TRANSITIONAL MOLDINGS. HOMOGENEOUS COMPOSITION OF POLYVINYLCHLORIDE, HIGH QUALITY ADDITIVES AND COLORANTS. STANDARD FORMULATION EXCEEDS ASTM E 648 CLASS 1 FLAMMABILITY REQUIREMENTS. PROFILE VARIES WITH FLOORING MATERIALS.

**RUBBER BASE** 

ROPPE, ARMSTRONG OR JOHNSONITE - RUBBER WALL BASE. 100% TYPE TS PINNACLE RUBBER BASE - 1/8" GAUGE. MEETS ASTM F 1861 - TYPE TS, GROUP 1, STYLES A, B & C.

SHERWIN WILLIAMS, BENJAMIN MOORE OR PPG - ACRYLIC COATING PAINT. 100% ACRYLIC EMULSION WATERBORNE, CORROSION RESISTANT COATING, USED DIRECTLY OVER MULTIPLE SUBSTRATES. LOW ODOR, LOW VOC, CHEMICAL RESISTANT, FAST DRY. CONFORMS TO AWWA D102 OCS #3. ACCEPTABLE FOR USE IN HIGH PERFORMANCE ARCHITECTURAL APPLICATIONS. MPI #134.

ACOUSTICAL TILE CEILING

ARMSTRONG, USG OR ROCKFON - WET-FORMED MINERAL FIBER SQUARE LAY-IN CEILING TILE. 15/16" SUSPENSION SYSTEM. 0.70 NRC RATING AND 0.86 LIGHT REFLECTANCE. 86% RECYCLED CONTENT, 94% BIOBASED. ASTM E1264 CLASSIFICATION, TYPE III, FORM 1, PATTERN E I, FIRE CLASS A.

SOLID SURFACE

WILSONART, CORIAN OR VENDURA - SOLID SURFACE PRODUCT. MANUFACTURED WITH ACRYLIC RESINS, FIRE-RETARDANT FILLERS AND PROPRIETARY COLORING AGENTS. DESIGNS CAN BE THERMOFORMED. NOT AFFECTED BY UV RAYS. 1/2" GAUGE PRODUCT.

FASTCAP, BEST BRACKET OR HAFELE - SUPPORT BRACKET. A36 STEEL PLATE, 12 GAUGE (O.1046" THICK). 1.5" X 1.5" NOTCH IN CORNER FOR WALL CLEAT AND TWO PASS-THROUGHS FOR CORDS. CHAMFERED SCREW HOLES WITH CAP. SUPPORT UP TO 1,000 ILBS PER PAIR - 16"OC.

DOUG MOCKETT & COMPANY, INC. , HAFELE OR WURTH BAER FLIP TOP GROMMET. INJECTION MOLDED 3" DIAMETER GROMMENT MADE WITH POLYSTYRENE.

## INTERIOR FINISHES PLAN NOTES

- 1. CONTRACTOR SHALL FURNISH AND INSTALL THE FOLLOWING ON THE EXISTING CONCRETE FLOOR SLAB/DECK:
  - A. REMOVE ALL EXISTING MASTIC/CUT-BACLK MATERIAL DOWN TO CONCRETE
  - B. PERFORM VACUUM-ASSISTED ABRASIVE BLASTING OVER COMPLETE FLOOR AREA SCHEDULED TO RECEIVE SHEET VINYL FLOORING.
  - C. REPAIR DAMAGED AND DETERIORATED CONCRETE ACCORDING TO FLOORING MANUFACTURERS WRITTEN RECOMMENDATIONS.
  - D. APPLY CEMENTITIOUS SELF-LEVELING UNDERLAYMENT.
  - E. REFER TO PROJECT MANUAL FOR ADDITIONAL WRITTEN REQUIREMENTS.

IDIQ NO. VA69D-13-D-0019 CONTRACT NO. VA69D-14-J-2293

Office of


Construction


and Facilities


Management


Department of Veterans Affairs

Project Title Drawing Title SITE PREP PARTIAL FIRST FLOOR - INTERIOR FINISHES 537-14-120 OP RADIOLOGY ROOM 1379 **Building Number** 700 Nicholas Blvd. Suite 403 Elk Grove Village, IL 60007 Approved: Project Director Location Drawing Number CHICAGO, IL T:**847.952.9362** F:**847.952.9403** I-101 Checked BANCROFT ARCHITECTS + ENGINEERS www.bancroft-ae.com Bancroft-AE Project No. 12-126-08 04/17/2015 EM









ENGINEERS + CONSULTANTS:

ARCHITECT + ENGINEERS:

BANCROFT ARCHITECTS + ENGINEERS

700 Nicholas Blvd. Suite 403 Elk Grove Village, IL 60007 T: 847.952.9362 F: 847.952.9403

Bancroft-AE Project No. 12-126-08

www.bancroft-ae.com

SITE PLAN:

**©** 

02/12/2015

11/24/2014

10/24/2014

100% CONSTRUCTION DOCUMENT - ISSUE FOR BID 04/17/2015

100% CONSTRUCTION DOCUMENT - REV. 1

35% SCHEMATIC DESIGN - MODIFICATION

95% CONSTRUCTION DOCUMENT

75% CONSTRUCTION DOCUMENT

VA FORM 08-6231

#### MECHANICAL VENTILATION KEY NOTES

- 1. CONTRACTOR SHALL FURNISH AND INSTALL SUPPLY DIFFUSER AND BRANCH SHEET METAL DUCT WORK AS SHOWN.
- 2. CONTRACTOR SHALL FURNISH AND INSTALL RETURN GRILLE AND BRANCH SHEET METAL DUCT WORK AS SHOWN.
- 3. EXISTING THERMOSTATS AND CONTROL WIRING IS SCHEDULED TO REMAIN.
- 4. EXISTING SUSPENDED VAV BOX, DUCT MOUNTED REHEAT COIL, AND RELATED COMPONENTS ARE SCHEDULED TO REMAIN.
- 5. CONTRACTOR SHALL PERFORM A TEST AND BALANCE OF THE MECHANICAL AIR SYSTEM AT PROJECT COMPLETION PHASE OF WORK. REFER TO PROJECT MANUAL.

|      | DIFFUSER, REGISTER, AND GRILLE SCHEDULE |          |          |                                |                      |        |        |  |  |  |  |  |  |  |
|------|---|----------|----------|--------------------------------|----------------------|--------|--------|--|--|--|--|--|--|--|
| MARK | TYPE                                    | MATERIAL | MOUNTING | PANEL /<br>FRAME SIZE<br>inxin | NECK<br>SIZE<br>(in) | DAMPER | FINISH |  |  |  |  |  |  |  |
| S1   | LOUVERED FACE                           | STEEL    | LAY-IN   | SEE DWG                        | 24x24                | NONE   | WHITE  |  |  |  |  |  |  |  |
| R1   | PERFORATED                              | STEEL    | LAY-IN   | SEE DWG                        | 24x24                | NONE   | WHITE  |  |  |  |  |  |  |  |

| EXISTING VAV BOX SCHEDULE |             |        |             |         |                 |       |  |  |  |  |  |  |
|---------------------------|-------------|--------|-------------|---------|-----------------|-------|--|--|--|--|--|--|
|                           | ROOMS       | INLET  | INLET       |         |                 |       |  |  |  |  |  |  |
| TAG                       | SERVED      | SIZE   | Δp<br>in-wg | Max     | PRIMARY AIRFLOW | NOTES |  |  |  |  |  |  |
|                           |             |        |             |         |                 |       |  |  |  |  |  |  |
| VAV-102                   | 1379        | 8      | 0.5         | 630     | 315             | 1     |  |  |  |  |  |  |
| VAV-103                   | 1381        | 8      | 0.5         | 450     | 200             | 1     |  |  |  |  |  |  |
| NOTES:                    |             |        |             |         |                 |       |  |  |  |  |  |  |
| 1. EXISTING V             | AV BOXES TO | REMAIN | . CONTR     | ACTOR 1 | O BALANCE C     | FM    |  |  |  |  |  |  |
| AS SHOWN.                 |             |        |             |         |                 |       |  |  |  |  |  |  |

#### MECHANICAL MATERIAL AND PROCEDURE NOTES

#### **DUCTWORK:**

- 1. ALL DUCTWORK SHALL BE FABRICATED FROM GALVANIZED METAL IN ACCORDANCE WITH SMACNA STANDARDS FOR LOW PRESSURE DUCT CONSTRUCTION, DUCT SIZES SHOWN INDICATE INSIDE DIMENSIONS.
- 2. FLEXIBLE DUCTWORK LOW PRESSURE DUCTWORK SHALL BE CONSTRUCTED OF SUPPORTING HELIX OF COATED SPRING STEEL WIRE IS PERMANENTLY BONDED TO A COATED WOVEN FIBERGLASS COVER. ACCEPTABLE MANUFACTURERS: THERMAFLEX, CLEVAFLEX, AND FLEXMASTER. LENGTHS SHALL NOT EXCEED 5'-0". FLEXIBLE DUCTWORK SHALL MEET THE REQUIREMENTS OF UL 181 AND NFPA 90A, AND BE SUITABLE FOR DUCT STATIC PRESSURE OF A MINIMUM OF +10" W.C. DUCT SIZES SHOWN ON DRAWINGS FOR FLEXIBLE DUCTWORK ARE INSIDE DIMENSIONS. ALL DIFFUSER CONNECTIONS SHALL HAVE THREE SHEET METAL SCREWS THROUGH HELIX OF FLEXIBLE DUCT. BAND CLAMP & SILVER ALUM. TAPED

#### **DUCT INSTALLATION:**

1. ALL SUPPLY AND RETURN DUCTWORK FROM HEATING/COOLING UNITS SHALL BE WRAPPED WITH 1 LB/FT DENSITY, 1-1/2" THICK FIBERGLASS DUCT INSULATION WITH A "K" FACTOR OF 0.21 OR LESS. INSULATION SHALL BE PROVIDED WITH A KRAFT VAPOR JACKET, AND BE CHEMICALLY TREATED FOR FLAME SAFETY.

#### GRILLES, REGISTERS, AND DIFFUSERS:

- 1. SUPPLY REGISTERS AND DIFFUSERS SHALL HAVE A FACE VELOCITY NOT TO EXCEED 500 FPM.
- 2. ACCEPTABLE MANUFACTURERS: TITUS, NAILOR, AND CARNES.

IDIQ NO. VA69D-13-D-0019 CONTRACT NO. VA69D-14-J-2293


Office of


Construction


and Facilities


Management

Project Title Drawing Title SITE PREP PARTIAL FIRST FLOOR - MECHANICAL 537-14-120 OP RADIOLOGY ROOM 1379 VENTILATION PLAN **Building Number** Approved: Project Director Drawing Number Location CHICAGO, IL M-101 Checked Department of Veterans Affairs 04/17/2015 EM










\_\_\_

\_\_\_




A PARTIAL DATA SYSTEM RISER DIAGRAM

\_\_\_

\_\_\_


VA FORM 08-6231



# B PARTIAL VOICE SYSTEM RISER DIAGRAM NOT TO SCALE

VOICE AND DATA NOTES:


- 1. SEE FLOOR PLANS FOR QUANTITY AND LOCATION OF DATA AND VOICE OUTLETS.
- 2. RISER DIAGRAM REPRESENTS GENERAL SCOPE OF WORK. PROVIDE ADDITIONAL MATERIALS AS REQUIRED.
- CONTRACTOR SHALL PULL ALL VOICE/DATA CABLE AND PROVIDE ALL NECESSARY TERMINATION AND TESTING.
- 4. VOICE/DATA CABLES MAY BE COMBINED INTO LARGER CONDUITS IN ACCORDANCE WITH THE APPROPRIATE CODE.



RISER DIAGRAM NOTES:

NOT TO SCALE

- 1. CONTINUITY CHECK AND 1000 VDC MEGGER TEST SHALL BE PERFORMED ON EXISTING CABLE. MEGGER TEST SHALL BE PERFORMED BETWEEN EACH PAIR OF CONDUCTORS AND FROM EACH CONDUCTOR TO GROUND.
- 2. CONTRACTOR SHALL FIELD VERIFY EXISTING 480V DISTRIBUTION PANEL MEET THE REQUIREMENTS OUTLINED ON GE SHEET E2.




## D ISOLATED GROUNDING DETAIL NOT TO SCALE

#### GROUNDING NOTES:

1. AS-BUILT DRAWING SHOWS ADDITIONAL GROUND CABLE FROM SUBSTATION 11 TO EXISTING X-RAY PANEL (TO BE DEMO'D). CONTRACTOR TO DE-TERMINATE FROM EXISTING X-RAY PANEL AND RE-TERMINATE TO GROUNG LUG IN MAIN DISCONNECT.

IDIQ NO. VA69D-13-D-0019

CONTRACT NO. VA69D-14-J-2293 Project Title Drawing Title Project Number SITE PLAN: ENGINEERS + CONSULTANTS: ARCHITECT + ENGINEERS: Office of SITE PREP 537-14-120 PARTIAL SINGLE LINE DIAGRAM OP RADIOLOGY ROOM 1379 Construction **(2) Building Number** and Facilities 100% CONSTRUCTION DOCUMENT - ISSUE FOR BID 04/17/2015 700 Nicholas Blvd. Suite 403 Elk Grove Village, IL 60007 Approved: Project Director Location Drawing Number 100% CONSTRUCTION DOCUMENT - REV. 1 03/17/2015 Management CHICAGO, IL 02/12/2015 95% CONSTRUCTION DOCUMENT T: **847.952.9362** F: **847.952.9403** E-501 75% CONSTRUCTION DOCUMENT Checked 11/24/2014 BANCROFT ARCHITECTS + ENGINEERS www.bancroft-ae.com Department of Veterans Affairs 35% SCHEMATIC DESIGN - MODIFICATION 10/24/2014 Bancroft-AE Project No. 12-126-08 04/17/2015 MA Revisions: TAYLOR STREET



\_\_\_

\_\_\_


#### INTERCONNECT DIAGRAM LEGEND

1. — — CONTRACTOR SHALL PROVIDE CABLES AND CONDUITS.

2. — GE FURNISHES AND INSTALLS CABLES. CONDUIT BY CONTRACTOR.

|                         |               |                | CABLE AND CC          | NDUIT SCHED           | ULE                  |                                    |
|-------------------------|---------------|----------------|-----------------------|-----------------------|----------------------|------------------------------------|
| FROM                    | TO CABLE SIZE |                | CABLE FURNISHED<br>BY | CABLE<br>INSTALLED BY | CONDUIT SIZE         | CONDUIT/FLOOR DUCT<br>INSTALLED BY |
| XRLC                    | PWR1          | 2#14, 1#14 GRD | CONTRACTOR            | CONTRACTOR            | 3/4"                 | CONTRACTOR                         |
| Α                       | SE0           | 2#14, 1#14 GRD | CONTRACTOR            | CONTRACTOR            | 1/2"                 | CONTRACTOR                         |
| SKL                     | SKL XRLC 4#14 |                | CONTRACTOR            | CONTRACTOR            | 1/2"                 | CONTRACTOR                         |
| SKL DLK1 2#14, 1#14 GRD |               | CONTRACTOR     | CONTRACTOR            | 1/2"                  | CONTRACTOR           |                                    |
| XRL1                    | XRLC          | 2#14, 1#14 GRD | CONTRACTOR            | CONTRACTOR            | 1/2"                 | CONTRACTOR                         |
| Α                       | SKL           | 3#2, 1#2 GRD   | CONTRACTOR            | CONTRACTOR            | 1-1 1/2"             | CONTRACTOR                         |
| DIST. PANEL<br>13E5     | A             | 3#2, 1#2 GRD   | CONTRACTOR            | CONTRACTOR            | 1-1 1/2"             | CONTRACTOR                         |
| SKL                     | TIB           | NA             | GE                    | GE                    | FLOOR DUCT           | CONTRACTOR                         |
| WBC1                    | TIB           | NA             | GE                    | GE                    | 1"                   | CONTRACTOR                         |
| SKL                     | D             | NA             | GE                    | GE                    | 1"                   | CONTRACTOR                         |
| OC PC SYS.              | D             | NA             | GE                    | GE                    | 1-1 1/2"             | CONTRACTOR                         |
| SKL                     | WBC1          | NA             | GE                    | GE                    | 1-2 1/2"             | CONTRACTOR                         |
| SKL                     | RT TABLE      | NA             | GE                    | GE                    | 1-2 1/2" &<br>ONE 2" | CONTRACTOR                         |
| SKL                     | WLS           | NA             | GE                    | GE                    | FLOOR DUCT           | CONTRACTOR                         |
| SKL                     | XTS1          | NA             | GE                    | GE                    | WALL DUCT            | CONTRACTOR                         |

TAYLOR STREET



#### PLAN LAYOUT LEGEND

----- CONDUIT BELOW FLOOR IN PIPE BASEMENT.

|               | EQUIPMENT SCHEDULE                                      |              |  |  |  |  |  |  |  |  |  |
|---------------|---|--------------|--|--|--|--|--|--|--|--|--|
| EQUIPMENT TAG | EQUIPMENT DISCRIPTION                                   | FURNISHED BY |  |  |  |  |  |  |  |  |  |
| А             | MAIN DISCONNECT. GE CAT #E4502RP                        | CONTRACTOR   |  |  |  |  |  |  |  |  |  |
| XRL1          | X-RAY ON WARNING LIGHT. GE CAT. #WXIABWW-OF-XIU         | CONTRACTOR   |  |  |  |  |  |  |  |  |  |
| DLK1          | DOOR LIMIT SWITCH                                       | CONTRACTOR   |  |  |  |  |  |  |  |  |  |
| XRLC          | X-RAY ROOM WARNING LIGHT CONTROLLER PANEL CAT. #E4502RL | CONTRACTOR   |  |  |  |  |  |  |  |  |  |
| SE0           | EMERGENCY OFF SWITCH                                    | CONTRACTOR   |  |  |  |  |  |  |  |  |  |
| XTS1          | XT RADIOGRAPHIC SUSPENSION WITH INBOARD MOUNTING.       | GE           |  |  |  |  |  |  |  |  |  |
| TIB           | TETHER INTERFACE BOX                                    | GE           |  |  |  |  |  |  |  |  |  |
| D             | DONGLE  | GE           |  |  |  |  |  |  |  |  |  |
| RT            | XR 656 DIGITAL ELEVATING TABLE                          | GE           |  |  |  |  |  |  |  |  |  |
| SKL           | SYSTEM CABINET  | GE           |  |  |  |  |  |  |  |  |  |
| WBC1          | OPERATORS CONSOLE                                       | GE           |  |  |  |  |  |  |  |  |  |
| WLS           | DIGITAL CHEST UNIT                                      | GE           |  |  |  |  |  |  |  |  |  |

#### **GENERAL NOTES:**

- A. RING OUT AND TAG ALL THE WIRES AT BOTH ENDS FOR FINAL CONNECTION BY GE CONTRACTOR.
- B. CONTRACTOR IS RESPONSIBLE TO SIZE ALL THE JUNCTION BOX TO COMPLY LATEST NEC REQUIREMENTS.
- C. REFER TO DRAWING E-602 FOR PANEL SCHEDULE AND LOCATION.
- D. CABLE LENGTHS SHOWN ON INTERCONNECT WIRING DIAGRAM IS MAXIMUM PERMITTED AS PER GE, CONTRACTOR SHALL ENSURE ROUTING OF THE CONDUITS IS LESS THAN MAXIMUM RUN LIMIT.

#### KEY NOTES:

- 1. RUN ALL THE CONDUITS IN PIPE BASEMENT. CONDUIT BELOW FLOOR MUST BE INSTALLED AS NEAR TO FLOOR AS POSSIBLE TO REDUCE RUN LENGTH.
- 2. CONDUITS IN PIPE BASEMENT, REFER TO DETAIL 1 INTERCONNECT WIRING DIAGRAM AND CABLE AND CONDUIT SCHEDULE FOR QUANTITY AND SIZE OF CONDUITS.
- 3. CONTRACTOR SHALL FIELD VERIFY EXISTING CONDUIT ROUTING AND FOLLOW THE SAME ROUTE FOR NEW CABLE IN NEW CONDUIT.
- 4. CONTRACTOR SHALL FIELD VERIFY EXACT LOCATION WITH GE.
- 5. ROUTE THE CABLE AND CONDUIT THROUGH THE STUD SPACE TO THE DONGLE.
- 6. FIELD VERIFY EXACT MOUNTING LOCATION WITH OWNER.
- 7. ALL THE CONDUITS TO BE INSTALLED IN PIPE BASEMENT ARE SHOWN ON DETAIL 2 THIS DRAWING. CONDUIT NOT SHOWN ON DETAIL 2 SHALL BE INSTALLED ABOVE GROUND.

PIPE BASEMENT



JUNCTION BOX

PROVIDE GALVANIZED STEEL & SUPPORT FRAMING AND GALVANIZED

THREADED ROD AND DECK ANCHORS

FLOOR BOX

IDIQ NO. VA69D-13-D-0019 **CONTRACT NO. VA69D-14-J-2293** 

SITE PLAN: 100% CONSTRUCTION DOCUMENT - ISSUE FOR BID 04/17/2015 100% CONSTRUCTION DOCUMENT - REV. 1 03/17/2015 95% CONSTRUCTION DOCUMENT 02/12/2015 11/24/2014 75% CONSTRUCTION DOCUMENT 35% SCHEMATIC DESIGN - MODIFICATION 10/24/2014

KEY NOTE 7

Revisions:

VA FORM 08-6231

ARCHITECT + ENGINEERS: ENGINEERS + CONSULTANTS:

700 Nicholas Blvd. Suite 403 Elk Grove Village, IL 60007 T:**847.952.9362** F:**847.952.9403** www.bancroft-ae.com BANCROFT ARCHITECTS + ENGINEERS Bancroft-AE Project No. 12-126-08

Drawing Title ELECTRICAL LAYOUT DETAILS AND WIRING DETAILS Approved: Project Director


Project Title Project Number SITE PREP 537-14-120 OP RADIOLOGY ROOM 1379 **Building Number** Location Drawing Number CHICAGO, IL E-601 Checked 04/17/2015

MA

Office of Construction and Facilities Management Department of Veterans Affairs

### **GENERAL NOTES:**

- CIRCUIT INFORMATION SHOWN ON PANEL IS BASED ON PANEL SCHEDULE INFORMATION RECEIVED FROM VA, CONTRACTOR SHALL BE RESPONSIBLE FOR TRACING THE CIRCUIT AND VERIFYING THE ACCURACY. AFTER THE FINAL INSTALLATION CONTRACTOR SHALL CREATE AS BUILT PANEL DIRECTORY FOR VA RECORD PURPOSE.
- 2. TOTAL LOAD SHOWN ON PANEL SCHEDULE ID FOR NEW LOAD ONLY.
- 3. LOCATION OF EXISTING DATA AND TELEPHONE CABINET.



| NAME                             | NAME NEW OR EXISTING LOCATION MOUNTING |      |     |                |                |             | JPPLIED<br>FROM     |  |          | VOLTAGE | BUS AMP<br>SIZE               | MAIN O.C.<br>DEVICE |         |  |  |  |
|----------------------------------|--|------|-----|----------------|----------------|-------------|---------------------|--|----------|---------|-------------------------------|---------------------|---------|--|--|--|
| GF                               | EXISTING                               | 13   | SE5 | SURFA          | ACE            |             | S                   | S4/CB27                                  | 7        |         | 120/208 V                     | 225                 | _       |  |  |  |
|                                  | LOAD                                   | TYPE | LOA | D (VA)         |                | ΑB          | C                   |  | LOA      | AD (VA) | LOAD TYF                      | PE                  |         |  |  |  |
| 101170 /05050710                 | 150 DE01                               |      | A   | B C            |                | $\frown$ 1  |                     |  | Α        | B C     |                               |                     |         |  |  |  |
| IGHTS/RECEPTAC                   | LES DESK                               |      |     |                | 20A -0         | 3           | 4 6                 | 6—20A                                    | //////// |         | SHUNT TRIP                    | 10 00 00            | 0.4     |  |  |  |
| IGHTS IN LAB                     |  |      |     |                | 20A -0         | $\sim$ 5    | $\frac{1}{6}$       | 0—20A<br>→20A                            |          | _ ///// | `                             | 7680, -82, -8       | 84, -86 |  |  |  |
| TG. RMS. 1365<br>CPTS. 1376.1380 | CODD                                   |      |     |                | 20A -0         | 7           | 18                  | -20A                                     |          |         | LTG. RMS. 138<br>RCPTS RMS. 1 |                     |         |  |  |  |
| RECEPTACLE RADI                  |  |      |     |                | 20A - 6        | ~ <u></u>   | 100                 | ZUA                                      |          |         | RCPTS. RMS.                   |                     |         |  |  |  |
| CPTS. RMS. 1386                  |  |      |     | ////           | 20A —          |             | 120                 | 20/1                                     |          |         | 4                             | RECEPTACLE X-RAY    |         |  |  |  |
| TG. RMS. CORR.                   | ). OOM.                                |      | _   |                | 20A -6         | 13          |                     | $\sim \frac{20A}{20A}$                   | _        |         | 1345 HANDICA                  |                     |         |  |  |  |
| TG. RMS. CORR.                   |  |      |     |                | 20A —          |             | 160                 | $\sim \frac{20 \text{ A}}{20 \text{ A}}$ |          | _       | $^{\prime\prime}$             | 1 HANDICAP          |         |  |  |  |
|                                  | 52 HANDICAP DOOR                       |      |     |                | 20A —          |             | 180                 | <u>~20A</u>                              |          |         |                               | 60, 1372, 1374      |         |  |  |  |
| CPTS. RMS. COR                   |  |      | -   |                | 20A —          | <u>0 19</u> | 206                 | ~_20A                                    | _        |         | RCPT. RMS. 13                 | · ·                 |         |  |  |  |
| RECEPTACLE REFR                  |  |      |     |                | 20A —          | 21          | 226                 | <u>~</u> 20A                             |          | -       | EXISTING EQUII                |                     |         |  |  |  |
|                                  |  |      |     | -              | 20A —          | 23          | +24 <sub>0</sub>    | 0—20A                                    |          |         | 1348 HANDICA                  |                     |         |  |  |  |
| O AMP SUB PAN                    | EL                                     |      | -   |                | 20A —          | 25          | 266                 | <u></u> 20A                              | _        |         | RCPT. RMS. C                  |                     |         |  |  |  |
|                                  |  |      |     |                | 20A —          | <u>27</u>   | 286                 | <u></u> 20A                              |          | -       | HAND DRYER                    |                     |         |  |  |  |
| ND FLOOR                         |  |      |     |                | 20A —          | 29          |                     | > <u>−</u> 20A                           |          |         | RCPTS. RMS.                   | 1360                |         |  |  |  |
| CARD READER                      |  |      | _   |                | 20A —          | 31          | $\frac{132}{326}$   | <u></u> 20A                              | _        |         | LIGHTS ROOM                   | 1379, 1381          |         |  |  |  |
| RECEPTACLE X-RA                  | AY                                     |      |     |                | 20A —          |             | $\frac{1.34}{3.00}$ | ò—20A                                    |          | -       | LIGHTS ROOM                   | 1379, 1381          |         |  |  |  |
| CPTS. RMS. 1383                  | 3                                      |      |     |                | 20A —          | 35          | 360                 | <u>−20A</u>                              |          |         | RCPTS. RMS.                   | 1381, 1383          |         |  |  |  |
| RECEPTACLE X-RA                  | AY                                     |      | -   |                | 20A <b>−</b> ∕ | 0.3/        | 386                 | <u>~20A</u>                              | _        |         | RCPTS. RMS.                   | 1381, 1383          |         |  |  |  |
| IGHTS CRAWL SP                   |  |      |     |                | 20A —          | 0.39        | 40                  | <u> 20A</u>                              |          | -       | LIGHTS ROOM                   | 1383                |         |  |  |  |
| GFI OGDEN ELEV.                  | PIT                                    |      |     |                | 20A <b>⊸</b> ∕ | 641         | 426                 | <b>→</b> 20A                             |          |         |                               |                     |         |  |  |  |
| ☐ ISOLATED                       | GND BUS                                |      |     | PHASE<br>CONN. | LOAD           | A -         | В                   | _  | С        | -       | VA                            |                     |         |  |  |  |
| 100% NEU                         | TRAL                                   |      |     | -              |                | TOTAL       | CONN.               | LOAD                                     |          | _       | VA                            |                     |         |  |  |  |
| 200% NEU                         | TRAL                                   |      |     |                |                |             |                     | - · · <del>-</del>                       |          |         |                               |                     |         |  |  |  |
|                                  |  |      | 1:  | sc=            |                | EST. D      | EMAND               | LOAD                                     |          | _       | VA                            |                     |         |  |  |  |

\_\_\_

| NAME           | NEW OR EXISTING         | LOCATION | MOUNTING                                     | SUPPL<br>FRO                            |                | VOLTAGE      | BUS AMP<br>SIZE | MAIN O.C.<br>DEVICE |
|----------------|-------------------------|----------|--|---|----------------|--------------|-----------------|---------------------|
| GEF            | EXISTING                | 13E5     | SURFACE                                      | SS11/CB                                 | 2 (GED)        | 120/208 V    | 100             | _                   |
|                | LOAD T                  | YPF LOA  | AD (VA)                                      | ABC                                     | LOAD (VA       | LOAD TY      | <br>PF          |                     |
|                | 207.5                   | A        | ВС   |   | A B            | C 20/12 /    |                 |                     |
| ECEPTACLES RN  | 1. 1364                 | -        | <u> 20A</u>                                  |   | 20A -          | MOTORIZED DO | OOR CONTROL PA  | NEL                 |
| IGHTING/RECEP1 | ACLE RM. 1370           |          | 20A —  | 5 5 4 6 6 9                             | 20A            |              | G LIGHT CONTROL |                     |
| ECEPTACLES RO  |                         |          | 20A —  |   | 20A            | 14           | G LIGHT CONTROL | . ROOM 1383         |
| ECEPTACLES RN  | ·                       | -        | <u>                                     </u> |   | 20A –          | SPARE        |                 |                     |
|                | 61, 2356, LTG. RM. 2361 |          | 20A -  | 5 5 4 10 5 5                            | 20A      -     | SPARE        |                 |                     |
|                | 11B N.E. CORNER         |          | 20A —  | 5 6 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 | 20A            | - SPARE      |                 |                     |
| ECEPTACLES RO  |                         |          | 1111111111120A —                             | 15 16                                   | 20A —          | SPARE        |                 |                     |
| IGHT ROOM 337  |                         |          | 20A —  | 17 1 18                                 | 20A      -     | SPARE        |                 |                     |
| ECEPTACLE/LIGI |                         |          | 20A —  | 19 20                                   | 20A            | - SPARE      |                 |                     |
| ECEPTACLE ROC  | )M 43/0                 | -        | 111111111120A —                              | 21 22                                   | 20A -          | SPARE        |                 |                     |
| PARE           |                         |          | 20A -  | 23 24                                   | 20A      -     | SPARE        |                 |                     |
| PARE DO DO     | 2011 7770               |          | 20A -  | 25 26                                   | 20A            | - SPARE      |                 |                     |
| ECEPTACLES RO  |                         |          | 1111111111120A —                             | 27 28                                   | 20A —          | SPARE        |                 |                     |
| ECEPTACLE/LIGI | HI RM 4370              |          | 20A  | 00 1 70 0                               | 20A      -     | SPARE        |                 |                     |
| IGHT RM 1372   |                         |          | 20A -  | $\bigcirc$ 31     32 $\bigcirc$ =       | 20A            | - SPARE      |                 |                     |
| M LIGHTS 1ST F |                         |          | 11111111111111111111111111111111111111       | 77       74                             | 20A —          | SPARE        |                 |                     |
| IGHTS ROOM 13  |                         |          | 20A -  | 35 36 -                                 | 20A            | SPARE        |                 |                     |
| XIT SIGNS 1355 | , 1301                  |          |  | 37 38                                   |                | - SPARE      |                 |                     |
| PARE           |                         |          | 20A —  | 70     40 0 -                           |                | SPARE        |                 |                     |
| PARE           |                         |          | 20A  | 41   40 0 -                             | 111111         | SPARE        |                 |                     |
| PARE           |                         |          |  | 3 341 + 426 3-2                         | 20A [[[[[]]]]] | - SPARE      |                 |                     |
| ☐ ISOLATED     | GND BUS                 |          | PHASE<br>CONN. LOAD                          | A   -   B   -                           | - C -          | VA           |                 |                     |
| 100% NE        | UTRAL                   |          |  | TOTAL CONN. LOA                         | D –            | VA           |                 |                     |
| 200% NE        | UTRAL                   |          |  |   |                |              |                 |                     |
|                |                         | ı        | sc=  | EST. DEMAND LOAI                        | )   –          | VA           |                 |                     |

IDIQ NO. VA69D-13-D-0019 CONTRACT NO. VA69D-14-J-2293

|   | SITE PLAN:                                | ENGINEERS + CONSULTANTS:   | ARCHITECT + ENGINEERS: |  | Drawing Title ELECTRICAL PANEL SCHEDULE | Project Title SITE PREP |         |                                | Project Number<br>537-14-120 | Office of                   |
|---|---|--|------------------------|--|---|-------------------------|---------|--------------------------------|------------------------------|-----------------------------|
|   | POLK STREET WEIGHT                        |  | $\sim$                 |  |   | OP RADIOLO              | GY ROOM | M 1379                         | Building Number 11B          | Construction and Facilities |
| 100% CONSTRUCTION DOCUMENT - 1850E FOR BID 04/17/2015<br>  100% CONSTRUCTION DOCUMENT - REV. 1      | 5 OST |  | -/3ana(/X              | 700 Nicholas Blvd. Suite 403<br>Elk Grove Village, IL 60007<br>T: 847.952.9362 F: 847.952.9403 | Approved: Project Director  -           | Location CHICAGO, IL    |         |                                | Drawing Number               | Management                  |
| 75% CONSTRUCTION DOCUMENT 11/24/2014 35% SCHEMATIC DESIGN - MODIFICATION 10/24/2014 Revisions: Date |   | BANCROFT ARCHITECTS + ENGINEERS  www.bancroft-ae.com Bancroft-AE Project No. 12-126-08 | _                      | Date<br>04/17/2015   | Checked                                 | Drawn<br>##             | E-602   | Department of Veterans Affairs |                              |                             |