































ELECTRICAL LEGEND

SYMBOL	DESCRIPTION	SYMBOL	DESCRIPTION
PROVIDE	LIGHTING	PROVIDE	TELEPHONE AND DATA SYSTEM
	LIGHTING FIXTURE TYPE. SEE LIGHTING FIXTURE SCHEDULE ON SHEET EL501.		LADDER TYPE CABLE TRAY. 8"W BY 2"H, SECURED TO STRUCTURE @5' ON CENTER PER MANUFACTURER'S RECOMMENDATIONS.
	INCANDESCENT, HIGH INTENSITY DISCHARGE (H.I.D.) OR COMPACT FLUORESCENT LIGHTING FIXTURE (-4 INDICATES BRACKET, WALL MOUNTED FIXTURE)		COMMUNICATIONS OUTLET
	SINGLE HEAD PARKING LOT FIXTURE		TELEPHONE OUTLET
	EXIT LIGHTING FIXTURE. ARROW(S), WHEN USED, INDICATES DIRECTION, NUMBER AND ORIENTATION OF ILLUMINATED FACE(S). TYPE U.O.N. (-4 INDICATES BRACKET, WALL MOUNTED FIXTURE).		DATA OUTLET
S	SINGLE POLE SWITCH, 20A, 120/277V		EQUIPMENT CONNECTIONS
S3	THREE-WAY SWITCH, 20 A, 120/277 V.		MOTOR CONNECTION AS INDICATED
SA	DUAL TECHNOLOGY, SINGLE RELAY (BASIS OF DESIGN WATTSTOPPER DSW-301)		JUNCTION BOX
SB	INFRARED DIMMING SENSOR SWITCH (BASIS OF DESIGN WATTSTOPPER PW-101D)		DISCONNECT SWITCH, 600V, 3P = NO. OF POLES. 60A = SWITCH AMPERAGE, N = FUSE RATING, (N = NON-FUSED) 3R = NEMA RATING.
SC	DIGITAL DIMMING WALL SWITCH (BASIS OF DESIGN WATTSTOPPER LMDM-101)		(MOTOR RATED SWITCH) (MANUAL MOTOR STARTER SWITCH) WITH OVERLOADS.
SD	SINGLE BUTTON DIGITAL WALL SWITCH (BASIS OF DESIGN WATTSTOPPER LMSW-101)		DISTRIBUTION
ST	DIGITAL ASTRONOMICAL TIMER SWITCH (BASIS OF DESIGN WATTSTOPPER RT-200)		PANELBOARD - 208Y/120V
	LIGHTING CONTACTOR, 12 POLE, NORMALLY OPEN, MECHANICALLY HELD.		WIRE, CONDUIT AND RACEWAY
	DIGITAL DUAL TECHNOLOGY CEILING MOUNTED SENSOR (BASIS OF DESIGN WATTSTOPPER LMDC-100)		BRANCH CIRCUIT OR FEEDER WIRING IN CONDUIT, CONCEALED IN WALL OR CEILING. SEE PANEL SCHEDULES.
	SINGLE RELAY ROOM CONTROLLER (BASIS OF DESIGN WATTSTOPPER LMRC-101)		HOMERUNS TO PANEL. PANEL AND CIRCUIT DESIGNATIONS AS INDICATED.
	POWER DEVICES		INDICATES A CONDUIT RUN UNDERGROUND OR UNDER SLAB.
	SINGLE RECEPTACLE, 20 A, 125 VAC, MOUNT 18" AFF UON.		FLEXIBLE CONDUIT.
	DUPLEX CONVENIENCE RECEPTACLE, 20 A, 125 VAC, MOUNT 18" AFF UON.		GENERAL
	RECEPTACLE MOUNTED 48" AFF OR 6" ABOVE BACKSPLASH OR COUNTERTOP WHERE COUNTER IS INDICATED.		ROOM NUMBER SYMBOL
	QUADRUPLIX CONVENIENCE RECEPTACLE MOUNTED IN TWO-GANG OUTLET BOX - EACH RATED 20A, 125 VOLTS WITH SINGLE COVER PLATE, MOUNT 18" AFF, UON.		
	RECEPTACLE AS NOTED ABOVE BUT WITH INTERNAL GROUND FAULT PROTECTION. "WP" INDICATES WEATHERPROOF OUTLET WITH INTERNAL GROUND FAULT PROTECTION.		
	SPECIAL PURPOSE RECEPTACLE. REFER TO PANEL SCHEDULE FOR AMPERAGE.		
	PAD MOUNTED TRANSFORMER (SITE)		
	PAD MOUNTED UTILITY SWITCH (SITE)		

LEGEND NOTES

- WIRE AND CONDUIT FOR MOTOR AND EQUIPMENT LOADS SHALL BE CONTINUOUS IN SIZE AND FROM SOURCE TO FINAL CONNECTION. SIZE AND COUNT SHALL BE AS INDICATED ON THE CIRCUIT HOMERUN UNLESS OTHERWISE NOTED.
- COORDINATE EXACT LOCATION OF CEILING MOUNTED LIGHTING FIXTURES AND SPEAKERS WITH ARCHITECTURAL REFLECTED CEILING PLANS.
- WHERE A CONNECTION IS INDICATED, THE CONTRACTOR SHALL PROVIDE ALL MATERIALS (JUNCTION BOXES, CONDUIT, WIRE, ETC.) AND LABOR REQUIRED TO MAKE THE CONNECTION.
- COORDINATE EXACT LOCATION OF WALL MOUNTED RECEPTACLES TO SERVE WALL MOUNTED EQUIPMENT WITH ARCHITECTURAL ELEVATIONS.
- SEE TELECOMMUNICATIONS DRAWINGS FOR LOCATIONS OF TELECOMMUNICATIONS AND SPECIAL SYSTEMS DEVICES. ELECTRICAL CONTRACTOR TO PROVIDE BOXES AND CONDUIT PER ELECTRICAL ROUGH-IN LEGEND AND NOTES ON T100.

ABBREVIATIONS

A	AMPERE	KAIC	THOUSAND AMP INTERRUPTING CAPACITY, RMS SYMMETRICAL
A/C	AIR CONDITIONING	KCMIL	THOUSAND CIRCULAR MILS
AC	ACCESS CONTROL	KWH	KILOWATT HOUR
AFF	ABOVE FINISHED FLOOR	KVA	KILOVOLT AMPERE
AHU	AIR HANDLING UNIT	LTG	LIGHTING
ATS	AUTOMATIC TRANSFER SWITCH	MCB	MAIN CIRCUIT BREAKER
AW	ANTI-WANDER	MLO	MAIN LUG ONLY
BLDG	BUILDING	MTD	MOUNTED
BRKR	BREAKER	MTG HT	MOUNTING HEIGHT
C	CONDUIT	NC	NURSE CALL
CATV	CABLE TELEVISION	NF	NON-FUSED
CB	CIRCUIT BREAKER	PA	PUBLIC ADDRESS
CCTV	CLOSED CIRCUIT TELEVISION	PNL	PANEL
DISC SW	DISCONNECT SWITCH	RECEPT	RECEPTACLE
DWG	DRAWING	SW	SWITCH
EC	EMPTY CONDUIT	UG	UNDERGROUND
EF	EXHAUST FAN	UON	UNLESS OTHERWISE NOTED
EQUIP	EQUIPMENT	V	VOLTS
EXIST	EXISTING	WH	WATER HEATER
FACP	FIRE ALARM CONTROL PANEL	WP	WEATHERPROOF
FLUOR	FLUORESCENT	XFMR	TRANSFORMER
G, GFI	GROUND FAULT INTERRUPTER		
GND	GROUND		
HID	HIGH INTENSITY DISCHARGE		

Revisions:

Date

CONSULTANTS:

CLARK♦NEXSEN

440 MARTIN LUTHER KING, JR. BLVD
MACON, GEORGIA 31201

478-743-8415 FAX 478-743-8239
WWW.CLARKNEXSEN.COM
CLARK NEXSEN LICENSE #C-1028

Professional Engineer
PE License No. 10000
PE Name: BRADY B. PEACOCK

ARCHITECT/ENGINEERS:

TOLAND
MIZELL
MOLNAR

590 MEANS ST NW ATLANTA GA 30318

Drawing Title:
LEGEND AND ABBREVIATIONS
ELECTRICAL

Approved: Project Director

Drawing Title:
FAYETTEVILLE CLC
PROJECT ONE

Location:
FAYETTEVILLE, NC

Date:
February 5, 2015

Checked:
PEACOCK

Drawn:
BRADY

Project Number:
565-131


Building Number:
.

Drawing Number:
E001

Dwg. of .

FINAL SUBMITTAL

OFFICE OF
CONSTRUCTION
AND FACILITIES
MANAGEMENT


 Department of
Veterans Affairs



- [illegible]


one-eighth inch = one foot

A three inches = one foot
B one and one-half inches = one foot
C one inch = one foot
D three-quarters inch = one foot
E one-half inch = one foot
F three-eighths inch = one foot
G one-quarter inch = one foot
H one-eighth inch = one foot




10 BED HOME MEZZANINE LIGHTING PLAN - ELECTRICAL
SCALE: 3/16" = 1'-0"

- GENERAL NOTES:**
1. THE BASIS OF DESIGN FOR LIGHTING IS WATT STOPPER ROOM CONTROLLER, AND ANY/ALL ASSOCIATED, COMPATIBLE WALL STATIONS, DAYLIGHT SENSORS, OCCUPANCY/VACANCY SENSORS, ETC. FOR A COMPLETE AND OPERABLE SYSTEM.
 2. COMMUNICATION BETWEEN ROOM CONTROLLER AND ANY/ALL DEVICES ASSOCIATED WITH CONTROLS SYSTEM (WALL STATIONS, DAYLIGHT SENSORS, OCCUPANCY/VACANCY SENSORS, ETC.) SHALL BE BY CAT 5 CABLE WITH RJ45 CONNECTORS.
 3. CAT 5 CABLE WITH PRE-TERMINATED RJ45 CONNECTORS SHALL BE PROVIDED BY LIGHTING CONTROL MANUFACTURER. CONTRACTOR SHALL PROVIDE TOTAL NUMBER OF CABLE REQUIRED, AND LENGTHS REQUIRED PRIOR TO ORDERING.
 4. EXACT MOUNTING LOCATIONS OF ROOM CONTROLLERS AND ANY/ALL DEVICES ASSOCIATED WITH CONTROLS SYSTEM TO BE FIELD VERIFIED. DRAWINGS ARE DIAGRAMMATIC ONLY.
 5. ALL POWER WIRING BETWEEN ROOM CONTROLLER AND LIGHTING FIXTURES, ETC. TO BE IN CONDUIT.
 6. ROUTING OF CAT 5 CABLE SHALL BE IN CONDUIT IN WALLS OR NON-ACCESSIBLE LOCATIONS AND ROUTED IN CABLE TRAY ABOVE CEILING, ROUTED PARALLEL AND AT 90° ANGLES TO BUILDING LINES FOR A NEAT AND ORGANIZED INSTALLATION. CONTRACTOR SHALL USE THIS ROUTING METHOD WHEN GIVING LENGTHS OF CABLE TO MANUFACTURER FOR ORDERING.
 7. ALL "F1" FIXTURES SHALL BE PROVIDED WITH LOW-VOLTAGE CONTROLLER, SEE FIXTURE SCHEDULE SHEET EL501. SWITCHING CONTROL OF FIXTURE TO BE BY PATIENT STATION LOCATED IN WALL BY BED. PROVIDE 1" C FROM FIXTURE CONTROLLER TO NURSE CALL PATIENT STATION. SEE SPECIAL SYSTEMS SHEET EY101.



10 BED HOME LIGHTING PLAN - ELECTRICAL
SCALE: 3/16" = 1'-0"

- NOTES:**
(THIS SHEET ONLY)
1. CONNECT TO FIXTURE AS REFERENCED IN NOTE 2.
 2. CONNECT TO FIXTURE AS REFERENCED IN NOTE 1.
 3. PROVIDE FLANGE KIT FOR THIS FIXTURE.
 4. ROUTE ALL EXTERIOR SITE AND BUILDING MOUNTED LIGHTING POWERED FROM 1LN11 THROUGH THIS LIGHTING CONTRACTOR. PROVIDE A PHOTOCELL IN PARALLEL WITH SWITCH SHOWN CONTROLLING CONTRACTOR. MOUNT PHOTOCELL TO BUILDING JUST BELOW ROOF LINE FACING EAST.




NOTE: ARCHITECTURAL, STRUCTURAL, MECHANICAL, ELECTRICAL, PLUMBING AND FIRE PROTECTION FLOOR PLAN DRAWINGS OF THE BUILDING ENVELOPE AND INTERIOR FOR THE 10 BEDROOM HOUSES ARE DRAWN OPPOSITE HAND (MIRROR IMAGE) OF THE REQUIRED ORIENTATION. REFERENCE THIS KEY PLAN AND/OR CIVIL AND LANDSCAPE DRAWINGS FOR THE PROPER BUILDING ORIENTATION AND ASSOCIATED WALKS, DRIVES, PARKING AND SITE UTILITIES.

BUILDING ORIENTATION KEY PLAN

CONSULTANTS:

CLARK NEXSEN

440 MARTIN LUTHER KING, JR. BLVD
MACON, GEORGIA 31201
478-743-8415 FAX 478-743-8239
WWW.CLARKNEXSEN.COM
CLARK NEXSEN LICENSE #C-1028



ARCHITECT/ENGINEERS:

TOLAND MIZELL MOLNAR
590 MEANS ST NW ATLANTA GA 30318

Drawing Title:
10 BED HOME LIGHTING PLAN ELECTRICAL

Approved: Project Director

Project Title:
FAYETTEVILLE CLC PROJECT ONE

Location:
FAYETTEVILLE, NC

Date:
February 5, 2015

Checked:
PEACOCK

Drawn:
BRADY



Project Number:
565-131
Building Number:
.
Drawing Number:
EL101
Dwg. of .

FINAL SUBMITTAL

OFFICE OF CONSTRUCTION AND FACILITIES MANAGEMENT


Department of Veterans Affairs

three inches = one foot
one and one-half inches = one foot
one inch = one foot
three-quarters inch = one foot
one-half inch = one foot
three-eighths inch = one foot
one-quarter inch = one foot
one-eighth inch = one foot




IT AND ELECTRICAL ROOMS
OTHER 10 BED HOME PLAN - ELECTRICAL
SCALE: 3/16" = 1'-0"

GENERAL NOTES:
(THIS SHEET ONLY)
A. ALL CIRCUITS SHOWN AS 1LE12-X IS 2LE11-X IN OTHER 10 BEDROOM BUILDING.




10 BED HOME MEZZANINE PLAN - ELECTRICAL
SCALE: 3/16" = 1'-0"

- NOTES:
(THIS SHEET ONLY)
- 1 REFER TO ELECTRICAL ROOM PLAN FOR OTHER 10 BEDROOM BUILDING, THIS SHEET.
 - 2 POWER FOR GAS MANIFOLD.
 - 3 POWER FOR GAS ALARM PANEL.
 - 4 POWER FOR MASTER GAS ALARM PANEL.
 - 5 RECEPTACLE TO BE SERVED BY SHUNT TRIP BREAKER. SHUNT TRIP SHALL BE CONNECTED TO RANGE HOOD CONTROLS WITH 3#12, #12G3/4".
 - 6 RECEPTACLE UNDER SINK TO POWER MOTION DETECTOR FAUCET.
 - 7 COORDINATE HEIGHT AND LOCATION OF RECEPTACLE FOR MICROWAVE WITH ARCHITECTURAL.
 - 8 COORDINATE EXACT MOUNTING HEIGHT AND LOCATION OF THIS OUTLET WITH PRE-MANUFACTURED FURNITURE FOR TV LOCATION.
 - 9 COORDINATE EXACT MOUNTING HEIGHT AND LOCATION OF THIS OUTLET WITH PRE-MANUFACTURED FURNITURE FOR DESK POWER.
 - 10 COORDINATE WITH RANGE HOOD.



10 BED HOME POWER PLAN - ELECTRICAL
SCALE: 3/16" = 1'-0"



NOTE: ARCHITECTURAL, STRUCTURAL, MECHANICAL, ELECTRICAL, PLUMBING AND FIRE PROTECTION FLOOR PLAN DRAWINGS OF THE BUILDING ENVELOPE AND INTERIOR FOR THE 10 BEDROOM HOUSES ARE DRAWN OPPOSITE HAND (MIRROR IMAGE) OF THE REQUIRED ORIENTATION. REFERENCE THIS KEY PLAN AND/OR CIVIL AND LANDSCAPE DRAWINGS FOR THE PROPER BUILDING ORIENTATION AND ASSOCIATED WALKS, DRIVES, PARKING AND SITE UTILITIES.

BUILDING ORIENTATION KEY PLAN

CONSULTANTS:

CLARK•NEXSEN

440 MARTIN LUTHER KING, JR. BLVD
MACON, GEORGIA 31201

478-743-8415 FAX 478-743-8239
WWW.CLARKNEXSEN.COM
CLARK NEXSEN LICENSE #C-1028



ARCHITECT/ENGINEERS:

TOLAND
MIZELL
MOLNAR

590 MEANS ST NW ATLANTA GA 30318

Drawing Title:
10 BED HOME
POWER PLAN
ELECTRICAL

Approved: Project Director

Project Title:
FAYETTEVILLE CLC
PROJECT ONE

Location:
FAYETTEVILLE, NC

Date:
February 5, 2015

Checked:
PEACOCK

Drawn:
BRADY

Project Number:
565-131

Building Number:
.


Drawing Number:
EP101

Dwg. of .


FINAL SUBMITTAL

OFFICE OF
CONSTRUCTION
AND FACILITIES
MANAGEMENT


Department of
Veterans Affairs



200 AMP "LOADBREAK"
15KV METAL OXIDE VARISTOR
OVERVOLTAGE SURGE ARRESTER INSTALLATION
SCALE: NONE




CABLE TAGS - TYPICAL
SCALE: NONE
NOTE: SEE SPECIFICATIONS FOR MATERIAL, COLORS,
AND MANNER OF INSTALLATION.



PAD NO.	A	B	C	D	E	F	G
P30	45	42	6	24	10	5	9
P10	48	48	8	28	29 1/4	9 1/8	10
P40	65	65	8	48	15	6	12
P70	85	85	8	48	15	8	18 1/2
P90	124	124	8	72	20	10	26

NOTES: (MINIMUMS)
1. CONCRETE: 3,000 PSI
2. STEEL: GRADE 60


TYPICAL PRECAST TRANSFORMER PADS
SCALE: NONE




- NOTES:
- REFER TO SPECIFICATIONS FOR ADDITIONAL REQUIREMENTS.
 - WHEN POSSIBLE INSTALL ELBOW ARRESTERS ON DE-ENERGIZED SYSTEM.
 - ATTACH GROUND LEAD TO ARRESTER AND HOTLINE CLAMP.
 - LUBRICATE ARRESTER INTERFACE.
 - THE ELBOW ARRESTER MUST BE INSTALLED AND REMOVED WITH A "SHOTGUN STICK".
 - THE ELBOW ARRESTER IS ENCASED IN A GROUNDED CASE AND MAY BE PLACED ANYWHERE IN THE PRIMARY COMPARTMENT. CARE SHOULD BE TAKEN SO AS NOT TO RESTRICT OTHER LOADBREAK DEVICES.

MATERIAL: ARRESTER, 9KV; FEED-THROUGH DEVICE; HOTLINE CLAMP; AND GREASE


U.D. CABLE ENTRANCE ARRANGEMENT
FOR THREE PHASE PAD-MOUNTED
TRANSFORMERS WITH ELBOW ARRESTERS
SCALE: NONE



- NOTES:
- SIDES OF TRENCH TO BE PROPER WIDTH AND TRIMMED SMOOTH TO ALLOW A MINIMUM OF 3 INCHES SPACE BETWEEN SIDE OF TRENCH AND OUTSIDE OF DUCT FOR CONCRETE.
 - BOTTOM OF TRENCH TO BE GRADED SMOOTH AND SLOPED AS SHOWN ON THE DUCT LINE AND MANHOLE CONSTRUCTION DRAWINGS.
 - INSTALL BASE SPACER SO AS TO PROVIDE 3 INCHES SPACE BETWEEN BOTTOM OF TRENCH AND BOTTOM ROW OF DUCTS FOR CONCRETE.
 - SLOPE AS REQUIRED FOR SITE CONDITIONS TO AVOID CAVE-INS.




METHOD OF ASSEMBLING DUCTS IN TRENCH
SCALE: NONE



- NOTES:
- BFP22SH POLYESTER-COATED FIBERGLASS CHANNEL, ANCHORED TO WALL.
 - PORCELAIN CABLE CLAMP SIZED FOR CABLE, (NOTE 2) WITH GLASS-REINFORCED POLYURETHANE PIPE STRAP.
 - BFP-409-12 OR -14 (DEPENDING ON WIDTH OF (2) POLYESTER-COATED FIBERGLASS CHANNEL BRACKETS.
 - BFP202, BFP225 STAINLESS STEEL (TYPE 316) HARDWARE.


NOTE 1: CONCENTRIC NEUTRAL GROUND BOND. (SEE DETAIL PLATE)
NOTE 2: ALLOW FOR FIREPROOF WRAP WHEN APPLICABLE.
NOTE 3: CAT. NOS. REFER TO B-LINE FOR APPROVED EQUALS, SEE SPECIFICATIONS. SUBMITTALS REQUIRED.
NOTE 4: ANY FIELD CUTS SHALL BE SEALED WITH MANUFACTURER'S RECOMMENDED SEALANT.
NOTE 5: BOND ALL NON-CURRENT-CARRYING METAL PARTS TO GRD. RING BUS, AND BOND BUS TO A 5/8"x10" COPPERWELD STEEL-DRIVEN GROUND ROD. SEE ALSO "GROUNDING DETAILS FOR PAD-MOUNT TRANSFORMER" FOR BONDING CABLES.

TYPICAL RACKING IN VAULTS
SCALE: NONE



TYPICAL REINFORCING & DIMENSIONS
CONCRETE ENCASED DUCT BANKS
SCALE: NONE


NOTE: OTHER CONFIGURATIONS TO BE SIMILAR.




- NOTES:
- EACH CONDUCTOR IN BOX SHALL BE OF SUFFICIENT LENGTH FOR MAKING UP SPLICES.
 - DO NOT INSTALL WIRES IN BACK OF DEVICE. LOOP AROUND TERMINAL SCREWS.
 - FACE OF PLASTER RING (WHERE UTILIZED) SHALL BE FLUSH WITH WALL.
 - FRONT OF DEVICE SHALL BE WITHIN 1/8" OF FINISHED WALL.

RECEPTACLE WIRING DETAIL
SCALE: NONE

CONSULTANTS:		ARCHITECT/ENGINEERS:		Drawing Title:		Project Title:		Project Number:		FINAL SUBMITTAL	
CLARK•NEXSEN		TOLAND MIZELL MOLNAR		DETAILS - ELECTRICAL		FAYETTEVILLE CLC PROJECT ONE		565-131		OFFICE OF CONSTRUCTION AND FACILITIES MANAGEMENT	
440 MARTIN LUTHER KING, JR. BLVD MACON, GEORGIA 31201		590 MEANS ST NW ATLANTA GA 30318		Approved: Project Director		Location: FAYETTEVILLE, NC		Building Number:		Department of Veterans Affairs	
478-743-8415 FAX 478-743-8239 WWW.CLARKNEXSEN.COM CLARK NEXSEN LICENSE #C-1028						Date: February 5, 2015		Checked: RBP		Drawing Number: E501	
Revisions:								Drawn: SJB		Dwg. of	




UD PRIMARY CABLE
METALLIC TAPE SHIELDED CABLE
SCALE: NONE




NOTE: ALWAYS FOLLOW MANUFACTURER'S INSTRUCTIONS.


30 MA GROUNDING DEVICE
FOR METALLIC TAPE SHIELDED CABLE
SCALE: NONE




600AMP DEADBREAK CABLE
TERMINATOR/APPARATUS CONNECTOR *
SCALE: NONE
* FOR TAPE SHIELDED CABLE



600AMP DEADBREAK CABLE
TERMINATOR/APPARATUS CONNECTOR * **
SCALE: NONE
* FOR TAPE SHIELDED CABLE
** WITH 600-200 AMP ADAPTOR FOR END-OF-LINE LIGHTNING ARRESTER



600/600 AMP
DEADFRONT CABLE TERMINATORS (SPICE) *
SCALE: NONE
* FOR TAPE SHIELDED CABLE



ACCESSORIES FOR USE
WITH 15KV LOADBREAK FITTINGS
SCALE: NONE


Revisions:	Date

CONSULTANTS:

CLARK•NEXSEN

440 MARTIN LUTHER KING, JR. BLVD
MACON, GEORGIA 31201

478-743-8415 FAX 478-743-8239
WWW.CLARKNEXSEN.COM
CLARK NEXSEN LICENSE #C-1028



ARCHITECT/ENGINEERS:

TOLAND MIZELL MOLNAR

590 MEANS ST NW ATLANTA GA 30318

Drawing Title:

DETAILS - ELECTRICAL

Approved: Project Director

Project Title:

FAYETTEVILLE CLC
PROJECT ONE

Location:

FAYETTEVILLE, NC

Date:

February 5, 2015

Checked:

RBP

Drawn:

SJB

Project Number:

565-131

Building Number:

.

Drawing Number:

E502

Dwg. of

FINAL SUBMITTAL

OFFICE OF
CONSTRUCTION
AND FACILITIES
MANAGEMENT

Department of
Veterans Affairs

PANEL DEFINITIONS				
BUILDING	VOLTAGE	POWER SYSTEM	LEVEL	PANEL #
B = BUILDING #	L = 120/208	N = NORMAL L = LIFE SAFETY C = CRITICAL G = GENERATOR	1 = FIRST	1 = ONE 2 = TWO 3 = THREE 4 = FOUR 5 = FIVE 6 = SIX ETC.

1/2" HIGH LETTERS

1/4" HIGH LETTERS (TYP)

BHNA2
277/480V
"CRITICAL"
FED FROM BHNA1

LAMINATED PHENOLIC RESIN WITH
WHITE CORE ENGRAVED LETTERING
BLACK FOR "NORMAL" EQUIPMENT
RED FOR "EMERGENCY" EQUIPMENT

TYPICAL EQUIPMENT IDENTIFICATION NAMEPLATE
SCALE: NONE

PANEL 1LN11 SCHEDULE																				
600 AMP BUS			600 AMP MCB			208Y/120 VOLTS			3PH, 4W, 3N			MIN. 65 KVA			SURFACE MOUNTED			SE RATED		
CKT. NO.	LOAD DESCRIPTION	COND. SIZE	WIRE SIZE	BKR TRIP	AMPS	KVA	PH	KVA	AMPS	BKR TRIP	WIRE SIZE	COND. SIZE	LOAD DESCRIPTION	CKT. NO.						
1	DAS-2	2	3/1/0	150	136.0	16.3	A	5.7	47.5	225	4/4/0	2-1/2	PANEL 1LN12	2						
2														4						
3														6						
4														8						
5														10						
6														12						
7														14						
8														16						
9	CU-1	1-1/4	3/12	80	66.0	7.9	A	20.0	168.0	225	4/4/0	2-1/2	PANEL 1LN13	10						
10														12						
11	WH-2	1-1/4	3/12	20	5.8	0.7	A	19.8	162.2					14						
12														16						
13	WH-2	1-1/4	3/12	20	66.0	7.9	A							18						
14														20						
15														22						
16														24						
17														26						
18														28						
19														30						
20														32						
21	WH-1	3/4	2/10	30	24.0	2.5	B							34						
22														36						
23														38						
24														40						
25	ARU-1/CO-2	3/4	2/12	15	12.0	1.3	A	0.5	4.2	20	3/12	3/4	EXISTING VALV	42						
26														44						
27														46						
28	SPARE													48						
29	SPARE													50						
30	SPARE													52						
31	SPARE													54						
32	SPARE													56						
33	SPARE													58						
34	SPARE													60						
35	SPARE													62						
36	SPARE													64						
37	SPARE													66						
38	SPARE													68						
39	SPARE													70						
40	SPARE													72						
41	SMOKE DAMPERS	3/4	3/12	20	7.0	0.2	A	0.8	7.7	20	3/12	3/4	SITE LIGHTING	74						
42														76						
TOTAL AMPS (CONN. LOAD)																				
TOTAL AMPS (FEEDTHRU)																				
TOTAL AMPS (CONN. LOAD + FEED-THRU)																				
PANELBOARD OPTIONS:																				
1. PROVIDE 100K RATED MCB.																				
PANELBOARD NOTES:																				
THIS PANEL IS ALSO 2LN11.																				

PANEL 1LN12 SCHEDULE													
225 AMP BUS		225 AMP MCB		208Y/120 VOLTS		3PH, 4W, 3N		MIN. 35 KAC		SURFACE MOUNTED			
CKT. NO.	LOAD DESCRIPTION	COND. SIZE	WIRE SIZE	BKR TRIP	AMPS	KVA	PH	AMPS	BKR TRIP	WIRE SIZE	COND. SIZE	LOAD DESCRIPTION	CKT. NO.
1	RECEPTACLES	3/4	3/12	20	3.3	0.4	A					SPARE	2
2	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	4
3	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	6
4	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	8
5	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	10
6	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	12
7	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	14
8	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	16
9	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	18
10	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	20
11	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	22
12	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	24
13	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	26
14	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	28
15	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	30
16	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	32
17	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	34
18	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	36
19	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	38
20	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	40
21	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	42
22	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	44
23	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	46
24	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	48
25	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	50
26	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	52
27	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	54
28	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	56
29	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	58
30	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	60
31	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	62
32	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	64
33	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	66
34	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	68
35	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	70
36	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	72
37	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	74
38	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	76
39	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	78
40	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	80
41	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	82
42	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	84
TOTAL AMPS (CONN. LOAD)													
TOTAL AMPS (FEEDTHRU)													
TOTAL AMPS (CONN. LOAD + FEED-THRU)													
PANELBOARD OPTIONS:													
THIS PANEL IS ALSO 2LN12.													
PANELBOARD NOTES:													
THIS PANEL IS ALSO 2LN12.													

PANEL 1LN13 SCHEDULE													
225 AMP BUS		225 AMP MCB		208Y/120 VOLTS		3PH, 4W, 3N		MIN. 10 KAC		FLUSH MOUNTED			
CKT. NO.	LOAD DESCRIPTION	COND. SIZE	WIRE SIZE	BKR TRIP	AMPS	KVA	PH	AMPS	BKR TRIP	COND. SIZE	WIRE SIZE	LOAD DESCRIPTION	CKT. NO.
1	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	2
2	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	4
3	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	6
4	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	8
5	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	10
6	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	12
7	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	14
8	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	16
9	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	18
10	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	20
11	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	22
12	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	24
13	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	26
14	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	28
15	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	30
16	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	32
17	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	34
18	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	36
19	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	38
20	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	40
21	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	42
22	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	44
23	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	46
24	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	48
25	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	50
26	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	52
27	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	54
28	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	56
29	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	58
30	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	60
31	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	62
32	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	64
33	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	66
34	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	68
35	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	70
36	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	72
37	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	74
38	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	76
39	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	78
40	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	80
41	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	82
42	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	84
43	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	86
44	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	88
45	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	90
46	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	92
47	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	94
48	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	96
49	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	98
50	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	100
51	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	102
52	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	104
53	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	106
54	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	108
55	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	110
56	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	112
57	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	114
58	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	116
59	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	118
60	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	120
61	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	122
62	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	124
63	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	126
64	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	128
65	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	130
66	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	132
67	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	134
68	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	136
69	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	138
70	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	140
71	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	142
72	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	144
73	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	146
74	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	148
75	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	150
76	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	152
77	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	154
78	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	156
79	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	158
80	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	160
81	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	162
82	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	164
83	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	166
84	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	168
85	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	170
86	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	172
87	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	174
88	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	176
89	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	178
90	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	180
91	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	182
92	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	184
93	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	186
94	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	188
95	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	190
96	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	192
97	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	194
98	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	196
99	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	198
100	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	200
101	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	202
102	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	204
103	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	206
104	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	208
105	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	210
106	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	212
107	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	214
108	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	216
109	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	218
110	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	220
111	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	222
112	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	224
113	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	226
114	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	228
115	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	230
116	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	232
117	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	234
118	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	236
119	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	238
120	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	240
121	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	242
122	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	244
123	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	246
124	RECEPTACLES	3/4	3/12	20	11.7	1.4	B					SPARE	248
125	RECEPTACLES	3/4	3/12	20	11.7	1.4	A					SPARE	250
126	RECEPTACLES	3/4	3/12	20	11.7	1.4							

