

SECTION 12 36 00

COUNTERTOPS

PART 1 - GENERAL

1.1 DESCRIPTION

- A. This section specifies casework countertops with integral accessories.
- B. Integral accessories include:
 - 1. Sinks with traps and drains.

1.2 RELATED WORK

- A. Color and patterns of plastic laminate: SECTION 09 06 00, SCHEDULE FOR FINISHES.
- B. DIVISION 22, PLUMBING.
- C. DIVISION 26, ELECTRICAL.
- D. Equipment Reference Manual for SECTION 12 36 00, COUNTERTOPS.

1.3 SUBMITTALS

- A. Submit in accordance with SECTION 01 33 23, SHOP DRAWINGS, PRODUCT DATA, AND SAMPLES.
- B. Shop Drawings
 - 1. Show dimensions of section and method of assembly.
 - 2. Show details of construction at 1/2 scale.
- C. Samples:
 - 1. 150 mm (6 inch) square samples each top.
 - 2. Front edge, back splash, end splash and core with surface material and booking.

1.4 APPLICABLE PUBLICATIONS

- A. Publications listed below form a part of this specification to the extent referenced. Publications are referenced in the text by the basic designation only.
- B. American Hardboard Association (AHA):
 - 1. A135.4-95 Basic Hardboard
- C. Composite Panel Association (CPA):
 - 1. A208.1-09 Particleboard
- D. American Society of Mechanical Engineers (ASME):
 - 1. A112.18.1-12 Plumbing Supply Fittings
 - 2. A112.1.2-12 Air Gaps in Plumbing System
 - 3. A112.19.3-08(R2004) Stainless Steel Plumbing Fixtures (Designed for Residential Use)

E. American Society for Testing and Materials (ASTM):

1. A167-99 (R2009) Stainless and Heat-Resisting Chromium-Nickel Steel Plate, Sheet and Strip
2. A1008-10 Steel, Sheet, Cold-Rolled, Carbon, Structural, High Strength, Low Alloy
3. D256-10 Pendulum Impact Resistance of Plastic
4. D570-98 (R2005) Water Absorption of Plastics
5. D638-10 Tensile Properties of Plastics
6. D785-08 Rockwell Hardness of Plastics and Electrical Insulating Materials
7. D790-10 Flexural Properties of Unreinforced and Reinforced Plastics and Electrical Insulating Materials
8. D4690-99 (2005) Urea-Formaldehyde Resin Adhesives

F. Federal Specifications (FS):

1. A-A-1936 Adhesive, Contact, Neoprene Rubber

G. U.S. Department of Commerce, Product Standards (PS):

1. PS 1-95 Construction and Industrial Plywood

H. National Electrical Manufacturers Association (NEMA):

1. LD 3-05 High Pressure Decorative Laminates

PART 2 - PRODUCTS

2.1 MATERIALS

A. Plastic Laminate: NEMA LD 3.

1. Concealed backing sheet Type BKL.
2. Decorative surfaces:
 - a. Flat components: Type GP-HGL.
3. Chemical Resistant Surfaces
 - a. Flat components: Type GP-HGL.
 - b. Resistance to reagents:
 - 1) Test with five 0.25 mil drops remaining on surface for 16 hours followed by washing off with tap water, then cleaned with liquid soap and water, dried with soft cotton cloth and then cleaned with naphtha.
 - 2) No change in color, surface texture, and original protectability remaining from test results of following reagents:

98% Acetic Acid	Butyl Alcohol	Acetone
90% Formic Acid--	Benzine	Chloroform
28% Ammonium Hydroxide	Xylene	Carbon
		Tetrachloride
Zinc Chloride (Sat.)	Toluene	Cresol

Sodium Carbonate (Sat.)	Gasoline	Ether
Calcium Hypochlorite (Sat.)	Kerosene	Cottonseed Oil
Sodium Chloride (Sat.)	Mineral Oil	40% Formaldehyde
Methyl Alcohol	Ethyl Acetate	Trichlorethylene
Ethyl Alcohol	Amyl Acetate	Monochlorobenzene

- 3) Superficial effects only: Slight color change, spot, or residue only with original protectability remaining from test results of following reagents:

77% Sulfuric Acid	37% Hydrochloric Acid	85% Phenol
33% Sulfuric Acid	20% Nitric Acid	Furfural
85% Phosphoric Acid	30% Nitric Acid	Dioxane

- 4) Minimum height of impact resistance: 300 mm (12 inches).

B. Molded Resin:

1. Non-glare epoxy resin or furan resin compounded and cured for minimum physical properties specified:

Flexural strength	70 MPa (10,000 psi)	ASTM D790
Rockwell hardness	105	ASTM D785
Water absorption, 14 hours (weight)	.01%	ASTM D570

2. Material of uniform mixture throughout.

C. Adhesive

1. For plastic laminate FS A-A-1936.
2. For Field Joints:
 - a. Epoxy type, resistant to chemicals as specified for plastic laminate laboratory surfaces.
 - b. Fungi resistant: ASTM G-21, rating of 0.

D. Solid Polymer Material:

1. Filled Methyl Methacrylic Polymer.
2. Performance properties required:

Property	Result	Test
Elongation	0.3% min.	ASTM D638
Hardness	90 Rockwell M	ASTM D785
Gloss (60° Gordon)	5-20	NEMA LD3.1
Color stability	No change	NEMA LD3 except 200 hour
Abrasion resistance	No loss of pattern Max wear depth 0.0762 mm (0.003 in) - 10000 cycles	NEMA LD3
Water absorption weight (5 max)	24 hours 0.9	ASTM D-570

Property	Result	Test
Izod impact	14 N·m/m (0.25 ft-lb/in)	ASTM D256 (Method A)
Impact resistance	No fracture	NEMA LD-3 900 mm (36") drop 1 kg (2 lb.) ball
Boiling water surface resistance	No visible change	NEMA LD3
High temperature resistance	Slight surface dulling	NEMA LD3

3. Cast into sheet form and bowl form.
4. Color throughout with subtle veining through thickness.
5. Joint adhesive and sealer: Manufacturers silicone adhesive and sealant for joining methyl methacrylic polymer sheet.
6. Bio-based products will be preferred.

2.2 SINKS

A. Molded Resin:

1. Cast or molded in one piece with interior corners 25 mm (one inch) minimum radius.
2. Minimum thickness of sides and ends 13 mm (1/2 inch), bottom 16 mm (5/8 inch).
3. Molded resin outlet for drain and standpipe overflow.
4. Provide clamping collar permitting connection to 38 mm (1-1/2 inch) or 50 mm (2 inch) waste outlet and trap, making sealed but not permanent connection.

B. Stainless Steel:

1. ANSI/ASME A112.19.3, Type 304.
2. Self-rim for plastic laminate or similar tops with concealed fasteners.
3. Flat rim for welded into stainless steel tops.
4. Ledge back or ledge sides with holes to receive required fixtures when mounted on countertop.
5. Apply fire resistant sound deadening material to underside.

C. Stainless steel circular or oval shaped bowl.

2.3 TRAPS AND FITTINGS

A. Material as specified in DIVISION 22, PLUMBING.

B. For Molded Resin Sinks:

1. Chemical resisting P-traps and fittings for chemical waste service.
2. Provide traps with cleanout plug easily removable without tools.

C. For Stainless Steel Sinks:

1. Either cast or wrought brass or stainless steel P-traps and drain fittings; ASME A112.18.1
2. Flat strainer, except where cup strainer or overflow standpipe specified.
 - a. Provide cup strainer in cabinet type 1B.
 - b. Provide stainless steel overflow stand pipe to within 38 mm (1-1/2 inches) of sink rim.
3. Exposed surface chromium plated finish.

2.4 WATER FAUCETS

A. ASME A112.18.1.

1. Cast or forged brass, compression type with replaceable seat and stem assembly or replaceable cartridge.
2. Indexed lever handles either with or without head.
3. Gooseneck minimum clearance above countertop of 190 mm (7-1/2 inches), bent 180 degrees for vertical discharge.
4. Swing spouts elevated to clear handles.
5. Exposed brass surfaces chromium plated.
6. Cast combination hot and cold fixture with one piece body for multiple outlets.
7. Adapter type connection which will permit field conversion of swing spouts to fixed or gooseneck grouts or vice versa.

B. Laminar flow control device on spouts.

C. Automatic Controlled Faucets.

1. Infra-red photocell sensor and a solenoid valve to control water flow automatically.
2. Breaking light beam activates water flow.
3. Water stops when user moves away from light beam.

D. Eye and Face Wash Unit Pull-Out-Type:

1. Deck mounted.
2. Designed for vandal resistant push-down control valve and 6 foot hose.
3. Eye and face wash head, provide a soft stream for flushing action.
4. Valve, when opened; remain open until manually closed.

E. Eye and Face Bath, Counter Mounted:

1. Stainless Steel circular or oval shaped self-rimmed sink, as shown on drawings.
2. Two fully enclosed rubber bound spray heads to provide an aerated flow of water simultaneously into both eyes and across face.
3. Push-pull hand operated valve.
4. Volume regulator for each spray.

2.5 FIXTURE IDENTIFICATION

- A. Code fixtures with full view plastic index buttons.
- B. Use following colors and codes:

SERVICE	COLOR	CODE	COLOR OF LETTERS
Cold Water	Dark Green	CW	White
Hot Water	Red	HW	White
Laboratory Air	Orange	AIR	Black
Fuel Gas	Dark Blue	GAS	White
Laboratory Vacuum	Yellow	VAC	Black
Distilled Water	White	DW	Black
Deionized Water	White	DI	Black
Oxygen	Light Green	OXY	White
Hydrogen	Pink	H	Black
Nitrogen	Gray	N	Black
All Other Gases	Light Blue	CHEM.SYM.	Black

2.6 ELECTRICAL RECEPTACLES

- A. Hospital grade per electrical specifications.
- B. Curb Mounted Receptacles:
 - 1. NEMA 5-20R duplex in galvanized steel box.
 - 2. Chromium plated brass or steel face plate.
- C. Pedestal Mounted Receptacles:
 - 1. NEMA 5-20R duplex installed in double faces.
 - 2. Polished stainless steel or aluminum, or chromium plated brass pedestal.

2.7 ELECTRIC DROP-IN HOTPLATE (RANGE) UNITS

- A. Built-in type units in stainless steel exposed surfaces.
- B. Basis of Design Bosch NITP666
- C. Service: 50 amp, 240 volt 3-wire
- D. Smooth flat cooking surfaces.

Metal sheath type heating units having removable heating elements and drip pans, protected terminals or lead wires with protected splices for connections and means for positive grounding.

- 1. No open seams or holes in metal sheath and made of material that will not scale or crack at temperatures reached in service.
- 2. Resistance wire: Uniformly spaced coil of nickel chromium alloy wire insulated from sheath by dense compaction of insulating material.
- 3. Terminals or lead wires suitable for rating of units.
- E. Heating Units:
 - 1. Double units rated not less than 2600 watts per unit.

Women's Wellness Center - Community Living Center
Martinsburg VA Medical Center
Martinsburg, WV

VA #613-115

HDG #12011

2. Not more than 200 mm (8 inches) in diameter.

3. Capable of bringing four quarts of cold water to boil in six minutes.
- F. Separate Control Unit:
 1. Suitably attached and prewired to range unit.
 2. Separate switch for each heating unit.
 - a. Commercial quality, rotatable in either direction through 360 degrees.
 - b. At least three heat levels.
 3. Operating dials for switches clearly marked to indicate control positions and easily visible in ordinary light.
 4. Control unit front removable.
- G. Indicating light assembly
 1. Mounted on the Control Unit Front.
 2. Red lens and high brightness neon glow type lamp with resistor suitably for 25,000 hours average life.
- H. Fuses and Circuit Breakers:
 1. Easily accessible from front of cabinet.
 2. Do not locate at back of storage or where articles can be stored in the front.
- I. Range and Control Units Concealed Surfaces:
 1. Made of materials suitable for the intended use.
 2. Low carbon steel galvanized or other suitable corrosion resistant finish.
 3. Provide a solid 1.5 mm (0.0598 inch) thick sheet steel barrier below the unit, located a minimum of nine inches below the unit top.

2.8 COUNTERTOPS

- A. Fabricate in largest sections practicable.
- B. Fabricate with joints flush on top surface.
- C. Fabricate countertops to overhang front of cabinets and end of assemblies 25 mm (one inch) except where against walls or cabinets.
- D. Provide 1 mm (0.039 inch) thick metal plate connectors or fastening devices (except epoxy resin tops).
- E. Join edges in a chemical resistant waterproof cement or epoxy cement, except weld metal tops.
- F. Fabricate with end splashes where against walls or cabinets.
- G. Splash Backs and End Splashes:
 1. Not less than 19 mm (3/4 inch) thick.
 2. Height 100 mm (4 inches) unless noted otherwise.
 3. Laboratories and pharmacy heights or where fixtures or outlets occur: Not less than 150 mm (6 inches) unless noted otherwise.

4. Fabricate epoxy splash back in maximum lengths practical of the same material.
- H. Drill or cutout for sinks, and penetrations.
 1. Accurately cut for size of penetration.
 2. Cutout for VL 81 photographic enlarger cabinet.
 - a. Finish cutout to fit flush with vertical side of cabinet, allowing adjustable shelf to fit into cutout space of cabinet at counter top level. Finish cutout surface as an exposed edge.
 - b. Provide braces under enlarger space to support not less than 45 kg (100 pounds) centered on opening side along backsplash.
- I. Plastic Laminate Countertops:
 1. Fabricate plastic laminate on five-ply plywood or particleboard core 19 mm (3/4 inch) thick with plastic laminate backing sheet.
 2. Front edge over cabinets not less than 38 mm (1-1/2 inches) thick except where plastic "T" insert is used, not less than 19 mm (3/4 inch) thick.
 3. Exposed Surface and edges of decorative laminated plastic or laboratory chemical resistant surface.
 - a. Use chemical resistant surface on tops 6A, 6B, and 6C.
 - b. Use decorative surface tops when noted plastic laminate, for tops 10A, 10B and 10C.
- J. Molded Resin Tops:
 1. Molded resin with drip groove cut on underside of overhanging edge.
 2. Finish thickness of top minimum 25 mm (1 inch).
 3. Joints: Epoxy Type.
 4. Secure reagent shelves to counter tops with fasteners from underside and seal seam.

PART 3 - EXECUTION

3.1 INSTALLATION

- A. Before installing countertops verify that wall surfaces have been finished as specified and that mechanical and electrical service locations are as required.
- B. Secure countertops to supporting rails of cabinets with metal fastening devices, or screws through pierced slots in rails.
 1. Where type, size or spacing of fastenings is not shown or specified, submit shop drawings showing proposed fastenings and method of installation.
 2. Use round head bolts or screws.

3. Use epoxy or silicone to fasten the epoxy resin countertops to the cabinets.
 4. Use wood or sheet metal screws for wood or plastic laminate tops; minimum penetration into top 16 mm (5/8 inch), screw size No 8, or 10.
- C. Rubber Moldings:
- D. Where shown install molding with butt joints in horizontal runs and mitered joints at corners where ceramic tile occurs omit molding.
1. Fasten molding to wall and to splash backs and splash ends with adhesive.
- E. Sinks
1. Install stainless steel sink in plastic laminate tops with epoxy compound to form watertight seal under shelf rim.
 - a. In laboratory and pharmacy fit stainless steel sink with overflow standpipe.
 - b. Install faucets and fittings on sink ledges with watertight seals where shown.
 2. Install molded resin sinks with epoxy compound to form watertight seal with underside of molded resin top.
 - a. Install sink with not less than two channel supports with threaded rods and nuts at each end, expansion bolted to molded resin top.
 - b. Design support for a twice the full sink weight.
 - c. Install with overflow standpipes.
 3. Install methyl methacrylic polymer sinks in manufacturer's recommended adhesive sealer or epoxy compound to underside of methyl methacrylic polymer countertop.
 - a. Bolt or screw to countertop to prevent separation of bowl and fracture of adhesive sealant joint.
 - b. Install drain and traps to sink.
- F. Faucets, Fixtures, and Outlets:
1. Seal opening between fixture and top.
 2. Secure to top with manufacturers standard fittings.
- G. Range Tops, Electrical Outlets, Film Viewer:
1. Set in cutouts with manufacturer's gasket sealing joint with top to prevent water leakage.
 2. Install control unit and electric outlets where shown. Seal escutcheon plate at lap if on counter or top to prevent water leakage.

3.2 PROTECTION AND CLEANING

- A. Tightly cover and protect against dirt, water, and chemical or mechanical injury.
- B. Clean at completion of work.

Women's Wellness Center - Community Living Center
Martinsburg VA Medical Center
Martinsburg, WV

VA #613-115

HDG #12011

- - - E N D - - -