


# FULLY SPRINKLERED

## GENERAL SIGNAGE NOTES

- A. Verify all conditions prior to fabrication, erection, and installation.
- B. Install room identification signs on knob side of door and 2" over from door frame.
- C. All tactile room number and room identification signs are required to meet ABA/ADA requirements for height and Braille text.
- D. Building plan for evacuation map will be furnished by the project COR.
- E. Sign text and copy is to be provided by the project COR.
- F. See Specifications for sign types and details.
- G. Provide finished backer on all signs that are installed on glass.
- H. Refer to IF200-S series for signage details.




**NINTH FLOOR SIGNAGE PLAN**  
Scale: 1/8" = 1'-0"



three inches = one foot  
 one and one-half inches = one foot  
 one inch = one foot  
 three-quarters inch = one foot  
 one-half inch = one foot  
 three-eighths inch = one foot  
 one-quarter inch = one foot  
 one-eighth inch = one foot

Revisions	Date
1 Bid Set Drawings	05.16.2016

CONSULTANTS:



ARCHITECT/ENGINEERS:  
**JOHN POE ARCHITECTS**  
3131 NEWMARK DRIVE, SUITE 200  
MIAMISBURG, OHIO 45342  
937 461 3290 PHONE  
jpa@johnpoe.com

Drawing Title  
**NINTH FLOOR SIGNAGE PLAN**  
Approved: Project Director

Project Title  
**RELOCATE PROSTHETICS AND PODIATRY CLINICS**  
Location  
**Dayton, Ohio**  
Date  
**05.16.2016**  
Approved  
**Approver**  
Drawn  
**Designer**

Project No. 552-15-502  
VA Project No. 14006.00  
Building Number  
**330**  
Drawing Number  
**330IF109-S**  
Dwg. of XX







# FULLY SPRINKLERED

## GENERAL SIGNAGE NOTES

- A. Verify all conditions prior to fabrication, erection, and installation.
- B. Install room identification signs on knob side of door and 2" over from door frame.
- C. All tactile room number and room identification signs are required to meet ABA/ADA requirements for height and Braille text.
- D. Building plan for evacuation map will be furnished by the project COR.
- E. Sign text and copy is to be provided by the project COR.
- F. See Specifications for sign types and details.
- G. Provide finished backer on all signs that are installed on glass.
- H. Refer to IF200-S series for signage details.

## ○ SIGNAGE NOTES

- 10.20 Plastic laminate face material.
- 10.21 Acrylic resin backer material.
- 10.22 3/4" helvetica bold raised text.
- 10.23 1 1/4" helvetica bold raised text.
- 10.24 Metal accent bar.
- 10.25 Paper insert.
- 10.26 3/8" radius corners.
- 10.27 Fire red B/G white arial copy and graphic.
- 10.28 Red plastic face.
- 10.29 Cable wires mounting system.
- 10.31 3" helvetica bold raised text.




Signage Details  
Scale: N.T.S.

1 Bid Set Drawings 05.16.2016 Revisions Date	CONSULTANTS:		ARCHITECT/ENGINEERS:	Drawing Title	Project Title	Project No.
			JOHN A. POE ARCHITECTS 3131 NEWMARK DRIVE, SUITE 200 MIAMISBURG, OHIO 45342 937.461.3290 PHONE jpa@johnpoe.com	NINTH FLOOR SIGNAGE DETAILS	RELOCATE PROSTHETICS AND PODIATRY CLINICS	VA Project No. 552-15-502 JPA Project No. 14006.00
				Approved: Project Director	Location	Building Number
					Dayton, Ohio	330
					Date	Drawing Number
					05.16.2016	330IF209-S
					Prepared	Dwg. of XX
					Approver	
					Designer	


Office of Construction and Facilities Management  
Department of Veterans Affairs




# FULLY SPRINKLERED




**4 FLOW CONTROLLER ASSEMBLY**  
SCALE: 1/8" = 1'-0"



**1 P103 WATER CLOSET**  
SCALE: 1/2" = 1'-0"



**2 P418 WALL HUNG LAVATORY**  
SCALE: 1/2" = 1'-0"



**3 RETRACTABLE AIR HOSE REEL - M1**  
SCALE: 1/8" = 1'-0"

Revisions	Date
1	03.05.2015
2	04.28.2015
3	08.14.2015
4	11.04.2015
5	01.15.2016

CONSULTANTS:

**Heapy Engineering**  
MEP Design Technology Planning Commissioning Energy  
*Nationally Recognized Leader in Sustainability*  
1400 W Dorothy Lane, Dayton, OH 45409-1310  
Ph 937-224-0861 Fax 937-224-5777 www.heapy.com  
Heapy Project No.: 2014-04034 Firm License No.: Q1528



ARCHITECT/ENGINEERS:

JOHN POE ARCHITECTS

3131 NEWMARK DRIVE, SUITE 200 MIAMISBURG, OHIO 45342  
937.461.3290 PHONE jpa@johnpoe.com

Drawing Title

DETAILS

Approved: Project Director

Project Title

RELOCATE PROSTHETICS AND PODIATRY CLINICS

Location

Dayton, Ohio

Date

05.16.2016

Checked

CSS

Drawn

DPB

Project No.

VA Project No. 552-15-502  
JPA Project No. 14006.00

Building Number

999

Drawing Number

P501

Dwg. of

Office of Construction and Facilities Management



5/13/2016 12:10:28 PM

SYMBOL	MOUNTING HEIGHT	DESCRIPTION	FLOW		FIXTURE UNITS WATER			SUPPLY				WASTE & VENT				REMARKS
			GPM	GPF	DRAINS	COLD	HOT	COLD	HOT	TEPID	OUTLET	VENT	DIRECT	INDIRECT		
P103	NOTE 1	WATER CLOSET/ WALL HUNG/ ELONGATED BOWL/ ADA	1.28		4	5			1"			4"	2"	•	BATTERY POWERED/ SENSOR OPERATED	
P201	NOTE 1	URINAL/ WALL HUNG/ ADA	.5		4	4	0	0.75"				2"	1.5"	•	BATTERY POWERED/ SENSOR OPERATED	
P418	34" TO RIM	LAVATORY/ WALL HUNG/ 20"x18" ADA/ NON-AERATED FLOW	0.5		1	0.6	0.6	0.5"	0.5"			1.5"	1.5"	•	SENSOR OPERATED/ GOOSENECK SPOUT/ LAV SHIELD	
P419	C/TOP SOLID SURFACE	LAVATORY/ BY G.C./ ADA/ NON-AERATED FLOW	0.5		1	0.6	0.6	0.5"	0.5"			1.25"	1.5"	•	SENSOR OPERATED/ GOOSENECK SPOUT/ ADA COVERS	
P420		LAVATORY/ SOLID SURFACE BY G.C. / ADA			1	1.5	1.5	0.5"	0.5"			1.25"	1.5"	•	LAVATORY AND FAUCET PROVIDED BY G.C.	
P502	FLOOR SET	MOP SINK/ 24"x24"x12"/ 6" DROP FRONT TERRAZZO			3	2.25	2.25	0.5"	0.5"			3"	1.5"	•	PAIL HOOK FAUCET/ VACUUM BREAKER/ CROSS HANDLES	
P505	30" TO RIM	CLINIC SERVICE SINK/ WALL HUNG/ BEDPAN WASHER			3	5	2.25	1"	0.5"			4"	2"	•	ELBOW BLADE HANDLES/ FOOT CONTROL/ RIM GUARD	
P525	C/TOP	SINK/ SS/ SINGLE COMPT	1.5		1	0.5	0.5	0.5"	0.5"			1.5"	1.5"	•	GOOSENECK SPOUT	
P528	C/TOP	SINK/ SS/ SINGLE COMPT	1.5		2	3	3	0.5"	0.5"			1.5"	1.5"	•	GOOSENECK SPOUT	
P608	36" TO SPOUT	WATER COOLER/ DRINKING FOUNTAIN/ ADA			0.5	0.5	0	0.5"				1.25"	1.5"	•	WALL MOUNTED	
P609	36" TO LOW SPOUT	WATER COOLER/ DRINKING FOUNTAIN/ DUAL HEIGHT/ ADA			0.5	0.5	0	0.5"				1.5"	1.5"	•	WALL MOUNTED	
P701	44" TO VALVE	SHOWER UNIT/ VALVE AND HEAD ASSEMBLY/ ADA	1.85		2	1.5	1.5	0.5"	0.5"			2"	1.5"	•		
P706	NOTE 2	EMERGENCY SHOWER/ EYE/ FACE WASH/ FREE-STANDING			1	6	6					1.25"	1.5"	•	EMERGENCY EQUIP./ TEPID WATER TO FIXTURE	
P811	48" TO CL	WATER SUPPLY BOX			0	0.5	0	0.75"							PROVIDE FLEXIBLE CONNECTOR TO EQUIPMENT	

PLUMBING FIXTURE NOTES:  
 1. REFER TO ARCHITECTURAL ELEVATIONS AND SPECIFICATION SECTION 22 40 00 FOR MOUNTING HEIGHTS.  
 2. REFER TO SPECIFICATIONS.

SYMBOL	DESCRIPTION	BODY				STRAINER / GRATE				TOP FINISH						
		C.I.	S.S.	C.R.	BRASS	RD.	SQ.	ADJUST.	FLAT	RECESS	DOME	NICKLE BRONZE	C.I.	C.R.	S.S.	
FD2	3" MEDIUM DUTY/ DOUBLE DRAINAGE/ VANDAL RESISTANT/ (TYPE G) TRAP PRIMER CONNECTION			•												

**LAB EQUIPMENT**

GENERAL NOTES:  
 A. PROVIDE ROUGH-IN.  
 B. INSTALL ALL "LOOSE" COMPONENTS.  
 C. PROVIDE ALL NECESSARY SUPPLIES, STOPS, TRAPS, FIX. DRAINS, CONTINUOUS WASTE, & ALL INDIRECT WASTE.  
 D. MAKE ALL FINAL CONNECTIONS TO EXISTING/RELOCATED EQUIPMENT. FINAL CONNECTIONS TO NEW EQUIPMENT SHALL BE BY THE EQUIPMENT SUPPLIER.  
 E. SUPPLIES SHALL BE AS LISTED. TERMINAL OUTLETS ON EQUIPMENT MAY BE SMALLER AND REDUCER FITTING REQUIRED.

NOTES:  
 1. REFER TO FLOOR PLAN FOR INFORMATION REGARDING NATURAL GAS, LAB AIR, AND LAB VACUUM CONNECTIONS AT L1 LOCATIONS.


MARK	DESCRIPTION	SUPPLY										WASTE & VENT					WASTE SYS.					
		C. W.	H. W.	MEDICAL AIR	MEDICAL VACUUM	OXYGEN	NITROGEN	NITROUS OXIDE	CARBON DIOXIDE	NATURAL GAS	GAS EVACUATION	PURE WATER (DEFINE CLASS)	FX. OUTLET	TRAP	FX. DRAIN	WASTE MIN.	VENT MIN.	INDIRECT	AIRGAP	AIRBREAK	SANITARY	LAB WASTE
L1		0.5"	0.5"									1.5"	1.5"	1.5"	1.5"	1.5"					•	#1

Revisions	Date
1	03.05.2015
2	04.28.2015
3	08.14.2015
4	11.04.2015
5	01.15.2016

CONSULTANTS:



**Heapy Engineering**  
 MEP Design Technology Planning Commissioning Energy  
*Nationally Recognized Leader in Sustainability*  
 1400 W Dorothy Lane, Dayton, OH 45409-1310  
 Ph 937-224-0861 Fax 937-224-5777 www.heapy.com  
 Heapy Project No.: 2014-04034 Firm License No.: Q1528



ARCHITECT/ENGINEERS:

JOHN POE ARCHITECTS



3131 NEWMARK DRIVE, SUITE 200  
 MIAMISBURG, OHIO 45342  
 937.461.3290 PHONE  
 jpa@johnpoe.com

Drawing Title

**SCHEDULES**

Approved: Project Director

Project Title

**RELOCATE PROSTHETICS AND PODIATRY CLINICS**

Location **Dayton, Ohio**

Date **05.16.2016** Checked **CSS** Drawn **DPB**

Project No. VA Project No. **552-15-902** JPA Project No. **14006.00**  
 Building Number **999**  
 Drawing Number **P601**  
 Dwg. of

Office of Construction and Facilities Management



Department of Veterans Affairs

three inches = one foot  
 one and one-half inches = one foot  
 one inch = one foot  
 three-quarters inch = one foot  
 one-half inch = one foot  
 three-eighths inch = one foot  
 one-quarter inch = one foot  
 one-eighth inch = one foot

A  
 B  
 C  
 D  
 E  
 F

5/13/2016 12:10:30 PM


# FULLY SPRINKLERED

## GENERAL NOTES

A REFER TO SHEET P001 FOR LEGEND, SYMBOLS & INDEX OF DRAWINGS.


## PLAN NOTES

- EXISTING TO REMAIN.
- MODIFY EXISTING SANITARY WASTE AND VENT PIPING TO ACCOMMODATE REPLACEMENT OF LAB SINK.



## BUILDING 315 SOIL, WASTE & VENT

Scale: N.T.S.



## KEY PLAN

Scale: N.T.S.


5/13/2016 12:10:37 PM

Revisions	Date	Description
1	03.05.2015	35% Schematic Design
2	04.28.2015	65% Design Development
3	08.14.2015	95% Owner Review
4	11.04.2015	100% Construction Documents
5	01.15.2016	Bid Set Drawings

CONSULTANTS:



**Heapy Engineering**  
MEP Design Technology Planning Commissioning Energy  
*Nationally Recognized Leader in Sustainability*  
1400 W Dorothy Lane, Dayton, OH 45409-1310  
Ph 937-224-0861 Fax 937-224-5777 www.heapy.com  
Heapy Project No.: 2014-04034 Firm License No.: Q1528



ARCHITECT/ENGINEERS:

JOHN POE ARCHITECTS



3131 NEWMARK DRIVE,  
SUITE 200  
MIAMISBURG, OHIO 45342  
937.461.3290 PHONE  
jpae@johnpoe.com

Drawing Title

**SOIL, WASTE & VENT**

Approved: Project Director

Project Title

**RELOCATE PROSTHETICS AND PODIATRY CLINICS**

Location

**Dayton, Ohio**

Date

05.16.2016

Checked

CSS

Drawn

DPB

Project No. 552-15-902  
VA Project No. 14006.00  
JPA Project No. 14006.00  
Building Number 999  
Drawing Number P901  
Dwg. of

Office of  
Construction  
and Facilities  
Management

Department of  
Veterans Affairs


# FULLY SPRINKLERED

## GENERAL NOTES

A REFER TO SHEET P001 FOR LEGEND, SYMBOLS & INDEX OF DRAWINGS.


## PLAN NOTES

1 EXISTING TO REMAIN.



**BUILDING 330 SOIL, WASTE & VENT**

Scale: N.T.S.



**KEY PLAN**

Scale: N.T.S.


5/13/2016 12:10:44 PM

Revisions	Date
1	03.05.2015
2	04.28.2015
3	08.14.2015
4	11.04.2015
5	01.15.2016

**CONSULTANTS:**



**Heapy Engineering**  
MEP Design Technology Planning Commissioning Energy  
*Nationally Recognized Leader in Sustainability*  
1400 W Dorothy Lane, Dayton, OH 45409-1310  
Ph 937-224-0861 Fax 937-224-5777 www.heapy.com  
Heapy Project No.: 2014-04034 Firm License No.: Q1528



**ARCHITECT/ENGINEERS:**

**JOHN POE ARCHITECTS**



3131 NEWMARK DRIVE,  
SUITE 200  
MIAMISBURG, OHIO 45342  
937 461 3290 PHONE  
jpa@johnpoe.com

Drawing Title

**SOIL, WASTE & VENT**

Approved: Project Director

Project Title

**RELOCATE PROSTHETICS  
AND PODIATRY CLINICS**


Location **Dayton, Ohio**

Date **05.16.2016** Checked **CSS** Drawn **DPB**


Project No. **552-15-902**  
VA Project No. **14006.00**  
Building Number **999**  
Drawing Number **P902**  
Dwg. of

**Office of  
Construction  
and Facilities  
Management**


 **Department of  
Veterans Affairs**



- NOTES:**
- RIGID STRAIGHT TERMINAL UNIT INLET LENGTH SHALL BE A MINIMUM OF 3 TIMES THE DIAMETER OF INLET SO AS TO ACHIEVE ACCURATE AIRFLOW SENSOR READINGS.
  - A FLEXIBLE AIR DUCT CONNECTOR IS NOT MANDATORY FOR INLET TO THIS BOX, BUT ALLOWED TO ACCOMMODATE MINOR OFFSETS. MAXIMUM LENGTH 3'-0".
  - PROVIDE DUCT TRANSITION WHERE SCHEDULED DUCT RUNOUT SIZE TO UNIT IS DIFFERENT THAN TERMINAL UNIT INLET SIZE.
  - FLEXIBLE AIR DUCT CONNECTORS, WHEN USED FROM TERMINAL UNIT SUPPLY AIR DUCT TO DIFFUSER, SHALL NOT EXCEED 5'-0". USE RIGID ELBOWS FOR CHANGE OF DIRECTION GREATER THAN 45°.
  - COMPONENT ARRANGEMENT MAY VARY BY MANUFACTURER. PROVIDE INSULATION W/VAPOR BARRIER FOR CONNECTING DUCT SECTIONS.
  - PROVIDE SOUND ATTENUATOR. PROVIDE DUCT TRANSITION BETWEEN TERMINAL UNIT AND SOUND ATTENUATOR WHERE ATTENUATOR SIZE DIFFERS FROM TERMINAL UNIT OUTLET SIZE.
  - DUCT RUNOUT TO DIFFUSERS SHALL BE SAME SIZE AS THE DIFFUSER NECK SIZE UNLESS OTHERWISE NOTED.




- NOTES:**
- RIGID STRAIGHT TERMINAL UNIT INLET LENGTH SHALL BE A MINIMUM OF 3 TIMES THE DIAMETER OF INLET SO AS TO ACHIEVE ACCURATE AIRFLOW SENSOR READINGS.
  - A FLEXIBLE AIR DUCT CONNECTOR IS NOT MANDATORY FOR INLET TO THIS BOX, BUT ALLOWED TO ACCOMMODATE MINOR OFFSETS. MAXIMUM LENGTH 3'-0".
  - PROVIDE DUCT TRANSITION WHERE SCHEDULED DUCT RUNOUT SIZE TO UNIT IS DIFFERENT THAN TERMINAL UNIT INLET SIZE.
  - FLEXIBLE AIR DUCT CONNECTORS, WHEN USED FROM TERMINAL UNIT SUPPLY AIR DUCT TO DIFFUSER, SHALL NOT EXCEED 5'-0". USE RIGID ELBOWS FOR CHANGE OF DIRECTION GREATER THAN 45°.
  - COMPONENT ARRANGEMENT MAY VARY BY MANUFACTURER. PROVIDE INSULATION W/VAPOR BARRIER FOR CONNECTING DUCT SECTIONS.
  - PROVIDE SOUND ATTENUATOR IF REQUIRED TO MEET DESIGN ROOM NC. PROVIDE DUCT TRANSITION BETWEEN TERMINAL UNIT AND SOUND ATTENUATOR WHERE ATTENUATOR SIZE DIFFERS FROM TERMINAL UNIT OUTLET SIZE.
  - DUCT RUNOUT TO DIFFUSERS SHALL BE SAME SIZE AS THE DIFFUSER NECK SIZE UNLESS OTHERWISE NOTED.




- NOTES:**
- THE INTERIOR SURFACE OF ALL RADIUS ELBOWS SHALL BE MADE ROUND.
  - ALL STANDARD RADIUS ELBOWS CAN BE SUBSTITUTED WITH SHORT RADIUS ELBOWS. ALL SHORT RADIUS ELBOWS SHALL HAVE VANES. VANES SHALL BE CONSTRUCTED, SUPPORTED AND FASTENED AS RECOMMENDED BY SMACNA.


**DUCTWORK RADIUS ELBOWS**



**DUCTWORK SQUARE VANE ELBOWS**





**EXHAUST OR RETURN BRANCH DUCTWORK**



THE BRANCH DUCT TAKE-OFF MAY BE USED FOR UP TO 15% OF THE MAIN DUCT CFM ANYTIME. AND UP TO 40% WHEN THE MAIN DUCT VELOCITY IS 1000 FPM OR LESS. THE AIR SPLIT DUCT TAKE-OFF SHALL BE USED IN ALL OTHER CASES.

**SUPPLY DUCTWORK TAKE-OFFS**



**DUCT CONNECTIONS-AIR TERMINAL UNITS**



- NOTES:**
- LATCHES SHALL BE OF THE WEDGE TYPE TO CLOSE DOORS TIGHTLY.
  - HINGES ON THE ACCESS DOORS SHALL HAVE NON-CORROSIVE PINS.
  - SEE SMACNA 2005, FIGURE 9-15

**ACCESS PANEL AND DOOR DETAIL**


**DUCT CONNECTIONS-AIR TERMINAL UNITS**




- NOTES:**
- DELETE INSULATION STAND-OFF ON DUCTWORK WITHOUT EXTERIOR INSULATION.
  - DETAIL SHOWS SINGLE BLADE DAMPER. DAMPER INSTALLATION SHALL BE SIMILAR FOR MULTI-BLADE DAMPERS & ROUND DAMPERS.

**VOLUME DAMPER DETAIL**

**SUPPLY DUCT TAKEOFF - AIR TERMINAL UNITS**




**ALTERNATE SUPPLY DUCT TAKEOFF - AIR TERMINAL UNITS**



NOTE: UNLESS OTHERWISE INDICATED ON PLANS, MAXIMUM ANGLES SHOWN SHALL APPLY.

**DUCTWORK TRANSITIONS**

**RETURN OR EXHAUST GRILLE/REGISTER CONNECTION**



- NOTES:**
- BRANCH DUCT TAKE-OFF WITH MANUAL DAMPER.
  - BRANCH DUCT SIZES, UNLESS NOTED ON PLANS ARE TO BE SIZED AS FOLLOWS:  
100 CFM AND LESS - 6" DIA.  
101 CFM TO 250 CFM - 8" DIA.  
251 CFM TO 400 CFM - 10" DIA.  
401 CFM TO 700 CFM - 12" DIA.


three inches = one foot  
one and one-half inches = one foot  
one inch = one foot  
three-quarters inch = one foot  
one-half inch = one foot  
three-eighths inch = one foot  
one-quarter inch = one foot  
one-eighth inch = one foot

5/13/2016 11:59:43 AM

Revisions	Date
1	35% Schematic Design 03.05.2015
2	65% Design Development 04.28.2015
3	95% Owner Review 08.14.2015
4	100% Construction Documents 11.04.2015
5	Bid Set Drawings 01.15.2016

**CONSULTANTS:**

**Heapy Engineering**  
MEP Design Technology Planning Commissioning Energy  
Nationally Recognized Leader in Sustainability  
1400 W Dorothy Lane, Dayton, OH 45409-1310  
Ph 937-224-0861 Fax 937-224-5777 www.heapy.com  
Heapy Project No.: 2014-04034 Firm License No.: Q1528



**ARCHITECT/ENGINEERS:**

**JOHN POE ARCHITECTS**  
3131 NEWMARK DRIVE, SUITE 202  
MIAMISBURG, OHIO 45342  
937-461-3290 PHONE  
jpae@johnpoe.com

Drawing Title: **DETAILS**

Approved: Project Director

Project Title: **RELOCATE PROSTHETICS AND PODIATRY CLINICS**

Location: **Dayton, Ohio**

Date: 05.16.2016 Checked: PCW Drawn: WJS


Project No. 552-15-902  
VA Project No. 14006.00  
Building Number 999  
Drawing Number M501  
Dwg. of

**Office of Construction and Facilities Management**  
Department of Veterans Affairs

# FULLY SPRINKLERED

## NOTES


1. PIPE REDUCER IF HEATING ELEMENT CONNECTION SIZE DIFFERS FROM PIPE SIZE. PROVIDE FULL TRIM ACCESSORIES FOR FINISHED APPEARANCE
2. WALL HUNG.
3. AUTOMATIC TWO PORT CONTROL VALVE. REFER TO EQUIPMENT SCHEDULE FOR SIZE.
4. PROVIDE COPPER FLEX CONNECTORS BETWEEN PANELS AND OFFSET FROM BACK OUTLET OF ONE PANEL TO FRONT INLET OF NEXT PANEL.




**MULTIPLE UNITS ON ONE RISER ARCHITECTURAL RADIATORS**

## NOTES

1. PIPE REDUCER IF HEATING ELEMENT CONNECTION SIZE DIFFERS FROM PIPE SIZE. PROVIDE FULL TRIM ACCESSORIES FOR FINISHED APPEARANCE
2. WALL HUNG.
3. AUTOMATIC TWO PORT CONTROL VALVE. REFER TO EQUIPMENT SCHEDULE FOR SIZE.




**INDIVIDUAL UNIT ARCHITECTURAL RADIATORS**




**SUPPORT FOR PIPE RISERS**

PIPE ANCHOR SCHEDULE										BOLT PATTERN
D	P	C	N	S						
IN	MM	IN	MM	IN	MM	IN	MM	IN	MM	
4"	102	3/8"	16	3/4"	19	4"	102	3/8"	19	[Pattern]
3"	76	1/2"	13	1/2"	13	4"	102	5/8"	16	[Pattern]
2 1/2"	64	3/8"	10	3/8"	10	4"	102	5/8"	16	[Pattern]
2"	51	3/8"	10	3/8"	10	4"	102	5/8"	16	[Pattern]
1 1/2"	38	3/8"	10	1/2"	6	4"	102	1/2"	13	[Pattern]




**SMALL PIPE ANCHOR 1 1/2" - 4"**



**TYPICAL CHILLED AND HOT WATER PIPING DRAIN VALVE CONNECTIONS**

## NOTES:

1. DRAIN ALL LOW POINTS AS INDICATED ABOVE.
2. WHERE SCALE POCKETS ARE SHOWN ON PIPE RISER DIAGRAMS AND/OR PLANS, LOCATE DRAIN AT BOTTOM OF SCALE POCKET.




**TYPICAL MANUAL AIR VENT**


## NOTES:

1. VENT ALL HIGH POINTS AS INDICATED ABOVE.
2. IF AUTOMATIC AIR VENTS ARE USED, PIPE DISCHARGE TO NEAREST DRAIN.

**DRAIN VALVE AND AIR VENT CONNECTIONS (HYDRONIC SYSTEMS)**



**ADJUSTABLE CLEVIS HANGER TYPE 1 - SEE SPECIFICATIONS**  
**ADJUSTABLE CLEVIS HANGER TYPE 43 - SEE SPECIFICATIONS**




NOTE: SEE SPECIFICATIONS FOR DETAILED HANGER REQUIREMENTS

MAXIMUM PIPE/TUBING SUPPORT SPACING																			
NOM. SIZE	IN.	THRU 3/4"	1	1 1/4"	1 1/2"	2	2 1/2"	3	4	5	6	8	10	12	14	16	18	20	24
PIPE	FT.	7	7	7	9	10	11	12	14	16	17	19	22	23	25	27	28	30	32
TUBING	FT.	5 FT	6	7	8	8	9	10	12	13	14	16	-	-	-	-	-	-	-

NOTE: FOR TRAPEZE HANGER TAKE SPACING OF SMALLEST SIZE ON TRAPEZE.


**PIPE HANGERS**




## NOTES:

1. SLOPE MAINS AND BRANCHES DOWN 1" PER 40 FEET IN DIRECTION OF FLOW UNLESS SHOWN OTHERWISE.
2. LIMIT UNTRAPPED, COUNTERFLOW, RUNOUTS TO 10 FEET MAXIMUM.
3. END OF MAIN SHOWN, LOW POINT IN STEAM MAIN SIMILAR.


**TYPICAL STEAM LINE & DRIP PIPING**



**STEAM LINE DRIP POCKET**



**STEAM LINE DRIP POCKET STEAM TRAP ASSEMBLY**



\* REFER TO SCHEDULES ON SHEETS M601 FOR VALVE TYPE (2-WAY OR 3-WAY)

**TERMINAL UNIT WATER COILS - PIPING CONNECTIONS**

5/13/2016 11:59:44 AM

Revisions	Date
1	35% Schematic Design 03.05.2015
2	65% Design Development 04.28.2015
3	95% Owner Review 08.14.2015
4	100% Construction Documents 11.04.2015
5	Bid Set Drawings 01.15.2016

## CONSULTANTS:

**Heapy Engineering**  
MEP Design Technology Planning Commissioning Energy  
*Nationally Recognized Leader in Sustainability*  
1400 W Dorothy Lane, Dayton, OH 45409-1310  
Ph 937-224-0861 Fax 937-224-5777 www.heapy.com  
Heapy Project No.: 2014-04034 Firm License No.: Q1528



## ARCHITECT/ENGINEERS:

JOHN POE ARCHITECTS

3131 NEWMARK DRIVE, SUITE 200 MIAMISBURG, OHIO 45342  
937-461-3290 PHONE jpa@johnpoe.com

## Drawing Title

DETAILS

Approved: Project Director

## Project Title

RELOCATE PROSTHETICS AND PODIATRY CLINICS

## Location

Dayton, Ohio

## Date

05.16.2016

## Checked

PCW

## Drawn

WJS

## Project No.

VA Project No. 552-15-902  
JPA Project No. 14006.00

## Building Number

999


## Drawing Number

M502

## Dwg. of


Office of Construction and Facilities Management





- NOTES:**
1. SECURE CURB CAP TO WOOD NAILING STRIP WITH 3/8" CADIUM PLATED LAG BOLTS NOT OVER 12" ON CENTER.
  2. SECURE ROOF CURB, DUCTWORK AND DAMPER TO ROOF WITH EXPANSION BOLTS (CONCRETE ROOF) OR RUST RESISTANT BOLTS (METAL DECK AND BAR JOIST ROOF).
  3. SIZE OF DUCT THROUGH ROOF SHALL NOT BE LARGER THAN CURB SUPPLIED WITH ROOF VENTILATOR.
  4. RUN ELECTRICAL LINES THROUGH CLEARANCE HOLE PROVIDED IN GRAVITY DAMPER, THEN THROUGH VENTILATOR ELECTRICAL CONDUIT GUIDE.

**POWER ROOF VENTILATOR**




- 1 18 GAUGE GALVANIZED STEEL COUNTER-FLASHING.
  - 2 WELDED 14 GAUGE EQUIPMENT SUPPORT CURB, MEETING ASTM A-446, 525, 526 AND 527 REQUIREMENTS, WITH WELDED CORNERS WITH SEAMS JOINED BY CONTINUOUS WELDS. CURB SHALL BE INTERNALLY REINFORCED WITH BULKHEADS AND SPREADERS, 24" ON CENTER TO MEET LOAD RATING OF EQUIPMENT. CURB TO EXTEND 6" BEYOND EQUIPMENT. REFER TO FLOOR PLANS FOR HEIGHT.
  - 3 SECURE CURB TO ROOF WITH EXPANSION BOLTS (CONCRETE ROOF) OR RUST RESISTANT BOLTS (METAL DECK AND BAR JOIST ROOF), 12" O.C.
- GENERAL NOTE:**
1. THIS DETAIL IS NOT INTENDED FOR ROOFTOP AHU SUPPORT. REFER TO STRUCTURAL DRAWINGS FOR REQUIREMENTS OF ROOFTOP AHU SUPPORT.

**EQUIPMENT/DUCT SUPPORT ROOF CURB**


HANGER STRAPS OR RODS			
MAX. DUCT DIA. - IN.	QUANTITY/SIZE IN.	MAX. LOAD LBS.	MAX. SPACING IN.
26	ONE 1 x 22 GA. STRAP	260	144
36	ONE 1 x 18 GA. STRAP	420	144
50	ONE 1 x 16 GA. STRAP	700	144
60	TWO 3/8 DIA. RODS	1320	144
84	TWO 1/2 DIA. RODS	2500	144

**NOTE:** TABULATED DATA FROM SMACNA ALLOWS FOR DUCT REINFORCING AND INSULATION, BUT NO EXTERNAL LOAD.


**ROUND DUCT HANGERS**



**SECURING HANGER RODS IN CONCRETE**




**DETAIL FOR SUPPORTING PIPE ON ROOF**



**CVR AND VVR TERMINAL CONTROLS**

\* REFER TO AIR TERMINAL UNIT SCHEDULE ON SHEET M601 FOR VALVE TYPE (2-WAY OR 3-WAY)



**GENERAL EXHAUST FANS**

- 1 EXHAUST FAN CONTROLS**
- 1.1 EXHAUST FAN SHALL BE STARTED AND STOPPED BY THE DCP OR REMOTELY AT THE EDC. EACH FAN SHALL BE SOFTWARE INTERLOCKED TO OPERATE WITH ITS RESPECTIVE AIR HANDLING UNIT. H-O-A SWITCH SHALL BE KEPT IN THE "AUTO" POSITION. "HAND" AND "OFF" SHALL BE USED ONLY FOR MAINTENANCE.

**FUME HOOD EXHAUST FANS**

- 1 EXHAUST FAN CONTROLS**
- 1.1 EXISTING CONTROLS SHALL BE RELOCATED WITH THE HOODS AND TIED INTO NEW FANS.

**GENERAL NOTES**

1. A COMPLETE SYSTEM OF AUTOMATIC TEMPERATURE CONTROLS SHALL BE INSTALLED UNDER THIS CONTRACT AS REQUIRED TO ACCOMPLISH THE SEQUENCE OF CONTROL FOR VARIOUS ITEMS OF EQUIPMENT AND SYSTEMS AS DESCRIBED HEREINAFTER. THE SYSTEM SHALL BE A DIRECT DIGITAL CONTROL SYSTEM UTILIZING ELECTRIC ACTUATION.
2. ELECTRICAL WORK INCLUDES A POWER SOURCE TO THE MOTOR STARTERS. ALL HVAC POWER SOURCES REQUIRED BEYOND THESE STARTERS OR BEYOND SOURCES EXPLICITLY SHOWN ON THE ELECTRICAL DRAWINGS, SHALL BE PROVIDED UNDER THE ATC WORK. THIS WORK SHALL INCLUDE BUT NOT BE LIMITED TO WIRING, CONDUIT, TRANSFORMERS, RELAYS AND FUSES.
3. CONTROLS SHALL BE FULLY INTEGRATED INTO EXISTING CAMPUS SYSTEM AND PROPER GRAPHICS SHALL BE CREATED TO MIMIC EXISTING.
4. BULB WELLS FOR TEMPERATURE SENSING AS INDICATED SHALL BE FURNISHED UNDER THE ATC WORK AND INSTALLED AS PART OF THE HVAC PIPING WORK. PIPING WORK SHALL INCLUDE PROPERLY SIZED WELDOLET OR THREEDOLET FITTINGS PLACED AS DIRECTED BY THE CONTROL SYSTEM SUPPLIER.

**CVR & VVR CONTROL SEQUENCES WITH OCCUPANCY SENSING**

- 1 CONSTANT VOLUME REHEAT TERMINAL CONTROL**
- 1.1 DURING THE OCCUPIED MODE OF OPERATION, WHEN ROOM TEMPERATURE AT T1 IS BELOW SETPOINT, HOT WATER VALVE V1 AND V2 (WHERE APPLICABLE), SHALL MODULATE OPEN TO COOL TO MAINTAIN TEMPERATURE SETPOINT. BOX DAMPER D1 SHALL REMAIN AT CONSTANT MAXIMUM CFM.
  - 1.2 EACH TERMINAL UNIT SHALL INCLUDE AN AIRFLOW SENSOR FOR CALCULATING CFM, AND A DISCHARGE AIR TEMPERATURE SENSOR.
  - 1.3 EXTEND 24 VOLT POWER TO THE TERMINAL BOX CONTROLLER FROM THE ASSOCIATED AIR HANDLING UNIT DDC CONTROL PANEL.
  - 1.4 ROOM SPACE TEMPERATURE SET POINT SHALL BE ADJUSTABLE FROM THE FRONT END COMPUTER INTERFACE.
  - 1.5 OCCUPANCY SENSOR OS1 PROVIDED UNDER DIV. 26 SHALL DETERMINE OCCUPIED/UNOCCUPIED MODES OF OPERATION. TO INVOKE UNOCCUPIED SEQUENCE (1.6 BELOW), OCCUPANCY SENSORS FOR ALL SPACES ON A GIVEN TERMINAL UNIT ZONE MUST SATISFY THIS CONDITION. EXTEND LOW VOLTAGE WIRING FROM ALL APPLICABLE OCCUPANCY SENSOR(S) TO THE TERMINAL UNIT CONTROLLER.
  - 1.6 DURING THE UNOCCUPIED MODE OF OPERATION, THE CONTROL DAMPER ACTUATOR D1 SHALL POSITION TO THE UNOCCUPIED AIRFLOW SETTING (REFER TO AIR TERMINAL UNIT SCHEDULE, SHEET M601).
  - 1.7 DURING THE UNOCCUPIED MODE OF OPERATION, WHEN THE ROOM TEMPERATURE AT T1 IS BELOW THE UNOCCUPIED HEATING SETPOINT (REFER TO HVAC DESIGN DATA SCHEDULE, SHEET M601), THE CONTROL SHALL INDEX TO THE OCCUPIED HEATING MODE OF OPERATION. THE CONTROL SHALL REVERT TO UNOCCUPIED OPERATION (SEE 1.6 ABOVE) WHEN ROOM TEMPERATURE T1 RISES 2 DEGREES (ADJUSTABLE) ABOVE THE UNOCCUPIED HEATING SETPOINT.
  - 1.8 DURING THE UNOCCUPIED MODE OF OPERATION, WHEN THE ROOM TEMPERATURE AT T1 IS ABOVE THE UNOCCUPIED COOLING SETPOINT (REFER TO HVAC DESIGN DATA SCHEDULE, SHEET M601), THE CONTROL SHALL INDEX TO THE OCCUPIED COOLING MODE OF OPERATION. THE CONTROL SHALL REVERT TO UNOCCUPIED OPERATION (SEE 1.6 ABOVE) WHEN ROOM TEMPERATURE T1 REDUCES 2 DEGREES (ADJUSTABLE) BELOW THE UNOCCUPIED COOLING SETPOINT.
- 2 VARIABLE VOLUME REHEAT TERMINAL CONTROL**
- 2.1 DURING THE OCCUPIED MODE OF OPERATION, WHEN ROOM TEMPERATURE AT T1 IS BELOW SETPOINT, THE CONTROL DAMPER ACTUATOR, D1 SHALL MODULATE THE DAMPER TO REDUCE AIRFLOW TO THE SUMMER MINIMUM SETTING. ON A FURTHER DROP IN ROOM TEMPERATURE AT T1, THE CONTROL DAMPER SHALL BE MODULATED UPWARD TO THE WINTER MINIMUM AIRFLOW AND THE HOT WATER VALVE V1 AND V2 (WHERE APPLICABLE) SHALL MODULATE OPEN TO COOL, TO MAINTAIN TEMPERATURE SETPOINT.
  - 2.2 DURING THE OCCUPIED MODE OF OPERATION, AS ROOM TEMPERATURE RISES ABOVE SETPOINT, HOT WATER VALVE V1 SHALL CLOSE. IF THE ROOM TEMPERATURE CONTINUES TO RISE ABOVE SETPOINT, DAMPER D1 SHALL MODULATE FROM SUMMER (COOLING) MINIMUM AIRFLOW TO MAXIMUM AIRFLOW TO MAINTAIN ROOM TEMPERATURE.
  - 2.3 EACH TERMINAL UNIT SHALL INCLUDE AN AIRFLOW SENSOR FOR CALCULATING CFM, AND A DISCHARGE AIR TEMPERATURE SENSOR.
  - 2.4 EXTEND 24 VOLT POWER TO THE TERMINAL BOX CONTROLLER FROM THE ASSOCIATED AIR HANDLING UNIT DDC CONTROL PANEL.
  - 2.5 ROOM SPACE TEMPERATURE SET POINT SHALL BE ADJUSTABLE FROM THE FRONT END COMPUTER INTERFACE.
  - 2.6 OCCUPANCY SENSOR OS1 PROVIDED UNDER DIV. 26 SHALL DETERMINE OCCUPIED/UNOCCUPIED MODES OF OPERATION. TO INVOKE UNOCCUPIED SEQUENCE (2.7 BELOW), OCCUPANCY SENSORS FOR ALL SPACES ON A GIVEN TERMINAL UNIT ZONE MUST SATISFY THIS CONDITION. EXTEND LOW VOLTAGE WIRING FROM ALL APPLICABLE OCCUPANCY SENSOR(S) TO THE TERMINAL BOX CONTROLLER.
  - 2.7 DURING THE UNOCCUPIED MODE OF OPERATION, THE CONTROL DAMPER ACTUATOR D1 SHALL POSITION TO THE UNOCCUPIED AIRFLOW SETTING (REFER TO AIR TERMINAL UNIT SCHEDULE, SHEET M601).
  - 2.8 DURING THE UNOCCUPIED MODE OF OPERATION, WHEN THE ROOM TEMPERATURE AT T1 IS BELOW THE UNOCCUPIED HEATING SETPOINT (REFER TO HVAC DESIGN DATA SCHEDULE, SHEET M601), THE CONTROL SHALL INDEX TO THE OCCUPIED HEATING MODE OF OPERATION. THE CONTROL SHALL REVERT TO UNOCCUPIED OPERATION (SEE 2.7 ABOVE) WHEN ROOM TEMPERATURE T1 RISES 2 DEGREES (ADJUSTABLE) ABOVE THE UNOCCUPIED HEATING SETPOINT.
  - 2.9 DURING THE UNOCCUPIED MODE OF OPERATION, WHEN THE ROOM TEMPERATURE AT T1 IS ABOVE THE UNOCCUPIED COOLING SETPOINT (REFER TO HVAC DESIGN DATA SCHEDULE, SHEET M601), THE CONTROL SHALL INDEX TO THE OCCUPIED COOLING MODE OF OPERATION. THE CONTROL SHALL REVERT TO UNOCCUPIED OPERATION (SEE 2.7 ABOVE) WHEN ROOM TEMPERATURE T1 REDUCES 2 DEGREES (ADJUSTABLE) BELOW THE UNOCCUPIED COOLING SETPOINT.

three inches = one foot  
one and one-half inches = one foot  
one inch = one foot  
three-quarters inch = one foot  
one-half inch = one foot  
three-eighths inch = one foot  
one-quarter inch = one foot  
one-eighth inch = one foot

5/13/2016 11:59:45 AM

Revisions	Date
1	35% Schematic Design 03.05.2015
2	65% Design Development 04.28.2015
3	95% Owner Review 08.14.2015
4	100% Construction Documents 11.04.2015
5	Bid Set Drawings 01.15.2016

**CONSULTANTS:**

**Heapy Engineering**  
MEP Design Technology Planning Commissioning Energy  
Nationally Recognized Leader in Sustainability  
1400 W Dorothy Lane, Dayton, OH 45409-1310  
Ph 937-224-0861 Fax 937-224-5777 www.heapy.com  
Heapy Project No.: 2014-04034 Firm License No.: Q1528

**ARCHITECT/ENGINEERS:**

STATE OF OHIO  
GARY S. EODICE  
E-52755  
REGISTERED PROFESSIONAL ENGINEER

**JOHN POE ARCHITECTS**

3131 NEWMARK DRIVE, SUITE 202 MIAMISBURG, OHIO 45342  
937 461 3290 PHONE jpa@johnpoe.com

Drawing Title  
**DETAILS AND CONTROLS**

Approved: Project Director

Project Title  
**RELOCATE PROSTHETICS AND PODIATRY CLINICS**

Location  
**Dayton, Ohio**

Date  
**05.16.2016**

Checked  
**PCW**

Drawn  
**WJS**

Project No.  
VA Project No. 552-15-502  
JPA Project No. 14006.00

Building Number  
**999**

Drawing Number  
**M503**

Dwg. of

Office of Construction and Facilities Management  
Department of Veterans Affairs

# FULLY SPRINKLERED

AIR DISTRIBUTION DEVICES									
SYMBOL	DESCRIPTION	TYPE MOUNTING		MATERIAL		FINISH		ACCESSORIES	SEE NOTE
		LAY-IN	SURFACE	STEEL	ALUM.	E.C.L.	W.B.E.		
BG1	HEAVY DUTY FIXED BLADE GRILLE - 38" HORIZONTAL BLADES-0.5" SPACING		*	*			*		
CD1	STANDARD SQ. PLAQUE CEILING DIFFUSER ROUND NECK	*		*			*		
CD2	STANDARD SQ. PLAQUE CEILING DIFFUSER ROUND NECK	*	*	*			*		
CD3	LINEAR PLENUM SLOT ADJUSTABLE BLADE DIFFUSER	*		*			*	INSULATED PLENUM	1,2
CG1	EGGCRATE CEILING GRILLE			*			*		
CG2	EGGCRATE CEILING GRILLE		*	*			*		
CR1	EGGCRATE CEILING REGISTER	*		*			*	OPPOSED BLADE DAMPER	
CR2	EGGCRATE CEILING REGISTER	*	*	*			*	OPPOSED BLADE DAMPER	
TG1	FIXED BLADE GRILLE 45 DEGREE 0.75" SPACING		*	*			*		3
TR1	ADJUSTABLE BLADE REGISTER	*		*			*	OPPOSED BLADE DAMPER	3
TR2	FIXED BLADE REGISTER 45 DEGREE 0.75" SPACING	*	*	*			*	OPPOSED BLADE DAMPER	3

NOTES:  
 1 48" LENGTH, 3-1" SLOTS  
 2 AIR DEVICE TO INCLUDE A CENTER NOTCH TO ACCOMMODATE A 2 FT. X 2 FT. CEILING GRID.  
 3 HORIZONTAL BLADES

FAN SCHEDULE															
FAN NO. (2)	LOCATION	FAN CFM	FAN S.P.	FAN TYPE	DESCRIPTION	WHEEL			MOTOR			SEE NOTE			
						TYPE	MIN. DIA.	MAX. RPM	DRIVE	MAX. SONES (dBA)	MAX. BHP		NOM. HP (1)	PHASE VOLT.	VSD
EF-212	B315 ROOF	900	1"	PEF	PLUME EXHAUST FAN	BIW	15"	2,700	BELT	-	3.48	5	460-3PH	NO	3
EF-213	B315 ROOF	900	1"	PEF	PLUME EXHAUST FAN	BIW	15"	2,700	BELT	-	3.48	5	460-3PH	NO	3
EF-215	B315 ROOF	1740	0.4"	PEF	PLUME EXHAUST FAN	BIW	12"	1,200	DIRECT	6.4	0.21	0.25	115-1PH	NO	
EF-1	B315 ROOF	2500	0.75"	CF	POWER ROOF VENTILATOR	BIW	16"	1,200	BELT	13.9	0.63	0.75	460-3PH	NO	
EF-2	B315 ROOF	1640	0.4"	CF	POWER ROOF VENTILATOR	BIW	16"	800	BELT	6.4	0.21	0.25	115-1PH	NO	

NOTES:  
 1 MOTORS SHALL BE ENERGY EFFICIENT TYPE.  
 2 CONTACT PLANT ENGINEERS FOR ACTUAL FAN NUMBER.  
 3 LAB SYSTEM EXHAUST=900 CFM; BYPASS AIRFLOW=3233 CFM; TOTAL INLET AIRFLOW=3222 CFM; ENTRAINMENT AIRFLOW=1189 CFM; TOTAL OUTLET AIRFLOW=4411 CFM.

DUCT PRESSURE CLASS & LEAKAGE TABLE						
SYSTEM	DUCT INVOLVED	POSITIVE (P) OR NEGATIVE (N) PRESSURE	SMACNA CONST. CLASS W.G.	SMACNA SEAL CLASS	SMACNA LEAKAGE CLASS	
					RECTANGULAR DUCT	ROUND DUCT
ALL SYSTEMS	ALL DUCTWORK EXCEPT AS LISTED BELOW.	P/N	+ 2"	A	6	3
	SUPPLY AIR DUCTS FROM OUTLET OF AH-UNIT TO INLET OF AIR TERMINAL UNITS.	P	4"	A	6	3
	SUPPLY AIR DUCTS FROM OUTLET OF AIR TERMINAL UNITS TO SUPPLY AIR DEVICES	P	1"	A	6	3
	RETURN AIR DUCTS FROM CEILING REGISTERS TO INLET OF AH-UNIT	N	-2"	A	6	3
	GENERAL EXHAUST DUCTS	N	-2"	A	6	3
	LABORATORY HOOD DUCTS	WELDED STAINLESS STEEL				

HVAC DESIGN DATA			
OUTDOOR DESIGN TEMPERATURES:	90.3 DEG. F. DB SUMMER	73.6 DEG. F. WB SUMMER	0 DEG. F. DB WINTER
DESIGN ALTITUDE:	1004 FT.		
INDOOR AREA DESIGN CONDITIONS	SUMMER		WINTER
	DB (°F)	% HUMIDITY	DB (°F) % HUMIDITY
BATHROOMS & TOILET ROOMS	75	-	68 30
ALL OTHER AREAS	75	50	70 30
UNOCCUPIED MODE (1)	80	-	60 -

NOTES:  
 1 REFERS TO OCCUPANCY STATUS FOR CONTROL OF AIR TERMINAL UNITS. REFER TO AIR TERMINAL UNIT SCHEDULE ON THIS SHEET AND CONTROL SEQUENCES ON SHEET M503.

ROOM HEATING UNITS									
GENERAL NOTES									
+ HEATING CAPACITY BASED ON 65° ENT. AIR & 160° ENT. WATER					* REFER TO PLANS FOR LENGTH OF EACH HEATER			* SEE PIPING DETAILS ON SHEET M502.	
+ MAXIMUM WATER PRESS. DROP THRU COIL 5 FT.									
UNIT NO.	DESCRIPTION	MOUNTING	CFM	HTG. MBH	GPM	RUNOUT SIZE	AUTO. VALVE	APPROX. CABINET DIMENSIONS	REMARKS
R1	ARCHITECTURAL RADIATOR	WALL MOUNTED	-	0.94/FT.	0.09/FT.	0.75	0.75	VARIES 3.625" 8.5"	1,2
R2	ARCHITECTURAL RADIATOR	PEDESTAL MOUNTED	-	0.94/FT.	0.09/FT.	0.75	0.75	VARIES 3.625" 8.5"	1,2

REMARKS:  
 1. RADIATORS SHALL BE R2F-3 SERIES.  
 2. MOUNT UNIT 4" A.F.F.

SOUND ATTENUATING DEVICE SCHEDULE																
MARK	LOCATION ROOM #	SYSTEM AND/OR SERVICE	TYPE	AIRFLOW CFM	APD [dB]	INLET SIZE IN [mm]	LENGTH IN [mm]	DYNAMIC INSERTION LOSS DB OCTAVE BAND AND MID-FREQUENCY (CPS)								REMARKS
								63	125	250	500	1000	2000	4000	8000	
SA3	493	315-AHU1	CIRCULAR	7,210	0.2	28"	XX	5	8	13	26	34	26	22	16	2ND FLR SA DUCT
SA4	493	315-AHU1	CIRCULAR	8,720	0.2	28"		5	8	13	26	34	26	22	16	2ND FLR SA DUCT

NOTE:  
 IN THE INLET SIZE COLUMN, WHEN ONE VALUE IS INDICATED, THE DUCT IS A ROUND DUCT. IF SIZE IS INDICATED AS ## X ##, THE DUCT IS A RECTANGULAR DUCT WITH SPECIFICATIONS OF "DUCT WIDTH" BY "DUCT DEPTH."

AIR TERMINAL UNIT SCHEDULE (B315)																		
UNIT NO.	CFM				APPROX. INLET SIZE (IN.)	DUCT RUNOUT SIZE TO UNIT (IN.) (1)	UNIT MAX. SP. AT MAX. CFM (2)	SOUND REQUIREMENTS				HOT WATER HEATING COIL					CONTROL TYPE (6)	
	MAX.	WINTER MIN.	SUMMER MIN.	UNOCCUPIED (7)				SP. ACROSS UNIT AT MAXIMUM ROOM NC	MAX. ROOM NC (3)(4)	ENT. AIR TEMP. F°	ENT. WATER TEMP. F°	GPM	MAX. WATER P.D. FT. HD.	PIPE RUNOUT SIZE TO COIL	AUTO VALVE Cv	AUTO VALVE TYPE		MIN. MBH (5)
2-01	290	290	45	45	6	6	0.35"	3.0"	35	55	160	0.6	2	0.75"	0.3	2-WAY	8	V.V.R.
2-02	360	200	55	55	6	6	0.35"	3.0"	35	55	160	0.6	2	0.75"	0.3	2-WAY	8	V.V.R.
2-03	220	220	35	35	6	6	0.35"	3.0"	35	55	160	0.5	2	0.75"	0.2	2-WAY	6	V.V.R.
2-04	755	380	115	115	9	9	0.35"	3.0"	35	55	160	1.0	2	0.75"	0.5	2-WAY	14	V.V.R.
2-05	745	375	115	115	9	9	0.35"	3.0"	35	55	160	0.9	2	0.75"	0.4	2-WAY	13	V.V.R.
2-06	160	160	25	25	6	6	0.35"	3.0"	35	55	160	0.5	2	0.75"	0.1	2-WAY	4	V.V.R.
2-07	835	580	130	130	9	9	0.35"	3.0"	35	55	160	1.7	2	0.75"	0.8	2-WAY	24	V.V.R.
2-08	365	225	55	55	7	7	0.35"	3.0"	35	55	160	0.7	2	0.75"	0.3	2-WAY	9	V.V.R.
2-11	700	350	105	105	9	9	0.35"	3.0"	35	55	160	0.6	2	0.75"	0.3	2-WAY	8	V.V.R.
2-14	460	230	70	70	7	7	0.35"	3.0"	35	55	160	0.7	2	0.75"	0.3	2-WAY	10	V.V.R.
2-15	540	465	85	85	7	7	0.35"	3.0"	35	55	160	1.4	2	0.75"	0.7	2-WAY	20	V.V.R.
2-16	555	555	85	85	8	8	0.35"	3.0"	35	55	160	1.6	2	0.75"	0.8	2-WAY	23	V.V.R.
2-17	480	240	75	75	7	7	0.35"	3.0"	35	55	160	0.6	2	0.75"	0.3	3-WAY	8	V.V.R.
2-18	310	310	50	50	6	6	0.35"	3.0"	35	55	160	0.9	2	0.75"	0.4	2-WAY	13	V.V.R.
2-21	1385	1385	210	210	14	14	0.35"	3.0"	35	55	160	4.1	2	1"	1.9	2-WAY	60	C.V.R.
2-22	1060	725	160	160	12	12	0.35"	3.0"	35	55	160	1.9	2	1"	0.9	2-WAY	27	C.V.R.
2-23	480	480	75	75	7	7	0.35"	3.0"	35	55	160	1.4	2	0.75"	0.7	3-WAY	20	V.V.R.
2-24	630	395	95	95	9	9	0.35"	3.0"	35	55	160	1.1	2	0.75"	0.5	2-WAY	16	V.V.R.
2-25	330	330	50	50	6	6	0.35"	3.0"	35	55	160	0.6	2	0.75"	0.3	2-WAY	9	C.V.R.
2-26	590	295	90	90	8	8	0.35"	3.0"	35	55	160	0.9	2	1"	0.4	2-WAY	13	C.V.R.

NOTES:  
 1 PROVIDE DUCT TRANSITION AT UNIT INLET WHERE UNIT INLET SIZE AND DUCT RUNOUT SIZE ARE DIFFERENT.  
 2 THE UNIT MAXIMUM SP IS THE PRESSURE DIFFERENCE BETWEEN THE UNIT INLET AND DISCHARGE INCLUDING REHEAT COIL AND SOUND ATTENUATOR. IT IS ALSO THE MINIMUM PRESSURE REQUIRED AT THE UNIT INLET TO OBTAIN THE RATED CFM.  
 3 PROVIDE HOSPITAL GRADE SOUND ATTENUATOR WHERE REQUIRED TO CONFORM TO THE MAXIMUM NC35 REQUIREMENT.  
 4 UNIT NOISE LEVEL SELECTION SHALL NOT EXCEED A ROOM NC OF 35 FROM BOTH AIRBORNE AND RADIATED NOISE, BASED ON A 10 DB ROOM ABSORPTION COEFFICIENT (REFERENCE 10-112) WATTS) WITH 3" S.P. DIFFERENTIAL ACROSS UNIT AT MAXIMUM CFM SETTING.  
 5 HEATING COIL CAPACITY BASED ON WINTER MINIMUM CFM.  
 6 CONTROL TYPES: V.V.R.: VARIABLE VOLUME REHEAT TERMINAL; C.V.R.: CONSTANT VOLUME REHEAT TERMINAL.  
 7 AIR TERMINAL UNIT WITH AIRFLOW LISTED IN THIS COLUMN IS CONNECTED TO AN OCCUPANCY SENSOR PROVIDED BY DIVISION 26, FOR UNOCCUPIED CONTROL MODE. REFER TO CONTROL SEQUENCES ON SHEET M503, AND UNOCCUPIED HEATING & COOLING SETPOINTS IN "HVAC DESIGN DATA" SCHEDULE ON THIS SHEET.

AIR TERMINAL UNIT SCHEDULE (B330)																		
UNIT NO.	CFM				APPROX. INLET SIZE (IN.)	DUCT RUNOUT SIZE TO UNIT (IN.) (1)	UNIT MAX. SP. AT MAX. CFM (2)	SOUND REQUIREMENTS				HOT WATER HEATING COIL					CONTROL TYPE (6)	
	MAX.	WINTER MIN.	SUMMER MIN.	UNOCCUPIED (7)				SP. ACROSS UNIT AT MAXIMUM ROOM NC	MAX. ROOM NC (3)(4)	ENT. AIR TEMP. F°	ENT. WATER TEMP. F°	GPM	MAX. WATER P.D. FT. HD.	PIPE RUNOUT SIZE TO COIL	AUTO VALVE Cv	AUTO VALVE TYPE		MIN. MBH (5)
8-06	410	205	65	65	7	9	0.35"	3.0"	35	55	160	0.5	2	0.75"	0.2	2-WAY	5	V.V.R.
8-07	870	870	135	135	9	11	0.35"	3.0"	35	55	160	1.7	2	0.75"	0.8	2-WAY	24	V.V.R.
8-08	540	-	85	-	7	9	0.35"	3.0"	35	-	-	-	-	-	-	-	-	V.V.
8-09	85	85	15	15	6	8	0.35"	3.0"	35	55	160	0.5	2	0.75"	0.2	2-WAY	2	V.V.R.
8-11	1085	675	165	165	12	14	0.35"	3.0"	35	55	160	2.0	2	0.75"	0.9	2-WAY	29	V.V.R.
8-14	930	530	140	140	12	14	0.35"	3.0"	35	55	160	1.6	2	0.75"	0.8	2-WAY	23	V.V.R.
8-15	135	70	25	25	6	8	0.35"	3.0"	35	55	160	0.5	2	0.75"	0.2	2-WAY	2	V.V.R.
8-16	145	110	25	25	6	8	0.35"	3.0"	35	55	160	0.5	2	0.75"	0.2	2-WAY	3	V.V.R.
8-17	1080	685	165	165	12	14	0.35"	3.0"	35	55	160	2.0	2	0.75"	0.9	3-WAY	30	V.V.R.
8-18	760	450	115	115	9	11	0.35"	3.0"	35	55	160	1.4	2	0.75"	0.7	2-WAY	20	V.V.R.
8-19	715	410	110	110	9	11	0.35"	3.0"	35	55	160	1.2	2	0.75"	0.6	2-WAY	18	V.V.R.
8-20	345	210	55	55	6	8	0.35"	3.0"	35	55	160	0.5	2	0.75"	0.2	2-WAY	5	V.V.R.
8-21	510	255	80	80	7	9	0.35"	3.0"	35	55	160	0.5	2	0.75"	0.2	2-WAY	6	V.V.R.
8-27	1030	715	155	155	12	14	0.35"	3.0"	35	55	160	1.2	2	0.75"	0.6	2-WAY	18	V.V.R.
8-30	540	290	85	85	7	9	0.35"	3.0"	35	55	160	0.5	2	0.75"	0.2	2-WAY	7	V.V.R.
8-31	320	205	50	50	6	8	0.35"	3.0"	35	55	160	0.5	2	0.75"	0.2	3-WAY	5	V.V.R.
8-32	120	80	20	20	6	8	0.35"	3.0"	35	55	160	0.5	2	0.75"	0.2	2-WAY	2	V.V.R.
8-33	210	210	35	35	6	8	0.35"	3.0"	35	55	160	0.5	2	0.75"	0.2	2-WAY	5	V.V.R.
8-36	210	110	35	35	6	8	0.35"	3.0"	35	55	160	0.5	2	0.75"	0.2	3-WAY	3	V.V.R.
8-37	520	520	80	80	7	9	0.35"	3.0"	35	55	160	0.9	2	0.75"	0.4	2-WAY	13	V.V.R.
8-38	345	195	55	55	6	8	0.35"	3.0"	35	55	160	0.6	2	0.75"	0.3	2-WAY	8	V.V.R.
8-39	120	70	20	20	6	8	0.35"	3.0"	35	55	160	0.5	2	0.75"	0.2	2-WAY	3	V.V.R.

NOTES:  
 1 PROVIDE DUCT TRANSITION AT UNIT INLET WHERE UNIT INLET SIZE AND DUCT RUNOUT SIZE ARE DIFFERENT.  
 2 THE UNIT MAXIMUM SP IS THE PRESSURE DIFFERENCE BETWEEN THE UNIT INLET AND DISCHARGE INCLUDING REHEAT COIL AND SOUND ATTENUATOR. IT IS ALSO THE MINIMUM PRESSURE REQUIRED AT THE UNIT INLET TO OBTAIN THE RATED CFM.  
 3 PROVIDE HOSPITAL GRADE SOUND ATTENUATOR WHERE REQUIRED TO CONFORM TO THE MAXIMUM NC35 REQUIREMENT.  
 4 UNIT NOISE LEVEL SELECTION SHALL NOT EXCEED A ROOM NC OF 35 FROM BOTH AIRBORNE AND RADIATED NOISE, BASED ON A 10 DB ROOM ABSORPTION COEFFICIENT (REFERENCE 10-112) WATTS) WITH 3"


# FULLY SPRINKLERED

## GENERAL NOTES

A REFER TO SHEET E001 FOR LEGEND, SYMBOLS & INDEX OF DRAWINGS.

## PLAN NOTES

- NEW PADMOUNT "PME" SWITCH FEED FROM EXISTING CIRCUIT IN MANHOLE #5. INSTALL 6" CONCRETE PAD FOR SWITCH.
- PROVIDE DEAD BREAK ELBOWS IN MANHOLE FOR CONNECTION TO NEW PME "C" FEEDER.
- CUT AND PATCH ROAD FOR TRANSFORMER T-36 FEEDER. SEE SINGLE LINE DIAGRAM FOR FURTHER DETAILS.
- REMOVE CABLES FROM EXISTING CONDUITS.
- RELOCATED SMOKING SHELTER. PROVIDE ELECTRIC SERVICE AS INDICATED. REFEED FROM BUILDING #315. 462 AWG, 8 GRND, 1-1/4"Ø. PROVIDE GROUND ROD AT SERVICE PANEL AND BOND TO GROUND IN PANEL. 16 BARE SOLID GROUND WIRE. CONNECT TO MAIN PANEL "MD" SPARE 100/3A CIRCUIT BREAKER LOCATED IN ELECTRIC ROOM.
- WIRE 2 ADA BUTTONS ON BOLLARDS TO MOTORIZED DOOR IN SHELTER. 2#12, 12 GRND 3#4C. ONE INSIDE AND ONE OUTSIDE AT DOOR. RELOCATE THEM FROM EXISTING SHELTER LOCATION. SEE ENLARGED SHELTER ON ARCHITECTURAL SHEETS FOR FURTHER DETAILS.
- OLD SHELTER LOCATION. DISCONNECT ELECTRIC FEEDER AND REMOVE WIRE AND CONDUIT BACK TO SOURCE. PANEL 4E-GB.
- (4) 4" CONDUITS IN DUCT BANK. CIRCUITS A & J TO NEW PME-C SWITCH. RUN (3#350 1-CONDUCTOR 15KV CABLE IN 4"Ø. FOR EACH CIRCUIT. INCLUDE TWO 4" SPARES IN DUCTBANK.




**SITE PLAN**  
Scale: 1" = 20'-0"  
PROJECT

5/13/2016 11:33:59 AM

Revisions	Date	Date
1	35% Schematic Design	03.05.2015
2	65% Design Development	04.28.2015
3	95% Owner Review	08.14.2015
4	100% Construction Documents	11.04.2015
5	Bid Set Drawings	01.15.2016

CONSULTANTS:

**Heapy Engineering**  
MEP Design Technology Planning Commissioning Energy  
*Nationally Recognized Leader in Sustainability*  
1400 W Dorothy Lane, Dayton, OH 45409-1310  
Ph 937-224-0861 Fax 937-224-5777 www.heapy.com  
Heapy Project No.: 2014-04034 Firm License No.: Q1528




ARCHITECT/ENGINEERS:  
**JOHN POE ARCHITECTS**  
3131 NEWMARK DRIVE, SUITE 200 MIAMISBURG, OHIO 45342  
937.461.3290 PHONE jpa@johnpoe.com

Drawing Title  
**ELECTRICAL SITE PLAN**  
Approved: Project Director

Project Title  
**RELOCATE PROSTHETICS AND PODIATRY CLINICS**  
Location  
**Dayton, Ohio**  
Date  
**05.16.2016**  
Checked  
**MSG**  
Drawn  
**SC**  
Project No.  
VA Project No. **552-15-502**  
JPA Project No. **14006.00**  
Building Number  
**999**  
Drawing Number  
**ES001**  
Dwg. of

Office of Construction and Facilities Management  
Department of Veterans Affairs

three inches = one foot  
 one and one-half inches = one foot  
 one inch = one foot  
 three-quarters inch = one foot  
 one-half inch = one foot  
 three-eighths inch = one foot  
 one-quarter inch = one foot  
 one-eighth inch = one foot




- PLAN NOTES**
1. PROVIDE 36\"/>

**TECHNOLOGY PARTIAL SITE PLAN**  
 Scale: 1/8" = 1'-0"  
 PROJECT

Revisions	Date
1	03.05.2015
2	04.28.2015
3	08.14.2015
4	11.04.2015
5	01.15.2016

**CONSULTANTS:**

**Heapy Engineering**  
 MEP Design Technology Planning Commissioning Energy  
*Nationally Recognized Leader in Sustainability*  
 1400 W Dorothy Lane, Dayton, OH 45409-1310  
 Ph 937-224-0861 Fax 937-224-5777 www.heapy.com  
 Heapy Project No.: 2014-04034 Firm License No.: Q1528



**ARCHITECT/ENGINEERS:**

**JOHN POE ARCHITECTS**  
 3131 NEWMARK DRIVE, SUITE 200  
 MIAMISBURG, OHIO 45342  
 937.461.3290 PHONE  
 jpa@johnpoe.com

Drawing Title  
**TECHNOLOGY PARTIAL SITE PLAN**  
 Approved: Project Director

Project Title  
**RELOCATE PROSTHETICS AND PODIATRY CLINICS**

Location  
**Dayton, Ohio**

Date  
**05.16.2016**

Checked  
**MSG**

Drawn  
**JDK**

Project No.  
 VA Project No. **552-15-502**  
 JPA Project No. **14006.00**

Building Number  
**999**

Drawing Number  
**ES002**

Dwg. of

**Office of Construction and Facilities Management**  
 Department of Veterans Affairs

5/13/2016 11:34:03 AM



three inches = one foot  
 one and one-half inches = one foot  
 one inch = one foot  
 three-quarters inch = one foot  
 one-half inch = one foot  
 three-eighths inch = one foot  
 one-quarter inch = one foot  
 one-eighth inch = one foot



3 SHELTER DISCONNECT  
 SCALE: NONE



1 BLD. 307 TRANSFORMER AND SWITCH  
 SCALE: NONE



2 SHELTER FEEDER  
 SCALE: NONE



4 BLD. 307 SWITCHBOARD  
 SCALE: NONE



5 T-36 TRANSFORMER  
 SCALE: NONE



6 EXISTING SHELTER  
 SCALE: NONE




7 SITE PHOTOGRAPH  
 SCALE: NONE

Revisions	Date
1	35% Schematic Design 03.05.2015
2	65% Design Development 04.28.2015
3	95% Owner Review 06.14.2015
4	100% Construction Documents 11.04.2015
5	Bid Set Drawings 01.15.2016

CONSULTANTS:

**Heapy Engineering**  
 MEP Design Technology Planning Commissioning Energy  
*Nationally Recognized Leader in Sustainability*  
 1400 W Dorothy Lane, Dayton, OH 45409-1310  
 Ph 937-224-0861 Fax 937-224-5777 www.heapy.com  
 Heapy Project No.: 2014-04034 Firm License No.: Q1528



ARCHITECT/ENGINEERS:

**JOHN POE ARCHITECTS**

3131 NEWMARK DRIVE,  
 SUITE 200  
 MIAMISBURG, OHIO 45342  
 937.461.3290 PHONE  
 jpa@johnpoe.com

Drawing Title

**SITE PHOTOGRAPH**

Approved: Project Director

Project Title

**RELOCATE PROSTHETICS AND PODIATRY CLINICS**

Location **Dayton, Ohio**

Date **05.16.2016** Checked **MSG** Drawn **SC**

Project No. VA Project No. **552-15-502** JPA Project No. **14006.00**

Building Number **999**


Drawing Number **E502**

Dwg. of


Office of Construction and Facilities Management

Department of Veterans Affairs

5/13/2016 11:32:30 AM



**BLDG 330-02 MECHANICAL ROOM**  
Scale: 1/8" = 1'-0"



**Bldg 330-02 ENLARGED FABRICATION ROOM**  
Scale: 1/4" = 1'-0"

**MISC EQUIPMENT**

NOTES:

MARK	DESCRIPTION	HORSEPOWER (HP)	CHARACTERISTICS							DISC MEANS	ELECTRICAL CONNECTION	FEEDER			SEE NOTE					
			LOAD (kVA)	120V/1PH	208V/1PH	240V/1PH	277V/1PH	480V/3PH	DISCONNECT SWITCH			RECEPTACLE	PANEL BREAKER	DIRECT CONNECTION		CORD & PLUG	OUTLET M.H.	CORD & PLUG FURN. BY	NUMBER OF CONDUCTORS	WIRE SIZE
M1	DUST COLLECTOR	3	3.819													3	12	12	3/4	
M2	LATEDA SHOE		2.054													3	12	12	3/4	
M4	BELT SANDER		1.055													2	12	12	3/4	
M5	TRAUTMANS CARVER		0.885													2	12	12	3/4	
M6	TRAUTMANS DISC SANDER	2	2.496													2	10	10	3/4	
M7	DRILL PRESS		1.08													2	12	12	3/4	
M10	SEWING MACH		1.08													2	12	12	3/4	
M11	SEWING PATCHER		1.56													2	12	12	3/4	
M12	SAND BLASTER TRINCO		1.08													2	12	12	3/4	
M13	OMEGA CARVER		1.08													2	12	12	3/4	
M18	THE TABLE	1/4	0.696													2	12	12	3/4	
M19	SHOE PRESS		1.08													2	12	12	3/4	
M20	AUTO NAILER		0.24													2	12	12	3/4	
M22	THERMOFORMER		3.12													2	12	12	3/4	
M25	OVEN		5.044													3	12	12	3/4	
M28	CHOP SAW		1.8													2	12	12	3/4	
M29	AIR COMPRESSOR		1.872													2	12	12	3/4	
M30	VACUUM PUMP		1.08													2	12	12	3/4	
M31	DISC GRINDER		1.08													2	12	12	3/4	
M32	VACUUM PUMP	7	9.145													3	12	12	3/4	
M116	BAND SAW		1.92													2	12	12	3/4	

**Panel: HC2D**

Location: [Blank] Mounting: Surface A.I.C. Rating: [Blank]  
Supply From: [Blank] Enclosure: Type 1 Mains Type: MLO  
Voltage: 480/277 Wye-3PH-4W Mains Rating: 250 A

CKT	Circuit Description	Trip	Poles	A	B	C	Poles	Trip	Circuit Description	CKT	
1	CWP-1	150 A	3	0 VA	0 VA		3	15 A	CWP-2	2	
3	--	--	--		0 VA	0 VA	--	--	--	4	
5	--	--	--			0 VA	0 VA	--	--	6	
7	AWU-1	25 A	3	0 VA	0 VA		3	20 A	CH1	8	
9	--	--	--		0 VA	0 VA	--	--	--	10	
11	--	--	--			0 VA	0 VA	--	--	12	
13	EF-1	15 A	3	0 VA	0 VA		3	15 A	EF-1	14	
15	--	--	--		0 VA	0 VA	--	--	--	16	
17	--	--	--			0 VA	0 VA	--	--	18	
19	EF-3	15 A	3	0 VA	0 VA		2	20 A	Spare	20	
21	--	--	--		0 VA	0 VA	--	--	--	22	
23	--	--	--			0 VA	0 VA	1	20 A	Spare	24
25	Spare	20 A	1	0 VA	0 VA		1	20 A	Spare	26	
27	Spare	20 A	1		0 VA	0 VA	1	20 A	Spare	28	
29	VAC PUMP	20 A	3			3048...	3	20 A	Spare	30	
31	--	--	--	3048...	0 VA		--	--	--	32	
33	--	--	--		3048...	0 VA	--	--	--	34	
35	Spare	15 A	3			0 VA	0 VA	3	20 A	Spare	36
37	--	--	--	0 VA	0 VA		--	--	--	38	
39	--	--	--		0 VA	0 VA	--	--	--	40	
41	Spare	20 A	1			0 VA	0 VA	1	20 A	Spare	42
				<b>Total Load:</b>	3.05 kVA	3.05 kVA	3.05 kVA				

Notes:

**TOTAL CONNECTED** 9.15 kVA **ESTIMATED DEMAND**

**Panel: LN2B6**

Location: [Blank] Mounting: Flush A.I.C. Rating: 10,000  
Supply From: T5 Enclosure: Type 1 Mains Type: MLO  
Voltage: 120/208 Wye-3PH-4W Mains Rating: 225 A

CKT	Circuit Description	Trip	Poles	A	B	C	Poles	Trip	Circuit Description	CKT	
1	M31	20 A	1	1080...	1800...		1	20 A	M25	2	
3	M5	20 A	1		868 VA	1920...	1	20 A	M116	4	
5	M4	20 A	1		1056...	360 VA	1	20 A	Receptacle	6	
7	Receptacle	20 A	1	360 VA	1560...		2	20 A	M22	8	
9	Receptacle	20 A	1		180 VA	1560...	--	--	--	10	
11	M13	20 A	1			1080...	1080...	1	20 A	M19	12
13	M12	20 A	1	1080...	1080...		1	20 A	Receptacle	14	
15	M20	20 A	1		240 VA	720 VA	1	20 A	Receptacle	16	
17	M11	20 A	1		1560...	540 VA	1	20 A	Receptacle	18	
19	Receptacle	20 A	1	360 VA	180 VA		1	20 A	Receptacle	20	
21	M25	20 A	3		1681...	696 VA	1	20 A	M16	22	
23	--	--	--	1681...	685 VA	1681...	3	20 A	M2	24	
25	Spare	20 A	1		0 VA	685 VA	--	--	--	26	
27	Spare	20 A	1		0 VA	685 VA	--	--	--	28	
29	Spare	20 A	1		0 VA	685 VA	--	--	--	30	
31	Spare	20 A	1	0 VA	0 VA		1	20 A	Spare	32	
33	Spare	20 A	1		0 VA	0 VA	--	--	Spare	34	
35	Spare	--	--		0 VA	0 VA	--	--	Spare	36	
37	Spare	--	--	0 VA	0 VA		--	--	Spare	38	
39	Spare	--	--		0 VA	0 VA	--	--	Spare	40	
41	Spare	--	--		0 VA	0 VA	--	--	Spare	42	
				<b>Total Load:</b>	9.87 kVA	8.57 kVA	8.04 kVA				

Notes:


**TOTAL CONNECTED** 26.48 kVA **ESTIMATED DEMAND** 27.0 kVA (75A)

5/13/2016 11:32:44 AM

Revisions	Date
1	35% Schematic Design 03.05.2015
2	65% Design Development 04.28.2015
3	95% Owner Review 08.14.2015
4	100% Construction Documents 11.04.2015
5	Bid Set Drawings 01.15.2016

CONSULTANTS:

**Heapy Engineering**  
MEP Design Technology Planning Commissioning Energy  
Nationally Recognized Leader in Sustainability  
1400 W Dorothy Lane, Dayton, OH 45409-1310  
Ph 937-224-0861 Fax 937-224-5777 www.heapy.com  
Heapy Project No.: 2014-04034 Firm License No.: Q1528



ARCHITECT/ENGINEERS:

**JOHN POE ARCHITECTS**  
3131 NEWMARK DRIVE, SUITE 200, MIAMISBURG, OHIO 45342  
937.461.3290 PHONE jpo@johnpoe.com

Drawing Title: **ENLARGED PLANS**

Approved: Project Director

Project Title: **RELOCATE PROSTHETICS AND PODIATRY CLINICS**

Location: **Dayton, Ohio**


Date: 05.16.2016 Checked: MSG Drawn: SC

Project No. VA Project No. 552-15-502 JPA Project No. 14006.00  
Building Number: 999  
Drawing Number: **E503**  
Dwg. of


Office of Construction and Facilities Management  
Department of Veterans Affairs

PLAN NOTES


- EXISTING RELAY RACK TO BE RE-USED. RACK MAY BE REQUIRED TO BE UNBOLTED FROM FLOOR, SHIFTED IN LOCATION AND RE-ANCHORED TO SUPPORT NEW VERTICAL CABLE MANAGERS ON EACH SIDE.
- PROVIDE NEW FULL HEIGHT, VERTICAL CABLE MANAGER PANELS.
- EXISTING PATCH PANELS TO BE REMOVED/REPLACED. DROPS SERVING AREA OF DEMOLITION TO BE REMOVED BACK TO OUTLETS BEING DEMOLISHED. DROPS SERVING AREAS NOT UNDER CONSTRUCTION TO BE IDENTIFIED, TESTED AND RECORDED. REMOVED FROM PATCH PANEL, TAGGED AND RE-TERMINATED IN NEW PATCH PANELS AND RE-TESTED TO CERTIFY OUTLETS ARE IN COMPLIANCE WITH CATEGORY RATINGS. APPROXIMATELY 120 DROPS ARE BEING REMOVED IN THE AREA OF DEMOLITION. APPROXIMATELY 280 DROPS ARE REMAINING THAT WILL REQUIRE RE-TERMINATION. FINAL COUNT IS TO BE VERIFIED BY THE CONTRACTOR PRIOR TO CABLING DEMOLITION WORK.
- EXISTING PATCH PANEL SERVING WIRELESS ACCESS POINTS TO BE MAINTAINED AND RE-INSTALLED IN EXISTING RACK UTILIZING PROPER MOUNTING HARDWARE.
- NEW 48 PORT, HIGH DENSITY PATCH PANEL. PROVIDE BLUE/YELLOW PANELS AS REQUIRED BY SEPARATION OF BLUE/YELLOW DATA CABLING. PANELS TO BE UTILIZED FOR NEW DATA DROPS IN THE AREA OF RENOVATION AND RE-TERMINATION OF EXISTING DATA DROPS OUTSIDE THE AREA OF RENOVATION.
- NEW 1RU HORIZONTAL WIRE MANAGEMENT PANEL.
- EXISTING NETWORK SWITCH TO BE RELOCATED TO NEW RACK POSITION AND RE-INSTALLED.
- NEW 48 PORT POE+ NETWORK SWITCH. REFER TO SPECIFICATIONS.
- NEW RACK MOUNTED, LINE INTERACTIVE, 2000VA, 120V-208V UPS WITH NETWORK AND ENVIRONMENTAL MONITORING ACCESSORIES.
- EXISTING ROUTER TO BE RELOCATED TO NEW RACK POSITION BY VA.
- EXISTING UPS TO BE REMOVED AND TURNED OVER TO THE VA.
- PROVIDE NEW RE-ENTERABLE, FIRE RATED CABLE SLEEVE ASSEMBLY, 4" CONDUIT CAPACITY EQUIVALENT ABOVE CEILING FOR NEW CABLING.
- EXISTING FIBER TERMINATION PANEL TO BE MAINTAINED.
- EXISTING PATCH PANEL WITH INTEGRAL CABLE MANAGER TO BE MAINTAINED WITHIN RACK. REMOVE CABLE DROPS SERVING OUTLETS BEING DEMOLISHED AND RE-LABEL PORTS SPARE.
- EXISTING NETWORK SWITCH TO BE REMOVED AND TURNED OVER TO VA.
- EXISTING PATCH PANEL TO BE MAINTAINED WITHIN RACK. REMOVE CABLE DROPS SERVING OUTLETS BEING DEMOLISHED AND RE-LABEL PORTS SPARE.
- NEW 48 PORT, 2RU PATCH PANEL FOR NEW DATA STATION CABLING. PROVIDE BLUE/YELLOW PANELS AS REQUIRED BY SEPARATION OF BLUE/YELLOW DATA CABLING.
- NEW 2RU HORIZONTAL CABLE MANAGERS.
- NEW 2-POST, FULL HEIGHT RELAY RACK.
- NEW 12"X14" WIRE BASKET TRAY RUN ABOVE RACKS. PROVIDE DROP OUTS INTO RACKS FOR CABLING. SECURE CABLE TRAY TO OVERHEAD RACKS. MOUNT AT 75" AFF.




EXISTING SIGNALS CLOSET 114  
Scale: 1/2" = 1'-0"




EXISTING SIGNALS CLOSET 2D-122  
Scale: 1/2" = 1'-0"




5 EXISTING RACK 114-DEMO  
SCALE: 1 1/2" = 1'-0"



6 EXISTING RACK 114-NEW WORK  
SCALE: 1 1/2" = 1'-0"



2 EXIST RACK 2D-122-DEMO  
SCALE: 1 1/2" = 1'-0"




3 EXIST. RACK 2D-122-NEW WORK  
SCALE: 1 1/2" = 1'-0"

Revisions	Date
1	03.05.2015
2	04.28.2015
3	06.14.2015
4	11.04.2015
5	01.15.2016

CONSULTANTS:

**Heapy Engineering**  
MEP Design Technology Planning Commissioning Energy  
Nationally Recognized Leader in Sustainability  
1400 W Dorothy Lane, Dayton, OH 45409-1310  
Ph 937-224-0861 Fax 937-224-5777 www.heapy.com  
Heapy Project No.: 2014-04034 Firm License No.: Q1528



ARCHITECT/ENGINEERS:

**JOHN POE ARCHITECTS**

3131 NEWMARK DRIVE, SUITE 200  
MIAMISBURG, OHIO 45342  
937.461.3290 PHONE  
jpa@johnpoe.com

Drawing Title

**ENLARGED SIGNALS CLOSET PLANS**

Approved: Project Director

Project Title

**RELOCATE PROSTHETICS AND PODIATRY CLINICS**

Location  
**Dayton, Ohio**

Date  
**05.16.2016**

Checked  
**MSG**

Drawn  
**JDK**

Project No.  
VA Project No. **552-15-502**  
JPA Project No. **14006.00**

Building Number  
**999**

Drawing Number  
**E504**

Dwg. of

Office of Construction and Facilities Management

Department of Veterans Affairs

5/13/2016 11:33:11 AM