


REPLACE AIR HANDLER UNITS BUILDING 77

PROJECT NO. 621-11-127
JAMES H. QUILLEN VA MEDICAL CENTER
MOUNTAIN HOME, TENNESSEE

SHEET INDEX

SEQUENCE NUMBER	SHEET NUMBER	SHEET NAME
1	GI1	TITLE SHEET, AREA MAP, SITE PLAN, SHEET INDEX
2	GI2	GENERAL NOTES, PHASING, SYMBOLS, ABBREVIATIONS
3	77-D1	DEMOLITION - 2ND FLOOR
4	77-D2	DEMOLITION - MECHANICAL ROOMS SB-160, FA-140
5	77-D3	DEMOLITION - 3RD FLOOR
6	77-D4	DEMOLITION - ROOF
7	77-MH1	HVAC - 2ND FLOOR
8	77-MH2	HVAC - MECHANICAL ROOMS SB-160, FA-140
9	77-MH3	HVAC - 3RD FLOOR
10	77-MH4	HVAC - ROOF
11	77-MH5	SCHEDULES
12	77-MH6	DETAILS
13	77-MH7	CONTROLS - DIAGRAMS AND POINTS LIST
14	77-MH8	CONTROLS - SEQUENCE OF OPERATIONS
15	77-ES1	ELECTRICAL - ROOMS SB-160, FA-140
16	77-ES2	ELECTRICAL - ROOM 3A-133, ROOF PLAN
17	77-ES3	PANEL SCHEDULES
18	77-ES4	SINGLE LINE DIAGRAM AND MCC SCHEDULE
19	77-HA1	HAZARDOUS MATERIALS
20	77-SS1	ROOF PLAN AND DETAILS



SITE PLAN
NOT TO SCALE



AREA MAP
NOT TO SCALE

DATE	REVISIONS

Entek III
812 Grayson Road
Pleasant Hill, CA 94523
(925) 947-1400
entekiii@comcast.net
BRANCH OFFICE
1000 Parkwood Circle, St. 140
Atlanta, GA 30339
(800) 326-6063




Approved : Project Engineer	Approved : Associate Director
Approved : Supervisory Engineer	Approved : Director
Approved : VP FMS	Approved :

Drawing Title:
TITLE SHEET, AREA MAP
SITE PLAN, SHEET INDEX

Project Title: REPLACE AIR HANDLER UNITS BUILDING 77		Date: 4/24/12
Drawn: BMA		Project No.: 621-11-127
Building Number: 77		Drawing No. GI-1
Checked: PM	Location: JAMES H. QUILLEN VA MEDICAL CENTER MOUNTAIN HOME, TN	Dwg 1 of 20



Department of
Veterans Affairs



NUMBERED NOTES ☒

1. DEMOLISH (E) TERMINAL UNIT. DEMOLISH (E) INLET AND OUTLET DUCTWORK AS REQUIRED FOR INSTALLATION OF NEW TERMINAL UNIT. DEMOLISH (E) VALVES. CAP (E) HHW PIPING TEMPORARILY. DEMOLISH (E) THERMOSTAT. DEMOLISH (E) PNEUMATIC TUBING BACK TO (E) TCP IN ROOM SB-160..

GENERAL NOTES

1. NOT ALL EXISTING UTILITIES LOCATED IN THE CEILING SPACE ARE SHOWN ON THE PLANS. UTILITIES NOT SHOWN INCLUDE BUT ARE NOT LIMITED TO POWER AND COMMUNICATIONS WIRING, AND CONDUIT, CABLE TRAYS, MEDICAL GAS, PLUMBING SERVICES, ETC. A CERTAIN QUANTITY OF THE EXISTING UTILITIES WILL HAVE TO BE RELOCATED AND/OR DEMOLISHED IN ORDER TO INSTALL THE NEW WORK. THE CONTRACTOR SHALL SURVEY THE SITE PRIOR TO BID AND INCLUDE IN HIS PROPOSAL A NECESSARY SUM AS REQUIRED FOR THE RELOCATION AND OR DEMOLITION OF EXISTING UTILITIES. ANY EXISTING UTILITIES WHICH ARE NO LONGER IN SERVICE (AS APPROVED BY THE VA) SHALL BE COMPLETELY DEMOLISHED IN THE AREA OF WORK.
2. SEE SHEETS GI-2 FOR ADDITIONAL WORK REQUIRED BY CONSTRUCTION PHASING.
3. PROVIDE INFECTION CONTROL MEASURES DURING ALL WORK IN THIS AREA. SEE SHEET GI2 "CONSTRUCTION DIRECTIVES."

PHASING


1. ALL WORK ON THIS SHEET IS PHASE 4.

SYMBOLS

- ☒ DEDUCTIVE BID ITEM INDICATOR




SECOND FLOOR PLAN
1/8" = 1'-0"



KEY PLAN
NOT TO SCALE

DATE	REVISIONS



Entek III
812 Grayson Road
Pleasant Hill, CA 94523
(925) 947-1400
entekiii@comcast.net
BRANCH OFFICE
1000 Parkwood Circle, St. 140
Atlanta, GA 30339
(800) 326-6063




Approved : Project Engineer	Approved : Associate Director
Approved : Supervisory Engineer	Approved : Director
Approved : VP FMS	Approved :






Drawing Title:

DEMOLITION - 2ND FLOOR

Project Title: REPLACE AIR HANDLER UNITS BUILDING 77		Date: 4/24/12
Drawn: BMA		Project No.: 621-11-127
Building Number: 77		Drawing No. 77-D1
Checked: PM		Location: JAMES H. DULLEN VA MEDICAL CENTER MOUNTAIN HOME, TN
		Dwg 3 of 20




Department of
Veterans Affairs



MECHANICAL ROOM SB-160 DEMOLITION

1/4" = 1'-0"



MECHANICAL ROOM FA-140-DEMOLITION

1/8" = 1'-0"

NUMBERED NOTES (X)


1. DEMOLISH (E) DISCONNECT. DEMOLISH (E) WIRE AND CONDUIT BACK TO (E) VFD. DEMOLISH (E) WIRE AND CONDUIT BACK TO (E) MCC "MCS".
2. RELOCATE (E) DISCONNECT ADJACENT TO (E) EF-11. EXTEND (E) WIRE AND CONDUIT TO RELOCATED DISCONNECT.
3. DEMOLISH (E) VFD. DEMOLISH (E) WIRE AND CONDUIT BACK TO (E) ISOLATION TRANSFORMER.
4. DEMOLISH (E) ISOLATION TRANSFORMER. DEMOLISH (E) WIRE AND CONDUIT BACK TO (E) MCC "MCS".
5. DEMOLISH (E) STARTERS, BREAKERS, ETC IN COMPARTMENTS 1 AND 2.
6. DEMOLISH (E) PNEUMATIC CONTROL PANEL INCLUDING SUPPORTS. DEMOLISH (E) PNEUMATIC TUBING BACK TO ALL CONTROL DEVICES. DEMOLISH (E) AIR CONNECTION BACK TO CONTROL AIR COMPRESSOR AND CAP.
7. DEMOLISH (E) AIR HANDLER UNIT INCLUDING CASING, DAMPERS, COILS, FILTERS, CONTROL ACTUATORS, ETC.
8. DEMOLISH (E) PIPING TO POINT SHOWN INCLUDING VALVES, HANGERS, FITTINGS, INSULATION..
9. DEMOLISH (E) DUCTWORK TO POINT SHOWN INCLUDING HANGERS, DAMPERS, INSULATION, ETC.
10. DEMOLISH (E) SOUND ATTENUATOR.
11. DEMOLISH (E) OR PIPING BACK TO MAIN AND CAP INCLUDING HANGERS, VALVES, INSULATION, ETC.
12. CONNECT TEMPORARY 36" DIAMETER DUCTING AT THIS POINT. ROUTE DUCTING UP THROUGH NEW RELIEF DUCT ROOF PENETRATION AND CONNECT TO TEMPORARY AIR HANDLER. SEE SHEET 77-MD4 AND 77-MH4 FOR LOCATION OF TEMPORARY AIR HANDLER RTU-1.
13. RELOCATE (E) 3" CONDUITS AS REQUIRED FOR INSTALLATION OF NEW RELIEF DUCT RISER.

GENERAL NOTES

1. NOT ALL EXISTING UTILITIES LOCATED IN THE CEILING SPACE ARE SHOWN ON THE PLANS. UTILITIES NOT SHOWN INCLUDE BUT ARE NOT LIMITED TO POWER AND COMMUNICATIONS WIRING, AND CONDUIT, CABLE TRAYS, MEDICAL GAS, PLUMBING SERVICES, ETC. A CERTAIN QUANTITY OF THE EXISTING UTILITIES WILL HAVE TO BE RELOCATED AND/OR DEMOLISHED IN ORDER TO INSTALL THE NEW WORK. THE CONTRACTOR SHALL SURVEY THE SITE PRIOR TO BID AND INCLUDE IN HIS PROPOSAL A NECESSARY SUM AS REQUIRED FOR THE RELOCATION AND OR DEMOLITION OF EXISTING UTILITIES. ANY EXISTING UTILITIES WHICH ARE NO LONGER IN SERVICE (AS APPROVED BY THE VA) SHALL BE COMPLETELY DEMOLISHED IN THE AREA OF WORK.
2. SEE SHEETS GI-2 FOR ADDITIONAL WORK REQUIRED BY CONSTRUCTION PHASING.
3. PROVIDE INFECTION CONTROL MEASURES DURING ALL WORK IN THIS AREA. SEE SHEET GI2 "CONSTRUCTION DIRECTIVES."

PHASING


1. ALL WORK ON THIS SHEET IS PHASE 1.



KEY PLAN

NOT TO SCALE

DATE	REVISIONS




Entek III
812 Grayson Road
Pleasant Hill, CA 94523
(925) 947-1400
entekiii@comcast.net
BRANCH OFFICE
1000 Parkwood Circle, St. 140
Atlanta, GA 30339
(800) 326-6063




Approved : Project Engineer	Approved : Associate Director
Approved : Supervisory Engineer	Approved : Director
Approved : VP FMS	Approved :

Drawing Title:
DEMOLITION- MECHANICAL ROOM SB-160, FA-140

Project Title:	Date:
REPLACE AIR HANDLER UNITS BUILDING 77	4/24/12
Drawn:	Project No.:
BMA	621-11-127
Checked:	Drawing No.
PM	77-D2
Location:	Dwg 4 of 20
JAMES H. GULLEN VA MEDICAL CENTER MOUNTAIN HOME, TN	



Department of
Veterans Affairs



THIRD FLOOR PLAN
1/8" = 1'0"

NUMBERED NOTES (X)

1. DEMOLISH (E) TU TERMINAL UNIT. DEMOLISH SECTION OF (E) INLET AND OUTLET DUCTWORK AS REQUIRED FOR INSTALLATION OF NEW UNIT. DEMOLISH (E) VALVES, SENSORS, ETC. CAP (E) HHW PIPING TEMPORARILY. DEMOLISH (E) THERMOSTAT. DEMOLISH (E) PNEUMATIC TUBING FROM THERMOSTAT TO UNIT, AND FROM UNIT TO TCP.
2. DEMOLISH (E) PNEUMATIC TCP. DEMOLISH (E) PNEUMATIC TUBING FROM PANEL BACK TO COMPRESSOR. FILL-IN, TAPE, AND PAINT (E) RECESS.
3. DEMOLISH (E) STEAM HUMIDIFIER INCLUDING STEAM DISPERSION TUBE, VALVES, ETC. DEMOLISH PNEUMATIC TUBING BACK TO TCP.
4. DEMOLISH (E) TERMINAL UNIT. DEMOLISH (E) INLET DUCTWORK BACK TO MAIN AND CAP. DEMOLISH (E) VALVES, SENSORS, ETC. DEMOLISH (E) HHW PIPING BACK TO MAIN AND CAP. DEMOLISH (E) THERMOSTAT. DEMOLISH (E) PNEUMATIC TUBING FROM THERMOSTAT TO UNIT, AND FROM UNIT TO TCP.
5. DEMOLISH (E) INTERNALLY INSULATED DUCT MAIN. VERIFY AND RECORD DUCT SIZES PRIOR TO DEMOLITION.
6. DEMOLISH (E) FIRE/SMOKE DAMPER. DEMOLISH (E) DUCT SMOKE DETECTOR. DEMOLISH (E) FIRE ALARM WIRING BACK TO SOURCE PANEL.
7. DEMOLISH (E) 2" CHS / CHR FROM ROOFTOP UNIT BACK TO POINT SHOWN INCLUDING VALVES, HANGERS, INSULATION, ETC.
8. DEMOLISH (E) 1 1/2" MPS AND 1 1/2" CR INCLUDING HANGERS, VALVES, INSULATION, ETC..
9. DEMOLISH (E) 1 1/8" HHWS / HHWR PIPING FROM MAIN UP TO ROOFTOP UNIT INCLUDING VALVES, INSULATION, ETC.
10. DEMOLISH (E) DUCT RISER. SIZES INDICATED ARE APPROXIMATE. VERIFY SIZE IN FIELD PRIOR TO DEMOLITION.

GENERAL NOTES


1. NOT ALL EXISTING UTILITIES LOCATED IN THE CEILING SPACE ARE SHOWN ON THE PLANS. UTILITIES NOT SHOWN INCLUDE BUT ARE NOT LIMITED TO POWER AND COMMUNICATIONS WIRING, AND CONDUIT, CABLE TRAYS, MEDICAL GAS, PLUMBING SERVICES, ETC. A CERTAIN QUANTITY OF THE EXISTING UTILITIES WILL HAVE TO BE RELOCATED AND/OR DEMOLISHED IN ORDER TO INSTALL THE NEW WORK. THE CONTRACTOR SHALL SURVEY THE SITE PRIOR TO BID AND INCLUDE IN HIS PROPOSAL A NECESSARY SUM AS REQUIRED FOR THE RELOCATION AND OR DEMOLITION OF EXISTING UTILITIES. ANY EXISTING UTILITIES WHICH ARE NO LONGER IN SERVICE (AS APPROVED BY THE VA) SHALL BE COMPLETELY DEMOLISHED IN THE AREA OF WORK.
2. SEE SHEETS G1-2 FOR ADDITIONAL WORK REQUIRED BY CONSTRUCTION PHASING.
3. PROVIDE INFECTION CONTROL MEASURES DURING ALL WORK IN THIS AREA. SEE SHEET G12 "CONSTRUCTION DIRECTIVES."

PHASING

1. WORK INVOLVING TERMINAL UNITS FOR 77-AC8 IS PHASE 5. WORK INVOLVING TERMINAL UNITS FOR 77-AC10 IS PHASE 6. WORK INVOLVING 77-AC8 IS PHASE 2. WORK INVOLVING 77-AC-10 IS PHASE 3. PROVIDE TEMPORARY COOLING / HEATING AS PER PHASING NOTES ON SHEET G12.


SYMBOLS

- (X) DEDUCTIVE BID ITEM INDICATOR



KEY PLAN
NOT TO SCALE

DATE	REVISIONS




Entek III
812 Grayson Road
Pleasant Hill, CA 94523
(925) 947-1400
entekiii@comcast.net
BRANCH OFFICE
1000 Parkwood Circle, St. 140
Atlanta, GA 30339
(800) 326-6063




Approved : Project Engineer	Approved : Associate Director
Approved : Supervisory Engineer	Approved : Director
Approved : VP FMS	Approved :

Drawing Title:
DEMOLITION - 3RD FLOOR

Project Title: REPLACE AIR HANDLER UNITS BUILDING 77		Date: 4/24/12
Drawn: BMA		Project No.: 621-11-127
Checked: PM		Drawing No. 77-D3
Location: JAMES H. DULAN VA MEDICAL CENTER MOUNTAIN HOME, TN		Dwg 5 of 20



Department of
Veterans Affairs



NUMBERED NOTES ⓧ


1. DEMOLISH (E) AIR HANDLER UNIT. DEMOLISH (E) INSULATED CURB. DISCONNECT (E) DUCTWORK. DEMOLISH (E) DUCT TRANSITIONS.
2. DEMOLISH (E) DISCONNECT. DEMOLISH (E) POWER WIRING AND CONDUIT BACK TO SOURCE PANEL.
3. DEMOLISH (E) PNEUMATIC ACTUATORS AND SENSORS. DEMOLISH (E) PNEUMATIC TUBING BACK TO SOURCE PANEL.
4. DEMOLISH (E) VALVES AND FITTINGS. DEMOLISH (E) PIPING DOWN TO CEILING SPACE.
5. DEMOLISH (E) CONDENSATE DRAIN LINE FROM UNIT TO ROOF DRAIN.
6. DISCONNECT (E) LIGHTNING PROTECTION CABLES AND RODS AND RESERVE.
7. (E) ROOF. PROTECT ROOF FROM DAMAGE DURING CONSTRUCTION.
8. DEMOLISH (E) J-BOX. DEMOLISH (E) WIRE AND CONDUIT BACK TO PANEL "3HN" IN ROOM 3A133. DEMOLISH (E) BREAKER AT PANEL.
9. DEMOLISH (E) DUCT RISER. VERIFY RISER DIMENSIONS IN FIELD.
10. REMOVE (E) CONCRETE PAVERS AND STORE.
11. RELOCATE (E) ROOF DRAIN.
12. DEMOLISH (E) ROOFING INCLUDING MEMBRANE, INSULATION, ETC. DEMOLISH (E) STEEL DECKING UNDER FOOTPRINT OF NEW UNIT.

GENERAL NOTES

1. NOT ALL EXISTING UTILITIES LOCATED IN THE CEILING SPACE ARE SHOWN ON THE PLANS. UTILITIES NOT SHOWN INCLUDE BUT ARE NOT LIMITED TO POWER AND COMMUNICATIONS WIRING, AND CONDUIT, CABLE TRAYS, MEDICAL GAS, PLUMBING SERVICES, ETC. A CERTAIN QUANTITY OF THE EXISTING UTILITIES WILL HAVE TO BE RELOCATED AND/OR DEMOLISHED IN ORDER TO INSTALL THE NEW WORK. THE CONTRACTOR SHALL SURVEY THE SITE PRIOR TO BID AND INCLUDE IN HIS PROPOSAL A NECESSARY SUM AS REQUIRED FOR THE RELOCATION AND OR DEMOLITION OF EXISTING UTILITIES. ANY EXISTING UTILITIES WHICH ARE NO LONGER IN SERVICE (AS APPROVED BY THE VA) SHALL BE COMPLETELY DEMOLISHED IN THE AREA OF WORK.
2. SEE SHEETS GI-2 FOR ADDITIONAL WORK REQUIRED BY CONSTRUCTION PHASING.
3. PROVIDE INFECTION CONTROL MEASURES DURING ALL WORK IN THIS AREA. SEE SHEET GI2 "CONSTRUCTION DIRECTIVES."
4. SEE SHEET 77-HA1 FOR HAZARDOUS MATERIALS REMOVAL.

PHASING

1. WORK INVOLVING 77-AC8 IS PHASE 2. WORK INVOLVING 77-AC-10 IS PHASE 3. PROVIDE TEMPORARY COOLING / HEATING AS PER PHASING NOTES ON SHEET GI2.




KEY PLAN
NOT TO SCALE

ROOF PLAN
1/8" = 1'0"



DATE	REVISIONS




Entek III
812 Grayson Road
Pleasant Hill, CA 94523
(925) 947-1400
entekiii@comcast.net
BRANCH OFFICE
1000 Parkwood Circle, St. 140
Atlanta, GA 30339
(800) 326-6063




Approved : Project Engineer	Approved : Associate Director
Approved : Supervisory Engineer	Approved : Director
Approved : VP FMS	Approved :

Drawing Title:
DEMOLITION - ROOF

Project Title: REPLACE AIR HANDLER UNITS BUILDING 77	Date: 4/24/12
Drawn: BMA	Building Number: 77
Checked: PM	Location: JAMES H. DUALIN VA MEDICAL CENTER MOUNTAIN HOME, TN
Project No.: 621-11-127	Drawing No. 77-D4
	Dwg 6 of 20



Department of
Veterans Affairs



SECOND FLOOR PLAN
1/8" = 1'-0"

NUMBERED NOTES ⓧ

1. INSTALL NEW TU TERMINAL UNIT. INSTALL NEW VALVE PACKAGE AND RECONNECT TO (E) HHW PIPING. INSTALL INLET AND OUTLET DUCT TRANSITIONS AND RECONNECT TO (E) DUCTWORK. INSTALL DDC CONTROLS, CONTROL WIRING, AND POWER WIRING. INSTALL THERMOSTAT IN LOCATION OF DEMOLISHED THERMOSTAT. PATCH AND PAINT WALL AS REQUIRED AT THERMOSTAT LOCATION. SEE DETAIL 6 ON SHEET 77-MH7 AND DETAIL 2 ON SHEET 77-MH7. TYP.
2. RECONSTRUCT AND/OR PATCH, TAPE, AND PAINT (E) GYPSUM BOARD CEILING AFTER INSTALLATION OF NEW EQUIPMENT IS COMPLETE. REINSTALL (E) ACCESS DOORS AT LOCATIONS THAT PERMIT SERVICING OF TERMINAL UNIT CONTROLLER AND VALVES.

GENERAL NOTES


1. NOT ALL EXISTING UTILITIES LOCATED IN THE CEILING SPACE ARE SHOWN ON THE PLANS. UTILITIES NOT SHOWN INCLUDE BUT ARE NOT LIMITED TO POWER AND COMMUNICATIONS WIRING, AND CONDUIT, CABLE TRAYS, MEDICAL GAS, PLUMBING SERVICES, ETC. A CERTAIN QUANTITY OF THE EXISTING UTILITIES WILL HAVE TO BE RELOCATED AND/OR DEMOLISHED IN ORDER TO INSTALL THE NEW WORK. THE CONTRACTOR SHALL SURVEY THE SITE PRIOR TO BID AND INCLUDE IN HIS PROPOSAL A NECESSARY SUM AS REQUIRED FOR THE RELOCATION AND OR DEMOLITION OF EXISTING UTILITIES. ANY EXISTING UTILITIES WHICH ARE NO LONGER IN SERVICE (AS APPROVED BY THE VA) SHALL BE COMPLETELY DEMOLISHED IN THE AREA OF WORK.
2. SEE SHEETS G1-2 FOR ADDITIONAL WORK REQUIRED BY CONSTRUCTION PHASING.
3. PROVIDE INFECTION CONTROL MEASURES DURING ALL WORK IN THIS AREA. SEE SHEET G12 "CONSTRUCTION DIRECTIVES."

PHASING

1. ALL WORK ON THIS SHEET IS PHASE 4.


SYMBOLS

- ⓧ DEDUCTIVE BID ITEM INDICATOR



KEY PLAN
NOT TO SCALE

DATE	REVISIONS




Entek III
812 Grayson Road
Pleasant Hill, CA 94523
(925) 947-1400
entekiii@comcast.net
BRANCH OFFICE
1000 Parkwood Circle, St. 140
Atlanta, GA 30339
(800) 326-6063








Approved : Project Engineer	Approved : Associate Director
Approved : Supervisory Engineer	Approved : Director
Approved : VP FMS	Approved :

HVAC - 2ND FLOOR

Project Title: REPLACE AIR HANDLER UNITS BUILDING 77		Date: 4/24/12
Drawn: BMA		Building Number: 77
Checked: PM		Location: JAMES H. SULLIVAN VA MEDICAL CENTER MOUNTAIN HOME, TN
Project No.: 621-11-127		Drawing No. 77-MH1
		Dwg 7 of 20



Department of
Veterans Affairs



THIRD FLOOR PLAN
1/8" = 1'0"

NUMBERED NOTES (X)

1. INSTALL NEW TU TERMINAL UNIT. INSTALL NEW VALVE PACKAGE AND RECONNECT TO (E) HHW PIPING. INSTALL INLET AND OUTLET DUCT TRANSITIONS AND RECONNECT TO (E) DUCTWORK. INSTALL DDC CONTROLS, CONTROL WIRING, AND POWER WIRING. SEE DETAIL 5 ON SHEET 77-MH7. TYP. INSTALL THERMOSTAT IN SAME LOCATION AS DEMOLISHED UNIT. PATCH AND PAINT WALL AS REQUIRED AT THERMOSTAT LOCATIONS.
2. INSTALL DDC CONTROL PANELS FOR 77-AC8 AND 77-AC9.
3. PATCH, TAPE, AND PAINT (E) HARD CEILING..
4. CAP (E) DUCT MAIN AT LOCATION OF REMOVED TERMINAL UNIT. FILL-IN AND SEAL (E) WALL PENETRATION.
5. INSTALL DUCT MAINS INCLUDING INSULATION, HANGERS, DAMPERS. DUCT MAINS TO MATCH (E) DEMOLISHED SIZES.
6. DUCT SMOKE DETECTOR. WIRE TO (E) ALARM PANEL AND AIR HANDLER SAFETY SHUTDOWN CIRCUIT.
7. 2 1/2" CHS / CHR PIPING INCLUDING INSULATION, HANGERS, ETC.
8. 2 1/2" CHS / CHR PIPING, EXTEND PIPING TO NEW PENETRATION POINT, AND PENETRATE THE ROOF TO NEW AIR HANDLING UNIT PIPE CABINET.
9. 1 1/2" HHWS / HHWR PIPING. CONNECT TO (E) MAIN, EXTEND PIPING TO NEW PENETRATION POINT, AND PENETRATE ROOF UP TO NEW AIR HANDLING UNIT PIPE CABINET.
10. 1 1/2" MPS, 1 1/2" CR. CONNECT TO (E) MAIN, EXTEND PIPING TO NEW PENETRATION POINT, AND PENETRATE ROOF UP TO AIR HANDLER PIPING CABINET.
11. PATCH AND SEAL DUCT MAIN AT POINT OF (E) HUMIDIFIER DEMOLITION.
12. DUCT RISER TO/FROM UNIT. TRANSITION TO DUCT MAIN.
13. DRIP LEG AT BOTTOM OF MPS RISER. SEE DETAIL 3 ON SHEET 77-MH6.
14. PATCH AND SEAL ABANDONED PIPE PENETRATION.

GENERAL NOTES


1. NOT ALL EXISTING UTILITIES LOCATED IN THE CEILING SPACE ARE SHOWN ON THE PLANS. UTILITIES NOT SHOWN INCLUDE BUT ARE NOT LIMITED TO POWER AND COMMUNICATIONS WIRING, AND CONDUIT, CABLE TRAYS, MEDICAL GAS, PLUMBING SERVICES, ETC. A CERTAIN QUANTITY OF THE EXISTING UTILITIES WILL HAVE TO BE RELOCATED AND/OR DEMOLISHED IN ORDER TO INSTALL THE NEW WORK. THE CONTRACTOR SHALL SURVEY THE SITE PRIOR TO BID AND INCLUDE IN HIS PROPOSAL A NECESSARY SUM AS REQUIRED FOR THE RELOCATION AND/OR DEMOLITION OF EXISTING UTILITIES. ANY EXISTING UTILITIES WHICH ARE NO LONGER IN SERVICE (AS APPROVED BY THE VA) SHALL BE COMPLETELY DEMOLISHED IN THE AREA OF WORK.
2. SEE SHEETS G1-2 FOR ADDITIONAL WORK REQUIRED BY CONSTRUCTION PHASING.
3. PROVIDE INFECTION CONTROL MEASURES DURING ALL WORK IN THIS AREA. SEE SHEET G12 "CONSTRUCTION DIRECTIVES."

PHASING

1. WORK INVOLVING TERMINAL UNITS FOR 77-AC8 IS PHASE 5. WORK INVOLVING TERMINAL UNITS FOR 77-AC10 IS PHASE 6. WORK INVOLVING 77-AC8 IS PHASE 2. WORK INVOLVING 77-AC-10 IS PHASE 3. PROVIDE TEMPORARY COOLING / HEATING AS PER PHASING NOTES ON SHEET G12.

SYMBOLS

- (X) DEDUCTIVE BID ITEM INDICATOR



KEY PLAN
NOT TO SCALE

DATE	REVISIONS

Entek III
812 Grayson Road
Pleasant Hill, CA 94523
(925) 947-1400
entekiii@comcast.net
BRANCH OFFICE
1000 Parkwood Circle, St. 140
Atlanta, GA 30339
(800) 326-6063




Approved : Project Engineer	Approved : Associate Director
Approved : Supervisory Engineer	Approved : Director
Approved : VP FMS	Approved :

Drawing Title:
HVAC - 3RD FLOOR


Project Title:	Date:
REPLACE AIR HANDLER UNITS BUILDING 77	4/24/12
Drawn:	Project No.:
BMA	621-11-127
Building Number:	Drawing No.
77	77-MH3
Checked:	Location:
PM	JAMES H. GULLEN VA MEDICAL CENTER MOUNTAIN HOME, TN
	Dwg 9 of 20






NUMBERED NOTES ⓧ

1. INSTALL AIR HANDLER UNIT INCLUDING POWER WIRING, ELECTRICAL, ETC.
2. INSTALL 30" HIGH INSULATED ROOF CURB. SEE SHEET 77-SS1 FOR STRUCTURAL REINFORCEMENT. PIPE CABINETS SHALL INCLUDE ROOF CURBS. FLASH AND SEAL ROOF CURB INCLUDING PIPING CABINETS. SEE DETAIL 14 ON SHEET 77-MH6.
3. INSTALL INSULATED DUCT TRANSITION FROM AIR HANDLER FACTORY OPENING TO DUCT RISER. TRANSITION ELBOWS SHALL INCORPORATE DOUBLE-THICKNESS ACOUSTICAL TURNING VANES. PROVIDE AND INSTALL DUCT SUPPORTS INDEPENDENT OF UNIT.
4. 1 1/2" CONDENSATE DRAIN FROM AIR HANDLER TO NEAREST ROOF DRAIN. THE DRAIN SHALL HAVE A MINIMUM SLOPE OF 1/8" PER FOOT IN THE DIRECTION OF FLOW. SEE DETAIL 10 ON SHEET 77-MH6.
5. RELOCATED (E) ROOF DRAIN. EXTEND (E) DRAIN LEADER AND RECONNECT. FLASH AND SEAL.
6. REHEAT COIL. AIR HANDLER PIPING CABINET DIMENSION SHALL BE SIZED TO ACCOMMODATE THE REHEAT COIL PIPING, PUMP, VALVES, ELECTRICAL, ETC. SEE DETAIL 8 ON SHEET 77-MH6.
7. STEAM HUMIDIFIER. AIR HANDLER PIPING CABINET DIMENSION SHALL BE SIZED TO ACCOMMODATE THE HUMIDIFIER COIL PIPING, VALVES, ETC. SEE DETAIL 5 ON SHEET 77-MH6.
8. CHILLED WATER COIL. AIR HANDLER PIPING CABINET DIMENSION SHALL BE SIZED TO ACCOMMODATE THE CHILLED WATER COIL PIPING, VALVES, ETC. SEE DETAIL 9 ON SHEET 77-MH6.
9. RELIEF HOOD ON 18" HIGH CURB. FLASH AND SEAL CURB INTO (E) ROOF. OPENING SHALL BE USED FOR TEMPORARY AIR DUCTING FOR THE 77-AC6 REPLACEMENT. WHEN THE TEMPORARY AIR IS NO LONGER REQUIRED SECURE RELIEF HOOD TO CURB.
10. (E) RTU-1. THIS UNIT MAY BE USED AS A SOURCE OF TEMPORARY AIR DURING THE REPLACEMENT OF 77-AC6. PROVIDED 460V, 82 MCA TEMPORARY POWER CABLING TO UNIT AND A PROPERLY SIZED SOURCE BREAKER, 100A MOP. COORDINATE WITH FACILITY FOR POWER SOURCE LOCATION.
11. PIPING CABINETS, HOODS, ENCLOSURES, VFDs NOT SHOWN. NOT ALL ACCESS DOORS SHOWN IN ELEVATION PROVIDE ACCESS DOORS ON EVERY SECTION.
12. DUCT RISER TO/FROM SPACE. FLASH AND SEAL TO (E) ROOF.
13. REINSTALL PAVERS COMPLETELY AROUND NEW UNIT. PROVIDE ADDITIONAL PAVERS AS REQUIRED. TYP.




⑪ AIR HANDLER AC-8 ELEVATION

1/4" = 1'-0"



⑪ AIR HANDLER AC-10 ELEVATION

1/4" = 1'-0"



KEY PLAN

NOT TO SCALE

IF THIS SHEET DOES NOT MEASURE 42" X 30" IT IS A REDUCED PRINT. SCALE ACCORDINGLY.

GENERAL NOTES


1. SEE SHEETS GI-2 FOR ADDITIONAL WORK REQUIRED BY CONSTRUCTION PHASING.
2. PROVIDE INFECTION CONTROL MEASURES DURING ALL WORK IN THIS AREA. SEE SHEET GI2 "CONSTRUCTION DIRECTIVES."
3. SEE SHEET 77-HA1 FOR HAZARDOUS MATERIALS REMOVAL.

PHASING

1. WORK INVOLVING 77-AC8 IS PHASE 2. WORK INVOLVING 77-AC-10 IS PHASE 3. PROVIDE TEMPORARY COOLING / HEATING AS PER PHASING NOTES ON SHEET GI2.

ROOF PLAN

1/8" = 1'-0"



Entek III
812 Grayson Road
Pleasant Hill, CA 94523
(925) 947-1400
entekiii@comcast.net
BRANCH OFFICE
1000 Parkwood Circle, St. 140
Atlanta, GA 30339
(800) 326-6063



Approved : Project Engineer

Approved : Associate Director

Approved : Supervisory Engineer

Approved : Director

Approved : VP FMS

Approved :

HVAC - ROOF

Drawing Title:

Project Title:
**REPLACE AIR HANDLER
UNITS BUILDING 77**

Date:
4/24/12

Project No.:
621-11-127

Drawn:
BMA


Building Number:
77

Drawing No.
77-MH4





Checked:
PM

Location:
JAMES H. GULLEN VA MEDICAL CENTER
MOUNTAIN HOME, TN

Dwg 10 of 20



Department of
Veterans Affairs



AIR HANDLING UNIT SCHEDULE															
MARK	LOCATION	AREA AND/OR BLDG SERVED	TYPE	AIRFLOW			SUPPLY FAN MARK	EXHAUST FAN MARK	PREFILTER MARK	AFTER FILTER MARK	PREHEAT COIL MARK	COOLING COIL MARK	REHEAT COIL	HUMIDIFIER MARK	WEIGHT (LBS)
				SUPPLY	MIN. O.A.	RETURN									
				CFM	CFM	CFM									
77-AC6	SA-132	RADIOLOGY 2ND FLOOR	-	22192	5530	16662	SF-6	RF-6	PF-6	AF-6A/B	PHC-6	CC-6	---	SH-6	15667
77-AC8	ROOF	DENTAL CLINIC 3RD FLOOR	-	11063	2901	8162	SF-8	RF-8	PF-8	AF-8A/B	PHC-8	CC-8	---	SH-8	9374
77-AC10	ROOF	IRM 3RD FLOOR	-	9915	2349	7566	SF-10	RF-10	PF-10	AF-10	PHC-10	CC-10	---	SH-10	8374

AIR HANDLERS SHALL BE BALANCED TO THE SUM OF THE TERMINAL UNIT SCHEDULED MAXIMUM AIRFLOWS.

FAN SCHEDULE															
MARK	LOCATION	SYSTEM AND/OR SERVICE	AIRFLOW	TSP	FAN							MOTOR ELECTRICAL			
					TYPE	WHEEL	CLASS	ARRANGEMENT, ROTATION, AND DISCHARGE	DIAMETER	DRIVE	FAN MAX RPM	NOMINAL POWER		PHASE/ VOLT	RPM
												BHP	HP		
SF-6	SA-132	77-AC6	22192	8.3	DWDI	AIRFOIL	2	3, CW, THD	28	BELT	1640	39.8	40	3/460	1800
RF-6	SA-132	77-AC6	16662	1.2	DWDI	AIRFOIL	2	3, CW, THD	32	BELT	656	4.9	7.5	3/460	1800
SF-8	ROOF	77-AC8	11063	7.4	DWDI	AIRFOIL	2	3, CW, THD	20	BELT	2296	19.2	20	3/460	1800
RF-8	ROOF	77-AC8	8162	1.2	DWDI	AIRFOIL	2	3, CW, THD	22	BELT	982	2.7	3	3/460	1800
SF-10	ROOF	77-AC10	9915	6.2	DWDI	AIRFOIL	2	3, CW, THD	20	BELT	2086	14.4	15	3/460	1800
RF-10	ROOF	77-AC10	7566	1.3	DWDI	AIRFOIL	2	3, CW, THD	22	BELT	976	2.6	3	3/460	1800

CHILLED WATER COOLING COIL SCHEDULE															
MARK	SYSTEM AND/OR SERVICE	AIRFLOW	MAX FACE VELOCITY	APD	EAT		LAT		TOTAL CAPACITY	SENSIBLE CAPACITY	CIRCULATING FLUID				
		CFM	FPM	IN WG	Db	Wb	Db	Wb			FLOW	EWT	LWT	WPD	ROWS
					*F	*F	*F	*F			GPM	*F	*F	FT	
CC-6	77-AC6	22192	452	0.8	80.2	66.4	51.7	51.6	980	697	122	45	61	20	8
CC-8	77-AC8	11063	532	1.2	80.2	66.4	51.7	51.6	489	347	61	45	61	19	8
CC-6	77-AC6	9915	476	1.0	80.2	66.4	51.7	51.6	438	311	55	45	61	16	8

HOT WATER PREHEAT COIL SCHEDULE												
MARK	SYSTEM AND/OR SERVICE	AIRFLOW	MAX FACE VELOCITY	APD	TEMPERATURES		TOTAL MIN CAPACITY	HOT WATER				
					EAT	LAT		FLOW	EWT	LWT	WPD	ROWS
		CFM	FPM	IN WG	*F	*F		MBH	GPM	*F	*F	
PH-8	77-AC8	11063	651	0.2	25	55	360	16	180	135	7.5	1
PH-10	77-AC10	9915	583	0.1	25	55	322	12	180	126	4.5	1

STEAM PREHEAT COIL SCHEDULE (IFB)											
MARK	SYSTEM AND/OR SERVICE	AIRFLOW	MAX FACE VELOCITY	APD	TEMPERATURES		TOTAL MIN CAPACITY	STEAM			
		CFM	FPM	IN WG	EAT	LAT		FLOW	PSIG	TRAP	ROWS
					*F	*F		MBH	LBS/HR		
PH-6	77-AC6	11096	414	0.1	25	53	335	352	25	704	1

STEAM HUMIDIFER SCHEDULE									
MARK	SYSTEM AND/OR SERVICE	HUMIDIFIER TYPE	AIRFLOW	NO. OF MANIFOLDS	EA		LA	STEAM	
			CFM		Db	%RH	%RH	PRESSURE	FLOW
					*F			PSIG	LBS/HR
SH-6	77-AC6	DISPERSION TUBE	22192	1	65	26	50	25	337
SH-8	77-AC8	DISPERSION TUBE	11063	1	65	26	50	25	168
SH-10	77-AC10	DISPERSION TUBE	6700	1	65	26	50	25	150

PUMP SCHEDULE										
MARK	SYSTEM AND/OR SERVICE	TYPE	CIRCULATING FLUID				ELECTRICAL MOTOR			
			FLUID	FLOW	HEAD	TEMPERATURE	NOMINAL POWER	PHASE	VOLT	MAX RPM
				GPM	FT	*F	HP			
HWP-8	PREHEAT	INLINE	HHW	16	20	180	1/4	1	120	1750
HWP-10	PREHEAT	INLINE	HHW	12	15	180	1/4	1	120	1750

AIR FILTER SCHEDULE			
MARK	MERV RATING	AIRFLOW	APD
		CFM	MID-LIFE
			IN WG
PF-6	8	SEE AHU SCHEDULE	0.627
PF-8	8	SEE AHU SCHEDULE	0.654
PF-10	8	SEE AHU SCHEDULE	0.632
AF-6A	11	SEE AHU SCHEDULE	0.715
AF-6B	14	SEE AHU SCHEDULE	0.847
AF-8A	11	SEE AHU SCHEDULE	0.737
AF-8B	14	SEE AHU SCHEDULE	0.774
AF-10	13	SEE AHU SCHEDULE	0.828

ROOF CURB	
MARK	DESCRIPTION
RC-8, 10	30" HIGH ROOF CURB WITH 1½" FACED INSULATION. FULLY-WELDED CONSTRUCTION WITH LOAD-DISTRIBUTING INTERNAL REINFORCEMENT. CURB SHALL BE CERTIFIED TO COMPLETELY SUPPORT WEIGHT OF AIR HANDLING UNIT AND INCLUDE ALL NECESSARY GASKETING, CLOSURE ANGLES, ETC. CURB SHALL BE CONSTRUCTED OF PRIMED AND PAINTED STEEL.

TERMINAL UNIT SCHEDULE						
SYSTEM	TAG	INLET (IN)	CFM		MAX INLET SP (INWG)	GPM
			MAX	MIN		
AC-6	TU2-1	10	750	750	0.75	2.0
AC-6	TU2-2	10	900	900	0.75	2.0
AC-6	TU2-3	6	360	360	0.75	1.0
AC-6	TU2-4*	8	580	580	0.75	3.0
AC-6	TU2-5					
AC-6	TU2-6	6	340	340	0.75	1.0
AC-6	TU2-7	8	410	410	0.75	1.5
AC-6	TU2-8	8	405	405	0.75	1.5
AC-6	TU2-9	8	430	430	0.75	1.5
AC-6	TU2-10*	10	800	800	0.75	2.0
AC-6	TU2-11	8	460	460	0.75	1.5
AC-6	TU2-12	12	1000	1000	0.75	3.0
AC-6	TU2-13	10	620	620	0.75	2.0
AC-6	TU2-14	8	550	550	0.75	1.5
AC-6	TU2-15*	10	800	800	0.75	2.0
AC-6	TU2-16	8	490	490	0.75	1.5
AC-6	TU2-17	8	560	560	0.75	1.5
AC-6	TU2-18	8	410	410	0.75	1.5
AC-6	TU2-19	10	790	790	0.75	2.0
AC-6	TU2-20	10	800	800	0.75	2.0
AC-6	TU2-21*	10	800	800	0.75	2.0
AC-6	TU2-22	6	280	280	0.75	1.0
AC-6	TU2-23*	12	980	980	0.75	3.0
AC-6	TU2-24	8	470	470	0.75	1.5
AC-6	TU2-25	8	480	480	0.75	1.5
AC-6	TU2-26	10	705	705	0.75	2.0
AC-6	TU2-27	8	560	560	0.75	1.5
AC-6	TU2-28	8	480	480	0.75	1.6
AC-6	TU2-29	8	370	370	0.75	1.5
AC-6	TU2-30	8	430	430	0.75	1.5
AC-6	TU2-31	6	150	150	0.75	1.0
AC-10	TU3-1*	16	1925	963	0.60	6.0
AC-10	TU3-2	6	110	55	0.40	0.5
AC-10	TU3-3*	14	1575	788	0.60	6.0
AC-10	TU3-4	10	775	388	0.50	2.0
AC-10	TU3-5	10	570	285	0.40	2.0
AC-10	TU3-6	10	295	295	0.40	1.0
AC-10	TU3-7					
AC-10	TU3-8	8	340	170	0.40	1.0
AC-10	TU3-9*	12	650	325	0.50	4.0
AC-10	TU3-10	12	685	343	0.50	4.0
AC-10	TU3-11	12	675	338	0.50	4.0
AC-10	TU3-12	12	770	385	0.50	4.0
AC-8	TU3-13*	12	910	455	0.50	4.0
AC-8	TU3-14	6	95	95	0.40	0.5
AC-8	TU3-15	8	240	240	0.40	1.0
AC-8	TU3-16	12	905	905	0.40	2.0
AC-8	TU3-17	6	160	80	0.40	0.5
AC-8	TU3-18	8	285	285	0.40	1.0
AC-8	TU3-19*	14	1420	1420	0.60	6.0
AC-8	TU3-20	10	565	283	0.40	2.0
AC-8	TU3-21	16	1900	1900	0.75	6.0
AC-8	TU3-22	8	500	250	0.40	1.0
AC-8	TU3-23	8	210	210	0.40	1.0
AC-8	TU3-24	12	895	895	0.40	2.0
AC-8	TU3-25	10	355	355	0.50	2.0
AC-8	TU3-26	10	300	300	0.50	2.0
AC-8	TU3-27	10	455	455	0.50	2.0
AC-8	TU3-28	10	505	505	0.40	2.0

NOTES:

1. EWT: 180° F, EAT: 55° F, REHEAT COIL SELECTED AT 50% OF MAX CFM, MAX WPD: 5 FT FOR VAV, 10 FT FOR CAV, MAX DISCHARGE NC: 27. UNITS WITH ASTERIX UTILIZE 3-WAY CONTROL VALVES, ALL OTHERS ARE 2-WAY.

DATE	REVISIONS




Entek III
812 Grayson Road
Pleasant Hill, CA 94523
(925) 947-1400
entekiii@comcast.net
BRANCH OFFICE
1000 Parkwood Circle, St. 140
Atlanta, GA 30339
(800) 326-6063



Approved : Project Engineer	Approved : Associate Director
Approved : Supervisory Engineer	Approved : Director
Approved : VP FMS	Approved :


Drawing Title: SCHEDULES		Project Title: REPLACE AIR HANDLER UNITS BUILDING 77	Date: 4/24/12
Drawn: BMA	Building Number: 77	Project No.: 621-11-127	Drawing No. 77-MH5
Checked: PM	Location: JAMES H. DULLEN VA MEDICAL CENTER MOUNTAIN HOME, TN	Dwg 11 of 20	

12
8
4
0
3/4"=1'-0"




- NOTES:
1. VENT ALL HIGH POINTS.
 2. IF AUTOMATIC AIR VENTS ARE USED, PIPE DISCHARGE TO DRAIN

AIR VENT DETAIL 1
SCALE: NONE 77-MH6




- NOTES:
1. DRAIN ALL LOW POINTS.
 2. WHERE SCALE POCKETS ARE SHOWN ON PIPE RISER DIAGRAMS AND/OR PLANS LOCATE DRAIN AT BOTTOM OF SCALE POCKET.

PIPING DRAIN VALVE CONNECTIONS 2
SCALE: NONE 77-MH6




NOTE: DRIP POCKET PIPE SIZE SAME AS STEAM MAIN UNLESS OTHERWISE NOTED.

DRIP LEG DETAIL 3
SCALE: NONE 77-MH6




STEAM TRAP ASSEMBLY DETAIL 4
SCALE: NONE 77-MH6




SEE MANUFACTURER'S PIPING RECOMMENDATIONS FOR FINAL LAYOUT

HUMIDIFIER DETAIL 5
SCALE: NONE 77-MH6




- NOTES
1. PROVIDE MINIMUM 2 DIAMETERS STRAIGHT DUCT UPSTREAM

TERMINAL UNIT DETAIL 6
SCALE: NONE 77-MH6




REHEAT COIL DETAIL 7
SCALE: NONE 77-MH6

DEFAULT COIL PIPING UTILIZES 2-WAY VALVES. PROVIDE 3-WAY VALVES AND BYPASS AS PER TERMINAL UNIT SCHEDULE.




HOT WATER PREHEAT COIL PIPING 8
SCALE: NONE 77-MH6



1. PIPING SHALL BE INSTALLED IN SUCH MANNER THAT IT WILL NOT BLOCK THE SWING OR USE OF ACCESS DOORS OR PANELS; NEITHER SHALL IT BLOCK THE SERVICING OF FILTERS, VALVES, OR EQUIPMENT.


CHILLED WATER COIL PIPING 9
SCALE: NONE 77-MH6




UNIT TYPE	A	B
DRAW THRU	2" [50mm] PLUS X	X

WHERE X = STATIC PRESSURE IN PAN

AIR HANDLER DRAIN DETAIL 10
SCALE: NONE 77-MH6




STEAM PREHEAT COIL DETAIL 11
SCALE: NONE 77-MH6




- NOTES:
1. SUPPORT PUMP FROM PIPING ONLY. DO NOT SUPPORT PUMP FROM MOTOR.

INLINE PUMP DETAIL 12
SCALE: NONE 77-MH6




- NOTES:
1. SEE FLOOR PLANS FOR PIPE SIZES.
 2. MAKE BYPASS VALVE DISCHARGE PIPE THE SAME SIZE AS PRV DISCHARGE.
 3. PROVIDE NECESSARY UNIONS FOR THE REMOVAL OF VALVE WITH SCREWED CONNECTIONS.

PRV STATION DETAIL 13
SCALE: NONE 77-MH5



1. METAL COPING CAP, EXPANSION JOINT, AND EDGE DETAILS ARE TYPICAL ONLY. ALL METALWORK SHOULD BE INSTALLED TO SHEET METAL CODES (SMACNA). CLEAN ALL METAL PRIOR TO INSTALLATION OF GENFLEX MATERIALS. ALL WOOD NAILERS TO BE APPROVED MATERIAL. ATTACHMENT OF WOOD NAILER TO BE ACCOMPLISHED BY USING FASTENERS PROVIDING NO LESS THAN 125 LB (56.603 N) OF PULLOUT. FASTENERS SHALL BE SPACED NO GREATER THAN 24" O.C. (609.60 MM).
2. FOR SEAMS ASSEMBLED WITH GENFLEX G-400 SEAM ADHESIVE, A BEAD OF GENFLEX EDGE CAULK IS REQUIRED ON ALL EXPOSED EDGES, FOLLOWING A PRE-CLEANING OF THE SEAM AREA WITH GENFLEX CLEANER. WHEN USING GENFLEX SEAM TAPE AND GENFLEX BAR COVER TAPE, FIRST CLEAN THE MEMBRANE WITH GENFLEX CLEANER. THEN APPLY GENFLEX PRIMER.

CURB FLASHING DETAIL 14
SCALE: NONE 77-MH6



1. FOR SEAMS ASSEMBLED WITH GENFLEX G-400 SEAM ADHESIVE, A BEAD OF GENFLEX EDGE CAULK IS REQUIRED ON ALL EXPOSED EDGES, FOLLOWING A PRE-CLEANING OF THE SEAM AREA WITH GENFLEX CLEANER.

PIPE FLASHING DETAIL 15
SCALE: NONE 77-MH6

DATE	REVISIONS

Entek III
812 Grayson Road
Pleasant Hill, CA 94523
(925) 947-1400
entekiii@comcast.net
BRANCH OFFICE
1000 Parkwood Circle, St. 140
Atlanta, GA 30339
(800) 326-6063



Approved : Project Engineer	Approved : Associate Director
Approved : Supervisory Engineer	Approved : Director
Approved : VP FMS	Approved :

Drawing Title:	
DETAILS	

Project Title:		Date:	
REPLACE AIR HANDLER UNITS BUILDING 77		4/24/12	
Project No.:		Drawing No.:	
621-11-127		77-MH6	
Drawn:	Building Number:	Dwg 12 of 20	
BMA	77		
Checked:	Location:		
PM	JAMES H. GULLEN VA MEDICAL CENTER MOUNTAIN HOME, TN		



12
8
4
0
SCALE: 3/4"=1'-0"

12
8
4
0
SCALE: 1/2"=1'-0"

12
8
4
0
SCALE: 1/4"=1'-0"

12
8
4
0
SCALE: 1/8"=1'-0"

AIR HANDLER POINTS LIST (TYP 3)												
POINT NAME	HARDWARE POINTS				SOFTWARE POINTS						SHOW ON GRAPHIC	
	AI	AO	BI	BO	AV	BV	NET	SCHED	TREND	ALARM		
SUPPLY AIR STATIC PRESSURE	X								X	X	X	
SUPPLY AIRFLOW	X								X		X	
RETURN AIRFLOW	X								X		X	
SUPPLY AIR HUMIDITY	X								X		X	
PREFILTER DIFFERENTIAL PRESSURE	X								X			
FINAL FILTER DIFFERENTIAL PRESSURE	X								X			
FINAL FILTER DIFFERENTIAL PRESSURE (77-AC6ONLY)	X											
MIXED AIR TEMP	X								X		X	
RETURN AIR HUMIDITY	X								X		X	
RETURN AIR TEMP	X								X		X	
SUPPLY AIR TEMP	X								X		X	
SUPPLY FAN VFD SPEED		X							X		X	
RETURN FAN VFD SPEED		X							X		X	
PREHEATING STEAM VALVE (77-AC6)				X					X		X	
PREHEATING FACE/BYPASS DAMPER (77-AC6)	X											
PREHEATING PUMP (77-AC-8,10)				X								
PREHEATING PUMP STATUS (77-AC-8,10)			X									
PREHEATING HOT WATER VALVE (77-AC-8,10)		X										
COOLING VALVE		X							X		X	
MIXED AIR DAMPERS		X							X		X	
HUMIDIFIER VALVE		X							X		X	
HUMIDIFIER JACKET VALVE				X								
FREEZESTAT			X						X	X	X	
HIGH STATIC SHUTDOWN			X						X	X	X	
RETURN AIR SMOKE DETECTOR			X						X	X	X	
SUPPLY AIR SMOKE DETECTOR			X						X	X	X	
SUPPLY FAN VFD FAULT			X							X	X	
SUPPLY FAN STATUS			X						X		X	
RETURN FAN VFD FAULT			X							X		
RETURN FAN STATUS			X						X		X	
SUPPLY FAN START/STOP				X					X		X	
RETURN FAN START/STOP				X					X		X	
HUMIDIFIER ENABLE				X							X	
SUPPLY AIR STATIC PRESSURE SETPOINT					X				X		X	
RETURN AIRFLOW SETPOINT					X				X		X	
PREHEATING MIXED AIR TEMP SETPOINT					X				X		X	
SUPPLY AIR TEMP SETPOINT					X				X		X	
ECONOMIZER MIXED AIR TEMP SETPOINT					X				X		X	
HUMIDIFIER SETPOINT				X							X	
EMERGENCY SHUTDOWN						X			X	X	X	
HIGH SUPPLY AIR STATIC PRESSURE										X		
LOW SUPPLY AIR STATIC PRESSURE										X		
SUPPLY FAN FAILURE										X		
SUPPLY FAN IN HAND										X		
SUPPLY FAN RUNTIME EXCEEDED										X		
RETURN FAN FAILURE										X		
RETURN FAN IN HAND										X		
RETURN FAN RUNTIME EXCEEDED										X		
HIGH RETURN AIRFLOW										X		
LOW RETURN AIRFLOW										X		
HIGH SUPPLY AIR TEMP										X		
LOW SUPPLY AIR TEMP										X		
HIGH SUPPLY AIR HUMIDITY										X		
LOW SUPPLY AIR HUMIDITY										X		
PREFILTER CHANGE REQUIRED										X	X	
FINAL FILTER CHANGE REQUIRED										X	X	
HIGH MIXED AIR TEMP										X		
LOW MIXED AIR TEMP										X		
HIGH RETURN AIR HUMIDITY										X		
LOW RETURN AIR HUMIDITY										X		
HIGH RETURN AIR TEMP										X		
LOW RETURN AIR TEMP										X		
HIGH SUPPLY AIR TEMP										X		
LOW SUPPLY AIR TEMP										X		
CHILLED WATER FLOW		X								X		
CHILLED WATER INLET TEMPERATURE		X								X		
CHILLED WATER OUTLET TEMPERATURE		X								X		
PRE-HEAT COIL INLET TEMPERATURE (AC-8,10)		X								X		
PRE-HEAT COIL OUTLET TEMPERATURE (AC-8,10)		X								X		

TERMINAL UNIT POINTS LIST (TYP 59)												
POINT NAME	HARDWARE POINTS				SOFTWARE POINTS						SHOW ON GRAPHIC	
	AI	AO	BI	BO	AV	BV	NET	SCHED	TREND	ALARM		
ZONE TEMP	X								X		X	
ZONE SETPOINT ADJUST	X								X		X	
AIRFLOW	X								X		X	
DISCHARGE AIR TEMPERATURE	X								X		X	
ZONE DAMPER		X							X		X	
REHEAT VALVE		X							X		X	
AIRFLOW SETPOINT MAX					X						X	
AIRFLOW SETPOINT MIN					X				X		X	
HIGH ZONE TEMP									X	X	X	
LOW ZONE TEMP									X	X	X	
HIGH DISCHARGE AIR TEMP									X	X	X	
LOW DISCHARGE AIR TEMP									X	X	X	

CONTROLS SYMBOLS

- T

ROOM THERMOSTAT/TRANSMITTER - WALL MOUNT
- TT

TEMPERATURE TRANSMITTER
- TT

TEMPERATURE TRANSMITTER, AVERAGING ELEMENT
- HT

MOISTURE (HUMIDITY) TRANSMITTER
- DPT

DIFFERENTIAL PRESSURE TRANSMITTER
- SPS

STATIC PRESSURE SENSOR
- FT

FLOW TRANSMITTER
- IT

CURRENT TRANSMITTER
- SD

SMOKE DETECTOR
- PDT

PRESSURE DIFFERENTIAL TRANSMITTER
- PDS

PRESSURE DIFFERENTIAL SWITCH
- HS

HAND SWITCH (HAND-OFF-AUTO SWITCH)
- TSL

TEMPERATURE SWITCH, LOW (FREEZESTAT)
- PSH

PRESSURE SWITCH HIGH
- PSL

PRESSURE SWITCH LOW
- FSH

FLOW SWITCH HIGH
- FSL

FLOW SWITCH LOW
- VFD

VARIABLE FREQUENCY DRIVE
- |||||

DAMPER
- ⊠

MOTOR STARTER
- ⌞

VALVE OR DAMPER ACTUATOR (MODULATING)
- ⌞

VALVE OR DAMPER ACTUATOR (TWO-POSITION)
- ⊠

CONTROL VALVE (SEE SPECIFICATIONS FOR TYPE)

SC

SPEED CONTROL

NT

BACNET NETWORK CONNECTION


B-AAC

BACNET APPLICATION AREA CONTROLLER

AIR HANDLER CONTROL DIAGRAM

SCALE: NONE


1
77-MH7



TERMINAL UNIT CONTROL DIAGRAM

SCALE: NONE

2
77-MH7




NETWORK DIAGRAM

SCALE: NONE

3
77-MH7

DATE	REVISIONS




Entek III
812 Grayson Road
Pleasant Hill, CA 94523
(925) 947-1400
entekiii@comcast.net
BRANCH OFFICE
1000 Parkwood Circle, St. 140
Atlanta, GA 30339
(800) 326-6063




Approved : Project Engineer	Approved : Associate Director
Approved : Supervisory Engineer	Approved : Director
Approved : VP FMS	Approved :

Drawing Title:
CONTROLS - DIAGRAMS AND POINTS LIST

Project Title: REPLACE AIR HANDLER UNITS BUILDING 77		Date: 4/24/12
Drawn: BMA		Building Number: 77
Checked: PM		Location: JAMES H. GUILLEN VA MEDICAL CENTER MOUNTAIN HOME, TN
Project No.: 621-11-127		Drawing No. 77-MH7
		Dwg 13 of 20



Department of
Veterans Affairs



VARIABLE AIR VOLUME – AHU (TYPICAL OF 3)

RUN CONDITIONS – CONTINUOUS:
THE UNIT SHALL RUN CONTINUOUSLY.

EMERGENCY SHUTDOWN:
THE UNIT SHALL SHUT DOWN AND GENERATE AN ALARM UPON RECEIVING AN EMERGENCY SHUTDOWN SIGNAL.

FREEZE PROTECTION:
THE UNIT SHALL SHUT DOWN AND GENERATE AN ALARM UPON RECEIVING A FREEZESTAT STATUS.

HIGH STATIC SHUTDOWN:
THE UNIT SHALL SHUT DOWN AND GENERATE AN ALARM UPON RECEIVING AN HIGH STATIC SHUTDOWN SIGNAL.

RETURN AIR SMOKE DETECTION:
THE UNIT SHALL SHUT DOWN AND GENERATE AN ALARM UPON RECEIVING A RETURN AIR SMOKE DETECTOR STATUS.

SUPPLY AIR SMOKE DETECTION:
THE UNIT SHALL SHUT DOWN AND GENERATE AN ALARM UPON RECEIVING A SUPPLY AIR SMOKE DETECTOR STATUS.

SUPPLY FAN:
THE SUPPLY FAN SHALL RUN ANYTIME THE UNIT IS COMMANDED TO RUN, UNLESS SHUTDOWN ON SAFETIES. TO PREVENT SHORT CYCLING, THE SUPPLY FAN SHALL HAVE A USER DEFINABLE (ADJ.) MINIMUM RUNTIME.

ALARMS SHALL BE PROVIDED AS FOLLOWS:
SUPPLY FAN FAILURE: COMMANDED ON, BUT THE STATUS IS OFF.
SUPPLY FAN IN HAND: COMMANDED OFF, BUT THE STATUS IS ON.
SUPPLY FAN RUNTIME EXCEEDED: STATUS RUNTIME EXCEEDS A USER DEFINABLE LIMIT (ADJ.).

SUPPLY AIR DUCT STATIC PRESSURE CONTROL:
THE CONTROLLER SHALL MEASURE DUCT STATIC PRESSURE AND MODULATE THE SUPPLY FAN VFD SPEED TO MAINTAIN A DUCT STATIC PRESSURE SETPOINT. THE SPEED SHALL NOT DROP BELOW 30% (ADJ.). THE STATIC PRESSURE SETPOINT SHALL BE RESET BASED ON ZONE COOLING REQUIREMENTS.
THE INITIAL DUCT STATIC PRESSURE SETPOINT SHALL BE 1.5IN H2O (ADJ.).
AS COOLING DEMAND INCREASES, THE SETPOINT SHALL INCREMENTALLY RESET UP TO A MAXIMUM OF 1.8IN H2O (ADJ.).
AS COOLING DEMAND DECREASES, THE SETPOINT SHALL INCREMENTALLY RESET DOWN TO A MINIMUM OF 1.3IN H2O (ADJ.) .

ALARMS SHALL BE PROVIDED AS FOLLOWS:
HIGH SUPPLY AIR STATIC PRESSURE: IF THE SUPPLY AIR STATIC PRESSURE IS 25% (ADJ.) GREATER THAN SETPOINT.
LOW SUPPLY AIR STATIC PRESSURE: IF THE SUPPLY AIR STATIC PRESSURE IS 25% (ADJ.) LESS THAN SETPOINT.
SUPPLY FAN VFD FAULT.

RETURN FAN:
THE RETURN FAN SHALL RUN WHENEVER THE SUPPLY FAN RUNS.

ALARMS SHALL BE PROVIDED AS FOLLOWS:
RETURN FAN FAILURE: COMMANDED ON, BUT THE STATUS IS OFF.
RETURN FAN IN HAND: COMMANDED OFF, BUT THE STATUS IS ON.
RETURN FAN RUNTIME EXCEEDED: STATUS RUNTIME EXCEEDS A USER DEFINABLE LIMIT (ADJ.).
RETURN FAN VFD FAULT.

RETURN AIRFLOW:
THE RETURN FAN VFD SHALL MODULATE IN UNISON WITH THE SUPPLY FAN VFD.
RETURN AIRFLOW SETPOINT SHALL BE 100% (ADJ.) OF THE SUPPLY AIRFLOW MINUS THE MINIMUM OUTSIDE AIR QUANTITY (ADJ.). THE RETURN FAN VFD SPEED SHALL NOT DROP BELOW 20% (ADJ.).

ALARMS SHALL BE PROVIDED AS FOLLOWS:
HIGH RETURN AIRFLOW: IF THE RETURN AIRFLOW IS AN ADJUSTABLE PERCENTAGE GREATER THAN SETPOINT.
LOW RETURN AIRFLOW: IF THE RETURN AIRFLOW IS AN ADJUSTABLE PERCENTAGE LESS THAN SETPOINT.

THE PREHEATING SHALL BE ENABLED WHENEVER:
OUTSIDE AIR TEMPERATURE IS LESS THAN 60°F (ADJ.).
AND THE ECONOMIZER (IF PRESENT) IS DISABLED.
AND THE SUPPLY FAN STATUS IS ON.

(77–AC6 ONLY) PREHEATING COIL STEAM VALVE:
THE CONTROLLER SHALL MEASURE THE MIXED AIR TEMPERATURE AND SHALL OPEN THE STEAM VALVE AND MODULATE THE INTEGRAL FACE AND BYPASS DAMPERS TO MAINTAIN ITS SETPOINT 5°F (ADJ.) LESS THAN THE SUPPLY AIR TEMPERATURE SETPOINT.

(77–AC6 ONLY) THE PREHEATING COIL STEAM VALVE SHALL OPEN FOR FREEZE PROTECTION WHENEVER:
MIXED AIR TEMPERATURE DROPS FROM 40°F TO 35°F (ADJ.).
OR THE FREEZESTAT (IF PRESENT) IS ON.

(77–AC8, 10 ONLY) PREHEATING COIL HOT WATER VALVE:
THE CONTROLLER SHALL MEASURE THE MIXED AIR TEMPERATURE AND SHALL MODULATE HOT WATER VALVE TO MAINTAIN ITS SETPOINT 5°F (ADJ.) LESS THAN THE SUPPLY AIR TEMPERATURE SETPOINT.

(77–AC8, 10 ONLY) THE PREHEATING COIL HOT VALVE SHALL OPEN FOR FREEZE PROTECTION WHENEVER:
MIXED AIR TEMPERATURE DROPS FROM 40°F TO 35°F (ADJ.).
OR THE FREEZESTAT (IF PRESENT) IS ON.

(77–AC8, 10 ONLY) PREHEATING COIL PUMP:
THE RECIRCULATION PUMP SHALL RUN WHENEVER:
THE PREHEATING COIL VALVE IS ENABLED.
OR THE FREEZESTAT (IF PRESENT) IS ON.
ALARMS SHALL BE PROVIDED AS FOLLOWS:
PREHEATING COIL PUMP FAILURE: COMMANDED ON, BUT THE STATUS IS OFF.
PREHEATING COIL PUMP IN HAND: COMMANDED OFF, BUT THE STATUS IS ON.
PREHEATING COIL PUMP RUNTIME EXCEEDED: STATUS RUNTIME EXCEEDS A USER DEFINABLE LIMIT.

SUPPLY AIR TEMPERATURE SETPOINT – OPTIMIZED:
THE CONTROLLER SHALL MONITOR THE SUPPLY AIR TEMPERATURE AND SHALL MAINTAIN A SUPPLY AIR TEMPERATURE SETPOINT RESET BASED ON ZONE COOLING AND HEATING REQUIREMENTS

THE SUPPLY AIR TEMPERATURE SETPOINT SHALL BE RESET FOR COOLING BASED ON ZONE COOLING REQUIREMENTS AS FOLLOWS:
THE INITIAL SUPPLY AIR TEMPERATURE SETPOINT SHALL BE 55°F (ADJ.).
AS COOLING DEMAND INCREASES, THE SETPOINT SHALL INCREMENTALLY RESET DOWN TO A MINIMUM OF 53°F (ADJ.).
AS COOLING DEMAND DECREASES, THE SETPOINT SHALL INCREMENTALLY RESET UP TO A MAXIMUM OF 72°F (ADJ.) .

IF MORE ZONES NEED HEATING THAN COOLING, THEN THE SUPPLY AIR TEMPERATURE SETPOINT SHALL BE RESET FOR HEATING AS FOLLOWS:
THE INITIAL SUPPLY AIR TEMPERATURE SETPOINT SHALL BE 82°F (ADJ.).
AS HEATING DEMAND INCREASES, THE SETPOINT SHALL INCREMENTALLY RESET UP TO A MAXIMUM OF 85°F (ADJ.).
AS HEATING DEMAND DECREASES, THE SETPOINT SHALL INCREMENTALLY RESET DOWN TO A MINIMUM OF 72°F (ADJ.).

COOLING COIL VALVE:
THE CONTROLLER SHALL MEASURE THE SUPPLY AIR TEMPERATURE AND MODULATE THE COOLING COIL VALVE TO MAINTAIN ITS COOLING SETPOINT.

THE COOLING SHALL BE ENABLED WHENEVER:
OUTSIDE AIR TEMPERATURE IS GREATER THAN 60°F (ADJ.).
AND THE ECONOMIZER (IF PRESENT) IS DISABLED OR FULLY OPEN.
AND THE SUPPLY FAN STATUS IS ON.
AND THE HEATING (IF PRESENT) IS NOT ACTIVE.

THE COOLING COIL VALVE SHALL OPEN TO 50% (ADJ.) WHENEVER THE FREEZESTAT (IF PRESENT) IS ON.

ALARMS SHALL BE PROVIDED AS FOLLOWS:
HIGH SUPPLY AIR TEMP: IF THE SUPPLY AIR TEMPERATURE IS 5°F (ADJ.) GREATER THAN SETPOINT.

LOW SUPPLY AIR TEMPERATURE ALARM:
THE CONTROLLER SHALL ALARM IF THE SUPPLY AIR TEMPERATURE IS LESS THAN 45°F (ADJ.).

ECONOMIZER:
THE CONTROLLER SHALL MEASURE THE MIXED AIR TEMPERATURE AND MODULATE THE ECONOMIZER DAMPERS IN SEQUENCE TO MAINTAIN A SETPOINT 2°F (ADJ.) LESS THAN THE SUPPLY AIR TEMPERATURE SETPOINT. THE OUTSIDE AIR DAMPERS SHALL MAINTAIN A MINIMUM ADJUSTABLE POSITION OF 20% (ADJ.) OPEN WHENEVER OCCUPIED.

THE ECONOMIZER SHALL BE ENABLED WHENEVER:
OUTSIDE AIR TEMPERATURE IS LESS THAN 65°F (ADJ.).
AND THE OUTSIDE AIR TEMPERATURE IS LESS THAN THE RETURN AIR TEMPERATURE.
AND THE SUPPLY FAN STATUS IS ON.

THE ECONOMIZER SHALL CLOSE WHENEVER:
MIXED AIR TEMPERATURE DROPS FROM 40°F TO 35°F (ADJ.).
OR THE FREEZESTAT (IF PRESENT) IS ON.
OR ON LOSS OF SUPPLY FAN STATUS.

THE OUTSIDE AND EXHAUST AIR DAMPERS SHALL CLOSE AND THE RETURN AIR DAMPER SHALL OPEN WHEN THE UNIT IS OFF. IF OPTIMAL START UP IS AVAILABLE THE MIXED AIR DAMPER SHALL OPERATE AS DESCRIBED IN THE OCCUPIED MODE EXCEPT THAT THE OUTSIDE AIR DAMPER SHALL MODULATE TO FULLY CLOSED.

MINIMUM OUTSIDE AIR VENTILATION – FIXED PERCENTAGE:
THE OUTSIDE AIR DAMPERS SHALL MAINTAIN A MINIMUM ADJUSTABLE POSITION DURING BUILDING OCCUPIED HOURS AND BE CLOSED DURING UNOCCUPIED HOURS.

HUMIDIFIER CONTROL:
THE CONTROLLER SHALL MEASURE THE RETURN AIR HUMIDITY AND MODULATE THE HUMIDIFIER TO MAINTAIN A SETPOINT OF 50% RH (ADJ.). THE HUMIDIFIER SHALL BE ENABLED WHENEVER THE SUPPLY FAN STATUS IS ON AND THE COOLING COIL VALVE STATUS IS OFF.

THE HUMIDIFIER SHALL TURN OFF WHENEVER:
SUPPLY AIR HUMIDITY RISES FROM 90% RH TO 95% RH (ADJ.).
OR ON LOSS OF SUPPLY FAN STATUS.

ALARMS SHALL BE PROVIDED AS FOLLOWS:
HIGH SUPPLY AIR HUMIDITY: IF THE SUPPLY AIR HUMIDITY IS GREATER THAN 90% RH (ADJ.).
LOW SUPPLY AIR HUMIDITY: IF THE SUPPLY AIR HUMIDITY IS LESS THAN 30% RH (ADJ.).

PREFILTER DIFFERENTIAL PRESSURE MONITOR:
THE CONTROLLER SHALL MONITOR THE DIFFERENTIAL PRESSURE ACROSS THE PREFILTER.

ALARMS SHALL BE PROVIDED AS FOLLOWS:
PREFILTER CHANGE REQUIRED: PREFILTER DIFFERENTIAL PRESSURE EXCEEDS A USER DEFINABLE LIMIT (ADJ.).

FINAL FILTER(S) DIFFERENTIAL PRESSURE MONITOR:
THE CONTROLLER SHALL MONITOR THE DIFFERENTIAL PRESSURE ACROSS THE FINAL FILTER.

ALARMS SHALL BE PROVIDED AS FOLLOWS:
FINAL FILTER CHANGE REQUIRED: FINAL FILTER DIFFERENTIAL PRESSURE EXCEEDS A USER DEFINABLE LIMIT (ADJ.).

MIXED AIR TEMPERATURE:
THE CONTROLLER SHALL MONITOR THE MIXED AIR TEMPERATURE AND USE AS REQUIRED FOR ECONOMIZER CONTROL OR PREHEATING CONTROL.

ALARMS SHALL BE PROVIDED AS FOLLOWS:
HIGH MIXED AIR TEMP: IF THE MIXED AIR TEMPERATURE IS GREATER THAN 90°F (ADJ.).
LOW MIXED AIR TEMP: IF THE MIXED AIR TEMPERATURE IS LESS THAN 45°F (ADJ.).

RETURN AIR HUMIDITY:
THE CONTROLLER SHALL MONITOR THE RETURN AIR HUMIDITY AND USE AS REQUIRED FOR ECONOMIZER CONTROL OR HUMIDITY CONTROL.

ALARMS SHALL BE PROVIDED AS FOLLOWS:
HIGH RETURN AIR HUMIDITY: IF THE RETURN AIR HUMIDITY IS GREATER THAN 70% (ADJ.).
LOW RETURN AIR HUMIDITY: IF THE RETURN AIR HUMIDITY IS LESS THAN 35% (ADJ.).

RETURN AIR TEMPERATURE:
THE CONTROLLER SHALL MONITOR THE RETURN AIR TEMPERATURE AND USE AS REQUIRED FOR SETPOINT CONTROL OR ECONOMIZER CONTROL (IF PRESENT).

ALARMS SHALL BE PROVIDED AS FOLLOWS:
HIGH RETURN AIR TEMP: IF THE RETURN AIR TEMPERATURE IS GREATER THAN 90°F (ADJ.).
LOW RETURN AIR TEMP: IF THE RETURN AIR TEMPERATURE IS LESS THAN 45°F (ADJ.).

SUPPLY AIR TEMPERATURE:
THE CONTROLLER SHALL MONITOR THE SUPPLY AIR TEMPERATURE.

ALARMS SHALL BE PROVIDED AS FOLLOWS:
HIGH SUPPLY AIR TEMP: IF THE SUPPLY AIR TEMPERATURE IS GREATER THAN 120°F (ADJ.).
LOW SUPPLY AIR TEMP: IF THE SUPPLY AIR TEMPERATURE IS LESS THAN 45°F (ADJ.).

VARIABLE AIR VOLUME – TERMINAL UNIT (TYPICAL OF 59)

RUN CONDITIONS – CONTINUOUS:
THE UNIT SHALL RUN CONTINUOUSLY AND SHALL MAINTAIN:
A 74°F (ADJ.) COOLING SETPOINT
A 70°F (ADJ.) HEATING SETPOINT.

ALARMS SHALL BE PROVIDED AS FOLLOWS:
HIGH ZONE TEMP: IF THE ZONE TEMPERATURE IS GREATER THAN THE COOLING SETPOINT BY A USER DEFINABLE AMOUNT (ADJ.).
LOW ZONE TEMP: IF THE ZONE TEMPERATURE IS LESS THAN THE HEATING SETPOINT BY A USER DEFINABLE AMOUNT (ADJ.).

ZONE SETPOINT ADJUST:
THE OCCUPANT SHALL BE ABLE TO ADJUST THE ZONE TEMPERATURE HEATING AND COOLING SETPOINTS AT THE ZONE SENSOR.

REVERSING VARIABLE VOLUME TERMINAL UNIT – FLOW CONTROL:
THE UNIT SHALL MAINTAIN ZONE SETPOINTS BY CONTROLLING THE AIRFLOW THROUGH ONE OF THE FOLLOWING:


OCCUPIED:
WHEN ZONE TEMPERATURE IS GREATER THAN ITS COOLING SETPOINT, THE ZONE DAMPER SHALL MODULATE BETWEEN THE MINIMUM OCCUPIED AIRFLOW (ADJ.) AND THE MAXIMUM COOLING AIRFLOW (ADJ.) UNTIL THE ZONE IS SATISFIED.
WHEN THE ZONE TEMPERATURE IS BETWEEN THE COOLING SETPOINT AND THE HEATING SETPOINT, THE ZONE DAMPER SHALL MAINTAIN THE MINIMUM REQUIRED ZONE VENTILATION (ADJ.).
WHEN ZONE TEMPERATURE IS LESS THAN ITS HEATING SETPOINT, THE CONTROLLER SHALL ENABLE HEATING TO MAINTAIN THE ZONE TEMPERATURE AT ITS HEATING SETPOINT.

REHEATING COIL VALVE:
THE CONTROLLER SHALL MEASURE THE ZONE TEMPERATURE AND MODULATE THE REHEATING COIL VALVE OPEN ON DROPPING TEMPERATURE TO MAINTAIN ITS HEATING SETPOINT.


DISCHARGE AIR TEMPERATURE:
THE CONTROLLER SHALL MONITOR THE DISCHARGE AIR TEMPERATURE.



ALARMS SHALL BE PROVIDED AS FOLLOWS:
HIGH DISCHARGE AIR TEMP: IF THE DISCHARGE AIR TEMPERATURE IS GREATER THAN 120°F (ADJ.).
LOW DISCHARGE AIR TEMP: IF THE DISCHARGE AIR TEMPERATURE IS LESS THAN 40°F (ADJ.).

DATE	REVISIONS





Entek III
812 Grayson Road
Pleasant Hill, CA 94523
(925) 947-1400
entekiii@comcast.net
BRANCH OFFICE
1000 Parkwood Circle, St. 140
Atlanta, GA 30339
(800) 326-6063



Approved : Project Engineer	Approved : Associate Director	Drawing Title: CONTROLS - SEQUENCE OF OPERATIONS	Project Title: REPLACE AIR HANDLER UNITS BUILDING 77		Date: 4/24/12	
Approved : Supervisory Engineer	Approved : Director		Project No.: 621-11-127			
Approved : VP FMS	Approved :		Drawn: BMA	Building Number: 77	Drawing No. 77-MH8	
Checked: PM		Location: JAMES H. GULLEN VA MEDICAL CENTER MOUNTAIN HOME, TN		Dwg 13 of 20		Department of Veterans Affairs



ROOM FA-140
1/8" = 1'-0"




ROOM SB-160
1/4" = 1'-0"



NUMBERED NOTES (X)

- 120V POWER CIRCUIT FOR AIR HANDLER RECEPTACLE AND LIGHTING. SEE DWG. 77-ES3.
- 120V POWER CIRCUIT FOR DDC CONTROL PANEL. CONTROL CONTRACTOR RESPONSIBLE FOR ENCLOSURE AND CLASS 2 TRANSFORMERS. SEE DWG. 77-ES3.
- MOUNT VFD ON UNISTRUT FRAMEWORK
- RELOCATED DISCONNECT FOR (E) EF-11. EXTEND (E) WIRE AND CONDUIT TO NEW LOCATION. MOUNT DISCONNECT ON UNISTRUT FRAMEWORK.
- PROVIDE NEW SOURCE BREAKERS FOR VFD-SF6 AND VFD-RF6 IN (E) MCSC. SEE DWG. 77-ES4.
- VERIFY EXISTING GROUND CONDUCTOR'S INTEGRITY AND CONTINUITY TO GROUND. INSTALL EXISTING LIGHTNING RODS, LAYING LOSE ON ROOF, ON AH UNIT, AND CONNECT AND BOND EXISTING GROUND WIRE TO RODS AND TO NEW UNIT.



DATE	REVISIONS

Entek III
812 Grayson Road
Pleasant Hill, CA 94523
(925) 947-1400
entekiii@comcast.net
BRANCH OFFICE
1000 Parkwood Circle, St. 140
Atlanta, GA 30339
(800) 326-6063




Approved : Project Engineer	Approved : Associate Director
Approved : Supervisory Engineer	Approved : Director
Approved : VP FMS	Approved :

Drawing Title:
ELECTRICAL - ROOM SB-160, FA-140

Project Title:	Date:
REPLACE AIR HANDLER UNITS BUILDING 77	4/24/12
Drawn:	Building Number:
BMA	77
Checked:	Location:
PM	JAMES H. GULLEN, VA MEDICAL CENTER MOUNTAIN HOME, TN
Dwg 15 of 20	77-ES1







ROOF PLAN
1/8" = 1'-0"

NUMBERED NOTES (X)


- 120V POWER CIRCUIT FOR AIR HANDLER RECEPTACLE AND LIGHTING.
- 120V POWER CIRCUIT FOR DDC CONTROL PANEL. CONTROL CONTRACTOR RESPONSIBLE FOR ENCLOSURE AND CLASS 2 TRANSFORMERS.
- MOUNT VFD.
- PROVIDE NEW SOURCE BREAKERS FOR AC-8 AND AC-10 IN (E) "3HN".
- U.O.N., ALL 120V. SEE PANEL SCHEDULE ON 77-ES3. CKTS. ARE 3-1/C#12.
- FURNISH & INSTALL FOR EACH HWP, NEMA3R COMBINATION SINGLE PHASE STARTER, MAGNETIC, W/OVERLOAD RESET BUTTON & INDICATING LIGHTS, AND HOA SWITCH. CONTACTOR/STARTER CAN BE 2 POLE, PRIMARY DISCONNECT SHALL BE A THERMAL-MAGNETIC BREAKER, 15A, 14 KAIC.
- FURNISH & INSTALL 2', COPPER LIGHTING ROD & CLAMPS, 2 PER AC UNIT. GROUND TO (E) EQUIP. GROUND WIRE W/#1/0 MIN. COPPER CONDUCTOR, USING MECHANICAL CONNECTOR. RECONNECT (E) EQUIPMENT GROUND CONDUCTOR TO (N) AC-8 & AC-10.



ROOM 3A-133
1/4" = 1'-0"



ROOM 3A-110
1/4" = 1'-0"



KEY PLAN
NOT TO SCALE

DATE	REVISIONS

Entek III
812 Grayson Road
Pleasant Hill, CA 94523
(925) 947-1400
entekiii@comcast.net
BRANCH OFFICE
1000 Parkwood Circle, St. 140
Atlanta, GA 30339
(800) 326-6063







Approved : Project Engineer	Approved : Associate Director
Approved : Supervisory Engineer	Approved : Director
Approved : VP FMS	Approved :

Drawing Title:
**ELECTRICAL - ROOM 3A-133
AND ROOF PLAN**

Project Title: REPLACE AIR HANDLER UNITS BUILDING 77	Date: 4/24/12
Drawn: ---	Project No.: 621-11-127
Building Number: 77	Drawing No.: 77-ES2
Location: JAMES H. DULLEN VA MEDICAL CENTER MOUNTAIN HOME, TN	Dwg 16 of 20





SCHEDULE - PANEL '3HN'

LOCATION: RM. 3A133		TYPE: MOLDED CASE, SURFACE MTD, NEMA 1, 600A MLO BUS TRANSFORMER: N/A				SYSTEM: 480/277V, 3ø, 4W			
DRAWING: 77-ES2						SOURCE:			
DESCRIPTION	LOAD VA		A	B	C	N	LOAD VA	DESCRIPTION	
77-EF27	-	1	20				20	2	77-EF26
	-							-	
	-							-	
77-EF30	-	3	20				30	4	LATHES
	-							-	
	-							-	
	-							-	
SPACE	-	5	20				100	6	SPACE
	-							-	
	-							-	
PANEL '3LN1' VIA XFMR	-	7	175				125	8	PANEL '3LN2' VIA XFMR
	-							-	
	-							-	
77-AC10 (20HP + 3 HP) VFD'S	8813	9	50				20	10	77-EF3
	8813							-	
	8813							-	
77-AC9	-	11	60				20	12	77-EF10
	-							-	
	-							-	
77-AC8 (15HP + 3 HP) VFD'S	7150	13	40				100	14	SPACE
	7150							-	
	7150							-	
TOTAL LOAD									
PHASE A:									
PHASE B:									
PHASE C:									
TOTAL:									

SCHEDULE - PANEL '1LS1'

LOCATION: RM. FA140		TYPE: SURFACE MTD.		SYSTEM: 208/120V, 3ø, 4W							
DRAWING: 77-ES1		TRANSFORMER:		SOURCE:							
DESCRIPTION	LOAD VA					LOAD VA	DESCRIPTION				
COLD ROOM COMPRESSOR	900	1	20	A	B	C	N	20	2	1100	WALK-IN DR. HTR. & LTS.
	900	3	20					20	4	1100	WALK-IN DR. HTR. & LTS.
	900	5	20					20	6	700	WALK-IN FAN COIL UNIT
WALK-IN INCUBATOR	1200	7	20					20	8	360	2 DUPLEX RECEPTS.
	1200	9	20					20	10	500	LIGHTING
	1200	11	20					20	12	540	3 DUPLEX RECEPTS.
MECH. ROOM LIGHTING	800	13	20					20	14	200	COLD ROOM BUILT IN RECEPT.
AC-6 LIGHTS & CONTROLS (RECEPTS)	272	15	20					30	16	1500	COLD ROOM
CONTROL PANEL DDCP2 - AHU	50	17	20					20	18	1500	
CONTROL PANEL DDCP2 - TERMINAL UNITS	2025	19	20					20	20	200	INCUBATOR BUILT IN RECEPT.
SPARE	-	21	20					30	22	1500	INCUBATOR
SPARE	-	23	20						24	1500	
SPACE	-	25							26	-	SPACE
SPACE	-	27							28	-	SPACE
SPACE	-	29							30	-	SPACE
TOTAL LOAD											
PHASE A:		- VA									
PHASE B:		- VA									
PHASE C:		- VA									
TOTAL:		- VA									

100


SCHEDULE - PANEL '2EDP'

LOCATION:		TYPE:		SYSTEM: 208/120V, 3ø, 4W							
DRAWING:		TRANSFORMER:		SOURCE:							
DESCRIPTION	LOAD VA					LOAD VA	DESCRIPTION				
JOHNSON CONTROLS	-	1	20	A	B	C	N	20	2	-	SPARE
3A-109 LIGHTS	-	3	20					20	4	-	SPARE
3A-109 LIGHTS	-	5	20					20	6	-	SPARE
SPARE	-	7	20					20	8	-	SPARE
SPARE	-	9	20					20	10	-	SPARE
SPARE	-	11	20					20	12	-	SPARE
SPARE	-	13	20					20	14	-	3A-121A
SPARE	-	15	20					20	16	-	3A-103
SPARE	-	17	20					20	18	-	3A-117 BATTERY CHARGER
HWP-8	696	19	15					20	20	-	3C-100, 3A-117, 3A-105
HWP-10	696	21	15					20	22	-	3A-105, 3A-103
AC-8 LIGHTS & CONTROLS (RECEPTACLES)	1272	23	20					20	24	-	3A-101, 3A-104
AC-10 LIGHTS & CONTROLS (RECEPTACLES)	1272	25	20					20	26	-	3A-147, 3A-109
CONTROL PANEL DDCP1-AHU	50	27	20					20	28	-	3A-107, 3A-106
CONTROL PANEL DDCP1-TERMINAL UNITS	2025	29	20					20	30	-	3A-108, 3A-107
SPACE	-	31							32	-	SPACE
SPACE	-	33							34	-	SPACE
SPACE	-	35							36	-	SPACE
SPACE	-	37							38	-	SPACE
SPACE	-	39							40	-	SPACE
SPACE	-	41							42	-	SPACE
TOTAL LOAD											
PHASE A:		- VA									
PHASE B:		- VA									
PHASE C:		- VA									
TOTAL:		- VA									

NUMBERED NOTES

1. ----

DATE	REVISIONS




Entek III
812 Grayson Road
Pleasant Hill, CA 94523
(925) 947-1400
entekiii@comcast.net
BRANCH OFFICE
1000 Parkwood Circle, St. 140
Atlanta, GA 30339
(800) 326-6063





Approved : Project Engineer	Approved : Associate Director
Approved : Supervisory Engineer	Approved : Director
Approved : VP FMS	Approved :

PANEL SCHEDULES

Project Title: REPLACE AIR HANDLER UNITS BUILDING 77		Date: 4/24/12
Drawn: KEM		Project No.: 621-11-127
Checked: EY		Drawing No. 77-ES3
Location: JAMES H. GILLEN VA MEDICAL CENTER MOUNTAIN HOME, TN		Dwg 17 of 20







Department of
Veterans Affairs




"MCC -MCSC"

NUMBERED NOTES (X)


1. FURNISH & INSTALL THERMAL MAGNETIC BREAKERS, 480V, 3Ø, 25kAIC, RATINGS AS SHOWN. SQUARE D, NO SUBSTITUTES, FOR MODEL 4 MCC.
2. DISCONNECT (E) FEEDERS FROM (E) COMBINATION STARTERS & PULL TO SECTION 2, UNITS 2L-L & 2L-R.
3. FURNISH & INSTALL (N) 12" BUCKET W/2 THERMAL MAGNETIC BREAKERS, PER NOTE 1, AND ONE 12" BLANK DOOR, PER MCC-MCSC ELEVATION, THIS DWG.
4. REUSE (E) CONDUITS & WIRES



DATE	REVISIONS




Entek III
812 Grayson Road
Pleasant Hill, CA 94523
(925) 947-1400
entekiii@comcast.net
BRANCH OFFICE
1000 Parkwood Circle, St. 140
Atlanta, GA 30339
(800) 326-6063




Approved : Project Engineer	Approved : Associate Director
Approved : Supervisory Engineer	Approved : Director
Approved : VP FMS	Approved :

SINGLE LINE DIAGRAM & MCC ELECTRICAL	
--	--


Project Title: REPLACE AIR HANDLER UNITS BUILDING 77		Date: 4/24/12
Building Number: 77		Project No.: 621-11-127
Drawn: SZ	Drawing No. 77-ES4	Dwg 18 of 20
Checked: EY	Location: JAMES H. SULLIVAN VA MEDICAL CENTER MOUNTAIN HOME, TN	




Department of
Veterans Affairs



ROOF PLAN
1"=20'-0"



3RD FLOOR PLAN
1"=20'-0"



2ND FLOOR PLAN
1"=20'-0"



NUMBERED NOTES


1. ROOFING MATERIALS ARE ASSUMED ACM. ABATE ALL AREAS IN ACCORDANCE WITH SPECIFICATIONS PRIOR TO REMOVAL OR DISTURBANCE OF ROOF.
2. PIPING GASKETS ARE ASSUMED ACM. DISPOSE OF GASKETS IN ACCORDANCE WITH SPECIFICATIONS. THIS NOTE APPLIES TO ALL PIPING DEMOLITION ON THE ROOF, 3RD FLOOR, AND 2ND FLOOR.

GENERAL NOTES

1. SEE MECHANICAL SHEETS FOR EXTENTS OF DEMOLITION WORK.

PHASING

1. WORK FOR 77-AC6 IS PHASE 1. WORK FOR 77-AC8 IS PHASE 2. WORK FOR 77-AC10 IS PHASE 3. WORK FOR 3RD FLOOR TERMINAL UNITS IS PHASE 4. WORK FOR 77-AC8 TERMINAL UNITS IS PHASE 5. WORK FOR 77-AC10 TERMINAL UNITS IS PHASE 6.



KEY PLAN
NOT TO SCALE

DATE	REVISIONS

Entek III
812 Grayson Road
Pleasant Hill, CA 94523
(925) 947-1400
entekiii@comcast.net
BRANCH OFFICE
1000 Parkwood Circle, St. 140
Atlanta, GA 30339
(800) 326-6063



Approved : Project Engineer	Approved : Associate Director
Approved : Supervisory Engineer	Approved : Director
Approved : VP FMS	Approved :

Drawing Title:
HAZARDOUS MATERIALS

Project Title: REPLACE AIR HANDLER UNITS BUILDING 77		Date: 4/24/12
Building Number: 77		Project No.: 621-11-127
Drawn: BMA	Location: JAMES H. DUALIN VA MEDICAL CENTER MOUNTAIN HOME, TN	Drawing No.: 77-HA1
Checked: PM		Dwg 19 of 20



