

CONSTRUCTION BID DOCUMENTS

NARRATIVE

Improve Emergency Cache

Project No. 595-11-127



Lebanon VA Medical Center
Lebanon, PA

Miller-Remick LLC
1010 Kings Highway South
Building One – 1st Floor
Cherry Hill, New Jersey 08034
(856) 429-4000

April 10, 2013



Miller-Remick LLC

M.E.P. & Structural Engineering

A Service Disabled Veteran Owned Small Business



TABLE OF CONTENTS

CHAPTER	DESCRIPTION	PAGE
	Introduction & Executive Summary	i
1	Architectural	1-1
2	Heating, Ventilating, and Air Conditioning (HVAC)	2-1
3	Electrical	3-1
4	Plumbing	4-1
5	Fire Protection	5-1
6	Structural	6-1
7	Hazardous Materials	7-1
8	Critical Path Method (CPM)	8-1

APPENDIX	DESCRIPTION	PAGE
A	Critical Path Method / Project Schedule	A-1
B	Architectural	B-1
C	Heating, Ventilating, and Air Conditioning (HVAC)	C-1
D	Hazardous Materials	D-1
E	Electrical	E-1

CHAPTER 1

GENERAL

1. APPLICABLE LOCAL CODES

- .1 State of Pennsylvania Uniform Construction Code
- .2 International Code Series 2009 Edition Including
 - International Building Code (IBC)
 - International Fire Code (IFC)
 - International Fuel Gas Code (IFGC)
 - International Mechanical Code (IMC)
 - International Plumbing Code (IPC)
- .3 International Existing Building Code 2009 Edition or Chapter 34 of IBC as selected by Design Professional
- .4 International Fire Code 2009 Edition (as referenced by IBC-2009)
- .5 NFPA 99 - Healthcare Facilities
- .6 NFPA 101 - Life Safety Code, 2009 Edition
- .7 NFPA 13 - Standard for the Installation of Sprinkler Systems
- .8 NFPA 72 - National Fire Alarm and Signaling Code

2. APPLICABLE NATIONAL STANDARDS

- .1 Barrier Free Design Guides that exceeds minimums of the Architectural Barriers Act (ABA) and the Americans with Disabilities Act (ADA) for healthcare projects.

3. APPLICABLE OWNER GUIDELINES

- .1 Architectural Design Manual, August 2011 Edition
- .2 A/E Submission Instructions for Minor and NRM Construction Program

ARCHITECTURAL DESIGN

1. STERILE STORAGE (ROOM SRS02)

- .1 Renovate existing Kitchen and auxiliary spaces to create Sterile Storage Room and Clean Supply Storage Room in Building 19. The Sterile Storage Room will house medical supplies and pandemic supplies. The room is accessed through a new double door. The Sterile Storage Room also has direct access to the adjacent Clean Storage Room.
- .2 Areas:
 - Sterile Storage: 888 sf
 - Total Net Area: 888 sf
- .3 Scope of Work (all rooms unless noted otherwise)
 - New Epoxy Resin Floor (remove existing flooring and adhesives, shot blast concrete floor, install new 3/16 inch thick resinous floor similar to VA standard RES-3 with additional epoxy topcoat in orange peel finish for mopable surface). Repair and restore concrete subfloor after demolition of existing flooring and prior to the installation of new flooring.
 - New Acoustical Ceiling Panels in suspended grid system (Armstrong - Health Zone Ultima). Ceiling height: 8'-4"
 - Existing Glazed Tile walls to be furred out with 2-1/2" metal studs to accept new Gypsum Board. Gypsum Board walls to receive epoxy paint finish.
 - Wall protection on all exposed surfaces. Heavy duty protection where likely to be impacted by forklift or carts.
 - Corner protection on all exposed corners.
 - New Fire Rated Doors.
 - 3'-0" gypsum board window pocket at each existing windows with 11'-0" head height.
 - New Fire Rated Window
 - New plastic laminate work station.
- .4 Details

- Enlarge existing door opening to corridor to accommodate new double door.
- Existing walls to be extended to underside of deck in order to achieve one hour rating.
- Remove the three existing walk-in freezers in their entirety.
- Remove existing cove tile base to allow for installation of furring strips or metal studs on all existing glazed tile walls.
- Existing exterior windows to remain.

2. CLEAN SUPPLY STORAGE (ROOM SRS01)

- .1 Renovate existing Kitchen and auxiliary spaces to create Sterile Storage Room and Clean Supply Storage Room in Building 19. The Clean Supply Storage Room will house medical supplies and pandemic supplies. The room is accessed through a new double door. The Sterile Storage Room also has direct access to the adjacent Clean Storage Room.
- .2 Areas:
 - Clean Supply Storage: 1078 sf
 - Total Net Area: 1078 sf
- .3 Scope of Work (all rooms unless noted otherwise)
 - New Epoxy Resin Floor (remove existing flooring and adhesives, shot blast concrete floor, install new 3/16 inch thick resinous floor similar to VA standard RES-3 with additional epoxy topcoat in orange peel finish for mopable surface). Repair and restore concrete subfloor after demolition of existing flooring and prior to the installation of new flooring.
 - New Acoustical Ceiling Panels in suspended grid system (Armstrong - Health Zone Ultima). Ceiling height: 8'-4"
 - Existing Glazed Tile walls to be furred out to accept new Gypsum Board. Gypsum Board walls to receive epoxy paint finish.
 - Wall protection on all exposed surfaces. Heavy duty protection where likely to be impacted by forklift or carts.
 - Corner protection on all exposed corners.
 - New Fire Rated Doors.

- New Fire Rated Window
- New plastic laminate work station and casework.
- 3'-0" gypsum board window pocket at each existing windows with 11'-0" head height.
- Existing Glazed Tile walls to be furred out with 2-1/2" metal studs to accept new Gypsum Board. Gypsum Board walls to receive epoxy paint finish.

.4 Details

- Remove existing corridor door and infill wall. Match existing glazed tile finish on corridor side of new wall.
- Remove portion of existing corridor wall to accommodate new double fire rated door.
- Existing walls to be extended to underside of deck in order to achieve one hour rating.
- Remove existing cove tile base to allow for installation of furring strips or metal studs on all existing glazed tile walls.
- Existing exterior windows to remain.
- Construct new demising wall between Clean Supply Storage and existing Elevator Machine Room.
- Construct new rated demising wall between Clean Supply Storage and Sterile Storage Room. New fire rated double door.

3. EXISTING ELEVATOR MACHINE ROOM, MECHANICAL ROOM AND EXISTING TOILET ROOM

- .1 Provide code compliant egress from existing elevator machine room and mechanical room through the existing toilet room and to the corridor in Building 19. Demolish plumbing fixtures and walls in existing toilet room. Enlarge existing toilet room door opening to accommodate egress door. Provide mechanical cooling in the existing Elevator Machine Room and Mechanical Room. The installation of new mechanical equipment/ductwork will require the demolition of the existing ceiling. New ceiling will be installed.

.2 Areas:

- Mechanical Room: 244 sf

- Elevator Machine Rm: 110 sf

- Total Net Area: 354 sf

.3 Scope of Work (all rooms unless noted otherwise)

- Demolish plumbing fixtures and portions of the existing walls in existing toilet room.
- Remove portion of existing wall in Mechanical Room to accommodate new opening to former toilet room.
- Enlarge existing door opening in former toilet room to accommodate egress door.
- Remove existing gypsum board ceilings in Elevator Machine Room and adjacent Mechanical Room to allow for installation of cooling equipment/system.

.4 Details

- Install egress door for enlarged Mechanical Room.
- Install new Acoustic Panel Ceilings (Armstrong Fissured 755).

4. EXISTING VENDING ROOM

- .1 Provide mechanical cooling in the existing Vending Room in Building 19. The installation of new mechanical equipment/ductwork will require the demolition of the existing ceiling. New acoustic ceiling will be installed.

.2 Areas:

- Existing Vending: 114 sf
- Total Net Area: 114 sf

.3 Scope of Work (all rooms unless noted otherwise)

- Remove existing ceiling system.
- Install new Acoustic Panel Ceilings (Armstrong Fissured 755).

5. BULK STORAGE AREA (ROOM SRS03)

- .1 Renovate and subdivide existing Storage Room in Building 22. Housekeeping Storage will house general janitorial supplies and equipment. The room is accessed through a new double door.
- .2 Areas:
 - Bulk Storage Area: 2349 sf
 - Total Net Area: 2349 sf
- .3 Scope of Work (all rooms unless noted otherwise)
 - New VCT Floor with rubber base (Construct new floor system to match the floor height of the existing corridor floor). Repair and restore concrete subfloor after demolition of existing flooring and prior to the installation of new flooring.
 - New Acoustical Ceiling Panels in suspended grid system. Ceiling height: 8'-4"
 - Gypsum Board walls to receive paint finish.
 - Wall protection on all exposed surfaces. Heavy duty protection where likely to be impacted by forklift or carts.
 - Corner protection on all exposed corners.
 - New Fire Rated Doors.
- .4 Details
 - Remove existing corridor door and expand opening to allow for new double door.
 - Remove existing corridor door and infill with gypsum board partition. Corridor side of wall to match existing adjacent finishes.
 - Existing walls to be extended to underside of deck in order to achieve one hour rating.
 - Existing exterior windows to remain.
 - Construct new rated demising wall between Housekeeping Storage and Office Suite.
 - Construct new floor structure to align with existing corridor floor.

6. OFFICE SUITE (ROOMS OFA01, OFA02, OFA03, OFA04, OFA05, OFA06, OFA07, OFA08)
- .1 Renovate and subdivide existing Storage Room in Building 22 to house an office suite with seven individual offices and cubicles.
- .2 Areas:
- Open Office Area: 1239 sf
 - Office: 143 sf
 - Office: 134 sf
 - Office: 125 sf
 - Office: 129 sf
 - Office: 111 sf
 - Office: 109 sf
 - Office: 130 sf
 - Total Net Area: 2120 sf
- .3 Scope of Work (all rooms unless noted otherwise)
- New Carpet with rubber base (Construct new floor system to match the floor height of the existing corridor. Prepare new flooring system for installation of new carpeting).
 - New Acoustical Ceiling Panels in suspended grid system. Ceiling height: 8'-4". (Armstrong Ultima).
 - Walls to be gypsum board with painted finish. Sound attenuation batt insulation in wall cavity to achieve STC 40 rating.
 - Furr out all existing walls with 7/8" metal hat channel and 5/8" gypsum board.
 - Corner protection on all exposed corners.
 - New fire rated demising wall between Office Suite and Housekeeping Storage
- .4 Details

- Remove portions of the existing walls to accommodate new door openings.
- Remove existing corridor doors and infill with gypsum board partition. Corridor side of wall to match existing adjacent finishes.
- Existing exterior windows to remain.
- Construct new rated demising wall between Housekeeping Storage and Office Suite.
- Construct new partition walls for the individual offices.
- Construct new floor structure to align with existing corridor floor.
- Fur out all existing walls with 7/8” metal hat channel and 5/8” gypsum board.

CHAPTER 2

MECHANICAL

1. GENERAL

.1 Building 19

- This project will provide the renovation and expansion of the Emergency Cache storage areas at the VA Medical Center in Lebanon, PA. The mechanical design will bring new and existing spaces up to current VA design criteria.
- The project will provide the design for the upgrade of existing storage areas totaling approximately 2,230 square feet to separate clean and sterile storage areas. The project will also include the cooling of existing adjacent spaces (elevator machine room, mechanical room and vending room) totaling approximately 530 square feet.

.2 Building 22

- This project will provide the renovation and expansion of the EMS storage areas and provide a new office area at the VA Medical Center in Lebanon, PA. The mechanical design will bring the new and existing spaces up to current VA design criteria.
- The project will provide the design for the upgrade of existing storage areas and a new office area totaling approximately 4,700 square feet.

2. SCOPE

.1 The renovation and expansion of storage areas include the following locations and scope:

- Building 19 – *Emergency Cache Clean and Sterile Storage Rooms* – The existing air handling unit, AC-3-19, currently serving the space will be modified and dedicated to serve the new clean and sterile storage rooms only. Both rooms will be designed to meet current VA design requirements for *Satellite SPD Storage*.
- Building 19 – *Vending and Mechanical Rooms* - Provide each room with a (1-1/2) ton, 2-pipe, cooling only chilled water fan coil unit mounted in the ceiling. Fan coil unit to have ducted supply and return. Provide return air filter grille. Individual outside air ductwork will not be provided to each fan coil unit. Cooling coil condensate piping to tie into existing cooling coil condensate drain line located above adjacent corridor ceiling. Controls will tie into the existing Delta control system.

- Building 19 - Elevator Machine Room – Provide a wall mounted (2) ton split system heat pump with inverter technology to serve the room. The condensing unit to be mounted outside, on the exterior wall, 2'0" above grade. Demolish existing fan and associated filter rack. Demolish existing baseboard connector. Blank off louvers and provide wall mount heat pump in location vacated by demolished fan. Cooling coil condensate piping to run through exterior wall and spill to grade. Unit to be on emergency power.
- Building 19 – Tele/Data Room – Per Lebanon VA, room will be cooled under separate contract.
- Building 22 – EMS Storage: Provide a new variable volume, return air AHU to serve both the new EMS storage area and the new office suite. The storage area will be designed to meet current VA design requirements for *Non-Sterile Storage*, except, per VA facilities, unit will *not* be designed for 100% OA.
- Building 22 – Office Suite: Provide a new variable volume, return air AHU to serve both the new EMS storage and the new office suite. The office suite will be designed to meet current VA design requirements.

3. EXISTING CONDITIONS

.1 Building 19

- EMS Storage - The former kitchen area is cooled and heated by a single zone, variable volume, air handling unit (AC-3-19) mounted on roof dunnage directly above the project area. The cooling medium is chilled water and the heating medium is steam. A general building exhaust fan (located outside the project boundary) exhausts the toilet room, janitor's closet and (2) small storage rooms that exit directly into the EMS storage area (within the former kitchen boundary). Per VA facilities, the supply and return fan VFD's for AC-3-19 are set to run as constant volume.
- Elevator Machine Room – Elevator equipment is cooled by bringing outside air, through an intake louver and filter, directly into the room and exhausting it through a wall-mounted fan and louver. Heating is provided by a wall mounted convactor.
- Elevator Machine Room Office/Storage Area – Room adjacent to elevator machine room and EMS storage area is cooled and heated from AC-3-19.
- Vending Area - Room adjacent to EMS storage area is cooled and heated from AC-3-19.

- Tele/Data Room – Room adjacent to EMS storage area brings transfer air under the door from adjacent Vending Room and exhausts through a general building exhaust fan located outside the project boundary.

.2 Building 22

- Storage areas for EMS, Electrical, and Emergency Cache are heated and cooled through (6) ceiling mounted, 4-pipe fan coil units. The cooling medium is chilled water and the heating medium is low pressure steam piped to each unit. Cooling coil condensate is manifolded together and piped to the exterior at a height above the windows. Outside air is ducted to (3) of the fan coils from an existing energy recovery unit located on the third floor roof.

4. DESIGN APPROACH

- .1 Each area was analyzed for design approach requirements in the DVA, 'HVAC Design Manual for New, Replacement, Addition, and Renovation of Existing VA Facilities,' for *Supply, Processing, and Distribution* (SPD) areas. The following preliminary design approach will be utilized for each type of storage space:

.2 **Building 19** - Sterile Storage and Clean Storage Areas

- Indoor design conditions: 72-78 degree F design temperature for heating and cooling seasons.
- Humidity: In order to maintain the spaces within a range of 20% to 60% relative humidity during all seasons, an electrode steam humidifier will be provided for each room.
- Minimum of ten air changes per hour (10 ACH).
- Modify existing AC-3-19 for variable volume control.
- An offset between supply and return air quantities will maintain positive air pressurization within each space.
- New supply and return ductwork will be run from existing AC-3-19 to each room.
- Each room will be designed with a VAV control box and electric reheat coil with SCR technology for individual temperature control.
- A wall mounted steam-to-clean steam generator (type Nortec; model SSG) will be provided for each VAV box. Steam and condensate branch piping to the generators will be from basement floor below. Steam distribution

pipings will be routed from each generator to a duct-mounted steam humidifier (type Nortec; model SAM-E; short absorption manifold) installed downstream of each VAV box. Ductwork 3'0" downstream of humidifier to be stainless steel.

- Each room to be provided with (2) one and a half ton split system heat pumps with inverter technology on emergency power for conditions when chiller plant is down. (1) Air cooled condensing unit will serve both heat pumps per room. Cooling coil condensate piping to run through exterior wall and spill to grade. Condensing units to be mounted outside, on the exterior wall, 2'0" above grade.
- New DDC controls to tie into existing building/site Delta control system.
- Refer to Appendix for sketches and load calculations.

.3 **Building 22 – Non-Sterile Storage**

- A new variable volume, return air, AHU will be designed to serve both the new EMS storage and new office suite within Building 22. The unit will be located on dunnage, 3'0" of the ground (per Lebanon VA site standards) at the exterior of the building adjacent to the project area. Ductwork will run outside and exposed before entering the project area overhead and above the ceiling.
- Per VA, outside air ductwork is not requested to extend up the side of the building to 30'0" off of the ground.
- Chilled water, steam and condensate will be delivered to the new unit via the basement crawl space.
- The new spaces will not be designed for humidity control. Space will be left in the AHU for a future humidifier.
- Each enclosed office to have a dedicated VAV control box with a hot water reheat coil for individual temperature control. Remaining open office space to be controlled through a single VAV control box with hot water reheat coil.
- The new storage area will be served by two variable air volume (VAV) control boxes with hot water reheat coils for temperature control.
- A new dual pump skid with steam-to-hot water heat exchanger will be located in the basement of Building 22 and will take medium pressure steam from the site loop and deliver heating hot water to the new first floor reheat coils.

- New DDC controls to tie into existing building/site Delta control system.
 - AHU shall be designed to provide design CFM with the fan VFD's set to 80%.
 - Refer to Appendix for sketches, load calculations, and AHU cut sheet.
4. Per VA, seismic restraints are not required.
5. HEATING PLANT
- .1 The existing Lebanon VA Medical Center utilizes high, medium, and low pressure steam as a medium to supply heat to the various systems throughout the campus. Steam piping is run to each building through a series of tunnels and crawl spaces, and will be tapped for the new systems being provided as part of this renovation project. Refer to the sketches for additional details.
6. COOLING PLANT
- .1 The existing Lebanon VA Medical Center utilizes chilled water as a medium to supply cooling to the various systems throughout the building. Chilled water piping is run to each building through a series of tunnels and crawl spaces, and will be tapped for the new systems being provided as part of this renovation project. Refer to the sketches for additional details.

CHAPTER 3

ELECTRICAL

1. GENERAL

.1 Building 19

- This project will provide the renovation and expansion of the Emergency Cache storage areas at the VA Medical Center in Lebanon, PA. The electrical design will bring new and existing spaces up to current VA design criteria.
- The project will provide the design for the upgrade of existing storage areas totaling approximately 2,230 square feet to separate clean and sterile storage areas. The project will also include the cooling of existing adjacent spaces (elevator machine room, mechanical room and vending room) totaling approximately 530 square feet.

.2 Building 22

- This project will provide the renovation and expansion of the EMS storage areas and provide a new office area at the VA Medical Center in Lebanon, PA. The electrical design will bring the new and existing spaces up to current VA design criteria.
- The project will provide the design for the upgrade of existing storage areas and a new office area totaling approximately 4,700 square feet.

2. SCOPE

.1 The renovation and expansion of storage areas include the following scope:

- Lighting: Building 19 shall be provided with new, fluorescent, recessed, and sealed fixtures. The fixtures will be designed to separate internal lighting components from the surrounding environment to prevent contamination of the environment with dirt, dust, and moisture. Lighting levels will be in accordance with VA Design Standards of 30 foot candles for clean and sterile supplies. Light switching shall be controlled with switching at the main doors and shall override ceiling mounted occupancy sensors. Building 22 shall follow the VA design guide for office fixtures and switching.
- Card Readers: Proximity card readers shall be provided for secure areas. The card readers shall be GE models per the VA request to match existing card readers at the facility.

- Convenience Receptacles: Convenience receptacles shall be provided every 13 feet in the clean supply and sterile storage areas of Building 19. Building 22 shall follow the VA design guide placement of receptacles for offices.
- Mechanical Systems: For Buildings 19 and 22, all new mechanical systems will be provided with new branch circuits and local disconnect switches as required in accordance with VA Electrical Design Standards.
- H.V.A.C.: Building 19 has an existing air handling unit, AC-3-19. It shall be upgraded to have (variable frequency drives) VFD's on its supply and return fans. Building 22 shall have a new air handling unit that shall come with VFD's.
- Phone and Data: For Building 19, phone and data outlets shall be provided at the doors and shall be provided every 13 feet in the clean supply and sterile storage areas next to receptacles. Building 22 shall follow the VA electrical design guide for offices. For both buildings, all data and phone outlets shall be tied into each building's existing system.
- Fire Alarm: For Building 19, strobes and voice mass notification speakers shall be placed in the storage areas, mechanical room, elevator machine room and vending room. Heat and smoke detection shall be provided in the elevator machine room. Smoke detection shall be provided in the machine room for the elevator landing smoke detector requirements. All new devices shall be tied into the building's existing fire alarm system. Building 22 shall be provided with speaker/strobes in the general office area and in the storage areas. All new devices shall be tied into the building's existing fire alarm system.
- Emergency power: the following equipment in the Building 19 renovation area shall be placed on emergency power. This includes:
 - Convenience receptacles
 - Lighting
 - The existing AHU currently serving the space.
 - The new split system DX units for the clean and sterile storage areas.
 - The new split system DX unit for the existing elevator machine room.

CHAPTER 4

PLUMBING

1. GENERAL

- .1 The plumbing systems will be in accordance with the DVA Plumbing Design Manual; Revised April 2010
- .2 The plumbing codes and standards planned to be utilized are the latest editions of the following;
 - International Building Code (IBC)
 - International Fire Code (IFC)
 - International Fuel Gas Code (IFGC)
 - International Mechanical Code (IMC)
 - International Plumbing Code (IPC)

2. EXISTING CONDITIONS

- .1 Building 19
 - The project boundary encompasses first floor areas and rooms in Building 19, formally used as a kitchen, and currently used as EMS storage. Much of the kitchen equipment has been removed; however various associated piping has been abandoned-in-place within the ceiling cavity.
 - Sanitary piping to existing floor drains runs on the basement level in crawl spaces located below the floor.
- .2 Building 22
 - There is currently no plumbing piping/equipment located within the project boundary of Building 22.

3. SCHEMATIC DESIGN APPROACH

- .1 Building 19
 - The project scope in Building 19 consists of demolition work only. There is no new plumbing work in Building 19.

- Demolition consists of removing an existing toilet, three sinks, multiple floor drains and all associated piping back to existing mains and capped air water/tight. Piping to be insulated to match existing.

.2 Building 22

- There is no plumbing scope (either demolition or new work) in Building 22.

CHAPTER 5

FIRE PROTECTION

1. GENERAL

- .1 The fire alarm and fire protection systems will be in accordance with the DVA Fire Protection Design Manual; Sixth Edition; Revised September 2011.
- .2 The fire protection codes and standards planned to be utilized are the latest editions of the National Fire Codes (NFC) as published by the National Fire Protection Association (NFPA). Where fire alarm or fire protection features are not addressed by the NFC, the International Building Code (IBC) or other referenced standard shall be used. For the renovations, the following NFC standards for the base code references.

- NFPA 101 – Life Safety Code
- NFPA 13 – Standard for the Installation of Sprinkler Systems
- NFPA 72 – National Fire Alarm and Signaling Code

Should the codes from the International Code Council (ICC), need to be consulted, the following form the base code references.

- International Building Code (IBC)
- International Fire Code (IFC)
- International Fuel Gas Code (IFGC)
- International Mechanical Code (IMC)
- International Plumbing Code (IPC)

2. EXISTING CONDITIONS

- .1 The design of the Improve Emergency Cache renovation will integrate into the systems and services of the existing VA Medical Center campus.
 - Fire Alarm System – Existing initiation devices and notification devices are connected to the FACP either directly or through Fire Alarm Terminal Cabinets (FATC). The existing fire alarm system is addressable, and any new devices will be compatible with the addressable system.

- Fire Protection System – Building 19 and Building 22 are fully sprinklered. The existing heads and piping will be modified as necessary to support the future project areas. Existing sprinkler piping within the Building 19 project boundary area has been identified as CPVC piping. Lebanon VA Facilities has indicated other similar installations on campus with CPVC piping were able to be modified without being replaced. Renovated areas are to be utilized as storage and thus classified as ordinary hazard per NFPA. CPVC piping is only rated for light hazard areas therefore it should be replaced with acceptable rated (steel) pipe.

3. SCHEMATIC DESIGN APPROACH

.1 Building 19

- The fire alarm system for the renovation will connect to, and extend from, the existing building fire alarm system.
- The fire protection system for the renovation will connect to, and extend from, the existing building wet pipe sprinkler fire suppression system.
- The renovated areas shall be designed as an NFPA 13, Ordinary Hazard Group 1 system hydraulically calculated utilizing the area density method by the contractor for 0.15 gpm per sq.ft over 1500 sq.ft. Calculated demand including hose stream requirements shall fall no less than 10 percent below the available water supply (to be determined).
- The existing CPVC piping within the new storage area will be removed. The new fire protection system shall utilize all Schedule 40 pipe and fittings. All other components shall be rated for 300 psi. Sprinkler heads in areas with acoustic tile ceilings shall be chrome plated, recessed heads with chrome plated steel escutcheons. Areas with unfinished exposed ceilings will be provided with rough brass upright heads. Sprinklers throughout to be ordinary temperature rated except for electrical rooms/closets which shall be intermediate temperature rated and mechanical rooms to be provided with high temperature rated heads.

.2 Building 22

- The fire alarm system for the renovation will connect to, and extend from, the existing building fire alarm system.
- All existing sprinkler piping within the project boundary to be demolished back to nearest main at project boundary. The new fire protection system for the renovation areas will connect to, and extend from, the existing building wet pipe sprinkler fire suppression system.

- The renovated areas shall be designed as an NFPA 13, Ordinary Hazard Group 1 system hydraulically calculated utilizing the area density method by the contractor for 0.15 gpm per sq.ft over 1500 sq.ft. Calculated demand including hose stream requirements shall fall no less than 10 percent below the available water supply (to be determined).
- The new fire protection system shall utilize all Schedule 40 pipe and fittings. All other components shall be rated for 300 psi. Sprinkler heads in areas with acoustic tile ceilings shall be chrome plated, recessed heads with chrome plated steel escutcheons. Areas with unfinished exposed ceilings will be provided with rough brass upright heads. Sprinklers throughout to be ordinary temperature rated except for electrical rooms/closets which shall be intermediate temperature rated heads.

CHAPTER 6

STRUCTURAL

1. Applicable Codes and Standards

- International Building Code – 2009 Edition
- American Society of Civil Engineers - Minimum Design Loads for Buildings and Other Structures - ASCE 7-05
- Department of Veterans Affairs Seismic Design Requirements H-18-8
- VA Program Guide PG-18-15 Volume C
- VA Structural Design Manual For Hospital Projects - August 2009
- American Concrete Institute - Building Code Requirements for Structural Concrete – ACI 318-08
- American Institute of Steel Construction - Manual of Steel Construction – Thirteenth Edition - AISC 360-05
- American Welding Society - Structural Welding Code for Steel – ASW D1.1
- American Society for Testing and Materials – ASTM Standards

2. Design Loads

1. Dead loads for the purpose of structural design are the actual self-weight of the permanent building construction materials. In addition to the self-weight of the structure, the following additional dead loads are to be included in the design:

- Partitions in Administrative Services Area: 20 PSF
- HVAC Units 5,000 LBS (+/-)

2. Design live loads to be supported are as follows:

- Administrative Services 80 PSF
- Corridors 100 PSF
- Light Storage 125 PSF
- Mechanical Areas 150 PSF

3. Snow Load:

- Ground Snow Load (Pg) 30 PSF
- Snow Importance Factor (Is) 1.2
- Exposure Factor (Ce) 1.0
- Thermal Factor (Ct) 1.2

4. Wind Load:

- Basic Wind Velocity 90 MPH (3-second gust)
- Exposure Category B
- Wind Importance Factor (Iw) 1.15

5. Seismic Load:

- Occupancy Category IV
- Seismic Importance Factor (Ie) 1.5
- 0.2 Second Spectral Response Acceleration Ss 0.228g
- 1.0 Second Spectral Response Acceleration S1 0.057g
- Soil Site Classification C
- Seismic Design Category C
- Seismic Force-Resisting System: N/A
- Analysis Procedure: N/A

6. All load combinations shall be in conformance with the listed codes and standards.

3. Structural Systems

1. Building 19:

- New mechanical equipment will be supported from the existing structure. Penetrations through the existing structure may be required to provide a pathway for mechanical services.

2. Building 22:

- The proposed project area was originally constructed as a bowling alley, and is recessed several feet below the adjacent finished floor elevation. The existing recessed floor is constructed of cast-in-place concrete, and a wood-framed platform has been built over a portion of this concrete floor. The existing wood-framed floor platform is proposed to be removed, with a new elevated slab constructed over the existing recessed concrete floor structure. The new slab will be supported on structural steel framing, and will match the existing floor elevation.
- A new HVAC unit is proposed to be located outside the building on grade, adjacent to the project area. The unit is proposed to be elevated on steel dunnage framing, over an exterior concrete slab on grade. It is understood by the design team that this support configuration is the preference of the DVA Lebanon.
- Penetrations through the existing structure may be required to provide a pathway for mechanical services.

4. Structural Materials

1. Concrete

- Minimum Compressive Strength: $f'_c=4,500$ psi
- Maximum Water-Cementitious Materials Ratio: 0.45
- Minimum Cementitious Materials Content: 500 lb/cu. yd.
- Air Content: 4.5 to 5.5 percent
- Reinforcing Bars: ASTM A 615/A 615M, Grade 60, deformed.
- Normal-Weight Aggregates: ASTM C 33, coarse aggregate or better, graded. Maximum Coarse-Aggregate Size: 1 1/2 inch nominal.
- Air-Entraining Admixture: ASTM C 260.
- High-Range, Water-Reducing Admixture: ASTM C 494/C 494M, Type F.

2. Structural Steel

- Rectangular and Square HSS: ASTM A 500/A 500M, Grade B ($F_y = 46$ ksi).
- Round HSS: ASTM A500, Grade B ($F_y = 42$ ksi).

- Channels, Angles, M, S-Shapes: ASTM A 36/A 36M (Fy=36 ksi).
- Plate: ASTM A 36/A 36M (Fy=36 ksi).
- Wide Flange Shapes: ASTM A992 (Fy = 50 ksi)

5. Structural Special Inspections

1. In accordance with Section 1704 of the international building code, and all applicable state and local requirements, an independent approved agency shall make periodic and/or continuous inspections of the construction progress in accordance with the following requirements:

Steel Construction	Section 1704.3, Table 1704.3
Concrete Construction	Section 1704.4, Table 1704.4

CHAPTER 7

HAZARDOUS MATERIALS

1. GENERAL

- .1 A previous hazardous material investigation associated with Building 19 and Building 22 was performed in August and September of 2010. The report was sent to Miller-Remick by the Lebanon VA, and has been included with this design narrative in Appendix E.
- .2 As part of this project, a new investigation was performed within both Building 19 and Building 22. The reports of which are included in Appendix E.

2. ASBESTOS CONTAINING MATERIALS

- .1 The 2010 hazardous materials inspection appears to have been limited solely to visually apparent suspect ACM, and did not include intrusive means of access such as opening wall and ceiling cavities to identify hidden and concealed ACM within wall cavities and chases.
- .2 As part of this project, samples were taken from floors, walls, wall cavities and chases, ceiling cavities, as well as pipe insulation and submitted for testing.

CHAPTER 8

CRITICAL PATH METHOD (CPM)

1. PROJECT MASTER SCHEDULE

- .1 Refer to Appendix A for the Project Master Schedule, which shows the projected overall schedule from the Design Phase Services Notice-To-Proceed (NTP), to the final turnover after completion of the design.
- .2 The schedule is not final and will be expanded and updated throughout the design and construction of this project.

2. PHASING

- .1 Phase I – Building 19 – Temporarily Relocate Existing EMS Storage
 - Prior to construction, temporarily relocate EMS storage items in Building 19 by consolidating them into underutilized space already within the existing Building 22 EMS storage area as well as into alternate locations within the VA. Possible locations within Building 19 include the adjacent office space outside of the existing elevator machine room and the adjacent storage room west of the elevator machine room.
- .2 Phase II – Building 19 – Emergency Cache
 - Once Phase I has been substantially completed, demolition and construction can begin in Building 19.
- .3 Phase III – Building 19 and 22 – Emergency Cache
 - Once Phase II has been substantially completed, Emergency Cache items currently stored within Building 22 can be relocated into the new clean and sterile storage areas of the new Emergency Cache within Building 19.
- .4 Phase IV – Building 22 – EMS Storage
 - Once Phase III has been substantially completed, EMS items currently stored in Building 22 can then be moved to the space vacated by Emergency Cache in Building 22 so demolition and construction can begin on the new EMS storage area within Building 22.
- .5 Phase V – Building 22 - EMS Storage
 - Once Phase IV has been substantially completed, EMS storage items temporarily housed in the existing Emergency Cache area in Building 22 can be moved to the new EMS storage area in Building 22.

.6 Phase VI – Building 22 – Office Suite

- Once Phase V has been substantially completed, demolition and construction can begin on the Office Suite within Building 22.

APPENDIX A


CRITICAL PATH METHOD (CPM) PROJECT SCHEDULE

ID	Task Name	Duration	Start	Finish
1	Notice to Proceed	1 day	6/15/12	6/15/12
2	Kick-Off Meeting	1 day	6/15/12	6/15/12
3				
4	SCHEMATIC DESIGN PHASE	134 days	6/15/12	12/19/12
5	Prepare Design Documents	26 days	6/15/12	7/20/12
6	VA Review	108 days	7/23/12	12/19/12
7				
8	25% DESIGN DEVELOPMENT PHASE	37 days	12/20/12	2/8/13
9	Prepare Design Documents	22 days	12/20/12	1/18/13
10	VA Review	15 days	1/21/13	2/8/13
11				
12	75% DESIGN DEVELOPMENT PHASE	25 days	2/14/13	3/20/13
13	Prepare Design Documents	20 days	2/14/13	3/13/13
14	VA Review	8 days	3/11/13	3/20/13
15				
16	100% DESIGN DEVELOPMENT PHASE	12 days	3/21/13	4/5/13
17	Prepare Design Documents	8 days	3/21/13	4/1/13
18	VA Review	7 days	3/28/13	4/5/13
19				
20	100% BID DOCUMENTS	4 days	4/5/13	4/10/13
21	Prepare Design Documents	4 days	4/5/13	4/10/13
22				
23	BID PHASE	25 days	4/11/13	5/15/13
24	Advertise for Bid	2 wks	4/11/13	4/24/13
25	Bid Period	3 wks	4/25/13	5/15/13
26				
27	AWARD PHASE	15 days	5/16/13	6/5/13
28	Evaluate Bids	2 wks	5/16/13	5/29/13
29	Award Contract	1 wk	5/30/13	6/5/13
30				
31	CONSTRUCTION PHASE	197 days	6/13/13	3/14/14
32	Submittal Review	4 wks	6/13/13	7/10/13
33	Procurement of Long Lead Items	16 wks	7/11/13	10/30/13
34	Mobilization	1 wk	8/22/13	8/28/13
35	Major Construction	130 days	8/29/13	2/26/14
36	Punchlist/Closeout	12 days	2/27/14	3/14/14
37	Pre-final inspection	1 day	2/27/14	2/27/14
38	Develop Punch List	5 days	2/28/14	3/6/14
39	As-built drawings/ O&M Manuals	10 days	2/28/14	3/13/14
40	Final cost analysis	5 days	3/7/14	3/13/14
41	Final Inspection	1 day	3/14/14	3/14/14

APPENDIX B
ARCHITECTURAL

Sterile and Non-Sterile Storage Area (Surgery) (ORSS1)

Floor Plan



NSF (NSM) per Space Criteria

M2 1 0 2'-8" 5'-4" 10'-8" Ft


Scale: 3/32" = 1'-0"



NOTE: Guide plates are graphical representations of selected room types, illustrating the integration of space, components, systems, and equipment. They provide typical configurations and general technical guidance, and are not intended to be project specific. Specific infrastructure design requirements are contained in VA Design Manuals and Space Planning Criteria located in the VA Technical Information Library.

Sterile and Non-Sterile Storage Area (Surgery) (ORSS1)

Reflected Ceiling Plan



NSF (NSM) per Space Criteria

M2 1 0 2'-8" 5'-4" 10'-8"Ft

Scale: 3/32" = 1'-0"



NOTE: Guide plates are graphical representations of selected room types, illustrating the integration of space, components, systems, and equipment. They provide typical configurations and general technical guidance, and are not intended to be project specific. Specific infrastructure design requirements are contained in VA Design Manuals and Space Planning Criteria located in the VA Technical Information Library.

Sterile and Non-Sterile Storage Area (Surgery) (ORSS1)

Design Standards

ARCHITECTURAL

Ceiling:	AT (SP)
Ceiling Height:	9'-0" (2700 mm)
Wall Finish:	GWB (SC)
Wainscot:	--
Base:	WSF
Floor Finish:	WSF
Slab Depression:	--
Sound Protection:	--
Notes:	--

SPECIAL EQUIPMENT

Wall Protection	--
-----------------	----

LIGHTING

General:	20 FC – 0.5 W/SF (MIN)
Special:	As Shown
Notes:	

- 1) Fixture A: 2'x4' (600 mm x 1200 mm) recessed, grid mounted fluorescent light fixture, UL listed for wet location, prismatic lens with gasketing, w/ F32T8 lamps 3500•K, CRI=70 (minimum).
- 2) The foot-candle level is average maintained.
- 3) Provide ballasts per fixture for desired switching configuration. To provide a uniform lighting level, switch inner lamp(s) on first switch and outer lamps on second switch.
- 4) Exact quantity, location, and lamping of light fixtures shall be chosen to meet the foot-candle requirement.

POWER

General:	As Shown
Emergency:	As Shown
Notes:	--

COMMUNICATION/SPECIAL SYSTEMS

Data:	Yes
Telephone:	Yes
Intercom:	--
Nurse Call:	--
Public Address:	--
Radio/Entertainment:	--
MATV:	--
CCTV:	--
MID:	--
Security/Duress:	--
VTEL:	--
VA Satellite TV:	--
Notes:	--

HEATING, VENTILATING AND AIR CONDITIONING

Inside Design Conditions:	
Dry-Bulb Temperature:	73F (23C)
Relative Humidity:	30% - 55%
Minimum Total Air Changes per Hour:	4
Room Air Exhaust Required:	Yes, 100%
Special Exhaust or General Exhaust:	General Exhaust
Room Air Return Permitted:	No
Room Air Balance:	Positive (+)
Notes:	

PLUMBING AND MEDICAL GASES

Cold Water:	--
Hot Water:	--
Laboratory Air:	--
Laboratory Vacuum:	--
Sanitary Drain:	--
Reagent Grade Water:	--
Medical Air:	--
Medical Vacuum:	--
Oxygen:	--
Notes:	--


Sterile and Non-Sterile Storage Area (Surgery) (ORSS1)

Equipment List

JSN	SYMBOL	QTY	AI	DESCRIPTION
		AR		<u>Shelves, Freestanding, Open Wire, on Wheels</u> Freestanding open wire shelves on wheels. Bottom shelf is to be solid and 8" from the floor.
A5145		1	CC	<u>Hook, Garment, Double, Stainless Steel, Surface Mounted</u> A surface mounted, satin finish stainless steel, double garment hook. Equipped with a concealed mounting bracket that is secured to a concealed wall plate. For general purpose use throughout the facility to hang various items of apparel.
F2000		1	VV	<u>Basket, Wastepaper, Round, Metal</u> Round wastepaper basket, approximately 18" high x 16" diameter. This metal unit is used to collect and temporarily store small quantities of paper refuse in patient rooms, administrative areas and nursing stations.
		AR	CC	Receptacle, electrical, duplex, 120 volt (PG-18-1, MCS 26 27 26).
		AR	CC	Receptacle, electrical, quadruplex, 120 volt, for computer equipment items (PG-18-1, MCS 26 27 26).
		AR	CC	Telephone/Data combination outlet (PG-18-1, MCS 27 31 00).

Sterile and Non-Sterile Storage Area (Nursing Units) (SRS01)

Floor Plan



NSF (NSM) per Space Criteria

M2 1 0 2'-8" 5'-4" 10'-8"Ft



Scale: 3/32" = 1'-0"



NOTE: Guide plates are graphical representations of selected room types, illustrating the integration of space, components, systems, and equipment. They provide typical configurations and general technical guidance, and are not intended to be project specific. Specific infrastructure design requirements are contained in VA Design Manuals and Space Planning Criteria located in the VA Technical Information Library.

Sterile and Non-Sterile Storage Area (Nursing Units) (SRS01)

Reflected Ceiling Plan



NSF (NSM) per Space Criteria

M2 1 0 2'-8" 5'-4" 10'-8"Ft

Scale: 3/32" = 1'-0"



NOTE: Guide plates are graphical representations of selected room types, illustrating the integration of space, components, systems, and equipment. They provide typical configurations and general technical guidance, and are not intended to be project specific. Specific infrastructure design requirements are contained in VA Design Manuals and Space Planning Criteria located in the VA Technical Information Library.

Sterile and Non-Sterile Storage Area (Nursing Units) (SRS01)

Design Standards

ARCHITECTURAL

Ceiling:	AT (SP)
Ceiling Height:	9'-0" (2700 mm)
Wall Finish:	GWB (SC)
Wainscot:	--
Base:	RB
Floor Finish:	VCT
Slab Depression:	--
Sound Protection:	--
Notes:	--

SPECIAL EQUIPMENT

Wall Protection	--
-----------------	----

LIGHTING

General:	20 FC – 0.5 W/SF (MIN)
Special:	As Shown
Notes:	

- 1) Fixture A: 2'x4' (600 mm x 1200 mm) recessed, grid mounted fluorescent light fixture, UL listed for wet location, prismatic lens with gasketing, w/ F32T8 lamps 3500•K, CRI=70 (minimum).).
- 2) The foot-candle level is average maintained.
- 3) Provide ballasts per fixture for desired switching configuration. To provide a uniform lighting level, switch inner lamp(s) on first switch and outer lamps on second switch.
- 4) Exact quantity, location, and lamping of light fixtures shall be chosen to meet the foot-candle requirement.

POWER

General:	As Shown
Emergency:	Egress lighting
Notes:	--

COMMUNICATION/SPECIAL SYSTEMS

Data:	--
Telephone:	--
Intercom:	--
Nurse Call:	--
Public Address:	--
Radio/Entertainment:	--
MATV:	--
CCTV:	--
MID:	--
Security/Duress:	--
VTEL:	--
VA Satellite TV:	--
Notes:	--

HEATING, VENTILATING AND AIR CONDITIONING

Inside Design Conditions:	
Dry-Bulb Temperature:	73F (23C)
Relative Humidity:	30% - 55%
Minimum Total Air Changes per Hour:	4
Room Air Exhaust Required:	Yes, 100%
Special Exhaust or General Exhaust:	General Exhaust
Room Air Return Permitted:	No
Room Air Balance:	Note 1)
Notes:	
1) Positive (+) to Clean Receiving & Breakout Area	

PLUMBING AND MEDICAL GASES

Cold Water:	--
Hot Water:	--
Laboratory Air:	--
Laboratory Vacuum:	--
Sanitary Drain:	--
Reagent Grade Water:	--
Medical Air:	--
Medical Vacuum:	--
Oxygen:	--
Notes:	--

Sterile and Non-Sterile Storage Area (Nursing Units) (SRS01)


Equipment List

JSN	SYMBOL	QTY	AI	DESCRIPTION
		AR		<u>Shelves, Freestanding, Open Wire, on Wheels</u> Freestanding open wire shelves on wheels. Bottom shelf is to be solid and 8" from the floor.
A5145		1	CC	<u>Hook, Garment, Double, Stainless Steel, Surface Mounted</u> A surface mounted, satin finish stainless steel, double garment hook. Equipped with a concealed mounting bracket that is secured to a concealed wall plate. For general purpose use throughout the facility to hang various items of apparel.
F2000		1	VV	<u>Basket, Wastepaper, Round, Metal</u> Round wastepaper basket, approximately 18" high X 16" diameter. This metal unit is used to collect and temporarily store small quantities of paper refuse in patient rooms, administrative areas and nursing stations.
M2070		AR	VV	<u>Shelving, Storage, 77x36x18</u> Storage shelving unit approximately 77" H X 36" W X 18" D. Corrosion resistant baked enamel, galvanized or stainless steel open unit with adjustable shelves. The closed version is also available. For use in the storage room.
		AR		<u>Shelves, Freestanding, Open Wire, on Wheels</u> Freestanding open wire shelves on wheels. Bottom shelf is to be solid.
		AR		Closed transport carts.
		AR	CC	Receptacle, electrical, duplex, 120 volt (PG-18-1, MCS 26 27 26).

Office (OFA01)(OFA02)(OFD01)(OFD03)(OFDC1)(SEC01)

Floor Plan

CONSIDER PROVIDING BACKING AND ROUGH-INS FOR CONVERSION TO EXAM ROOM-
SEE GUIDE PLATE 4-76 SIMILAR.



Typical: 120 NSF/ 11.2 NSM (Shown Above)

Minimum: 80 NSF/ 7.4 NSM


Maximum: 150 NSF/ 13.9 NSM

SCALE $\frac{1}{4}" = 1'-0"$



NOTE: Guide plates are graphical representations of selected room types, illustrating the integration of space, components, systems, and equipment. They provide typical configurations and general technical guidance, and are not intended to be project specific. Specific infrastructure design requirements are contained in VA Design Manuals and Space Planning Criteria located in the VA Technical Information Library.

Office (OFA01)(OFA02)(OFD01)(OFD03)(OFDC1)(SEC01)
Reflected Ceiling Plan



Typical: 120 NSF/ 11.2 NSM (Shown Above)
Minimum: 80 NSF/ 7.4 NSM
Maximum: 150 NSF/ 13.9 NSM

SCALE $\frac{1}{4}" = 1'-0"$



NOTE: Guide plates are graphical representations of selected room types, illustrating the integration of space, components, systems, and equipment. They provide typical configurations and general technical guidance, and are not intended to be project specific. Specific infrastructure design requirements are contained in VA Design Manuals and Space Planning Criteria located in the VA Technical Information Library.

Office (OFA01) (OFA02) (OFD01) (OFD03) (OFDC1) (SEC01)

Design Standards

ARCHITECTURAL

Ceiling:	AT
Ceiling Height:	9'-0" (2700 mm)
Wall Finish:	GWB-P
Wainscot:	--
Base:	RB
Floor Finish:	CPT
Slab Depression:	--
Sound Protection:	STC 40
Notes:	--

SPECIAL EQUIPMENT**LIGHTING**

General:	--
Special:	--
Notes:	<ol style="list-style-type: none"> 1) 2' x 4' (600 mm x 1200 mm) recessed fluorescent light fixture, parabolic louver, w/ F32T8 lamps 3500°K, CRI=70 (minimum). 2) The foot-candle level is average maintained. 3) Provide ballasts per fixture for desired switching configuration. To provide a uniform lighting level, switch inner lamp(s) on first switch and outer lamps on second switch. 4) Exact quantity, location, and lamping of light fixtures shall be chosen to meet the foot-candle requirement. 5) Fixture description for alternate 80 and 150 NSF rooms is the same as described in Note 1 above. Orient the two fixtures for 150 NSF room in the same manner as shown for 120 NSF room. Orient single fixture and grid for 80 NSF room at 90° from orientation shown in 150 NSF room. For 80 and 150 NSF rooms, increase fixture wattage by 50%.

POWER

General:	As Shown
Emergency:	As Shown
Notes:	<ol style="list-style-type: none"> 1) Coordinate location and height of work station receptacles with modular furniture.

COMMUNICATION/SPECIAL SYSTEMS

Data:	Yes
Telephone:	Yes
Intercom:	--
Nurse Call:	Rough-in only
Public Address:	--
Radio/Entertainment:	--
MATV:	--
CCTV:	--
MID:	--
Security/Duress:	--
VTEL:	--
VA Satellite TV:	--
Notes:	<ol style="list-style-type: none"> 1) Coordinate location and height of work station telephone/data outlets with modular furniture.

HEATING, VENTILATING AND AIR CONDITIONING

Inside Design Conditions:	70°F (21°C) to 75°F (24°C) Dry-Bulb Temperature
	30 Percent to 50 Percent Relative Humidity
Minimum Air Changes per Hour:	4
100% Exhaust:	No
100% Outside Air:	No
Room Air Balance:	Neutral (0)
Dedicated Exhaust System:	No
Occupancy:	2
AC Load (Equipment):	As Required
AC Load-(Light):	As Required
Notes:	--

PLUMBING AND MEDICAL GASES

Cold Water:	Rough-in only
Hot Water:	Rough-in only
Laboratory Air:	--
Laboratory Vacuum:	--
Sanitary Drain:	Rough-in only
Reagent Grade Water:	--
Medical Air:	--
Medical Vacuum:	--
Oxygen:	--
Notes:	--



Office (OFA01) (OFA02) (OFD01) (OFD03) (OFDC1) (SEC01)


Equipment List

JSN	SYMBOL	QTY	AI	DESCRIPTION
	P-418	1	CC	Rough-in for lavatory, sensor control (PG-18-1, MCS 22 40 00; PG-18-4, NCS SD 22 40 00)
A1010		1	CC	Outlet, telephone/data, wall mounted (PG-18-1, MCS 27 15 00)
		1	CC	Receptacle, electrical, quadruplex, for computer equipment items (PG-18-1, MCS 26 27 26)
		AR	CC	Receptacle, electrical, duplex (PG-18-1, MCS 26 27 26)
		1	CC	Rough-in for nurse call, emergency station, and corridor signal light (PG-18-1, MCS 27 52 23)
E0210		1	VV	Modular work station with under counter keyboard tray, overhead storage, and wall hanger strips.
F0205		1	VV	Chair, rotary, with arms
F0120		1	VV	Bookcase, sectional, each section, 33" x 13" x 75" (825 mm x 325 mm x 1875 mm) with 10" (250 mm) base
A5145		2	VV	Hook, coat, wall mounted
F2000		1	VV	Receptacle, waste, 13" (325 mm) diameter
M1801		1	VV	PC, computer system, with keyboard
F0210		2	VV	Chair, straight, without arms
F3010		1	VV	Bulletin board, 48" x 36" (1200 mm x 900 mm)
F3200		1	VV	Clock, atomic, battery operated
Refer to Examination Room Guide Plate (EXRG3) for location of following:				
		AR	CC	Provide backing for future wall mounted equipment and accessories: Sphygmomanometer Otoscope / Ophthalmoscope Glove dispenser Sharps container Paper towel dispenser
		1	CC	Rough-in j-box for future x-ray film illuminator



Bulk Storage Area (SRS01)

Floor Plan



NSF (NSM) per Space Criteria


M2 1 0 1 2 4Ft

Scale: $\frac{1}{4}" = 1'-0"$

NOTE: Guide plates are graphical representations of selected room types, illustrating the integration of space, components, systems, and equipment. They provide typical configurations and general technical guidance, and are not intended to be project specific. Specific infrastructure design requirements are contained in VA Design Manuals and Space Planning Criteria located in the VA Technical Information Library.

Bulk Storage Area (SRS01)

Reflected Ceiling Plan



NSF (NSM) per Space Criteria

M2 1 0 1 2 4Ft

Scale: $\frac{1}{4}'' = 1'-0''$

NOTE: Guide plates are graphical representations of selected room types, illustrating the integration of space, components, systems, and equipment. They provide typical configurations and general technical guidance, and are not intended to be project specific. Specific infrastructure design requirements are contained in VA Design Manuals and Space Planning Criteria located in the VA Technical Information Library.

Bulk Storage Area (SRS01)**Design Standards****ARCHITECTURAL**

Ceiling:	AT (SP)
Ceiling Height:	9'-0" (2700 mm)
Wall Finish:	GWB (SC)
Wainscot:	--
Base:	RB
Floor Finish:	VCT
Slab Depression:	--
Sound Protection:	--
Notes:	--

SPECIAL EQUIPMENT

Wall Protection	--
-----------------	----

LIGHTING

General:	20 FC – 1 W/SF (MIN)
Special:	As Shown
Notes:	

- 1) Fixture A: 2'x4' (600 mm x 1200 mm) recessed, grid mounted fluorescent light fixture, UL listed for wet location, prismatic lens with gasketing, w/ F32T8 lamps 3500•K, CRI=70 (minimum).`
- 2) The foot-candle level is average maintained.
- 3) Provide ballasts per fixture for desired switching configuration. To provide a uniform lighting level, switch inner lamp(s) on first switch and outer lamps on second switch.
- 4) Exact quantity, location, and lamping of light fixtures shall be chosen to meet the foot-candle requirement.

POWER

General:	As Shown
Emergency:	Egress lighting
Notes:	--

COMMUNICATION/SPECIAL SYSTEMS

Data:	--
Telephone:	--
Intercom:	--
Nurse Call:	--
Public Address:	--
Radio/Entertainment:	--
MATV:	--
CCTV:	--
MID:	--
Security/Duress:	--
VTEL:	--
VA Satellite TV:	--
Notes:	--

HEATING, VENTILATING AND AIR CONDITIONING

Inside Design Conditions:	
Dry-Bulb Temperature:	73F (23C)
Relative Humidity:	30% - 55%
Minimum Total Air Changes per Hour:	4
Room Air Exhaust Required:	Yes, 100%
Special Exhaust or General Exhaust:	General Exhaust
Room Air Return Permitted:	No
Room Air Balance:	Neutral (0)
Notes:	--


PLUMBING AND MEDICAL GASES

Cold Water:	--
Hot Water:	--
Laboratory Air:	--
Laboratory Vacuum:	--
Sanitary Drain:	--
Reagent Grade Water:	--
Medical Air:	--
Medical Vacuum:	--
Oxygen:	--
Notes:	--

Bulk Storage Area (SRS01)

Equipment List

JSN	SYMBOL	QTY	AI	DESCRIPTION
F0530		1	VV	<u>Cart, Trash</u> Heavy duty trash cart, 42" high X 74" wide X 34" deep with two (2) solid non-marking rubber roller bearing wheels, two (2) swivel casters, 2000 pound capacity and tilt mechanism.
F2000		1	VV	<u>Basket, Wastepaper, Round, Metal</u> Round wastepaper basket, approximately 18" high X 16" diameter. This metal unit is used to collect and temporarily store small quantities of paper refuse in patient rooms, administrative areas and nursing stations.
M2055		1	VV	<u>Shelving, Storage, Wire, with Adjustable Shelves</u> Stationary, wire, shelving unit. Unit has fully adjustable shelves constructed of stainless steel. For use in general purpose storage areas. Shelving is provided in various sizes and configurations. Price provided is for a unit approximately 74"H x 18"D x 48"W with four shelves.
M2070		AR	VV	<u>Shelving, Storage, 77x36x18</u> Storage shelving unit approximately 77" H X 36" W X 18" D. Corrosion resistant baked enamel, galvanized or stainless steel open unit with adjustable shelves. The closed version is also available. For use in the storage room.
		AR		Bulk shelving units.
		AR	CC	Receptacle, electrical, duplex, 120 volt (PG-18-1, MCS 26 27 26).



Georgian Beveled Tegular with Prelude® 15/16" Exposed Tee grid (Pg. 215)


Key Selection Attributes

- Unique spatter-painted visual
- Excellent sound absorption (items 795, 796, 1750)
- High Washability
 - Durable – Washable
 - Impact-resistant
 - Scratch-resistant
 - Scrubbable
- Meets USDA/FSIS guidelines for use in food processing establishments
- 30-Year Limited System Warranty against visible sag (excludes item 791), mold/mildew, and bacterial growth

Typical Applications

- Schools/classrooms
- Healthcare – assists in addressing HIPAA and FGI acoustical requirements (Items 795, 796 & 1750)
- Corridors/conference rooms
- Kitchen/food preparation (Items 793, 794, 828)
- Enclosed parking garages (Items 793, 794, 828)

Detail (Other Suspension Systems compatible. Refer to listing on page 170.)



Georgian
Beveled Tegular



Georgian
Beveled Tegular with
Prelude 15/16"
Exposed Tee grid



Georgian
Beveled Tegular with
Silhouette® 9/16"
Bolt-Slot grid 1/4" Reveal

Color



White (WH)

LEED® Credits

Energy	Waste Mgmt	Recycled Content	Local Materials	Renewable Materials	Daylight & Views
✓	✓	✓	✓	✓	✓
Location Dependent					



















LEED for Schools

Acoustics	Low Emitting or CHPS
✓	✓


\$\$\$\$\$

Visual Selection

Performance Selection Dots represent highest level of performance.

Edge Profile	Suspension Detail Dwg. Pgs. 226-228	Item No.	Dimensions		UL Classified		Fire Rating	Light Reflect	Sag Resist	Anti-Microbial	Durable				Recycle Program
					Acoustics										
					NRC	CAC									
GEORGIAN															
9/16" Beveled Tegal	31-34, 54	1753 1753M	2' x 2' x 5/8" 600 x 600 x 15mm		0.55	35	Class A	0.86	HumiGuard+	BioBlock+	Wash	Scrub	Impact	Scratch	Yes
	1	764 764M	2' x 2' x 5/8" 600 x 600 x 15mm		0.55	33	Class A	0.86							
	1	763 763M	2' x 4' x 5/8" 600 x 1200 x 15mm		0.55	33	Class A	0.86							
	1	898	2' x 4' x 5/8"		0.55	35	Fire Guard	0.86							
	1	791 791M	30" x 5' x 3/4" 750 x 1500 x 19mm		0.55	33	Class A	0.86	Standard						
15/16" Beveled Tegal	12	1752 1752M	2' x 2' x 5/8" 600 x 600 x 15mm		0.55	35	Class A	0.86							
GEORGIAN – High Acoustics															
15/16" Square Lay-in	1	796 796M	2' x 2' x 3/4" 600 x 600 x 19mm		0.65	35	Class A	0.86							
	1	795 795M	2' x 4' x 3/4" 600 x 1200 x 19mm		0.65	35	Class A	0.86							
15/16" Angled Tegal	7	1750 1750M	2' x 2' x 3/4" 600 x 600 x 19mm		0.65	38	Class A	0.86							
GEORGIAN – High Washability, Unperforated															
15/16" Square Lay-in	1	794 794M	2' x 2' x 5/8" 600 x 600 x 15mm		N/A	33	Class A	0.88							
	1	793 793M	2' x 4' x 5/8" 600 x 1200 x 15mm		N/A	33	Class A	0.88							
	1	828	2' x 4' x 5/8"		N/A	35	Fire Guard	0.88							

Suspension Systems



Item 1753-CAC 33 on 9/16" Interlude, Sonata, Suprafine

Physical Data

Material

Wet-formed mineral fiber

Surface Finish

793, 794, 828: factory-applied vinyl latex paint
All other items: factory-applied latex paint

Fire Performance

ASTM E84 and CAN/ULC S102 surface burning characteristics. Flame Spread Index 25 or less.
Smoke Developed Index 50 or less. (UL labeled)
Fire Guard™: A fire resistive ceiling when used in applicable UL assemblies

ASTM E1264 Classification

Type III, Form 2, Pattern C E
Items 794, 793, 828 –
Type IX, Form 2, Pattern G
Fire Class A

Sag Resistance

HumiGuard® Plus – superior resistance to sagging in high humidity conditions up to, but not including, standing water and outdoor applications.

VOC/Formaldehyde Emissions

(Excludes items 796, 795, 1750)
Meets CA Dept. of Health Services Standard Practice for the testing of VOC Emissions and is listed on CHPS High Performance Products Database for Low-Emitting Materials.

(Items 796, 795, 750)

Meets CA Dept. of Health Services Standard Practice for the testing of VOC Emissions depending on ceiling use and building parameters. Specific project data is required to evaluate performance.

Anti Mold/Mildew & Bacteria

BioBlock® Plus contains an anti-microbial treatment and provides guaranteed resistance against growth of

mold/mildew and Gram-positive and Gram-negative odor/stain-causing bacteria for 30 years.

Insulation Value

R Factor - 1.6 (BTU units)
R Factor - 0.28 (Watts units)

30-Year Performance Guarantee & Warranty Information

See warranty details in the back of this catalog

Weight; Square Feet/Carton

763, 793 – 0.67 lbs/SF; 96 SF/ctn
764, 794, 1752, 1753 – 0.72 lbs/SF; 64 SF/ctn
791 – 0.76 lbs/SF; 75 SF/ctn
828, 898 – 1.13 lbs/SF; 64 SF/ctn
796, 1750 – 1.31 lbs/SF; 48 SF/ctn
795 – 1.38 lbs/SF; 64 SF/ctn

Health Zone™ ULTIMA®

Square Lay-in, Tegal

fine texture

Recycled Content: **70%**

armstrong.com/greengenie

LEED® Credits

Energy	Waste Mgmt	Recycled Content	Local Materials	Renewable Materials	Daylight & Views
✓	✓	✓	✓	✓	✓
Location Dependent					

LEED for Schools

Acoustics	Low Emitting or CHPS
✓	✓

\$\$\$


Key Selection Attributes

- Clean Rooms up to ISO Class 5 (Class 100) (items 1935 & 1937)
- Exceeds FGI Guidelines for acoustics and cleanability in general healthcare spaces
- Meets USDA/FSIS guidelines for use in food processing areas
- Long-lasting water-repellency; Washable and Scrubbable
- Smooth, clean, durable finish – Impact-, Scratch-, and Soil-resistant; safe for use with disinfectants
- Excellent sound absorption
- Visual complements Ultima and Optima®
- Now available with Ultima® Create!™ custom colors and images
- Available with Ultima Themes™ images – Blooms, Bubbles, Dragonflies, and Stars
- 30-Year Limited System Warranty against visible sag, mold/mildew, and bacterial growth

Typical Applications

- Clean Rooms (items 1935 & 1937)
Healthcare
- Patient rooms
 - Treatment rooms
 - Nurses stations
 - Emergency rooms
 - Semi-restricted surgical areas
 - Corridors
 - Lavatories and restrooms
 - Kitchen/food prep areas

Color










Health Zone Ultima Square Lay-in with Prelude® 15/16" Exposed Tee grid

Visual Selection

Performance Selection

Dots represent highest level of performance.

Edge Profile	Grid Drawings Cat. pgs. 226-228 or armstrong.com/catdwg	Item No.	Dimensions		UL Classified													Recycle Program
					Acoustics		Fire Rating	Light Reflect	Sag Resist	Anti-Microbial	Durable							
					NRC	CAC					Wash	Scrub	Water Repel	Impact	Scratch	Soil		
Health Zone ULTIMA†																		
15/16" Square Lay-in	1, 2	1935*	2' x 2' x 3/4"		0.70	35	Class A	0.86	HumiGuard+	BioBlock+	Wash	Scrub	Water Repel	Impact	Scratch	Soil	Yes	
					•			•	•	•	•	•	•	•	•	•	•	
9/16" Beveled Tegal	31-33, 54	1936*	2' x 2' x 3/4"		0.70	35	Class A	0.86										
					•			•	•	•	•	•	•	•	•	•	•	
15/16" Beveled Tegal	12, 2A	1937	2' x 2' x 3/4"		0.70	35	Class A	0.86										
					•			•	•	•	•	•	•	•	•	•	•	

* Ultima® Create!™ custom images and colors available for this item (see Ultima Create! Brochure CS-4374 for details). armstrong.com/ceilings (search: ultimacreate)

Suspension Systems

15/16"			9/16"					
--------	--	--	-------	--	--	--	--	--

Physical Data

Material
Wet-formed mineral fiber with DuraBrite® acoustically transparent water-repellent membrane

Surface Finish
DuraBrite with factory-applied latex paint

Fire Performance
ASTM E84 and CAN/ULC S102 surface burning characteristics. Flame Spread Index 25 or less. Smoke Developed Index 50 or less. (UL labeled)

ASTM E1264 Classification
Type IV, Form 2, Pattern E
Fire Class A

Sag Resistance
HumiGuard® Plus – superior resistance to sagging in high humidity conditions up to, but not including, standing water and outdoor applications.

VOC/Formaldehyde Emissions
Meets CA Dept. of Health Services Standard Practice

for the testing of VOC Emissions and is listed on CHPS High Performance Products Database for Low-Emitting Materials.

Anti Mold/Mildew & Bacteria
BioBlock® Plus contains an anti-microbial treatment and provides guaranteed resistance against growth of mold/mildew and Gram-positive and Gram-negative odor/stain-causing bacteria for 30 years.

Insulation Value
R Factor – 2.2 (BTU units)
R Factor – 0.39 (Watts units)

30-Year Performance Guarantee & Warranty Information
Details in back of catalog or at armstrong.com/warranty

Application Considerations
For Clean Room installations use full-size panels. Testing for Clean Room 5 (Class 100) was completed with full-size Lay-in (1935) and 15/16" Beveled Tegal (1937) with Clean Room 15/16" gasketed grid. For Clean Rooms

that require field cut perimeter panels, use Lay-in panels (1935) or Tegal panels (1937) with Lay-in field cut panels at the perimeter.

Health Zone Ultima has an easy-to-clean, semi-gloss surface that is smoother in appearance than Ultima and Optima®. Health Zone Ultima will complement Ultima and Optima, but is not recommended for installation within the same room. Lighting conditions may emphasize the difference in gloss levels.

Cleaning Recommendations

To clean panel, use a clean, white cloth with water or a mild detergent and wipe surface. To disinfect panel, lightly spray surface and wipe clean with a clean, white cloth. Acceptable colorless disinfectants include:

- Sodium hypochlorite
- Isopropyl alcohol
- Hydrogen peroxide
- Quaternary ammonium

Weight; Square Feet/ Carton
1.08 lbs/SF; 48 SF/ctn

LEED® is a registered trademark of the U.S. Green Building Council
All other trademarks used herein are the property of AWI Licensing Company and/or its affiliates
© 2011 AWI Licensing Company • Printed in the United States of America



Clean Room™ FL & VL Clean Room OPTIMA®, Clean Room ULTIMA®

Square Lay-in, Tegular
smooth texture



Items 1715, 1716, 1720, 1721



Clean Room Ultima with Clean Room 15/16" grid (Pg. 210)



Clean Room Optima with Prelude® 15/16" Exposed Tee grid (Pg. 215)



Clean Room FL with Clean Room 1-1/2" Exposed Tee grid (Pg. 210)

Key Selection Attributes

- Clean Rooms up to ISO Class 5 (Class 100)
- Meets USDA/FSIS guidelines for use in food processing areas (excludes items 869, 871)
- Durable – Washable, Scrubbable, Soil-resistant
- Non-directional visual reduces installation time and scrap
- 30-Year Limited System Warranty against visible sag, mold/mildew, and bacterial growth

Clean Room Optima and Ultima Additional Benefits

- Exceeds FGI Guidelines for acoustics and cleanability in general healthcare spaces
- Long-lasting water-repellency

Typical Applications

Clean Room FL, Clean Room VL, Clean Room Ultima

- Clean Rooms
- Kitchens/food preparation areas
- Laboratories
- Healthcare
 - Patient Rooms
 - Treatment Rooms
 - Semi-restricted surgical areas
 - Emergency rooms


Clean Room Optima

- Clean Rooms
- Kitchens/food preparation areas
- Laboratories
- Healthcare
 - Patient rooms (walls-to-deck)
 - Treatment rooms (walls-to-deck)
 - Emergency rooms (walls-to-deck)
 - Semi-restricted surgical areas (walls-to-deck)
 - MRI rooms


VL (Perforated)

- Lavatories/restrooms

Detail (Other Suspension Systems compatible. Refer to listing on pages 151-152.)




Clean Room FL



Clean Room VL




Clean Room Optima
Square Lay-in




Clean Room Ultima
Square Lay-in



Clean Room FL
with Clean Room 1-1/2"
Exposed Tee grid



VL



White (WH)
(Clean Room Optima,
Clean Room Ultima,
Clean Room VL
& VL)



White with
Gray Spatter
(Clean Room
FL)

Square Lay-in, Tegal

smooth texture

LEED® Credits

Energy	Waste Mgmt	Recycled Content	Local Materials	Renewable Materials	Daylight & Views
✓	✓	✓	✓		✓
Location Dependent					














LEED for Schools

Acoustics	Low Emitting or CHPS
✓	✓

\$\$\$\$\$

Visual Selection


Performance Selection Dots represent highest level of performance.

Edge Profile	Suspension Detail Dwg. Pgs. 226-228	Item No.	Dimensions		UL Classified		AC	Fire Rating	Light Reflect	Sag Resist	Anti-Microbial	Durable						Recycle Program
					Acoustics	CAC						Wash	Scrub	Water Repel	Impact	Scratch	Soil	
					NRC	CAC						Wash	Scrub	Water Repel	Impact	Scratch	Soil	
Clean Room OPTIMA (see Health Zone™ Optima, Items 3114, 3115, 3214, 3215, Pgs. 113-114)																		
	2	3114	2' x 2' x 1"		0.95	N/A	190	Class A	0.86	HumiGuard+	Inherent	Wash	Scrub	Water Repel	Impact	Scratch	Soil	Yes
					•		•		•	•	•	•	•	•	•	•	•	•
	12, 2	3115	2' x 4' x 1"		0.95	N/A	190	Class A	0.86		•	•	•	•	•	•	•	•
					•		•		•	•	•	•	•	•	•	•	•	•
	12, 2	3314	2' x 2' x 1-1/2"		0.95	29	190	Class A	0.86		•	•	•	•	•	•	•	—
					•		•		•	•	•	•	•	•	•	•	•	—
	12, 2	3315	2' x 4' x 1-1/2"		0.95	29	190	Class A	0.86		•	•	•	•	•	•	•	—
					•		•		•	•	•	•	•	•	•	•	•	—
	12, 2	3214	2' x 2' x 1"		0.95	N/A	190	Class A	0.86		•	•	•	•	•	•	•	•
					•		•		•	•	•	•	•	•	•	•	•	•
	12, 2	3215	2' x 4' x 1"		0.95	N/A	190	Class A	0.86		•	•	•	•	•	•	•	•
					•		•		•	•	•	•	•	•	•	•	•	•
	12, 2	3316	2' x 2' x 1-1/2"		0.95	29	190	Class A	0.86		•	•	•	•	•	•	•	—
					•		•		•	•	•	•	•	•	•	•	•	—
	12, 2	3317	2' x 4' x 1-1/2"		0.95	29	190	Class A	0.86		•	•	•	•	•	•	•	—
					•		•		•	•	•	•	•	•	•	•	•	—

Clean Room ULTIMA (see Health Zone Ultima, Items 1935 and 1937, Pg. 173)

15/16" Square Lay-in	2	1935	2' x 2' x 3/4"	□	0.70	35	N/A	Class A	0.86	HumiGuard+	Inherent	•	•	•	•	•	•	•
15/16" Beveled Tegal	12, 2A	1937	2' x 2' x 3/4"	□	0.70	35	N/A	Class A	0.86	•	•	•	•	•	•	•	•	•

Suspension Systems



Physical Data

Material

3114, 3115, 3214, 3215 – Fiberglass with DuraBrite® acoustically transparent membrane
1935, 1937 – Wet formed mineral fiber with DuraBrite acoustically transparent water-repellent membrane

Surface Finish

DuraBrite with factory-applied latex paint

Fire Performance

ASTM E84 and CAN/ULC S102 surface burning characteristics. Flame Spread Index 25 or less. Smoke Developed Index 50 or less. (UL labeled)

ASTM E1264 Classification

3114, 3115, 3214, 3215, 3314, 3315, 3316, 3317 – Type XII, Form 2, Pattern E
1935, 1937 – Type IV, Form 2, Pattern E
Fire Class A

Sag Resistance

HumiGuard® Plus – superior resistance to sagging in high humidity conditions up to, but not including, standing water and outdoor applications.

VOC/Formaldehyde Emissions

Meets CA Dept. of Health Services Standard Practice for the testing of VOC Emissions and is listed on CHPS High Performance Products Database for Low-Emitting Materials.

Anti Mold/Mildew & Bacteria

3114, 3115, 3214, 3215, 3314, 3315, 3316, 3317 – Fiberglass substrate is inherently resistant to the growth of mold, mildew, and bacteria.

1935, 1937 – BioBlock® Plus contains an anti-microbial treatment and provides guaranteed resistance against growth of mold/mildew and Gram-positive and Gram-negative odor/stain-causing bacteria for 30 years.

Acoustical Details

3314, 3315, 3316, and 3317 have CAC backing. Products with CAC backing are not UL Classified for acoustics. Contact TechLine for independent laboratory acoustic testing.

Insulation Value

3114, 3115, 3214, 3215, 3314, 3315, 3316, 3317 –
R Factor – 4.0 (BTU units)
R Factor – 0.70 (Watts units)
1935, 1937 –
R Factor – 2.2 (BTU units)
R Factor – 0.39 (Watts units)

30-Year Performance Guarantee & Warranty Information

See warranty details at armstrong.com/warranty

Application Considerations

Clean Room Optima (Health Zone Optima)

For Clean Room installations with Clean Room Optima, use full-size panels with Clean Room grid.

Clean Room Ultima (Health Zone Ultima)

For Clean Room installations with Clean Room Ultima, use full-size panels (items 1935 and 1937) with Clean Room grid. Clean Room Ultima has been tested to withstand 500 wash and scrub cycles.

Cleaning Recommendations

To clean panel, use a clean, white cloth with water or a mild detergent and wipe surface. To disinfect panel, lightly spray surface and wipe clean with a clean, white cloth. Acceptable colorless disinfectants include:

- Sodium hypochlorite
- Isopropyl alcohol
- Hydrogen peroxide
- Quaternary ammonium

Weight; Square Feet/ Carton

3114, 3115, 3214, 3215 – 0.45 lbs/SF; 96 SF/ctn
1935, 1937 – 1.08 lbs/SF; 48 SF/ctn
3314, 3315, 3316, 3317 – 0.78 lbs/SF; 64 SF/ctn

Note: For assistance on proper Clean Room installation, contact TechLine at 1 877 ARMSTRONG. For Clean Room installations, use Clean Room Optima or Clean Room Ultima only with Armstrong Clean Room Grid Systems.

LEED® Credits

Energy	Waste Mgmt	Recycled Content	Local Materials	Renewable Materials	Daylight & Views
		✓	✓	✓	
Location Dependent					

LEED for Schools

Acoustics	Low Emitting or CHPS
	✓

\$\$\$\$\$

Clean Room™ FL/
Clean Room VL & VL

Square Lay-in, Tegal


smooth texture

Visual Selection

Performance Selection Dots represent highest level of performance.

Edge Profile	Suspension Detail Dwg. Pgs. 226-228	Item No.	Dimensions	UL Classified	Acoustics NRC	CAC	Fire Rating	Light Reflect	Sag Resist	Anti-Microbial	Durable	Recycle Program
				UL Classified								
				Acoustics								
				Fire Rating								
				Light Reflect								
				Sag Resist								
				Anti-Microbial								
				Durable								
				Recycle Program								
Clean Room FL Field Unit – Class 5 (Class 100)												
15/16" or 1-1/2" Square Lay-in	1,2	1715 1715M	2' x 2' x 3/4" 600 x 600 x 19mm	□	0.55	35	Class A	0.79	HumiGuard+	BioBlock+	Wash Scrub Water Repel Soil	–
	1,2	1716 1716M	2' x 4' x 3/4" 600 x 1200 x 19mm	□	0.55	35	Class A	0.79	•	•	• • • •	–
Clean Room FL Border Unit – Class 5 (Class 100)												
15/16" or 1-1/2" Square Lay-in	1,2	1720 1720M	2' x 2' x 5/8" 600 x 600 x 15mm	□	N/A	35	Class A	0.79	•	•	• • • •	–
	1,2	1721 1721M	2' x 4' x 5/8" 600 x 1200 x 15mm	□	N/A	35	Class A	0.79	•	•	• • • •	–
Clean Room VL Unperforated – Class 5 (Class 100)												
15/16" or 1-1/2" Square Lay-in	1	868 868M	2' x 2' x 5/8" 600 x 600 x 15mm	□	N/A	40	Fire Guard	0.80	•	•	• • • •	–
	1	870 870M	2' x 4' x 5/8" 600 x 1200 x 15mm	□	N/A	40	Fire Guard	0.80	•	•	• • • •	–
VL Perforated												
15/16" or 1-1/2" Square Lay-in	1	869 869M	2' x 2' x 5/8" 600 x 600 x 15mm	□	0.55	35	Fire Guard	0.78	•	•	• • • •	–
	1	871 871M	2' x 4' x 5/8" 600 x 1200 x 15mm	□	0.55	35	Fire Guard	0.78	•	•	• • • •	–

Suspension Systems



Physical Data

Material
Wet-formed mineral fiber

Surface Finish
1715, 1716, 1720, 1721 – Soil-resistant polyester film
868, 870, 869, 871 – Vinyl-faced membrane

Fire Performance
ASTM E84 and CAN/ULC S102 surface burning characteristics. Flame Spread Index 25 or less. Smoke Developed Index 50 or less. (UL labeled) Fire Guard™: A fire resistive ceiling when used in applicable UL assemblies

ASTM E1264 Classification
1715, 1716, 1720, 1721 – Type IV, Form 2, Pattern G H
868, 870, – Type IV, Form 2, Pattern E
869, 871 – Type IV, Form 2, Pattern C E
Fire Class A

Sag Resistance
HumiGuard® Plus – superior resistance to sagging in high humidity conditions up to, but not including, standing water and outdoor applications.

VOC/Formaldehyde Emissions

Meets CA Dept. of Health Services Standard Practice for the testing of VOC Emissions and is listed on CHPS High Performance Products Database for Low-Emitting Materials.

Anti Mold/Mildew & Bacteria

BioBlock® Plus contains an anti-microbial treatment and provides guaranteed resistance against growth of mold/mildew and Gram-positive and Gram-negative odor/stain-causing bacteria for 30 years.

Insulation Value

R Factor – 1.5 (BTU units)
R Factor – 0.26 (Watts units)

30-Year Performance Guarantee & Warranty Information

See warranty details at armstrong.com/warranty

Application Considerations

Clean Room FL
If acoustical absorption is required, specify a combination of field and border units – field units for use as full-size panels only; border units for use where panels must be cut on the job (borders, sprinkler head penetrations, etc.).

VL Perforated

869, 871 – VL Perforated is not intended for Clean Room and kitchen/food preparation applications. Use unperforated product – 868, 870.

Clean Room VL

Clean Room VL has been tested to withstand 10,000 scrub cycles.

Clean Room VL is not appropriate for applications where germicidal lamps are being used.

Weight; Square Feet/Cartron

1715 – 1.02 lbs/SF; 48 SF/ctn
1716 – 1.02 lbs/SF; 64 SF/ctn
1720 – 1.04 lbs/SF; 48 SF/ctn
1721 – 1.17 lbs/SF; 64 SF/ctn
868, 869 – 1.10 lbs/SF; 48 SF/ctn
870, 871 – 1.11 lbs/SF; 64 SF/ctn

Note: For assistance on proper Clean Room installation, contact TechLine at 1 877 ARMSTRONG. For Clean Room installations, use Clean Room FL or Clean Room VL only with Armstrong Clean Room Grid Systems.

Clean Room™ *ClimaPlus*™



High Recycled Content



CLEAN ROOM Class 10M–100M Panels with *CLIMAPLUS* Performance/
DONN DXLA Suspension System

Features and Benefits

- CLEAN ROOM™ *CLIMAPLUS*™ Class 100 and Class 10M–100M panels have an embossed, vinyl-laminated face with sealed back and edges for use in Class 100 or 10M–100M clean rooms.
- USDA Certified Biobased Product®.
- FIRECODE® product designed to meet life-safety codes.
- *CLIMAPLUS* 30-year lifetime system warranty against visible sag.

Applications

- Clean rooms
- Laboratories
- Surgical areas/emergency rooms
- MRI rooms
- Kitchens/food prep areas (Class 100 only)

Substrate

- Water-felted mineral fiber


See LEED report tool at usgdesignstudio.com
for detailed sustainability information.

To order samples, go to usg.com




Flat White
050

Smooth-Textured Panel, Class 100



Smooth-Textured Panel, Class 10M–100M



UL Classified											
Edge ⁵	Panel Size	Class ²	Item No.	NRC ³	CAC Min.	LR ⁴	Color	Grid Options	Recycled Content ¹	Panel Cost	
CLEAN ROOM™ CLIMAPlus™ Class 100 Panels	SQ	2'x2'x5/8"	56099	—	35	.79	White	A, B, C, D, E	52% 	\$\$\$	
		Unperforated									
		2'x4'x5/8"	56091	—	35	.79	White	A, B, C, D, E	52% 	\$\$\$	
CLEAN ROOM CLIMAPlus Class 10M-100M Panels ⁷	SQ	2'x2'x5/8"	56060	.55	35	.79	White	A, B, C, D, E	52% 	\$\$\$	
		Perforated									
		2'x4'x5/8"	56090	.55	35	.79	White	A, B, C, D, E	52% 	\$\$\$	
Legend											
Low Emissions (VOC) Low-emitting performance meets CA Specification 01350 (CA Dept. of Health Services Standard Practice for the testing of VOC emissions) and is listed on the CHPS database for low-emitting materials. USG Certificate of Compliance for Low VOC Emissions also available on usg.com.				High Recycled Content Classified as containing greater than 50% total recycled content. Total recycled content is based on product composition of post-consumer and pre-consumer (post-industrial) recycled content per FTC guidelines.				FIRECODE®			
A DX®/DXL™		B DXLA™		C ZXLA™		D AX™		E CE™ ⁶			
Grid Profile Options											

Physical Data/ Footnotes	Product literature Data sheet: SC1811 ASTM E1264 classification Class 100: Type X, Pattern GI Class 10-100M: Type X, Pattern CGI ASTM E84 surface burning characteristics Class A Flame spread: 25 Smoke developed: 50 Weight 1.1 lbs./sq. ft. (Class 100 panels) 1.2 lbs./sq. ft. (Class 10M-100M panels) Thermal resistance R-1.6	Maximum backloading See USG 30-Year Limited Warranty Commercial Applications SC2102. Maintenance Can be cleaned easily with a damp sponge, mild detergent and water. Do not use acetate, ammonia, or highly concentrated chlorine, bromide or other harsh chemicals. Notes 1. For details, see LEED report tool at usgdesignstudio.com. 2. Fire-rated items: see UL design details. 3. NRC rating for CLEAN ROOM CLIMAPlus Class 100 panels is .10. USG does not consider a ceiling panel to be acoustically rated if NRC is less than .50.	4. LR values are shown as averages. 5. Field-cut edges of CLEAN ROOM panels may be sealed with white latex paint. 6. Clean-room-rated applications require a suspension system with gasketed tee flanges such as DOWN CE. 7. Not intended for kitchen/food prep applications. Use unperforated product (Class 100)—item numbers 56099 and 56091. 8. This product has achieved both BioPreferred initiatives: Federal Procurement Preference and Certified Product Labeling. See the complete listing of all USG ceiling panels on biopreferred.gov website.
-------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

APPENDIX C

HEATING, VENTILATING, and AIR CONDITIONING (HVAC)

June 19, 2012

**MANAGEMENT OF ENVIRONMENTALLY CONTROLLED CLEAN/STERILE
SUPPLY ROOMS**

1. **PURPOSE:** To establish guidelines for clean/sterile storage supply rooms, including control of temperature, humidity, air exchange and purpose. Policies, procedures and responsibilities to ensure safe storage and assessment of clean/sterile medical supplies are further defined in this guidance.

2. **INTRODUCTION:**

a. Clean/Sterile supplies are necessary for patient care. To ensure availability, supplies may be stored in bulk at a primary storage location, at point of use in secondary storage locations or at immediate use in examination room storage locations.

b. Supplies stored over time must be maintained in a temperature and humidity controlled environment to ensure product integrity.

c. Various professional organizations including Association of Operating Room Nurses (AORN), American Association of Medical Instruments (AAMI), Veteran's Health Administration (VHA) and American Institute of Architects (AIA) identify suggested environmental parameters for clean/sterile storage. In addition, the Under Secretary for Health for Clinical Operations provided guidelines for primary storage locations in a memorandum dated January 04, 2012, which replaces previous recommendations in the VA Handbook 7176 – Supply Processing and Distribution.

3. **POLICY:** It is the policy of this medical center to provide clean/sterile medical supplies safe for patient use.

a. Clean/Sterile supplies are acquired, reprocessed (if necessary), and placed into storage for use following existing standard operating procedures in the Logistics and Sterile Processing Service (SPS) policy manuals.

b. Clean/Sterile supply stock is rotated on a "First In First Out" (FIFO) schedule. Product expiration dates are verified by Logistics and SPS Staff. Products exceeding the documented expiration date are removed from inventory following established procedures for reprocessing or return/disposal as outlined in the Logistics procedure manual.

c. Primary storage areas will hold bulk supplies awaiting distribution to secondary storage areas or examination room storage areas. The primary storage area will meet recommended engineering controls for clean/sterile storage, to include temperature 72-

78 degrees Fahrenheit, humidity control of 20-60%, and appropriate air exchange (>10). The primary storage area will store supplies until distribution or expiration.

d. Secondary storage areas (point of use) will hold supplies at par levels determined by Logistics and staff responsible for utilizing the supplies. The secondary storage area will meet recommended engineering controls for clean/sterile storage to include temperature 72-78 degrees Fahrenheit, humidity control 20-60%, and appropriate air exchange (>4) ("Interim Guidance"). The secondary storage area will store supplies until use, relocation to examination room storage or removal by Logistics staff based on par level, expiration and need.

e. Examination room storage areas (immediate use) will hold supplies specific for use in that patient examination room not to exceed a one week supply of an item as determined via collaboration of Logistics and staff responsible for utilizing the supplies. Supplies will follow the FIFO system for supply utilization. Supplies exceeding one week in the examination room will be assessed for integrity and compromise by the staff utilizing the examination room. Any supply suspected of compromise will be returned to Logistics.

f. Temperature and humidity will be monitored in primary and secondary storage areas using the TempTrak System. A combination of visual cues, alarms and electronic messaging will alert staff of a potential temperature or humidity concern. Staff will respond to TempTrak alerts appropriately as outlined in the Procedure section of this Medical Center Memorandum (MCM).

g. Minor failures in environmental control of temperature, humidity or air flow do not require immediate relocation of materials unless there is valid concern for compromise, the humidity level exceeds 60% for greater than 12 hours, there is security or structural damage to the storage room, or it becomes evident that water or air contamination exists. Corrective action will begin immediately and will not exceed three days.

h. A minor failure may convert to a major failure if it is determined corrective action could not be completed in 3 days, humidity exceeds 60% for greater than 12 hours, there is security or structural damage to the storage room or water or air contamination enters the room.

i. A major failure in environmental control of security, structure, temperature, humidity or airflow requires immediate relocation of sterile supplies to an alternate storage location. Critical and semi-critical reusable medical equipment (RME) will be reprocessed by SPS. Invasive sterile devices will be returned to Logistics for disposition. Non-invasive sterile products will be returned to Logistics for possible redistribution to low risk areas.

j. Newly constructed and renovated areas involving replacement of HVAC systems, which will meet recommended requirements, are to include temperature 72 +/- 1

degrees Fahrenheit, humidity control of 20-60%, and appropriate air exchange (>4) ("Interim Guidance").

k. Invasive sterile products stored in an area where humidity has exceeded 60% for greater than 12 hours will be removed and disposition will follow existing Logistic policy for return or disposal. Non-invasive sterile products returned to Logistics will be assessed for possible compromise based on visible signs of condensation, package tears, discoloration or other evidence of contamination. Products deemed compromised will be disposed of by Logistics following existing procedures. Products deemed viable will be redistributed to low risk areas.

l. An Infection Control Risk Assessment (ICRA) of primary and secondary storage areas in this medical center provides guidance on the potential risk of infection in the event engineering controls, temperature/humidity or proper air flow are compromised. Areas of highest risk include Logistics primary storage, Operating Room secondary storage including:

(1) Sterile Core rooms

(2) Primary Acute Care Unit rooms, and

(3) Endoscopy Procedure rooms, ICU secondary storage, ED secondary storage and secondary storage on 1-2A, 1-3A, Specialty Clinic and Dental. Staff will respond to TempTrak alerts appropriately as outlined in the procedure section of this MCM.

4. **DEFINITIONS:**

a. **Clean/Sterile Supplies:** Any medical device or consumable designed for patient care that has been prepared by an authorized vendor or facility Sterile Processing Service (SPS) using aseptic or sterile technique. For the purpose of this MCM, "supplies" will refer to medical consumables and/or clean/sterile supplies.

b. **Clean/Sterile Storage:** Areas purposed to store clean/sterile supplies until use or expiration. (Attachment A).

c. **Primary Storage Area:** Areas purposed to hold bulk clean/sterile supplies awaiting distribution to Secondary Storage area (point of use) or Examination Storage Room (immediate use).

d. **Secondary Storage Area:** Areas purposed at point of use to hold clean/sterile supplies for a service or group of services. Supplies in this area are maintained at par levels established by the service utilizing the supply storage room in collaboration with Logistics.

e. **Examination Room Storage Area (Immediate Use/Just in Time Use):** Areas purposed within a patient examination room to hold clean/sterile supplies for immediate

use, not to exceed a week's worth of supplies. Examination Room Storage Areas are not monitored for temperature and humidity.

f. Par levels: The quantity of an item needed to meet the needs of a service over a defined time.

g. Temperature: An environmental measurement of hotness or coldness. Primary and Secondary Clean/Sterile storage areas will be maintained in a temperature range of 72–78 degrees Fahrenheit in accordance with the Under Secretary of Health of Operations and Management Memorandum dated January 26, 2011. Temperature will not be monitored in Examination Room Storage areas.

h. Humidity: an environmental measurement of the amount of water vapor in the air. Humidity in Primary and Secondary Clean/Sterile Storage will be maintained within a range of 20–60% humidity in accordance with the Under Secretary of Health of Operations and Management Memorandum dated January 26, 2011. Humidity will not be measured in examination room storage areas.

i. TempTrak: An automated temperature and humidity monitoring system designed to record real time temperature and humidity measurements with audio and visual alert of readings outside defined parameters.

j. Infection Control Risk Assessment (ICRA) for Clean/Sterile Storage: An assessment tool utilized by staff to evaluate the disposition of clean/sterile supplies when environmental storage conditions have been compromised. (Attachment B).

k. Minor Problem: Can be resolved immediately or within three days. Does not compromise the security or structure of the storage room. Is not due to humidity in excess of 60% for greater than 12 hours. Is not due to water or air contamination entering the storage room.

l. Major Problem: Cannot be resolved immediately and will exceed three days to correct. Compromises the security or structure of the room. Is due to humidity in excess of 60% for greater than 72 hours. Is due to temperature in excess of 78 degrees Fahrenheit greater than 72 hours. Is due to water or air contamination entering the storage room.

m. Alternate Storage Location: A place where sterile supplies can be safely maintained and secured until consumables are returned to their original storage location. Options for alternate storage locations include return to Logistics primary storage, an uncompromised secondary storage location in close proximity or an area such as a hallway or unused exam room. A hallway or unused exam room should be used only for a short duration, not to exceed eight hours. Supplies must be covered when stored in the hallway.

5. PROCEDURES:

a. **General:** The Lebanon VA Medical Center provides clean/sterile storage for medical supplies.

b. **Logistics:**

(1) has primary responsibility for the Clean/Sterile supply bulk storage maintained in the primary storage area and secondary storage areas. Supply inventory will be inspected upon receipt and placed into stock using FIFO supply rotation. Removal, reprocessing and destruction of supplies will follow existing Logistic policies and SPS procedures in all clean/sterile storage locations.

(2) collaborates with staff utilizing secondary clean/sterile storage rooms to establish and maintain par supply levels for the appropriate services.

(3) replenishes and rotates par level supplies.

(4) destroys/disposes of compromised supplies of using destruction procedures after a complete summary of all actions taken are accomplished in accordance with VA Handbook 7348 Utilization of Personal Property. RME items will be sent to the SPS for reprocessing.

c. **Staff Utilizing Secondary Clean/Sterile Storage or Examination Room Storage:**

(1) ensures no "other" stored items are placed in the clean/sterile supply locations without first consulting Logistics. "Other" refers to any item not identified by Logistics as a clean/sterile medical supply item.

(2) ensures no more than a one week supply is stored in the examination room for immediate use items. Clean/Sterile supplies will be physically separated from "dirty" supplies. Staff consults with Logistics or Infection Control Committee (ICC) to ensure examination room storage is appropriate.

(3) removes from use and return to Logistics any supplies stored in excess of 7 days.

d. **The TempTrak system** monitors temperature and humidity in primary and secondary clean/sterile storage areas. A combination of visual cues and alarms will alert staff to possible temperature/humidity failures. Monitoring devices will be placed on the storage rack where supplies are stored. A visual read unit will be adjacent to the TempTrak monitoring device.

(1) Engineering will ensure primary and secondary clean/sterile supply rooms are maintained at a temperature range of 72-78 degrees Fahrenheit, humidity of 20-60 percent and have adequate airflow. A quarterly report on the above parameters will be submitted to the ICC.

(2) TempTrak sensors are attached to storage racks. In addition to sensors, visual digital thermometers are in each room to provide an immediate visual aid in response to a TempTrak alarm. In the event of a TempTrak alarm, immediate corrective action will begin as described below. (Attachment C).

(3) TempTrak Process:

(a) TempTrak System Alerts of Temperature or Humidity Failure

(b) Determine Tour of Duty

1 Day Tour

a Alert is received by Logistics and Engineering

b Logistics/Engineering collaborate with unit staff to define problem

2 Off Tour

a Alert is monitored by NOD/AOD and/or police

b NOD/AOD and/or police collaborate with unit staff to define problem. If unit staff is not available police may inspect area for obvious compromise and correction (i.e. An open door)

c Collaborate with Logistics and Engineering to define problem

(c) Define Problem

1 Minor Problem (see definition)

a Correct problem

b Document findings and resolution

2 Major Problem (see definition)

a Immediately relocate Clean/Sterile Supplies to Alternate Storage Location and Brief Leadership

b If indicated activate the Emergency Operation Command (EOC) via the EverBridge System

c Consult with Infection Prevention to Implement Product Infection Control Risk Assessment (ICRA)

(1) ICRA – low risk

(a) Return supplies

(b) Document incident

(2) ICRA – high risk

(a) Replenish supplies

(b) Follow Logistics SOP for return and destruction

(c) Document incident

e. Infection Control Risk Assessment (ICRA):

(1) If clean/sterile supplies are exposed to temperature or humidity beyond the parameters for storage defined in this MCM, the ICRA will be utilized in addition to manufactures guidelines to evaluate product disposition.

(2) High Risk Locations include areas where Critical RME, Semi-Critical RME, Invasive Sterile Devices and/or Non-invasive sterile products for use on surgery or acute care patients are stored.

(3) Low Risk Locations include areas where Non-Invasive Sterile Devices are stored for use on non acute patients and areas with minimal Critical RME, Semi-Critical RME and Invasive Sterile Devices.

(4) When a Major Risk occurs staff will follow the ICRA to guide disposition of sterile supplies. (Attachment B).

f. Clean/Sterile Room Designation:

(1) Designated Clean/Sterile Supply Rooms will be identified with appropriate signage on exterior doorways. Doorways will be kept locked at all times to ensure limited access to clean/sterile supply rooms.

(2) In the event a new Clean/Sterile Supply Room is required, the storage area must meet approval from Engineering, Infection Control, Safety, and Logistics. (Attachment A).

6. RESPONSIBILITIES:

a. The **Medical Center Director**, or designee, is responsible to ensure resources are available for appropriate clean/sterile storage.

b. The **Associate Director** is responsible for supporting Logistics and Engineering to comply with this memorandum.

c. The **Associate Director of Patient Care Services** supports Nursing Staff and SPS comply with this memorandum.

d. The **Chief of Staff** provides consultative guidance to ensure safe medical supplies are provided for patient use.

e. The **Logistics Chief**:

(1) ensures staff compliance with this memorandum.

(2) collaborates with engineering and nursing staff to continually assess clean/sterile storage rooms.

(3) is responsible for procuring, storing, distributing and delivering medical supplies and following established procedures in the Logistics procedure manual.

(4) coordinates product relocation to alternate storage area in the event of a storage room failure.

(5) provides a quarterly report to the ICC to include environmental failures (temperature, humidity or air flow), timely responses of appropriate responsible persons to alarms, compromised products, near misses and corrective actions.

f. **Engineering**:

(1) maintains temperature and humidity control for clean/sterile primary and secondary storage rooms.

(2) via Heating, Ventilation and Air Conditioning (HVAC) mechanics, sets acceptable parameters with input care/service line and in accordance with this MCM and will make appropriate system repairs when necessary.

(3) provides a quarterly report on air flow for primary and secondary clean/sterile storage locations to the Infection Control Committee. The report will include number of air exchanges flow failures and corrective action.

(4) coordinates with TempTrak users to reset alarms upon repair.

g. **FITS (Facility Information Technology Services)** maintains the operating integrity of the TempTrak alert system.

h. **The Nurse Officer on Duty (NOD), Administrative Officer of the Day (AOD), Operator and Police:**

- (1) responds to TempTrak alerts during non-administrative hours.
- (2) investigates probable cause of the alert following procedures outlined in this memorandum
- (3) activates the TempTrak Admin Group in the Everbridge System if indicated. The TempTrak Admin Group will include Engineering, Logistics and others as indicated.

i. **Service area staff** utilizing a Primary or Secondary Storage Room (not limited to Nursing):

- (1) ensures doors to clean/sterile storage areas are closed and purposed for clean/sterile supply storage only.
- (2) act as a first point of contact for visual inspection in the event of an environmental failure.
- (3) coordinate with assigned Inventory Manager for permission to store other than par level consumables.

7. **REFERENCES:**

"Interim Guidance for Ventilation Requirements in Sterile Processing Service"
Department of Veterans Affairs Memorandum from Deputy Under Secretary for Clinical Operations

8. **KEYWORDS:** TempTrak, Clean/Sterile Supply

9. **AUTHOR:** Chief, Logistics Services

10. **RECSCISSION:** None

11. **REISSUE DATE:** April 2015

Robert W. Callahan, Jr.
Director

Attachments: 3

MEDICAL CENTER MEMORANDUM 134-002
June 19, 2012

Attachment A

CLEAN/STERILE SUPPLY ROOM CHECKLIST		Engineering		Infection Control		Logistics		Safety	
		Initials	Date	Initials	Date	Initials	Date	Initials	Date
1	Room w have ability to be locked, control traffic and limit access								
2	Room will have TempTrak installed								
3	Room will have a thermostat to control room temperature								
4	Storage racks will be movable with a solid bottom shelf								
5	Windows will be kept locked and blinds will be closed at all times								
6	Visual aid thermometers will be attached to shelving units								
7	Corrugated boxes will be removed before supplies enter clean/sterile room								
8	Positive air flow								
9	Sign on exterior door will be posted as "Clean/Sterile Supply Room"								
10	Paperclips, staples, rubber bands, or tape are prohibited (except indicating tape)								
11	Storage will not block electrical access panels or sprinkler system								
12	Clean/Sterile Supply room will be kept clean and uncluttered								
13	No water supply in clean sterile supply rooms (except for fire suppression)								
14	Items will not be stored on floors								
15	Stored items are under the direction of Inventory Management, supplies obtained elsewhere should not be added without the approval of the Logistics Services Chief.								

MEDICAL CENER MEMORANDUM 134-002
June 19, 2012


Attachment B

INFECTION CONTROL RISK ASSESSMENT – Clean/Sterile Storage					
Clean/Sterile Storage Location	Probability of Causing Patient Harm 4 – High 3 – Moderate 2 – Low 1 – None/NA	Risk/Impact Severity 4 – Catastrophic Major 3 – Moderate 2 – Minor 1 – None/NA	Current Storage Location 4 – None 3 – Poor 2 – Good/Fair 1 – Excellent/Solid	Used for Major Events Only	
				Risk/Impact Score = Probability + Risk + Current System	Comments
Operating Room Storage					
Sterile core rooms	4	4	3	11	High Risk, sterile, invasive items
PACU rooms	4	4	3	11	High Risk, sterile, invasive items
Endoscopy	3	3	3	9	Clean storage
Acute Care Storage					
ICU	4	4	1	9	
ED	4	4	2	10	
1-2A and 1-3A	3	3	3	9	
CLC Storage					
1-4B and 1-5AB	2	2	1	5	
Inventory Management Storage					
Bld 1 Room 51	4	4	3	11	High Risk, sterile, invasive items
Primary Care Storage					
Bld 17 floors 2, 3 and 5	2	2	3	7	
Specialty Clinic Storage					
Bld 17 floors 3 and 4	3	3	3	9	
Dental Clinic Storage					
Bld 17 - 5	3	3	1	7	

<p>Minor Risk</p> <p>Corrective Action Completed within 3 days Humidity greater than 60% does not exceed 12 hours Security and or structure of room intact No water or air contamination in room</p> <p><u>Immediate Relocation of supplies is not indicated</u></p> <p>*Minor Risk will convert to Major Risk if any component of this definition is breached. See grid below for Major Risk.</p>	
<p>Major Risk - with a Risk Impact Score ≥ 9</p> <p>Corrective Action cannot be completed within 3 days Humidity greater than 60% exceeds 12 hours Security and or structure of room are compromised Evidence of water or air contamination in room</p> <p>On the ICRA, if the Risk Impact Score for the affected area is greater than 9, the following apply:</p> <ol style="list-style-type: none"> 1. Requires immediate corrective action 2. Relocate clean/sterile supplies to alternate storage location 3. Reprocess all Critical Sterile and Semi Critical RME through SPS 4. Return Invasive sterile products to Logistics for disposition 5. Return Non Invasive sterile products to Logistics for redistribution in low risk areas. If there is no visible sign of compromise. Visible signs of compromise include condensation, package tears, discoloration or other evidence of contamination. <p>Areas of High Risk Include: Inventory Management Sterile Storage, OR Sterile Core, PACU, Endoscopy, ICU, ED, 1-2A, 1-3A, Specialty Clinic and Dental</p>	<p>Major Risk - with a Risk Impact Score ≤ 9</p> <p>Corrective Action cannot be completed within 3 days Humidity greater than 60% exceeds 12 hours Security and or structure of room are compromised Evidence of water or air contamination in room</p> <p>On the ICRA, if the Risk Impact Score for the affected area is less than 9, the following apply:</p> <ol style="list-style-type: none"> 1. Requires immediate corrective action 2. Relocate clean/sterile supplies to alternate storage location 3. Return invasive sterile devices to Logistics for disposition 4. Any Critical (sterile) or Semi Critical RME should be reprocessed in SPS 5. Non Invasive Sterile products can be used if there is no visible sign of compromise. Visible signs of compromise include condensation, package tears, discoloration or other evidence of contamination <p>Areas of Low Risk Include: 1-4B, 1-5 and Primary Care</p>

Attachment C

TEMPTRAK FLOW PROCESS



HBP

Factory assembled, horizontal blow-thru ducted HBP fan coils are designed for concealed installations above ceilings with ducted return and discharge air and are suitable for projects such as hotels, motels, condominiums and general commercial applications.



HBP

STANDARD FEATURES INCLUDE

- Performance AHRI Certified to Standard 440.
- ETL-Listed. Constructed in compliance with ANSI/UL 1995 Standard.
- All casing sheet metal components fabricated of 18GA G90 galvanized steel.
- Return air plenum thermally and acoustically insulated covering the motor(s)/blower(s) assembly to reduce noise dissipation from the unit.
- High-efficiency 2-row coil suitable for a 2-pipe system.
- Coil manual air vent.
- 1-Inch thick disposable filter.
- Multi-speed motor of the permanent split capacitor (PSC) type.
- Double Width Double Inlet (DWDI) direct driven blowers of the whisper quite type.
- Controls installed in a single control box suitable for single power supply.
- Single wall condensate pan in galvanized steel, thermally protected on the outside. (Consult Titus for availability).
- 1-Inch discharge air flange.
- 1-Inch return air flange
- Anti-vibration mounts for field installation.

OPTIONAL FEATURES INCLUDE


- 3-, 4- And 5-row coils for 2-pipe systems.
- Single block 2, 3 and 4 rows CW with 1 row re-heat or pre-heat coils for 4-pipe system applications (5 rows max).
- Single block 2 and 3 rows CW with 2 rows re-heat or pre-heat for 4-pipe system applications (5 rows max).
- Automatic coil air vents.
- LH or RH entry pipe connections.
- Filter option include:
 - ◊ 1-inch high-efficiency pleated filters.
 - ◊ 1-inch washable filters.

- Bottom or rear return air and filter location.
- Filter supports with slides or clips.
- Filter removal from LH/RH, bottom and rear.
- Cabinet liner in 1/2-inch foil face.
- Motor voltage suitable for 208V, 230V or 277V/1Ph/60Hz power supplies.
- Motor in-line quick disconnect (Not available on bottom return filter).
- Thermostat and Accessories (Refer to Accessories on page V86 for details).
- Single power supply disconnect switch and fuses.
- Automatic 2-pipe changeover switch for heating and cooling applications.
- Electric heaters.
- HW standby electric heater auto changeover switch.
- Valve Packages (Refer to Accessories on page V86 for details).
- Condensate pan options:
 - ◊ Single wall condensate pan manufactured in 20GA 304 Stainless Steel.
 - ◊ Double wall construction consisting of outer and inner skins.
 - ◊ Condensate pan overflow safety switch.
 - ◊ Condensate pan safety overflow connection.



DIMENSIONS

HBP CONCEALED CEILING WITH PLENUM



- | | | |
|----------------------------------------------|----------------------------------------------|----------------------------------------------------------------------------------|
| 1. Return Air Flange | 5. Condensate Copper Connection
3/4" MNPT | 9. Supply Air Flange |
| 2. Filter Rear Return | 6. Coil Connections (2-Pipe Shown) | 10. Electric Control Panel - Note:
Control box may mounted on
either side. |
| 3. Motor/Blower(s) Assembly | 7. Hanging Points | 11. Electric Heaters (optional) |
| 4. Condensate Tray (Double Wall
optional) | 8. Coil | |

Model	Dimensions (inches)						Approx. Weight (pounds)
	A	B	C	D	E	Filter	
HBP02	25 1/2	14 1/4	18 1/4	5/8	18 1/4	20x12x1	63
HBP03	28 1/2	17 1/4	21 1/4	5/8	21 1/4	23x12x1	70
HBP04	34 1/2	23 1/4	27 1/4	5/8	27 1/4	29x12x1	80
HBP06	43 1/2	32 1/4	36 1/4	5/8	36 1/4	38x12x1	99
HBP08	51 1/2	40 1/4	44 1/4	5/8	44 1/4	46x12x1	106
HBP10	61 1/2	50 1/4	54 1/4	7/8	54 1/4	56x12x1	136
HBP12	71 1/2	60 1/4	64 1/4	7/8	64 1/4	66x12x1	150

All dimensions are in inches.



HBP CONCEALED CEILING WITH PLENUM

2-PIPE SYSTEM							
Model	2 Rows Cooling (1)				2 Rows Heating (1)		
	Total MBH	Sensible MBH	Flow gpm	PD ft wg	Sensible MBH	Flow gpm	PD ft wg
HBP02	4.1	3.3	0.8	0.34	13.2	0.9	0.32
HBP03	5.9	4.8	1.2	0.77	18.6	1.3	0.69
HBP04	8.7	7.0	1.7	1.84	26.9	1.8	1.56
HBP06	11.6	9.7	2.3	0.92	37.6	2.6	0.97
HBP08	15.0	11.9	3.0	1.66	45.9	3.1	1.58
HBP10	21.2	16.7	4.2	3.66	62.9	4.3	3.24
HBP12	24.1	19.4	4.8	2.50	74.3	5.1	2.54

2-PIPE SYSTEM							
Model	3 Rows Cooling				3 Rows Heating		
	Total MBH	Sensible MBH	Flow gpm	PD ft wg	Sensible MBH	Flow gpm	PD ft wg
HBP02	5.8	4.2	1.2	1.00	17.0	1.2	0.78
HBP03	8.4	6.1	1.7	2.25	24.2	1.6	1.70
HBP04	12.5	9.1	2.5	5.39	35.2	2.4	3.92
HBP06	16.8	12.6	3.4	2.44	49.5	3.4	2.12
HBP08	21.1	15.3	4.2	4.26	59.7	4.1	3.41
HBP10	27.5	20.6	5.5	3.67	80.7	5.5	3.36
HBP12	34.0	25.0	6.8	6.02	97.1	6.6	5.20

2-PIPE SYSTEM							
Model	4 Rows Cooling				4 Rows Heating		
	Total MBH	Sensible MBH	Flow gpm	PD ft wg	Sensible MBH	Flow gpm	PD ft wg
HBP02	6.9	4.8	1.4	1.88	18.7	1.3	1.26
HBP03	10.0	6.9	2.0	4.21	26.9	1.8	2.78
HBP04	13.1	9.6	2.6	1.52	38.5	2.6	1.31
HBP06	20.4	14.3	4.1	4.36	55.5	3.8	3.25
HBP08	23.5	16.6	4.7	2.88	65.5	4.5	2.40
HBP10	33.3	23.4	6.6	6.24	90.7	6.2	4.94
HBP12	39.0	27.6	7.8	5.82	100.8	7.4	4.96

2-PIPE SYSTEM							
Model	5 Rows Cooling				5 Rows Heating		
	Total	Sensible	Flow	PD	Sensible	Flow	PD
	MBH	MBH	gpm	ft wg	MBH	gpm	ft wg
HBP02	7.6	5.0	1.5	2.77	19.2	1.3	1.65
HBP03	9.8	6.8	2.0	0.93	27.1	1.9	0.72
HBP04	14.7	10.2	2.9	2.23	40.4	2.8	1.68
HBP06	22.4	15.0	4.5	6.20	57.7	3.9	4.13
HBP08	26.0	17.5	5.2	4.00	68.0	4.6	2.93
HBP10	35.2	24.0	7.0	4.91	93.7	6.4	3.93
HBP12	43.2	29.2	8.6	7.86	112.4	7.7	5.99

4-PIPE SYSTEM							
Model	2 Rows Cooling				1 Row Heating		
	Total MBH	Sensible MBH	Flow gpm	PD ft wg	Sensible MBH	Flow gpm	PD ft wg
HBP02	3.9	3.2	0.8	0.31	7.5	0.5	0.40
HBP03	5.7	4.6	1.1	0.72	10.4	0.7	0.84
HBP04	8.4	6.7	1.7	1.72	14.9	1.0	1.89
HBP06	11.2	9.3	2.2	0.85	22.0	1.5	5.24
HBP08	14.3	11.3	2.9	1.52	25.8	1.8	1.22
HBP10	20.4	15.9	4.1	3.39	35.0	2.4	2.60
HBP12	23.0	18.4	4.6	2.28	42.3	2.9	4.22

4-PIPE SYSTEM							
Model	3 Rows Cooling				1 Row Heating		
	Total MBH	Sensible MBH	Flow gpm	PD ft wg	Sensible MBH	Flow gpm	PD ft wg
HBP02	5.5	4.0	1.1	0.93	7.2	0.5	0.38
HBP03	8.0	5.8	1.6	2.07	10.0	0.7	0.80
HBP04	11.9	8.7	2.4	4.92	14.4	1.0	1.80
HBP06	16.0	11.9	3.2	2.22	21.1	1.4	4.94
HBP08	20.2	14.5	4.0	3.91	24.8	1.7	1.27
HBP10	26.2	19.5	5.2	3.34	33.7	2.3	2.60
HBP12	32.6	23.8	6.5	5.53	40.6	2.8	4.28

4-PIPE SYSTEM							
Model	4 Rows Cooling				1 Row Heating		
	Total MBH	Sensible MBH	Flow gpm	PD ft wg	Sensible MBH	Flow gpm	PD ft wg
HBP02	6.6	4.5	1.3	1.70	6.9	0.5	0.36
HBP03	9.5	6.5	1.9	3.81	9.6	0.7	0.76
HBP04	12.3	9.0	2.5	1.35	13.7	0.9	1.68
HBP06	19.2	13.4	3.8	3.91	20.2	1.4	4.63
HBP08	22.2	15.6	4.4	2.58	23.7	1.6	1.25
HBP10	31.6	22.0	6.3	5.64	32.2	2.2	2.63
HBP12	37.0	26.0	7.4	5.23	38.9	2.7	4.19

- Standard basic unit.
- All ratings are based at sea level altitude, nominal air volumes at 0 external static pressure and with water as the cooling fluid.
- Cooling capacities are based on 80°F DB/67°F WB entering air, 45°F entering water, 10°F water temperature rise and high fan speed.
- Heating capacities are based on 70°F DB entering air temperature, 180°F entering hot water, 30°F water temperature drop and high fan speed.

PERFORMANCE DATA

Fan Coils

Nominal Air Volumes			
Model	cfm (1)		
	High	Med	Low
HBP02	219	187	171
HBP03	326	289	230
HBP04	503	391	310
HBP06	696	567	439
HBP08	813	647	535
HBP10	1150	867	696
HBP12	1370	931	781

Air Volume (cfm) Vs External Static Pressure in wg (2)						
Model	0.05	0.10	0.15	0.20	0.25	0.30
HBP02	198	182	166	-	-	-
HBP03	289	262	219	150	-	-
HBP04	478	441	399	341	245	-
HBP06	651	613	569	504	401	-
HBP08	777	722	681	658	628	536
HBP10	1075	1012	939	848	737	616
HBP12	1297	1236	1171	1095	1015	947

1. Nominal air volume ratings are based on a 2-row coil at sea level altitude with 0 external static pressure.
2. Air volumes at alternative external static pressures are based at high fan speed.

Model	Motor	
	HP	Total AMPS
HBP02	1/20	0.8
HBP03	1/20	0.8
HBP04	1/20	0.8
HBP06	1/10	1.5
HBP08	1/10	1.5
HBP10	1/10	1.5
HBP12	1/10	1.5

1. Electric ratings are based on units suitable for a power supply of 115V/1Ph/60Hz.



SUBMITTAL DATA: PKA-A24KA4 & PUY-A24NHA4.....24,000 BTU/H WALL-MOUNTED AIR-CONDITIONING SYSTEM

Job Name:	Location:	Date:
Purchaser:	Engineer:	
Submitted to:	For <input type="checkbox"/> Reference <input type="checkbox"/> Approval <input type="checkbox"/> Construction	
System Designation:	Schedule No.:	

GENERAL FEATURES

- Wall-mounted indoor unit for residential and commercial applications
- Shiny-white-exterior plastic; compact design
- Quiet operation—both indoor and outdoor units
- Self-check function—integrated diagnostics
- Limited warranty: five years on parts and defects and seven years on compressors

OPTIONAL ACCESSORIES
Indoor Unit

- ☐ Mini Condensate Pump (SI3100-230, 230V)
- ☐ L-Connector Pipe (PAC-SC84PI; for left side unit piping installation)

Outdoor Unit

- ☐ Drain Pan (PAC-SG63DP)
- ☐ Drain Socket (PAC-SG61DS)
- ☐ Three-pole Disconnect Switch (TAZ-MS303)
- ☐ Wind Baffle (WB-PA2)
- ☐ Air Outlet Guide (PAC-SG59SG)
- ☐ Mounting Base (DSD-400N)
- ☐ Mounting Pad (ULTRILITE2)
- ☐ Wall-mounting Brackets (CWMB1)

Controller Options

- ☐ Wireless Remote Controller Kit (MHK1) with Remote Controller (MRCH1), Wireless Receiver (MIFH1), and cable (MRC1)*
- ☐ Setback down to 50°F when used with MRCH1 Remote Controller
- ☐ Portable Controller (MCCH1; for use with Wireless Remote Controller Kit MHK1)*
- ☐ Outdoor Air Sensor (MOS1; for use with Remote Controller (MRCH1), Wireless Remote Controller Kit (MHK1) and Portable Controller (MCCH1)*

*See Submittal for information on each option.

- ☐ Wall-mounted Wired Remote Controller (PAR-21MAA)
- ☐ M-NET Adapter (PAC-SF81MA)
- ☐ CN51 Connector for Multiple Remote Controller Adapters/Duct Fan Controller (PAC-725AD)
- ☐ CN32 Connector for Remote On/Off (PAC-715AD)
- ☐ Remote Temperature Sensor (PAC-SE41TS)
- ☐ Remote Operation Adapter - Display and On/Off (PAC-SF40RM)
- ☐ Hand-held Wireless Remote Controller (PAR-FL32MA)
- ☐ Lockdown Bracket for Hand-held Controller (RCMKP1CB)
- ☐ Control/Service Tool (PAC-SK52ST)

Cooling*

Rated Capacity.....24,000 Btu/h
Minimum Capacity.....12,000 Btu/h
SEER.....17.0 Btu/h/W
EER.....10.6 Btu/h/W
Total Input.....2,270 W

* Rating Conditions (Cooling) - Indoor: 80°F (27°C) DB / 67°F (19°C) WB.
Outdoor: 95°F (35°C) DB / 75°F (24°C) WB.

Electrical Requirements

Power Supply.....208 / 230V, 1-Phase, 60 Hz
Recommended Fuse/Breaker Size.....25 A

Voltage

Indoor - Outdoor S1-S2.....AC 208 / 230V
Indoor - Outdoor S2-S3.....DC 24V

OPERATING CONDITIONS

	Indoor Intake Air Temp.	Outdoor Intake Air Temp.
Cooling	Maximum 95°F (35°C) DB, 71°F (22°C) WB	115°F (46°C) DB
	Minimum 67°F (19°C) DB, 57°F (14°C) WB	0°F** (-18°C) DB

** With optional wind baffle accessory installed. If not installed, the minimum temperature will be 23°F (-5°C) DB.



Indoor Unit: PKA-A24KA4



Outdoor Unit: PUY-A24NHA4

Indoor Unit

MCA.....1 A
Fan Motor.....0.36 F.L.A.
Fan Motor Output......56 W
Airflow (Lo - Mid - Hi).....635 - 705 - 775 Dry CFM
570 - 635 - 700 Wet CFM
Air Filter.....Polypropylene Honeycomb
Sound Pressure Level (Lo - Mid - Hi).....39 - 42 - 45 dB(A)
SHF.....0.77
Moisture Removal.....5.0 pt./h

DIMENSIONS	UNIT INCHES / MM
W	46-1/16 / 1,170
D	11-5/8 / 295
H	14-3/8 / 365

Weight......46 lbs. / 21 kg
External Finish.....Munsell No. 1.0Y 9.2 / 0.2
Field Drainpipe Size O.D.....5/8" / 16 mm

Outdoor Unit

Compressor.....DC Inverter-driven Twin Rotary
MCA.....18 A
MOCP.....30 A
Fan Motor.....0.75 F.L.A.
Sound Pressure Level
Cooling......48 dB(A)


DIMENSIONS	INCHES / MM
W	37-3/8 / 950
D	13 + 1-3/16 / 330 + 30
H	37-1/8 / 943

Weight......163 lbs. / 74 kg
External Finish.....Munsell No. 3Y 7.8 / 1.1
Refrigerant Type.....R410A
Refrigerant Pipe Size O.D.
Gas Side.....5/8" / 15.88 mm
Liquid Side.....3/8" / 9.52 mm
Max. Refrigerant Pipe Length.....165' / 50 m
Max. Refrigerant Pipe Height Difference.....100' / 30 m
Connection Method.....Flared



INVERTER

DIMENSIONS: PKA-A24KA4

Unit: inch (mm)



DIMENSIONS: PUY-A24NHA4



Intertek



3400 Lawrenceville Suwanee Rd
Suwanee, GA 30024
Tele: 678-376-2900 • Fax: 800-889-9904
Toll Free: 800-433-4822 (#3)
www.mehvac.com
Specifications are subject to change without notice.

Job Name: _____ Location: _____

Drawing Reference: _____ Schedule No. _____

System No.: _____ Date: _____

GENERAL FEATURES



- R410A refrigerant
- Seven sizes from 6,000 to 30,000 Btu/h
- Powerful airflow (CFM)
- Compact, lightweight, shiny-white, flat-panel design
- Quiet operation
- Multiple fan-speed settings
- Intake grille filter is easily removed for cleaning
- Built-in receiver is standard

SPECIFICATIONS

Capacity*

Cooling.....18,000 Btu/h
Heating.....20,000 Btu/h

Power

Power Source.....208 / 230V, 1-phase, 60Hz

Power Consumption

Cooling.....0.03 kW
Heating.....0.03 kW

Current

Cooling.....0.30 A
Heating.....0.30 A

Minimum Circuit Ampacity (MCA).....0.38 A

Maximum Overcurrent Protection (MOCP) Fuse.....15 A

External Finish.....Munsell No. 1.0Y 9.2 / 0.2

External Dimensions

Inches.....11-5/8 H x 35-3/8 W x 9-13/16 D
mm.....295 H x 898 W x 249 D

Net Weight

Unit.....29 lbs. / 13 kg

Coil Type.....Cross Fin
(Aluminum Plate Fin and Copper Tube)

Fan

Type x Quantity.....Line Flow Fan x 1
Airflow Rate (Low-Mid-High).....320 - 370 - 425 CFM

Motor

Type.....Direct-drive DC Motor
Output.....0.030 kW

Air Filter.....Polypropylene Honeycomb

Refrigerant Piping Dimensions

Liquid (High Pressure).....1/4" / 6.35 mm (Flare)
Gas (Low Pressure).....1/2" / 12.7 mm (Flare)

Drainpipe Dimension.....I.D. 5/8" / 16 mm

Sound Pressure Levels

Low-Mid-High.....36 - 41 - 45 dB(A)

OPTIONS

- ☐ Condensate Pump.....SI3100-230
- ☐ External Heat Adapter.....PAC-725AD
- ☐ CN24 Relay Kit.....CN24RELAY-KIT-CM

* Cooling / Heating capacity indicated at the maximum value at operation under the following conditions:


Cooling: Indoor 80°F (27°C) DB / 67°F (19°C) WB, Outdoor 95°F (35°C) DB

Heating: Indoor 70°F (21°C) DB, Outdoor 47°F (8°C) DB / 43°F (6°C) WB

Note: Ventilation air: Providing sufficient ventilation air is an important part of every building design. ASHRAE Standard 62 provides the minimum ventilation air requirement. Also, check local codes.



Model: PKFY-P18NHMU-E – DIMENSIONS



Mitsubishi Electric Air Conditioning & Refrigeration Systems Works acquired ISO 9001 certification under Series 9000 of the International Standard Organization (ISO) based on a review of quality warranties for the production of refrigeration and air conditioning equipment.

ISO Authorization System
The ISO 9000 series is a plant authorization system relating to quality warranties as stipulated by the ISO. ISO 9001 certifies quality warranties based on the "design, development, production, installation and auxiliary services" for products built at an authorized plant.



Mitsubishi Electric Air Conditioning & Refrigeration Systems Works acquired environmental management system standard ISO 14001 certification.

The ISO 14000 series is a set of standards applying to environmental protection set by the International Standard Organization (ISO).



HVAC Advanced Products Division

Mitsubishi Electric & Electronics USA, Inc.
3400 Lawrenceville Suwanee Rd.

Suwanee, GA 30024

Tele: 678-376-2900 • Fax: 800-889-9904

Toll Free: 800-433-4822 (#4)

www.mehvac.com

Specifications are subject to change without notice.

Job Name: _____

Location: _____

Drawing Reference: _____

Schedule No. _____

System No.: _____

Date: _____

OUTDOOR VRF SYSTEM FEATURES

- Single-phase outdoor unit with variable refrigerant flow zoning (VRF) technology
- Inverter-driven (variable speed) compressor
- Total refrigerant piping length of 394' (120 m)
- Uses CITY MULTI indoor units and Controls Network
- External finish: Precoated Galvanized-steel Sheets
- Operating Outdoor Temperature Range
Cooling: 23°F ~ 115°F (-5° ~ +46°C) DB*
Heating: 0°F ~ +60°F (-18° ~ +15°C) WB

* If PKFY-P06/08 indoor units are connected, then range is 50°F ~ 115°F (10°C ~ 46°C).





OPTIONAL PARTS


- ☐ Branch Joint (T-Branch).....CMY-Y62-G-E
- ☐ Header - Four-Branch.....CMY-Y64-G-E
- ☐ Header - Eight-Branch.....CMY-Y68-G-E
- ☐ Air Outlet Guide (One Piece)**.....PAC-SG59SG-E
- ☐ Wind Baffle (One Piece)**.....WB-PA2
- ☐ Drain Pan.....PAC-SG64DP-E
- ☐ Drain Socket.....PAC-SG61DS-E

** PUMY requires two outlet guides or wind baffles for installation.

Specifications		Model Name
Unit Type		PUMY-P36NHMU
Nominal Cooling Capacity	Btu/h	36,000
Nominal Heating Capacity	Btu/h	40,000
External Dimensions (H x W x D)	In. / mm	53-3/16 x 37-7/16 x 13 (+1-3/16) / 1,350 h x 950 w x 330 (+30)
Net Weight	Lbs. / kg	287 / 130
Electrical Power Requirements	Voltage, Phase, Hertz	208 / 230V, 1-phase, 60Hz
Cooling Power Input	kW	3.22
Heating Power Input	kW	2.93
Cooling Current (208/230V)	A	14.2 / 15.7
Heating Current (208/230V)	A	12.9 / 14.2
Minimum Circuit Ampacity (MCA)	A	26
Recommended Fuse/Breaker Size	A	30
Maximum Fuse Size	A	40
Piping Diameter (Braze) (In. / mm)	Liquid (High Pressure)	3/8 / 9.52
	Gas (Low Pressure)	5/8 / 15.88
Indoor Unit	Total Capacity	50 to 130% of Outdoor Unit Capacity
	Model / Quantity	P06 to P36 / 1 to 6
Sound Pressure Levels	dB(A)	49/51
Fan		
Type x Quantity		Propeller Fan x 2
Airflow Rate	CFM	3,530
Direct-drive Inverter Motor Output	kW	0.086
Compressor Operating Range		33% to 100%
Compressor Type x Quantity		Inverter-driven Scroll Hermetic x 1
Compressor Motor Output	kW	2.4
Refrigerant		R410A
Lubricant		FV50S
High-pressure Protection Device		601 psi / 4.15 MPa
Compressor / Fan Protection Device		Overheat Protection / Thermal Switch
Inverter Protection Device		Overheat / Overcurrent Protection
Blue Fin Anti-corrosion Protection: Cellulose- and polyurethane-resin coating treatment applied to condenser coil that protects it from air contaminants; ≥1µm thick; Salt Spray Test Method - no unusual rust development to 240 hours.		

Model: PUMY-P36NHMU – DIMENSIONS

Unit : mm(in)



Certificate Number FM33568

Mitsubishi Electric Air Conditioning & Refrigeration Systems Works acquired ISO 9001 certification under Series 9000 of the International Standard Organization (ISO) based on a review of quality warranties for the production of refrigeration and air conditioning equipment.

ISO Authorization System

The ISO 9000 series is a plant authorization system relating to quality warranties as stipulated by the ISO. ISO 9001 certifies quality warranties based on the "design, development, production, installation and auxiliary services" for products built at an authorized plant.

Mitsubishi Electric Air Conditioning & Refrigeration Systems Works acquired environmental management system standard ISO 14001 certification.

The ISO 14000 series is a set of standards applying to environmental protection set by the International Standard Organization (ISO).



MITSUBISHI ELECTRIC

HVAC Advanced Products Division

Mitsubishi Electric & Electronics USA, Inc.

3400 Lawrenceville Suwanee Rd.

Suwanee, GA 30024

Tele: 678-376-2900 • Fax: 800-889-9904

Toll Free: 800-433-4822 (#4)

www.mehvac.com

Specifications are subject to change without notice.



Certificate Number EC97J1227

C SD - PUMY-P36NHMU - 1 - 201007 © MITSUBISHI ELECTRIC / HVAC 2010



Your guide to selecting and specifying Nortec Steam Exchange Humidifiers!



SE Series

Engineering Manual

Includes technical specifications,
guidelines, and options for selection
and application of SETC B+ / SEP
Steam Exchange humidifiers

5. SHORT ABSORPTION MANIFOLD (SAM-e)

A. GENERAL

- (1) NORTEC's best performing steam absorption system for use in Air Handling Units and duct systems where short steam absorption distance is critical.
- (2) The SAM-e, Figure 17, distributes clean steam, precisely controlled, uniformly into the entire air stream, void of any condensate spray. Steam distribution takes place via distributor tubes with integrated nozzles. The steam is kept dry as condensate is drained through the main header.
- (3) The stainless steel distribution tubes are typically mounted vertically but can also be mounted horizontally (10° slope) for vertical airflow applications. The distribution tubes come equipped with evenly spaced stainless steel nozzles providing optimum steam distribution, over the entire length of the tube.
- (4) The nozzles extend into the center of the distribution tube ensuring only condensate free steam is released. (See Figure 18.) Condensate drains out of the distribution tubes, through the header, eliminating the need for jacketed tubes. A permanent bond between the nozzle and distribution tube is made when the nozzle is pressed into the tube. The nozzles and tubes have the same thermal expansion characteristics guaranteeing a permanent union. The specifically sized orifices ensure consistent output from each nozzle.



Figure 17. SAM-e Tubes




Figure 18. Cross-Section of Distributor Pipe


Tag	NORTEC Model	Load	Power Circuit	Stm. Press.	Max. Fuse	Quantity
19-SH-1	SETC 050, 110-120V	11.72 lbs/hr	110-120/1/60	15.00 psi	15.00 A	1
Distribution Method					Absorption Distance	
In Duct mini Short Absorption Manifold (see option schedule)					0.32 ft	

Tag	NORTEC Model	Load	Power Circuit	Stm. Press.	Max. Fuse	Quantity
19-SH-2	SETC 050, 110-120V	11.72 lbs/hr	110-120/1/60	15.00 psi	15.00 A	1
Distribution Method					Absorption Distance	
In Duct mini Short Absorption Manifold (see option schedule)					0.20 ft	


Tag	NORTEC Option	Part Number	Quantity
19-SH-1	Header Insulation, mini SAM-e 18"-6 Centers	2539633	1
	Tube Insulation, mini SAM-e 11" (Covers 1 Tube)	2538869	3
	Water Filter Cartridge 5 micron (x2)	1329506	1
	In-Line Water filter c/w 5 micron filter	1329505	1
	Switch Air Proving (duct airflow safety interlock)	1329203	1
	0-10V Dig. Duct Humidistat pkg	2520266	1
	0 - 10 Vdc single channel DEMAND signal acceptance	2523066	1
	Nortec LINKS XPS for SETC 050, BACnet/MSTP	2559031	1
	Inlet adapter, mini SAM-e, 1-3/4" OD	1509837	1
	Header mini SAM-e 18", 6" centers	1509832	1
	Steam Tube, mini SAM-e, 11 in Type MB	1509798	3
Tag	NORTEC Option	Part Number	Quantity
19-SH-2	Water Filter Cartridge 5 micron (x2)	1329506	1
	In-Line Water filter c/w 5 micron filter	1329505	1
	Switch Air Proving (duct airflow safety interlock)	1329203	1
	0 - 10 Vdc single channel DEMAND signal acceptance	2523066	1
	0-10V Dig. Duct Humidistat pkg	2520266	1
	Header Insulation, mini SAM-e 12"-3 Centers	2538932	1
	Tube Insulation, mini SAM-e 13" (Covers 1 Tube)	2538870	3
	Nortec LINKS XPS for SETC 050, BACnet/MSTP	2559031	1
	Inlet adapter, mini SAM-e, 1-3/4" OD	1509837	1
	Header mini SAM-e 12", 3" centers	1509811	1
	Steam Tube, mini SAM-e, 13 in Type MB	1509799	3

Square and Rectangular Ceiling Diffusers Steel • Louvered Face • Induction Vanes


Model: TDV • Square, Rectangle or Round Neck




☐ Border Type 1 (Surface Mount) Square or Rectangular Neck




☐ Border Type 1 (Surface Mount) Round Neck




☐ Border Type 2 (Snap-In)



☐ Border Type 3 (Lay-In)



☐ Border Type 4 (Spline)





Dimensions are in inches.

For Dimensions "A" see table on next page.

(Please see reverse side).


D-44.0-S

Border Types, Dimensions (Continued)



***Note:** Dimension A refers to either square/rectangle or round neck diffusers. See drawings below.

Available Duct Sizes, Square and Rectangular Necks




Border Type 1, 5, 6	
Minimum Duct Size A	Maximum Duct Size A
6 x 6	48 x 48

Border Type 2, 3, 4		
Available Module Size	Minimum Duct Size A	Maximum Duct Size A
12 x 12	6 x 6	9 x 9
24 x 24	6 x 6	18 x 18
48 x 24	12 x 12	42 x 18

Note: Duct sizes are available in 3" increments only.
Maximum duct size for border 5 is 36 x 36.

Available Duct Sizes, Round Necks



Border Type 1, 5, 6	
Dimensions A	Available Round Duct Size
6 x 6	6
9 x 9	6, 8
12 x 12	8, 10, 12
15 x 15	6, 8, 10, 12, 14
18 x 18	6, 8, 10, 12, 14, 16


Border Type 2,3,4		
Available Module Size	Minimum A	Available Round Duct Size
12 x 12	6 x 6	6
	9 x 9	6, 8
24 x 24	6 x 6	6
	9 x 9	6, 8
	12 x 12	6, 8, 10, 12
	15 x 15	6, 8, 10, 12, 14
	18 x 18	6, 8, 10, 12, 14, 16

***Note:** Round duct sizes are available only in sizes shown.

Accessories (Optional) for Round Neck


Check ☐ if provided

- ☐ Model AG-100 Radial Sliding Blade Damper *
- ☐ Model EG Equalizing Grid




Model AG-100 damper is available in duct sizes 6 thru 14 inches only

- ☐ Model D-100 Radial Sliding Blade Damper *
- ☐ Model EG Equalizing Grid




Model D-100 damper is available in duct sizes 6 thru 14 inches only.

- ☐ Model AG-65 Combination Damper and Equalizing Grid *




- ☐ Model AG-85 Butterfly Damper *
- ☐ Model EG Equalizing Grid



Accessories (Optional) for Rectangular Neck


Check ☐ if provided

- ☐ Model AG-35B Opposed Blade Damper
- ☐ Model EG Equalizing Grid



All dimensions are in inches.

- ☐ Model AG-95 Opposed Blade Damper with Slot Operator
- ☐ Model EG Equalizing Grid



Accessories (Optional)

Check ☐ if provided

Accessories	Nominal Round Duct Sizes					
	6	8	10	12	14	16
<input type="checkbox"/> AG-100	•	•	•	•	•	N/A
<input type="checkbox"/> D-100	•	•	•	•	•	N/A
<input type="checkbox"/> AG-85	•	•	•	•	•	•
<input type="checkbox"/> AG-65	•	•	•	•	•	•
<input type="checkbox"/> EG	•	•	•	•	•	•
<input type="checkbox"/> EQT	•	•	•	•	•	•

• Available Sizes

Accessories	Nominal Rectangular Duct Sizes
<input type="checkbox"/> AG-95 Type 1	Available in Sizes 6 x 6 through 18 x 18
<input type="checkbox"/> AG-35B	
<input type="checkbox"/> EG-L/EG-S	
<input type="checkbox"/> AG-65-L/AG-65-S	
<input type="checkbox"/> EQT	

Other Accessories (Optional)

Standard Finish: #26 White

☐ Model SR Square-to-Round Transition


Optional Patterns

Check ☐ selection


1 Way	<input type="checkbox"/> S1 Square	<input type="checkbox"/> A1	<input type="checkbox"/> B1
2 Way	<input type="checkbox"/> A2	<input type="checkbox"/> S2 Square	<input type="checkbox"/> B2
2 Way Corner	<input type="checkbox"/> E2	<input type="checkbox"/> F2	<input type="checkbox"/> G2 Square
3 Way	<input type="checkbox"/> A3 $X \geq Y$	<input type="checkbox"/> E3 $X > 2Y$	<p>For A3, $X > Y$ For A3-2, $X > Y, X < 2Y$ For B3, $X = 2Y$ For E3, $X > 2Y$</p> <p>* Dimensions X and Y shown here are the proportions of available rectangular duct sizes. Duct sizes are available in 3" increments. Dimension X is always the longer dimension for each core option.</p>
	<input type="checkbox"/> A3-2 $X > Y, X < 2Y$	<input type="checkbox"/> B3 $X = 2Y$	
4 Way	<input type="checkbox"/> A4 Square	<input type="checkbox"/> B4	

Removing Center Core


1. Remove shipping clips.



2. Push core sideways against spring.



3. Hold core securely and allow to drop down.



General Description

- TITUS Model TDV is a high capacity ceiling diffuser. Because it maintains an unbroken horizontal flow pattern from maximum cfm down to minimum, it is an excellent choice for variable air volume application.
- Core is removable from the face of the diffuser.
- Slot operator on optional, neck-mounted Model AG-95 damper allows easy volume adjustment by removing the diffuser core. (Rectangular necks only).
- Model TDV is extremely flexible, with cores available for 1, 2, 3 or 4-way horizontal flow patterns.
- Material is heavy gauge steel.
- The TITUS TDV has louvered face with integrated induction vanes for exceptional air mixing.



Note: This submittal is meant to demonstrate general dimensions of this product. The drawing on this submittal are not meant to detail every aspect of the product with exactness. Drawings are not to scale. TITUS reserves the right to make changes without written notice.

D-44.0-S

Performance Data • Round Neck

TDV • Louvered Face, Induction Vanes • Horizontal Discharge Pattern

F177

PERFORMANCE DATA

Return Factors -SP = 1.1 TP Add 1 to NC		Total cfm Total Pressure NC Side	78 0.031 9	98 0.050 15	117 0.071 20	137 0.097 24	156 0.126 28	176 0.160 31	215 0.239 37
			cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw
6 x 6"	S1	X	78 6-9-17	98 7-11-20	117 9-13-21	137 10-15-23	156 12-17-25	176 13-19-26	215 16-21-29
	S2&G2	X & Y	39 3-5-10	49 4-6-12	59 5-7-15	69 6-9-16	78 6-10-17	88 7-11-19	108 9-13-21
	A3	X	28 3-4-8	37 3-5-9	44 4-6-9	52 5-7-10	59 5-8-11	66 6-8-12	81 7-9-13
	A4	Y	19 2-3-6	25 3-4-8	29 3-5-9	34 4-5-10	39 4-6-11	44 5-7-12	54 6-8-13
Round		X & Y	19 2-3-6	29 3-4-8	34 3-5-9	39 4-5-10	44 4-6-11	54 5-7-12	64 6-8-13
Return Factors -SP = 1.1 TP Add 1 to NC		Total cfm Total Pressure NC Side	98 0.050 15	117 0.071 20	137 0.097 24	156 0.126 28	176 0.160 31	215 0.239 37	254 0.334 41
			cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw
9 x 9"	S1	X	98 7-11-20	117 9-13-21	137 10-15-23	156 12-17-25	176 13-19-26	215 16-21-29	254 18-22-32
	S2&G2	X & Y	49 4-6-12	59 5-7-15	69 6-9-16	78 6-10-17	88 7-11-19	108 9-13-21	127 11-16-22
	A3	X	37 3-5-9	44 4-6-9	52 5-7-10	59 5-8-11	66 6-8-12	81 7-9-13	96 8-10-14
	A4	Y	25 3-4-8	29 3-5-9	34 4-5-10	39 4-6-11	44 5-7-12	54 6-8-13	64 7-10-14
Round		X & Y	25 3-4-8	29 3-5-9	34 4-5-10	39 4-6-11	44 5-7-12	54 6-8-13	64 7-10-14
Return Factors -SP = 1.1 TP Add 1 to NC		Total cfm Total Pressure NC Side	139 0.032 10	174 0.049 16	209 0.071 21	244 0.097 25	279 0.127 29	314 0.161 32	383 0.239 38
			cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw
9 x 9"	S1	X	139 8-12-23	174 10-15-26	209 12-18-29	244 14-21-31	279 16-23-33	314 18-25-35	383 22-27-39
	S2&G2	X & Y	70 4-6-13	87 5-8-16	105 6-10-19	122 8-11-22	140 9-13-23	157 10-15-25	192 12-18-27
	A3	X	52 4-5-10	66 4-7-11	79 5-8-13	92 6-9-14	105 7-10-15	119 8-11-15	145 10-12-17
	A4	Y	35 3-4-8	44 3-5-10	52 4-6-12	61 5-7-14	70 6-8-15	79 6-9-16	96 8-11-17
Round		X & Y	35 3-4-8	44 3-5-10	52 4-6-12	61 5-7-14	70 6-8-15	79 6-9-16	96 8-11-17
Return Factors -SP = 1.1 TP Add 1 to NC		Total cfm Total Pressure NC Side	174 0.049 16	209 0.071 21	244 0.097 25	279 0.127 29	314 0.161 32	383 0.239 38	453 0.335 42
			cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw
12 x 12"	S1	X	174 10-15-26	209 12-18-29	244 14-21-31	279 16-23-33	314 18-25-35	383 22-27-39	453 24-30-42
	S2&G2	X & Y	87 5-8-16	105 6-10-19	122 8-11-22	140 9-13-23	157 10-15-25	192 12-18-27	227 14-21-30
	A3	X	66 4-7-11	79 5-8-13	92 6-9-14	105 7-10-15	119 8-11-15	145 10-12-17	171 11-13-18
	A4	Y	44 3-5-10	52 4-6-12	61 5-7-14	70 6-8-15	79 6-9-16	96 8-11-17	113 9-13-19
Round		X & Y	44 3-5-10	52 4-6-12	61 5-7-14	70 6-8-15	79 6-9-16	96 8-11-17	113 9-13-19
Return Factors -SP = 1.1 TP Add 1 to NC		Total cfm Total Pressure NC Side	218 0.032 11	272 0.049 17	327 0.072 22	381 0.097 26	447 0.127 30	490 0.161 33	599 0.240 38
			cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw
12 x 12"	S1	X	218 10-15-29	272 12-18-33	327 15-22-36	381 17-26-39	447 20-29-41	490 22-31-44	599 27-34-48
	S2&G2	X & Y	109 5-8-16	136 7-10-20	164 8-12-24	191 9-14-27	218 11-16-29	245 12-18-31	300 15-22-34
	A3	X	82 4-7-13	103 6-8-14	123 7-10-16	144 8-12-17	165 9-13-18	185 10-14-19	226 12-15-21
	A4	Y	55 3-5-10	68 4-6-13	82 5-8-16	95 6-9-17	109 7-10-18	123 8-12-20	150 9-14-22
Round		X & Y	55 3-5-10	68 4-6-13	82 5-8-16	95 6-9-17	109 7-10-18	123 8-12-20	150 9-14-22
Return Factors -SP = 1.1 TP Add 1 to NC		Total cfm Total Pressure NC Side	235 0.020 -	314 0.035 15	392 0.055 20	471 0.079 25	549 0.107 29	628 0.140 33	706 0.177 36
			cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw
12 x 12"	S1	X	235 9-14-27	314 12-18-35	392 15-23-39	471 18-27-43	549 21-32-46	628 24-35-50	706 27-37-53
	S2&G2	X & Y	118 5-7-15	157 7-10-20	196 8-12-25	236 10-15-30	275 12-17-33	314 13-20-35	353 15-22-37
	A3	X	89 4-6-12	119 5-8-15	148 7-10-17	178 8-12-19	207 10-14-20	237 11-15-22	267 12-16-23
	A4	Y	59 2-5-10	79 4-6-13	98 5-8-16	118 6-10-19	137 7-11-21	157 8-13-22	177 10-14-23
Round		X & Y	59 2-5-10	79 4-6-13	98 5-8-16	118 6-10-19	137 7-11-21	157 8-13-22	177 10-14-23
Return Factors -SP = 1.1 TP Add 1 to NC		Total cfm Total Pressure NC Side	314 0.035 13	392 0.055 19	471 0.079 24	549 0.107 28	623 0.138 32	706 0.177 35	863 0.264 40
			cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw
15 x 15"	S1	X	314 12-18-35	392 15-23-39	471 18-27-43	549 21-32-46	623 24-35-49	706 27-37-53	863 33-41-58
	S2&G2	X & Y	157 7-10-20	196 8-12-25	236 10-15-30	275 12-17-33	312 13-20-35	353 15-22-37	432 18-27-41
	A3	X	119 5-8-15	148 7-10-17	178 8-12-19	207 10-14-20	235 11-15-22	267 12-16-23	326 15-18-26
	A4	Y	79 4-6-13	98 5-8-16	118 6-10-19	137 7-11-21	156 8-13-22	177 10-14-23	216 12-17-26
Round		X & Y	79 4-6-13	98 5-8-16	118 6-10-19	137 7-11-21	156 8-13-22	177 10-14-23	216 12-17-26

- All pressures are in inches of water.
- Throw velocities given are for isothermal terminal velocities of 150, 100 and 50 fpm. See the section, Engineering Guidelines for additional information.
- NC values based on Octave Band 2 to 7 sound power levels minus a room absorption of 10 dB.

- Dash (-) in space denotes an NC value less than 10.
- Data obtained from tests conducted in accordance with ANSI/ASHRAE Standard 70-2006.
- Throw values given are for isothermal conditions.

For Performance Notes, please refer to page F166.

Performance Data • Round Neck (continued)

TDV • Louvered Face, Induction Vanes • Horizontal Discharge Pattern

Return Factors -SP = 1.1 TP Add 1 to NC		Total cfm Total Pressure NC Side	320 0.018 5	427 0.032 12	534 0.050 18	641 0.072 23	748 0.097 27	855 0.127 31	863 0.130 31
			cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw
15 x 15 14"	S1	X	320 10-15-31	427 14-21-41	534 17-26-46	641 21-31-50	748 24-36-54	855 28-41-58	863 28-41-58
	S2&G2	X & Y	160 6-9-17	214 8-11-23	267 9-14-28	321 11-17-34	374 13-20-38	428 15-23-41	432 15-23-41
	A3	X	121 4-7-14	161 6-9-18	202 8-12-20	242 9-14-22	282 11-16-24	323 12-18-25	326 13-18-26
	Y	80 3-5-11	107 5-7-14	134 6-9-18	160 7-11-22	187 8-13-24	214 10-14-26	216 10-15-26	
Round		A4	80 3-5-11	107 5-7-14	134 6-9-18	160 7-11-22	187 8-13-24	214 10-14-26	216 10-15-26
			cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw
18 x 18 6"	S1	X	98 7-11-20	117 9-13-21	137 10-15-23	156 12-17-25	176 13-19-26	215 16-21-29	254 18-22-32
	S2&G2	X & Y	49 4-6-12	59 5-7-15	69 6-9-16	78 6-10-17	88 7-11-19	108 9-13-21	127 11-16-22
	A3	X	37 3-5-9	44 4-6-9	52 5-7-10	59 5-8-11	66 6-8-12	81 7-9-13	96 8-10-14
	Y	25 3-4-8	29 3-5-9	34 4-5-10	39 4-6-11	44 5-7-12	54 6-8-13	64 7-10-14	
Round		A4	25 3-4-8	29 3-5-9	34 4-5-10	39 4-6-11	44 5-7-12	54 6-8-13	64 7-10-14
			cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw
18 x 18 8"	S1	X	174 10-15-26	209 12-18-29	244 14-21-31	279 16-23-33	314 18-25-35	383 22-27-39	453 24-30-42
	S2&G2	X & Y	87 5-8-16	105 6-10-19	122 8-11-22	140 9-13-23	157 10-15-25	192 12-18-27	227 14-21-30
	A3	X	66 4-7-11	79 5-8-13	92 6-9-14	105 7-10-15	119 8-11-15	145 10-12-17	171 11-13-18
	Y	44 3-5-10	52 4-6-12	61 5-7-14	70 6-8-15	79 6-9-16	96 8-11-17	113 9-13-19	
Round		A4	44 3-5-10	52 4-6-12	61 5-7-14	70 6-8-15	79 6-9-16	96 8-11-17	113 9-13-19
			cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw
18 x 18 10"	S1	X	218 10-15-29	272 12-18-33	327 15-22-36	381 17-26-39	436 20-29-41	490 22-31-44	599 27-34-48
	S2&G2	X & Y	109 5-8-16	136 7-10-20	164 8-12-24	191 9-14-27	218 11-16-29	245 12-18-31	300 15-22-34
	A3	X	82 4-7-13	103 6-8-14	123 7-10-16	144 8-12-17	165 9-13-18	185 10-14-19	226 12-15-21
	Y	55 3-5-10	68 4-6-13	82 5-8-16	95 6-9-17	109 7-10-18	123 8-12-20	150 9-14-22	
Round		A4	55 3-5-10	68 4-6-13	82 5-8-16	95 6-9-17	109 7-10-18	123 8-12-20	150 9-14-22
			cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw
18 x 18 12"	S1	X	314 12-18-35	392 15-23-39	471 18-27-43	549 21-32-46	623 24-35-49	706 27-37-53	863 33-41-58
	S2&G2	X & Y	157 7-10-20	196 8-12-25	236 10-15-30	275 12-17-33	312 13-20-35	353 15-22-37	432 18-27-41
	A3	X	119 5-8-15	148 7-10-17	178 8-12-19	207 10-14-20	235 11-15-22	267 12-16-23	326 15-18-26
	Y	79 4-6-13	98 5-8-16	118 6-10-19	137 7-11-21	156 8-13-22	177 10-14-23	216 12-17-26	
Round		A4	79 4-6-13	98 5-8-16	118 6-10-19	137 7-11-21	156 8-13-22	177 10-14-23	216 12-17-26
			cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw
18 x 18 14"	S1	X	427 14-21-41	534 17-26-46	641 21-31-50	748 24-36-54	855 28-41-58	962 31-43-61	1175 38-48-68
	S2&G2	X & Y	214 8-11-23	267 9-14-28	321 11-17-34	374 13-20-38	428 15-23-41	481 17-26-43	588 21-31-48
	A3	X	161 6-9-18	202 8-12-20	242 9-14-22	282 11-16-24	323 12-18-25	363 14-19-27	444 17-21-30
	Y	107 5-7-14	134 6-9-18	160 7-11-22	187 8-13-24	214 10-14-26	241 11-16-27	294 13-20-30	
Round		A4	107 5-7-14	134 6-9-18	160 7-11-22	187 8-13-24	214 10-14-26	241 11-16-27	294 13-20-30
			cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw
18 x 18 16"	S1	X	628 18-27-50	698 20-30-52	837 24-35-57	977 28-41-62	1256 35-50-70	1530 43-55-77	1808 49-60-84
	S2&G2	X & Y	314 10-15-29	349 11-16-32	419 13-19-39	488 15-23-44	628 19-29-50	765 24-36-55	904 28-42-60
	A3	X	237 8-12-22	263 9-13-23	316 11-16-25	369 12-19-27	474 16-22-31	578 20-24-34	683 21-26-37
	Y	157 6-9-19	174 7-10-21	209 8-12-25	244 10-14-28	314 12-19-31	383 15-23-35	452 18-27-38	
Round		A4	157 6-9-19	174 7-10-21	209 8-12-25	244 10-14-28	314 12-19-31	383 15-23-35	452 18-27-38
			cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw	cfm Throw


- All pressures are in inches of water.
- Throw velocities given are for isothermal terminal velocities of 150, 100 and 50 fpm. See the section, Engineering Guidelines for additional information.
- NC values based on Octave Band 2 to 7 sound power levels minus a room absorption of 10 dB.
- Dash (-) in space denotes an NC value less than 10.
- Data obtained from tests conducted in accordance with ANSI/ASHRAE Standard 70-2006.
- Throw values given are for isothermal conditions.

For Performance Notes, please refer to page F166.

- | | | | |
|---------------------------------------|------------------|----------------|---------------------|
| <input type="checkbox"/> 350FL | • 35° Deflection | • Long Blades | • ¾" Blades Spacing |
| <input type="checkbox"/> 350FS | • 35° Deflection | • Short Blades | • ¾" Blades Spacing |

Louvered Return Grilles • Aluminum

- ☐
- Border Type 1 (Surface Mount)



Available Sizes (D" x D")


Border Type 1 is available in sizes 6" x 4" through 48" x 48" in 2" increments in one piece construction. Odd and fractional sizes are available at additional cost. Sizes larger than 48" x 48" are shipped in multiple sections with joining strips for field assembly.

Note: Wall or duct opening should be duct size $\pm 1/8"$. All dimensions are in inches.

Fastenings

- ☐
- Type A • External Screw

- ☐
- Type C • Concealed Screw




Type A & C available with Border Type 1 only. Type C available with damper

Mounting Frames

- ☐
- PF • Steel Plaster Frame

- ☐
- PFA • Aluminum Plaster Frame



Surface Mounted Example

Recessed Mounted Example

Note: Wall opening should be listed duct size $+ 1/8"$ to listed duct size $+ 1/4"$.

Accessories (Optional) Check ☒ if provided.

- | | |
|-------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| <input type="checkbox"/> Neck mounted opposed blade damper (galvanized steel) | <input type="checkbox"/> IS • Insect Screen ($1/16"$ square mesh – galvanized steel) |
| <input type="checkbox"/> EQT • Earthquake Tabs | <input type="checkbox"/> DS • Debris Screen ($1/4"$ square mesh – galvanized steel) |
| <input type="checkbox"/> Other: _____ | |

Standard Finish: #26 White


☐ Other Finish: _____

General Description

- Available with louvers vertical or horizontal.
- #8 x $1 \frac{1}{4}"$ lg. Phillips flat head sheet metal screws painted white.
- Optional opposed blade damper has screwdriver adjustment accessible through face of grille.
- Insect screen & debris screen are not available with damper option
- Material is Aluminum.
- All dimensions are $\pm 1/16"$.


Optional Border Types Available

☐ Border Type 2 (Snap-in)
Panel Mounted




Available in 24" x 24" modules with neck sizes up to 20" x 20".

☐ Border Type 3 (Lay-in)
Panel Mounted




Available in all standard module sizes with neck sizes up to module size minus 2".

☐ Border Type 4 (Spline)
Panel Mounted



Available in 24" x 24" modules with neck sizes up to 20" x 20".
Splines on 2 opposite sides only

☐ Border Type NT (Narrow Tee)



NT Border is available in module sizes 24" x 12" & 24" x 24" only.

Border Type 2, 3, 4, NT

• Accessories & Options

Check ☒ if provided.

☐ AG-15 • Neck mounted opposed blade damper (galvanized steel)

☐ IS • Insect Screen (1/16" square mesh – galvanized steel)

☐ DS • Debris Screen (1/4" square mesh – galvanized steel)

☐ EQT • Earthquake tabs


☐ Other: _____

Standard Finish: #26 White

☐ Optional finish: _____


Louvered Return Filter Grilles • Aluminum • 3/4" Blade Spacing

Models: 350FLF1 • 35° Fixed Deflection • Long Blades • 1" Filter Frame
 350FSF1 • 35° Fixed Deflection • Short Blades • 1" Filter Frame
 350FLF2 • 35° Fixed Deflection • Long Blades • 2" Filter Frame
 350FSF2 • 35° Fixed Deflection • Short Blades • 2" Filter Frame



Face View:

Border Type 1 (Surface Mount) & Border Type 3 (Lay-in T-Bar)



Side Cross-Sectional View:

Border Type 1 (Surface Mount) & Border Type 3 (Lay-in T-Bar)

Hinge Location Options:


- ☐ Hinged Top
- ☐ Hinged Left
- ☐ Hinged Right
- ☐ Hinged Bottom
- ☐ No Hinge

Finish Options:

- Standard Finish: #26 White
- ☐ Other Finish: _____

Fastening Options:

- ☐ Quarter-Turn Fastener (standard)
- ☐ Knurled Knob (optional)



Available Sizes: 10" x 8" to 48" x 36" in one-inch increments. Fractional and oversize filter grilles are not available.
 Maximum size for border type 3 is module size minus 4".

All dimensions are in inches.

General Description

- Series 350 filter grilles feature louvers spaced 3/4" apart.
- Blade deflection angle is 35°.
- All dimensions are ± 1/16".
- 350 models are available in common filter sizes. 1" thick filters may be purchased from hardware stores for the most common sizes.
- Quarter turn fasteners are standard to make filter access easy.
- Filters by others
- Knurled knob fastener available as option
- Dimensions are the same for border type 1 (surface mount) and border type 3 (lay-in T-bar)

PERFORMANCE DATA

300/350 Grilles

350R, 350F AND 350R-SS

PERFORMANCE BASED ON NOMINAL SIZES SHOWN IN BOLD.

NC-20													NC-30	
Nominal Duct Size (in.)	Nominal Duct Area (ft ²)	Core Area (ft ²)	Core Velocity Velocity Pressure Neg. Static Pressure	100 0.001 0.002	200 0.002 0.008	300 0.006 0.018	400 0.010 0.032	500 0.016 0.051	600 0.022 0.073	700 0.031 0.099	800 0.040 0.130	900 0.050 0.164		
6x6	0.25	0.19	Airflow, cfm NC	19 -	38 -	57 -	76 -	95 -	114 13	133 19	152 25	171 29		
8x6	0.33	0.26	Airflow, cfm NC	26 -	52 -	78 -	104 -	130 -	156 15	182 20	208 26	234 30		
10x6	0.42	0.34	Airflow, cfm NC	34 -	68 -	102 -	136 -	170 -	204 16	238 21	272 28	306 32		
8x8	0.44	0.37	Airflow, cfm NC	37 -	74 -	111 -	148 -	185 -	222 16	259 22	296 28	333 32		
12x6	0.5	0.41	Airflow, cfm NC	41 -	82 -	123 -	164 -	205 -	246 17	287 22	328 30	369 34		
14x6	0.58	0.48	Airflow, cfm NC	48 -	96 -	144 -	192 -	240 -	288 18	336 24	384 30	432 34		
16x6			Airflow, cfm NC	57 -	114 -	171 -	228 -	285 10	342 19	399 25	456 30	513 35		
12x8	0.67	0.57	Airflow, cfm NC	59 -	118 -	177 -	236 -	295 10	354 19	413 25	472 31	531 35		
10x10	0.69	0.59	Airflow, cfm NC	63 -	126 -	189 -	252 -	315 10	378 19	441 25	504 32	567 35		
18x6	0.75	0.63	Airflow, cfm NC	72 -	144 -	216 -	288 -	360 11	432 19	504 25	576 30	648 35		
20x6			Airflow, cfm NC	77 -	154 -	231 -	308 -	385 11	462 19	539 25	616 30	693 35		
22x6	0.92	0.77	Airflow, cfm NC	88 -	176 -	264 -	352 -	440 11	528 19	616 25	704 30	792 35		
24x6			Airflow, cfm NC	111 -	222 -	333 -	444 -	555 12	666 20	777 26	888 32	999 35		
18x10	1.25	1.11	Airflow, cfm NC	122 -	244 -	366 -	488 -	610 12	732 20	854 27	976 32	1098 35		
14x14	1.36	1.22	Airflow, cfm NC	135 -	270 -	405 -	540 -	675 13	810 20	945 27	1080 32	1215 35		
36x6			Airflow, cfm NC	137 -	274 -	411 -	548 -	685 13	822 20	959 27	1096 32	1233 36		
22x10	1.53	1.37	Airflow, cfm NC	149 -	298 -	447 -	596 -	745 14	894 21	1043 27	1192 33	1341 37		
30x8			Airflow, cfm NC	159 -	318 -	477 -	636 -	795 14	954 21	1113 27	1272 33	1431 37		
24x10	1.67	1.49	Airflow, cfm NC	162 -	324 -	486 -	648 -	810 14	972 21	1134 27	1296 33	1458 37		
42x6			Airflow, cfm NC	182 -	364 -	546 -	728 -	910 14	1092 21	1274 28	1456 33	1638 38		
18x14	1.75	1.59	Airflow, cfm NC	207 -	414 -	621 -	828 -	1035 14	1242 21	1449 28	1656 33	1863 38		
16x16	1.78	1.62	Airflow, cfm NC	214 -	428 -	642 -	856 -	1070 14	1284 22	1498 28	1712 33	1926 38		
24x12	2	1.82	Airflow, cfm NC	229 -	458 -	687 -	916 -	1145 15	1374 22	1603 28	1832 33	2061 38		
18x18	2.25	2.07	Airflow, cfm NC	246 -	492 -	738 -	984 -	1230 15	1476 22	1722 29	1968 34	2214 39		
24x14	2.33	2.14	Airflow, cfm NC	257 -	514 -	771 -	1028 -	1285 16	1542 23	1799 29	2056 34	2313 39		
30x12	2.5	2.29	Airflow, cfm NC	275 -	550 -	825 -	1100 -	1375 16	1650 23	1925 29	2200 34	2475 39		
24x16	2.67	2.46	Airflow, cfm NC	311 -	622 -	933 -	1244 -	1555 17	1866 24	2177 30	2488 35	2799 40		
20x20	2.78	2.57	Airflow, cfm NC	314 -	628 -	942 -	1256 -	1570 17	1884 24	2198 30	2512 35	2826 40		
36x12	3	2.75	Airflow, cfm NC	322 -	644 -	966 -	1288 -	1610 17	1932 24	2254 30	2576 36	2898 40		
24x22	3.67	3.43	Airflow, cfm NC	343 -	686 -	1029 -	1372 -	1715 17	2058 24	2401 30	2744 36	3087 40		
30x18	3.75	3.5	Airflow, cfm NC	350 -	700 -	1050 -	1400 -	1750 17	2100 24	2450 30	2800 36	3150 40		

• Static pressures are negative, in inches of water, measured per ANSI/ASHRAE Standard 70-2006.

• NC based on room absorption of 10 dB, re 10⁻¹² watts, measured per ANSI/ASHRAE Standard 70-2006.

**Department of
Veterans Affairs**

Memorandum

Date: JAN 4 2012

From: Assistant Deputy Under Secretary for Health for Clinical Operations (10NC)

Subj: Interim Guidance for Ventilation Requirements in Sterile Processing Service (SPS)

To: VISN Directors, VISN CMOs, VISN QMOs, VISN Nurse Executives,
VISN Sterile Processing Boards

1. This memorandum extends interim guidance for ventilation requirements in Sterile Processing Services pending the release of a formal directive.

2. The following are the minimum number of air exchanges per hour (ACH) based on the functional area and the Design Temperature for existing buildings:

- a. Soiled / decontamination
 - i. Airflow = Negative (in)
 - ii. Minimum ACH = 6 (Temp 72-78 F)
 - iii. Relative Humidity Range = 20% to 60%
- b. Sterilizer Equipment Access Room
 - i. Airflow = Negative (in)
 - ii. Minimum ACH = 10 (Temp N/R)
 - iii. Relative Humidity Range = N/R
- c. Restrooms / Housekeeping
 - i. Airflow = Negative (in)
 - ii. Minimum ACH = 10 (Temp N/R)
 - iii. Relative Humidity Range = N/R
- d. Preparation, Assembly, Sterilization Area
 - i. Airflow = Positive (out)
 - ii. Minimum ACH = 4 (72 – 78 F)
 - iii. Relative Humidity Range = 20% to 60%
- e. Clean / Sterile Storage
 - i. Airflow = Positive (out)
 - ii. Minimum ACH = 4 (Temp 72 – 78F)
 - iii. Relative Humidity Range = 20% to 60%

3. The following are the minimum number of air exchanges per hour (ACH) based on the functional area and the Design Temperature for new construction and renovations involving replacement of HVAC systems:

- a. Soiled / decontamination
 - a. Airflow = Negative (in)
 - b. Minimum ACH = 6 (Temp 72 +/- 1F)
 - c. Relative Humidity Range = 20% to 60%

Interim Guidance for Ventilation Requirements in Sterile Processing Service (SPS)

- b. Sterilizer Equipment Access Room
 - i. Airflow = Negative (in)
 - ii. Minimum ACH = 10 (Temp N/R)
 - iii. Relative Humidity Range = N/R
- c. Restrooms / Housekeeping
 - i. Airflow = Negative (in)
 - ii. Minimum ACH = 10 (Temp N/R)
 - iii. Relative Humidity Range = N/R
- d. Preparation, Assembly, Sterilization Area
 - i. Airflow = Positive (out)
 - ii. Minimum ACH = 4 (72 +/- 1F)
 - iii. Relative Humidity Range = 20% to 60%
- e. Clean / Sterile Storage
 - i. Airflow = Positive (out)
 - ii. Minimum ACH = 4 (Temp 72 +/- 1F)
 - iii. Relative Humidity Range = 20% to 60%

4. Effective immediately all references in VA Handbook 7176 dealing with ventilation are superseded.

5. All new construction and HVAC renovations should comply with the design parameters identified above which meet or exceed those set forth in ANSI/ ASHRAE/ ASHE Standard 170 – 2008 or the current version, Ventilation of Health Care Facilities and should comply with the VA SPS Design Guide.

6. This memorandum remains in effect until December 31, 2012, or until the appropriate directive is published, whichever comes first.

7. Point of contact for questions is Tommy Stewart, Acting Director, National Program Office for Sterile Processing, at (202) 461-7139 or Tommy.Stewart@va.gov.



George W. Arana, MD

Table 7-1 CLIMATIC CONDITIONS

Table 7-1 CLIMATIC CONDITIONS																
Location	Weather Station	North Latitude	MSL Elevation	Temperatures										Annual Extreme Daily-Mean Db		
				Col. 1a 0.4%		Col. 1b 99.6%		Col. 2a 1%		Col. 2b 99%		Col. 3 Wet Bulb				
				Summer		Winter		Summer		Winter		0.4%			1%	
				Db	Wb	Db	Wb	Db	Wb	Db	Wb	Maximum	Minimum			
Oklahoma City	Oklahoma City Will Rogers World AP	35.39	1306	99.5	74.1	11.4		96.8	74.1	17.4		77.7	102.7	6.1		
OREGON																
Portland	Portland Intl AP	45.59	108	91.2	67.5	23.9		87.1	66.5	28.6		69.4	99.0	20.5		
Roseburg*	Roseburg AP	43	505	93	69	18		90	67	18		-	-	-		
White City	Medford Rogue Valley Intl AP	42.39	1329	98.6	67.2	22.9		95.3	65.9	25.7		69.0	104.2	18.1		
PENNSYLVANIA																
Altoona	Altoona Blair Co AP	40.30	1470	88.5	72.0	4.7		85.7	70.7	9.6		74.7	92.5	-2.6		
Butler*	Butler Co (AWOS)	40.78	1247	88.0	72.4	3.1		84.4	70.6	8.9		74.6	91.1	-2.3		
Coatesville*	New Castle	41	825	91	75	2		88	74	2		-	-	-		
Erie	Erie Intl AP	42.08	738	86.4	72.9	5.2		84.0	71.6	9.7		75.3	91.5	-0.5		
Lebanon	Harrisburg Capital City AP	40.22	348	92.4	73.8	8.7		89.6	72.5	13.3		76.5	96.3	1.6		
Philadelphia	Philadelphia Intl AP	39.87	30	93.2	75.4	12.6		90.6	74.5	16.9		78.3	97.0	6.6		
Pittsburgh	Pittsburgh Intl AP	40.50	1204	89.5	72.5	3.7		86.6	71.1	9.4		75.2	92.4	-3.0		
Wilkes-Barre	Wilkes-Barre Scranton Intl AP	41.34	961	88.9	72.1	3.5		86.0	70.6	8.3		75.0	93.0	-2.7		
PUERTO RICO																
San Juan	San Juan Intl AP	18.42	62	91.4	77.4	69.1		89.6	77.8	70.2		80.6	93.9	66.8		

SPD CLEAN - ROOM DATA SHEET														
ROOM NAME	INDOOR TEMPERATURE				INDOOR RELATIVE HUMIDITY		MIN TOTAL ACH	MIN OA ACH	ROOM AIR	MAX NOISE LEVEL NC	ROOM AIR BALANCE	INDIVIDUAL ROOM CONTROL		
									RETURN			TEMP	FLOW	
	COOLING	HEATING	% RH MAX	% RH MIN	EXHAUST (G) EXHAUST (S)									
	F	C	F	C										
Non Sterile Storage	72	22	72	22	60	20	4	4	Exhaust (G)	40	(+)	Yes	CV	
Note 1 - None														
PPE	72	22	72	22	60	20	10	10	Exhaust (G)	40	(+)	Yes	CV	
Note 1- Room Air Balance														
Provide a dedicated terminal unit to serve Clean Lockers - Men and Women. Provide transfer air, as required, from Sterile/Non Sterile Storage. The space air shall infiltrate to the Clean Toilet/Showers - Men and Women.														
Preparation, Assembly, and Sterilization Area	72	22	72	22	60	20	4	4	Exhaust (G)	40	(+ +)	Yes	CV	
Note 1 - Room Air Changes per Hour														
Minimum (total and outdoor) air changes specified for this room are based on ASHRAE Standard 170 - 2008. Actual air changes may vary based on the transfers air requirements of the adjoining spaces (ETO Sterilizer Room and Decontamination Area), cooling load to meet the space temperature, and transfer air to the clean storage spaces to maintain positive air balance.														
Note 2 - Room Air Balance														
Provide simple devices, such as, ball-in-tube or flutter strips to show the airflow direction. Device shall be installed between Preparation, Assembly, and Sterilization Area and the Sterile/Non Sterile Storage Area. Provide airflow control valves in the exhaust air ducts to measure and monitor the design air balance.														
Receiving & Breakout	72	22	72	22	60	20	6	6	Exhaust (G)	40	(+)	Yes	CV	
Note 1 - None														

SPD CLEAN - ROOM DATA SHEET														
ROOM NAME	INDOOR TEMPERATURE				INDOOR RELATIVE HUMIDITY		MIN TOTAL ACH	MIN OA ACH	ROOM AIR	MAX NOISE LEVEL NC	ROOM AIR BALANCE	INDIVIDUAL ROOM CONTROL		
	COOLING		HEATING		% RH MAX	% RH MIN			RETURN EXHAUST (G) EXHAUST (S)			TEMP	FLOW	
	F	C	F	C										
Satellite SPD Storage	NA	NA	NA	NA	NA	NA	4	2	Return	40	(+)	No	CV	
Note 1- Ventilation Air Requirement Do not provide 100% outdoor air to, or 100% exhaust from, the SPD Storage Room and Warehouses remotely located from the Central SPD Department. Note 2 - Individual Room Temperature Control Not required for rooms of 80 to 100 sf [8 to 10 m ²]. Required for larger rooms with intermittent occupancy. Note 3 - Return Air Pick-Up Return air from rooms under 100 sf [10 m ²] is optional. Note 4 - Room Air Balance Provide supply air from an adjoining air terminal unit.														
Scope Storage Room	NA	NA	NA	NA	NA	NA	4	4	NA	40	(+)	No	CV	
Note 1 - Room Air Balance Allow room air to ex-filtrate into the Endoscope Processing/High Level Decontamination Room. Maintain Endoscope Processing/High Level Decontamination Room under negative air balance and the Scope Storage Room under positive air balance.														
Staff Breakroom/Conference	75	24	70	21	60	20	6	4	Exhaust (G)	35	(o)	Yes	CV	
Note - None														
Sterile Storage	72	22	72	22	60	20	4	4	Exhaust (G)	40	(+)	Yes	CV	
Note 1 - None														

Improve Emergency Cache - 19

Location	Lebanon, PA
Building owner	
Program user	Miller-Remick LLC
Company	Miller-Remick LLC
Comments	
By	Miller-Remick
Dataset name	C:\Users\mprzybylski\Documents\TRACE 700 Projects\BLDG 19.TRC
Calculation time	05:48 PM on 01/21/2013
TRACE® 700 version	6.2.9
Location	Harrisburg, Pennsylvania
Latitude	40.0 deg
Longitude	76.0 deg
Time Zone	5
Elevation	335 ft
Barometric pressure	29.5 in. Hg
Air density	0.0751 lb/cu ft
Air specific heat	0.2444 Btu/lb·°F
Density-specific heat product	1.1011 Btu/h·cfm·°F
Latent heat factor	4,846.9 Btu·min/h·cu ft
Enthalpy factor	4.5046 lb·min/hr·cu ft
Summer design dry bulb	92 °F
Summer design wet bulb	77 °F
Winter design dry bulb	0 °F
Summer clearness number	1.00
Winter clearness number	1.00
Summer ground reflectance	0.20
Winter ground reflectance	0.20
Carbon Dioxide Level	400 ppm
Design simulation period	January - December
Cooling load methodology	RTS (ASHRAE Tables)
Heating load methodology	UATD



Room Checksums

By Miller-Remick

Elevator Machine Room

COOLING COIL PEAK					CLG SPACE PEAK					HEATING COIL PEAK					TEMPERATURES		
Peaked at Time: Mo/Hr: 7 / 4					Mo/Hr: 7 / 4					Mo/Hr: Heating Design							
Outside Air: OADB/WB/HR: 74 / 68 / 92					OADB: 74					OADB: 0							
Space Sens. + Lat.	Plenum Sens. + Lat.	Net Total	Percent Of Total		Space Sensible	Percent Of Total				Space Peak	Coil Peak	Percent					
Btu/h	Btu/h	Btu/h	(%)		Btu/h	(%)				Space Sens	Tot Sens	Of Total	(%)				
Envelope Loads					Envelope Loads					Envelope Loads							
Skylite Solar	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00	SADB	Cooling	Heating
Skylite Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00	Ra Plenum	75.1	69.8
Roof Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00	Return	75.1	69.8
Glass Solar	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00	Ret/OA	75.1	69.8
Glass/Door Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00	Fn MtrTD	0.0	0.0
Wall Cond	254	126	380	1	254	1	0	0	0	-751	-1,126	100.00	0	0.00	Fn BldTD	0.0	0.0
Partition/Door	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00	Fn Frict	0.0	0.0
Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Adjacent Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Infiltration	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Sub Total ==>	254	126	380	1	254	1	0	0	0	-751	-1,126	100.00	0	0.00			
Internal Loads					Internal Loads					Internal Loads							
Lights	300	75	375	1	300	1	0	0	0	0	0	0.00	0	0.00			
People	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Misc	30,000	0	30,000	98	30,000	98	0	0	0	0	0	0.00	0	0.00			
Sub Total ==>	30,300	75	30,375	99	30,300	99	0	0	0	0	0	0.00	0	0.00			
Ceiling Load					Ceiling Load					Ceiling Load							
Ventilation Load	0	0	0	0	0	0	0	0	0	-8	0	0.00	0	0.00			
Adj Air Trans Heat	0	0	0	0	0	0	0	0	0	0	0	0	0	0			
Dehumid. Ov Sizing			0	0			0	0		0	0	0.00	0	0.00			
Ov/Undr Sizing	0		0	0	0		0	0		0	0	0.00	0	0.00			
Exhaust Heat		0	0	0			0	0		0	0	0.00	0	0.00			
Sup. Fan Heat			0	0			0	0		0	0	0.00	0	0.00			
Ret. Fan Heat		0	0	0			0	0		0	0	0.00	0	0.00			
Duct Heat Pkup		0	0	0			0	0		0	0	0.00	0	0.00			
Underflr Sup Ht Pkup			0	0			0	0		0	0	0.00	0	0.00			
Supply Air Leakage		0	0	0			0	0		0	0	0.00	0	0.00			
Grand Total ==>	30,559	197	30,756	100.00	30,559	100.00	0	0	0	-760	-1,126	100.00	0	0.00			

TEMPERATURES		
	Cooling	Heating
SADB	55.0	70.5
Ra Plenum	75.1	69.8
Return	75.1	69.8
Ret/OA	75.1	69.8
Fn MtrTD	0.0	0.0
Fn BldTD	0.0	0.0
Fn Frict	0.0	0.0

AIRFLOWS		
	Cooling	Heating
Diffuser	1,388	1,388
Terminal	1,388	1,388
Main Fan	1,388	1,388
Sec Fan	0	0
Nom Vent	0	0
AHU Vent	0	0
Infil	0	0
MinStop/Rh	0	0
Return	1,388	1,388
Exhaust	0	0
Rm Exh	0	0
Auxiliary	0	0
Leakage Dwn	0	0
Leakage Ups	0	0

ENGINEERING CKS		
	Cooling	Heating
% OA	0.0	0.0
cfm/ft²	12.62	12.62
cfm/ton	541.42	
ft²/ton	42.92	
Btu/hr-ft²	279.60	-10.23
No. People	0	

COOLING COIL SELECTION										AREAS			HEATING COIL SELECTION				
Total Capacity	Sens Cap.	Coil Airflow	Enter DB/WB/HR		Leave DB/WB/HR					Gross Total	Glass		Capacity	Coil Airflow	Ent	Lvg	
ton	MBh	MBh	cfm	°F °F	gr/lb	°F °F	gr/lb				ft²	(%)	MBh	cfm	°F	°F	
Main Clg	2.6	30.8	30.8	1,388	75.1 56.9	41.0	55.0 48.5	40.7		Floor	110		Main Htg	-1.1	1,388	69.8	70.5
Aux Clg	0.0	0.0	0.0	0	0.0 0.0	0.0	0.0 0.0	0.0		Part	0		Aux Htg	0.0	0	0.0	0.0
Opt Vent	0.0	0.0	0.0	0	0.0 0.0	0.0	0.0 0.0	0.0		Int Door	0		Preheat	0.0	0	0.0	0.0
										ExFlr	0						
										Roof	0	0	Humidif	0.0	0	0.0	0.0
										Wall	233	0	Opt Vent	0.0	0	0.0	0.0
										Ext Door	0	0	Total	-1.1			
Total	2.6	30.8															

Room Checksums

By Miller-Remick

Mechanical Room

COOLING COIL PEAK					CLG SPACE PEAK			HEATING COIL PEAK				TEMPERATURES		
Peaked at Time: Mo/Hr: 7 / 14					Mo/Hr: 7 / 15			Mo/Hr: Heating Design				Cooling Heating		
Outside Air: OADB/WB/HR: 92 / 77 / 115					OADB: 92			OADB: 0				SADB	55.0	72.0
												Ra Plenum	73.0	72.0
												Return	73.0	72.0
												Ret/OA	78.8	50.0
												Fn MtrTD	0.0	0.0
												Fn BldTD	0.0	0.0
												Fn Frict	0.0	0.0
												</		

Room Checksums

By Miller-Remick

Storage 1 (Clean)

COOLING COIL PEAK					CLG SPACE PEAK			HEATING COIL PEAK				TEMPERATURES		
Peaked at Time: Mo/Hr: 7 / 16					Mo/Hr: 7 / 18			Mo/Hr: Heating Design				Cooling Heating		
Outside Air: OADB/WB/HR: 92 / 76 / 109					OADB: 89			OADB: 0				SADB	55.0	76.4
Space Sens. + Lat.	Plenum Sens. + Lat.	Net Total	Percent Of Total		Space Sensible	Percent Of Total		Space Peak	Coil Peak	Percent		Ra Plenum	79.2	64.2
Btu/h	Btu/h	Btu/h	(%)		Btu/h	(%)		Space Sens	Tot Sens	Of Total		Return	72.0	72.0
Btu/h	Btu/h	Btu/h	(%)		Btu/h	(%)		Btu/h	Btu/h	(%)		Ret/OA	76.0	57.6
Envelope Loads					Envelope Loads			Envelope Loads				Fn MtrTD	0.0	0.0
Skylite Solar	0	0	0	0	0	0	0	0	0	0.00	0	Fn BldTD	0.0	0.0
Skylite Cond	0	0	0	0	0	0	0	0	0	0.00	0	Fn Frict	0.0	0.0
Roof Cond	0	1,369	1,369	2	0	0	0	0	-1,794	2.74	0	AIRFLOWS		
Glass Solar	4,763	0	4,763	8	7,131	21	0	0	0	0.00	0	Cooling Heating		
Glass/Door Cond	1,121	0	1,121	2	915	3	0	-4,677	-4,677	7.15	0	Diffuser	1,833	1,833
Wall Cond	456	212	668	1	454	1	0	-1,505	-2,434	3.72	0	Terminal	1,833	1,833
Partition/Door	0	0	0	0	0	0	0	0	0	0.00	0	Main Fan	1,833	1,833
Floor	0	0	0	0	0	0	0	0	0	0.00	0	Sec Fan	0	0
Adjacent Floor	0	0	0	0	0	0	0	0	0	0.00	0	Nom Vent	367	367
Infiltration	0	0	0	0	0	0	0	0	0	0.00	0	AHU Vent	367	367
Sub Total ==>	6,340	1,580	7,920	14	8,500	25	0	-6,182	-8,905	13.61	0	Infil	0	0
Internal Loads					Internal Loads			Internal Loads				MinStop/Rh	1,833	1,833
Lights	3,304	826	4,130	7	3,304	10	0	0	0	0.00	0	Return	1,833	1,833
People	3,025	0	3,025	5	1,513	4	0	0	0	0.00	0	Exhaust	367	367
Misc	1,877	0	1,877	3	1,877	5	0	0	0	0.00	0	Rm Exh	0	0
Sub Total ==>	8,206	826	9,032	16	6,693	20	0	0	0	0.00	0	Auxiliary	0	0
Ceiling Load					Ceiling Load			Ceiling Load				Leakage Dwn	0	0
Ventilation Load	0	-2,498	0	0	2,772	8	0	-2,704	0	0.00	0	Leakage Ups	0	0
Adj Air Trans Heat	0	0	20,662	37	0	0	0	0	-29,069	44.44	0	ENGINEERING CKS		
Dehumid. Ov Sizing	0	0	0	0	0	0	0	0	0	0.00	0	Cooling Heating		
Ov/Undr Sizing	18,786	0	18,786	33	16,352	48	0	0	0	0.00	0	% OA	20.0	20.0
Exhaust Heat	0	0	0	0	0	0	0	0	0	0.00	0	cfm/ft²	1.67	1.67
Sup. Fan Heat	0	0	0	0	0	0	0	0	-27,454	41.97	0	cfm/ton	390.07	
Ret. Fan Heat	0	0	0	0	0	0	0	0	0	0.00	0	ft²/ton	234.04	
Duct Heat Pkup	0	0	0	0	0	0	0	0	0	-0.03	0	Btu/hr-ft²	51.27	-59.46
Underflr Sup Ht Pkup	0	0	0	0	0	0	0	0	0	0.00	0	No. People	6	
Supply Air Leakage	0	0	0	0	0	0	0	0	0	0.00	0			
Grand Total ==>	35,830	-92	56,400	100.00	34,317	100.00	0	-8,886	-65,409	100.00	0			

COOLING COIL SELECTION										AREAS			HEATING COIL SELECTION				
Total Capacity	Sens Cap.	Coil Airflow	Enter DB/WB/HR	Leave DB/WB/HR						Gross Total	Glass		CapacityCoil Airflow	Ent	Lvg		
ton MBh	MBh	cfm	°F °F gr/lb	°F °F gr/lb							ft² (%)		MBh cfm	°F	°F		
Main Clg	4.7	56.4	42.3	1,833	76.0	63.6	69.3	55.0	53.2	58.3			Main Htg	-43.2	1,833	55.0	76.4
Aux Clg	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0			Aux Htg	0.0	0	0.0	0.0
Opt Vent	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0			Preheat	-22.2	367	0.0	55.0
													Reheat	-34.3	1,833	55.0	72.0
Total	4.7	56.4											Humidif	0.0	0	0.0	0.0
													Opt Vent	0.0	0	0.0	0.0
													Total	-65.4			

Room Checksums

By Miller-Remick

Storage 2 (Sterile)

COOLING COIL PEAK					CLG SPACE PEAK					HEATING COIL PEAK					TEMPERATURES		
Peaked at Time: Mo/Hr: 7 / 15					Mo/Hr: 7 / 18					Mo/Hr: Heating Design					Cooling Heating		
Outside Air: OADB/WB/HR: 92 / 76 / 114					OADB: 89					OADB: 0					SADB	55.0	75.1
Space Sens. + Lat.	Plenum Sens. + Lat.	Net Total	Percent Of Total		Space Sensible	Percent Of Total				Space Peak	Coil Peak	Percent			Ra Plenum	78.6	64.2
Btu/h	Btu/h	Btu/h	(%)		Btu/h	(%)				Space Sens	Tot Sens	Of Total			Return	72.0	72.0
										Btu/h	Btu/h	(%)			Ret/OA	76.1	57.6
Envelope Loads					Envelope Loads					Envelope Loads					Fn MtrTD	0.0	0.0
Skylite Solar	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00	Fn BldTD	0.0	0.0
Skylite Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00	Fn Frict	0.0	0.0
Roof Cond	0	1,166	1,166	2	0	0	0	0	0	0	-1,794	3.50	0	0.00			
Glass Solar	1,442	0	1,442	3	3,410	12	0	0	0	0	0	0.00	0	0.00			
Glass/Door Cond	551	0	551	1	437	2	0	0	0	-2,235	-2,235	4.35	0	0.00			
Wall Cond	191	97	287	1	188	1	0	0	0	-622	-1,022	1.99	0	0.00			
Partition/Door	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Adjacent Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Infiltration	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Sub Total ==>	2,183	1,263	3,446	7	4,035	14	0	0	0	-2,857	-5,051	9.84	0	0.00			
Internal Loads					Internal Loads					Internal Loads							
Lights	2,703	676	3,379	7	2,703	10	0	0	0	0	0	0.00	0	0.00			
People	2,475	0	2,475	5	1,238	4	0	0	0	0	0	0.00	0	0.00			
Misc	1,536	0	1,536	3	1,536	5	0	0	0	0	0	0.00	0	0.00			
Sub Total ==>	6,714	676	7,390	16	5,476	20	0	0	0	0	0	0.00	0	0.00			
Ceiling Load	1,870	-1,870	0	0	2,268	8	0	0	0	-2,213	0	0.00	0	0.00			
Ventilation Load	0	0	18,115	38	0	0	0	0	0	0	-23,784	46.35	0	0.00			
Adj Air Trans Heat	0	0	0	0	0	0	0	0	0	0	0	0	0	0.00			
Dehumid. Ov Sizing			0	0			0	0	0	0	0	0.00	0	0.00			
Ov/Undr Sizing	18,549		18,549	39	16,299	58	0	0	0	0	0	0.00	0	0.00			
Exhaust Heat		0	0	0			0	0	0	0	0	0.00	0	0.00			
Sup. Fan Heat		0	0	0			0	0	0	0	-22,462	43.77	0	0.00			
Ret. Fan Heat		0	0	0			0	0	0	0	0	0.00	0	0.00			
Duct Heat Pkup		0	0	0			0	0	0	0	-18	0.04	0	0.00			
Underflr Sup Ht Pkup		0	0	0			0	0	0	0	0	0.00	0	0.00			
Supply Air Leakage		0	0	0			0	0	0	0	0	0.00	0	0.00			
Grand Total ==>	29,315	69	47,500	100.00	28,078	100.00	0	0	0	-5,069	-51,315	100.00	0	0.00			

COOLING COIL SELECTION										AREAS			HEATING COIL SELECTION				
Total Capacity	Sens Cap.	Coil Airflow	Enter DB/WB/HR	Leave DB/WB/HR						Gross Total	Glass		Capacity	Coil Airflow	Ent	Lvg	
ton MBh	MBh	cfm	°F °F gr/lb	°F °F gr/lb							ft² (%)		MBh	cfm	°F	°F	
Main Clg	4.0	47.5	34.9	1,500	76.1	63.8	70.3	55.0	53.2	58.2			Main Htg	-33.2	1,500	55.0	75.1
Aux Clg	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0			Aux Htg	0.0	0	0.0	0.0
Opt Vent	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0			Preheat	-18.2	300	0.0	55.0
													Reheat	-28.1	1,500	55.0	72.0
Total	4.0	47.5											Humidif	0.0	0	0.0	0.0
													Opt Vent	0.0	0	0.0	0.0
													Total	-51.3			

Room Checksums

By Miller-Remick

Vending Room

COOLING COIL PEAK					CLG SPACE PEAK					HEATING COIL PEAK					TEMPERATURES		
Peaked at Time: Mo/Hr: 7 / 14					Mo/Hr: 7 / 15					Mo/Hr: Heating Design							
Outside Air: OADB/WB/HR: 92 / 77 / 115					OADB: 92					OADB: 0							
Space Sens. + Lat.	Plenum Sens. + Lat.	Net Total	Percent Of Total		Space Sensible	Percent Of Total				Space Peak	Coil Peak	Percent					
Btu/h	Btu/h	Btu/h	(%)		Btu/h	(%)				Space Sens	Tot Sens	Of Total	(%)				
Envelope Loads					Envelope Loads					Envelope Loads							
Skylite Solar	0	0	0	0	0	0	0	0	0	0	0	0	0.00	0			
Skylite Cond	0	0	0	0	0	0	0	0	0	0	0	0	0.00	0			
Roof Cond	0	0	0	0	0	0	0	0	0	0	0	0	0.00	0			
Glass Solar	0	0	0	0	0	0	0	0	0	0	0	0	0.00	0			
Glass/Door Cond	0	0	0	0	0	0	0	0	0	0	0	0	0.00	0			
Wall Cond	0	0	0	0	0	0	0	0	0	0	0	0	0.00	0			
Partition/Door	0	0	0	0	0	0	0	0	0	0	0	0	0.00	0			
Floor	0	0	0	0	0	0	0	0	0	0	0	0	0.00	0			
Adjacent Floor	0	0	0	0	0	0	0	0	0	0	0	0	0.00	0			
Infiltration	0	0	0	0	0	0	0	0	0	0	0	0	0.00	0			
Sub Total ==>	0	0	0	0	0	0	0	0	0	0	0	0	0.00	0			
Internal Loads					Internal Loads					Internal Loads							
Lights	314	79	393	7	314	7	0	0	0	0	0	0	0.00	0			
People	259	0	259	5	144	3	0	0	0	0	0	0	0.00	0			
Misc	4,215	0	4,215	76	4,215	90	0	0	0	0	0	0	0.00	0			
Sub Total ==>	4,788	79	4,866	88	4,673	100	0	0	0	0	0	0	0.00	0			
Ceiling Load	11	-11	0	0	11	0	0	0	0	0	0	0	0.00	0			
Ventilation Load	0	0	682	12	0	0	0	0	0	0	-886	100.01	0	0			
Adj Air Trans Heat	0		0	0	0	0	0	0	0	0	0	0	0	0			
Dehumid. Ov Sizing			0	0			0	0	0	0	0	-0.01	0	0			
Ov/Undr Sizing	0		0	0	0	0	0	0	0	0	0	0.00	0	0			
Exhaust Heat		-4	-4	0			0	0	0	0	0	0.00	0	0			
Sup. Fan Heat			0	0			0	0	0	0	0	0.00	0	0			
Ret. Fan Heat		0	0	0			0	0	0	0	0	0.00	0	0			
Duct Heat Pkup		0	0	0			0	0	0	0	0	0.00	0	0			
Underflr Sup Ht Pkup			0	0			0	0	0	0	0	0.00	0	0			
Supply Air Leakage		0	0	0			0	0	0	0	0	0.00	0	0			
Grand Total ==>	4,798	64	5,545	100.00	4,683	100.00	0	0	0	0	-886	100.00	0	0			

	Cooling	Heating
SADB	55.0	70.0
Ra Plenum	75.3	70.0
Return	75.3	70.0
Ret/OA	76.2	66.2
Fn MtrTD	0.0	0.0
Fn BldTD	0.0	0.0
Fn Frict	0.0	0.0

AIRFLOWS		
	Cooling	Heating
Diffuser	213	213
Terminal	213	213
Main Fan	213	213
Sec Fan	0	0
Nom Vent	12	12
AHU Vent	12	12
Infil	0	0
MinStop/Rh	0	0
Return	213	213
Exhaust	12	12
Rm Exh	0	0
Auxiliary	0	0
Leakage Dwn	0	0
Leakage Ups	0	0

ENGINEERING CKS		
	Cooling	Heating
% OA	5.4	5.4
cfm/ft²	1.85	1.85
cfm/ton	460.25	
ft²/ton	248.88	
Btu/hr-ft²	48.22	-7.71
No. People	1	

COOLING COIL SELECTION										AREAS			HEATING COIL SELECTION				
Total Capacity	Sens Cap.	Coil Airflow	Enter DB/WB/HR		Leave DB/WB/HR					Gross Total	Glass		Capacity	Coil Airflow	Ent	Lvg	
ton	MBh	MBh	°F	°F	°F	°F	gr/lb	°F	°F	gr/lb	ft²	(%)	MBh	cfm	°F	°F	
Main Clg	0.5	5.5	5.0	213	76.2	61.6	59.6	55.0	52.5	55.6	Floor	115	-0.9	213	66.2	70.0	
Aux Clg	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0	Part	0	0.0	0	0.0	0.0	
Opt Vent	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0	Int Door	0	0.0	0	0.0	0.0	
											ExFlr	0					
											Roof	0	0	0			
											Wall	0	0	0			
											Ext Door	0	0	0			
Total	0.5	5.5											Total	-0.9			

PROJECT INFORMATION

Location
Building owner
Program user
Company
Comments

By
Dataset name

Miller-Remick
C:\Users\mprzybylski\Documents\TRACE 700
Projects\BLDG22.TRC

Calculation time
TRACE® 700 version

06:08 PM on 01/21/2013
6.2.9

Location
Latitude
Longitude
Time Zone
Elevation
Barometric pressure

Harrisburg, Pennsylvania
40.0 deg
76.0 deg
5
335 ft
29.5 in. Hg

Air density
Air specific heat
Density-specific heat product
Latent heat factor
Enthalpy factor

0.0751 lb/cu ft
0.2444 Btu/lb·°F
1.1011 Btu/h·cfm·°F
4,846.9 Btu·min/h·cu ft
4.5046 lb·min/hr·cu ft

Summer design dry bulb
Summer design wet bulb
Winter design dry bulb
Summer clearness number
Winter clearness number
Summer ground reflectance
Winter ground reflectance
Carbon Dioxide Level

92 °F
77 °F
0 °F
1.00
1.00
0.20
0.20
400 ppm

Design simulation period
Cooling load methodology
Heating load methodology

January - December
RTS (ASHRAE Tables)
UATD



Room Checksums

By Miller-Remick

Bulk Storage Room

COOLING COIL PEAK					CLG SPACE PEAK					HEATING COIL PEAK					TEMPERATURES		
Peaked at Time: Mo/Hr: 7 / 14					Mo/Hr: 6 / 9					Mo/Hr: Heating Design							
Outside Air: OADB/WB/HR: 92 / 77 / 115					OADB: 75					OADB: 0							
Space Sens. + Lat.	Plenum Sens. + Lat.	Net Total	Percent Of Total		Space Sensible	Percent Of Total				Space Peak	Coil Peak	Percent					
Btu/h	Btu/h	Btu/h	(%)		Btu/h	(%)				Space Sens	Tot Sens	Of Total	(%)				
Envelope Loads					Envelope Loads					Envelope Loads							
Skylite Solar	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Skylite Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Roof Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Glass Solar	2,747	0	2,747	7	6,764	23	0	0	0	0	0	0.00	0	0.00			
Glass/Door Cond	1,020	0	1,020	3	-147	0	0	0	0	-4,955	-4,955	13.23	0	0.00			
Wall Cond	507	428	935	2	384	1	0	0	0	-1,994	-3,747	10.00	0	0.00			
Partition/Door	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Adjacent Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Infiltration	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Sub Total ==>	4,275	428	4,703	12	7,002	24	0	0	0	-6,949	-8,701	23.23	0	0.00			
Internal Loads					Internal Loads					Internal Loads							
Lights	6,052	1,513	7,565	19	6,052	20	0	0	0	0	0	0.00	0	0.00			
People	550	0	550	1	275	1	0	0	0	0	0	0.00	0	0.00			
Misc	3,439	0	3,439	9	3,439	12	0	0	0	0	0	0.00	0	0.00			
Sub Total ==>	10,041	1,513	11,554	30	9,766	33	0	0	0	0	0	0.00	0	0.00			
Ceiling Load	550	-550	0	0	522	2	0	0	0	-383	0	0.00	0	0.00			
Ventilation Load	0	0	5,870	15	0	0	0	0	0	0	-7,765	20.73	0	0.00			
Adj Air Trans Heat	0	0	0	0	0	0	0	0	0	0	0	0	0	0.00			
Dehumid. Ov Sizing	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Ov/Undr Sizing	14,992	0	14,992	38	12,293	42	0	0	0	0	67	-0.18	0	0.00			
Exhaust Heat	0	-96	-96	0	0	0	0	0	0	0	0	0.00	0	0.00			
Sup. Fan Heat	0	0	1,990	5	0	0	0	0	0	0	-21,544	57.51	0	0.00			
Ret. Fan Heat	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Duct Heat Pkup	0	0	0	0	0	0	0	0	0	0	483	-1.29	0	0.00			
Underflr Sup Ht Pkup	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Supply Air Leakage	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Grand Total ==>	29,858	1,295	39,013	100.00	29,583	100.00	0	0	0	-7,332	-37,461	100.00	0	0.00			

	Cooling	Heating
SADB	55.0	75.0
Ra Plenum	75.9	69.4
Return	75.9	69.4
Ret/OA	77.1	64.2
Fn MtrTD	0.1	0.0
Fn BldTD	0.3	0.0
Fn Frict	0.9	0.0

AIRFLOWS		
	Cooling	Heating
Diffuser	1,343	1,343
Terminal	1,343	1,343
Main Fan	1,343	1,343
Sec Fan	0	0
Nom Vent	101	101
AHU Vent	101	101
Infil	0	0
MinStop/Rh	1,343	1,343
Return	1,343	1,343
Exhaust	101	101
Rm Exh	0	0
Auxiliary	0	0
Leakage Dwn	0	0
Leakage Ups	0	0

ENGINEERING CKS		
	Cooling	Heating
% OA	7.5	7.5
cfm/ft²	0.67	0.67
cfm/ton	413.20	
ft²/ton	619.79	
Btu/hr-ft²	19.36	-18.59
No. People	1	

COOLING COIL SELECTION										AREAS			HEATING COIL SELECTION				
Total Capacity	Sens Cap.	Coil Airflow	Enter DB/WB/HR		Leave DB/WB/HR					Gross Total	Glass		Capacity	Coil Airflow	Ent	Lvg	
ton	MBh	MBh	°F	°F	°F	°F	gr/lb	°F	°F	ft²	(%)		MBh	cfm	°F	°F	
Main Clg	3.3	39.0	34.7	1,343	77.1	62.5	62.3	53.7	52.4	57.5			Main Htg	-31.5	1,343	53.7	75.0
Aux Clg	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0			Aux Htg	0.0	0	0.0	0.0
Opt Vent	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0			Preheat	-6.0	101	0.0	53.7
													Reheat	-24.2	1,343	53.7	70.0
Total	3.3	39.0											Humidif	0.0	0	0.0	0.0
													Opt Vent	0.0	0	0.0	0.0
													Total	-37.5			

Room Checksums

By Miller-Remick

Electrical Storage Room

COOLING COIL PEAK					CLG SPACE PEAK			HEATING COIL PEAK				TEMPERATURES		
Peaked at Time: Mo/Hr: 7 / 14					Mo/Hr: 7 / 23			Mo/Hr: Heating Design						
Outside Air: OADB/WB/HR: 92 / 77 / 115					OADB: 79			OADB: 0						
Space Sens. + Lat.	Plenum Sens. + Lat.	Net Total	Percent Of Total		Space Sensible	Percent Of Total		Space Peak	Coil Peak	Percent		Cooling	Heating	
Btu/h	Btu/h	Btu/h	(%)		Btu/h	(%)		Space Sens	Tot Sens	Of Total				
Btu/h	Btu/h	Btu/h	(%)		Btu/h	(%)		Btu/h	Btu/h	(%)				
Envelope Loads					Envelope Loads			Envelope Loads						
Skylite Solar	0	0	0	0	0	0	0	0	0	0.00	0	SADB	55.0	70.3
Skylite Cond	0	0	0	0	0	0	0	0	0	0.00	0	Ra Plenum	75.9	69.4
Roof Cond	0	0	0	0	0	0	0	0	0	0.00	0	Return	75.9	69.4
Glass Solar	0	0	0	0	0	0	0	0	0	0.00	0	Ret/OA	77.1	64.2
Glass/Door Cond	0	0	0	0	0	0	0	0	0	0.00	0	Fn MtrTD	0.1	0.0
Wall Cond	0	0	0	0	0	0	0	0	0	0.00	0	Fn BldTD	0.3	0.0
Partition/Door	0	0	0	0	0	0	0	0	0	0.00	0	Fn Frict	0.9	0.0
Floor	0	0	0	0	0	0	0	0	0	0.00	0			
Adjacent Floor	0	0	0	0	0	0	0	0	0	0.00	0			
Infiltration	0	0	0	0	0	0	0	0	0	0.00	0			
Sub Total ==>	0	0	0	0	0	0	0	0	0	0.00	0			
Internal Loads					Internal Loads			Internal Loads						
Lights	1,682	420	2,102	19	1,682	20	0	0	0	0.00	0			
People	550	0	550	5	275	3	0	0	0	0.00	0			
Misc	956	0	956	9	956	12	0	0	0	0.00	0			
Sub Total ==>	3,188	420	3,608	33	2,913	35	0	0	0	0.00	0			
Ceiling Load					Ceiling Load			Ceiling Load						
Ventilation Load	0	-153	0	0	161	2	-106	0	0	0.00	-106			
Adj Air Trans Heat	0	0	1,631	15	0	0	0	0	-2,158	25.45	0			
Dehumid. Ov Sizing	0	0	0	0	0	0	0	0	0	0.00	0			
Ov/Undr Sizing	5,156	-27	5,156	47	5,148	63	0	0	0	0.00	0			
Exhaust Heat	0	0	-27	0	0	0	0	18	0	-0.22	0			
Sup. Fan Heat	0	0	553	5	0	0	0	0	-5,987	70.61	0			
Ret. Fan Heat	0	0	0	0	0	0	0	0	0	0.00	0			
Duct Heat Pkup	0	0	0	0	0	0	0	0	-353	4.16	0			
Underflr Sup Ht Pkup	0	0	0	0	0	0	0	0	0	0.00	0			
Supply Air Leakage	0	0	0	0	0	0	0	0	0	0.00	0			
Grand Total ==>	8,496	241	10,922	100.00	8,222	100.00	Grand Total ==>	-106	-8,480	100.00				

TEMPERATURES		
	Cooling	Heating
SADB	55.0	70.3
Ra Plenum	75.9	69.4
Return	75.9	69.4
Ret/OA	77.1	64.2
Fn MtrTD	0.1	0.0
Fn BldTD	0.3	0.0
Fn Frict	0.9	0.0

AIRFLOWS		
	Cooling	Heating
Diffuser	373	373
Terminal	373	373
Main Fan	373	373
Sec Fan	0	0
Nom Vent	28	28
AHU Vent	28	28
Infil	0	0
MinStop/Rh	373	373
Return	373	373
Exhaust	28	28
Rm Exh	0	0
Auxiliary	0	0
Leakage Dwn	0	0
Leakage Ups	0	0

ENGINEERING CKS		
	Cooling	Heating
% OA	7.5	7.5
cfm/ft²	0.67	0.67
cfm/ton	410.18	
ft²/ton	615.27	
Btu/hr-ft²	19.50	-15.14
No. People	1	

COOLING COIL SELECTION									
	Total Capacity	Sens Cap.	Coil Airflow	Enter DB/WB/HR		Leave DB/WB/HR			
	ton	MBh	cfm	°F	°F	°F	°F	°F	gr/lb
Main Clg	0.9	10.9	9.5	373	77.1	62.5	62.3	53.7	52.3
Aux Clg	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0
Opt Vent	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0
Total	0.9	10.9							

AREAS			
Gross Total	Glass		
	ft²	(%)	
Floor	560		
Part	0		
Int Door	0		
ExFlr	0		
Roof	0	0	0
Wall	0	0	0
Ext Door	0	0	0

HEATING COIL SELECTION				
	Capacity	Coil Airflow	Ent	Lvg
	MBh	cfm	°F	°F
Main Htg	-6.8	373	53.7	70.3
Aux Htg	0.0	0	0.0	0.0
Preheat	-1.7	28	0.0	53.7
Reheat	-6.7	373	53.7	70.0
Humidif	0.0	0	0.0	0.0
Opt Vent	0.0	0	0.0	0.0
Total	-8.5			

Room Checksums

By Miller-Remick

Office 01

COOLING COIL PEAK					CLG SPACE PEAK					HEATING COIL PEAK					TEMPERATURES		
Peaked at Time: Mo/Hr: 7 / 14					Mo/Hr: 7 / 9					Mo/Hr: Heating Design							
Outside Air: OADB/WB/HR: 92 / 77 / 115					OADB: 79					OADB: 0							
Space Sens. + Lat.	Plenum Sens. + Lat.	Net Total	Percent Of Total		Space Sensible	Percent Of Total				Space Peak	Coil Peak	Percent					
Btu/h	Btu/h	Btu/h	(%)		Btu/h	(%)				Space Sens	Tot Sens	Of Total	(%)				
Envelope Loads					Envelope Loads					Envelope Loads							
Skylite Solar	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00	SADB	Cooling	Heating
Skylite Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00	Ra Plenum	75.9	69.4
Roof Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00	Return	75.9	69.4
Glass Solar	343	0	343	6	910	41	0	0	0	0	0	0.00	0	0.00	Ret/OA	83.9	34.7
Glass/Door Cond	142	0	142	3	26	1	0	0	0	-688	-688	12.16	0	0.00	Fn MtrTD	0.1	0.0
Wall Cond	89	72	161	3	85	4	0	0	0	-347	-639	11.30	0	0.00	Fn BldTD	0.3	0.0
Partition/Door	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00	Fn Frict	0.9	0.0
Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Adjacent Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Infiltration	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Sub Total ==>	573	72	645	12	1,021	46	0	0	0	-1,035	-1,327	23.46	0	0.00			
Internal Loads					Internal Loads					Internal Loads							
Lights	436	109	544	10	436	19	0	0	0	0	0	0.00	0	0.00			
People	450	0	450	8	250	11	0	0	0	0	0	0.00	0	0.00			
Misc	495	0	495	9	495	22	0	0	0	0	0	0.00	0	0.00			
Sub Total ==>	1,380	109	1,489	28	1,180	53	0	0	0	0	0	0.00	0	0.00			
Ceiling Load					Ceiling Load					Ceiling Load							
Ventilation Load	0	0	2,816	52	0	0	0	0	0	-28	0	0.00	0	0.00			
Adj Air Trans Heat	0	0	0	0	0	0	0	0	0	0	-3,725	65.84	0	0.00			
Dehumid. Ov Sizing	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Ov/Undr Sizing	336	0	336	6	0	0	0	0	0	0	0	0.00	0	0.00			
Exhaust Heat	0	-46	-46	-1	0	0	0	0	0	0	32	-0.56	0	0.00			
Sup. Fan Heat	0	0	143	3	0	0	0	0	0	0	0	0.00	0	0.00			
Ret. Fan Heat	0	0	0	0	0	0	0	0	0	0	-838	14.81	0	0.00			
Duct Heat Pkup	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Underflr Sup Ht Pkup	0	0	0	0	0	0	0	0	0	0	201	-3.55	0	0.00			
Supply Air Leakage	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Grand Total ==>	2,329	95	5,383	100.00	2,241	100.00	0	0	0	-1,063	-5,658	100.00	0	0.00			

TEMPERATURES		
	Cooling	Heating
SADB	55.0	80.0
Ra Plenum	75.9	69.4
Return	75.9	69.4
Ret/OA	83.9	34.7
Fn MtrTD	0.1	0.0
Fn BldTD	0.3	0.0
Fn Frict	0.9	0.0

AIRFLOWS		
	Cooling	Heating
Diffuser	102	97
Terminal	102	97
Main Fan	102	97
Sec Fan	0	0
Nom Vent	48	48
AHU Vent	48	48
Infil	0	0
MinStop/Rh	97	97
Return	102	97
Exhaust	48	48
Rm Exh	0	0
Auxiliary	0	0
Leakage Dwn	0	0
Leakage Ups	0	0

ENGINEERING CKS		
	Cooling	Heating
% OA	47.5	50.0
cfm/ft²	0.70	0.67
cfm/ton	226.81	
ft²/ton	323.22	
Btu/hr-ft²	37.13	-39.02
No. People	1	

COOLING COIL SELECTION										AREAS				HEATING COIL SELECTION				
Total Capacity	Sens Cap.	Coil Airflow	Enter DB/WB/HR	Leave DB/WB/HR						Gross Total	Glass			CapacityCoil Airflow	Ent	Lvg		
ton MBh	MBh	cfm	°F °F gr/lb	°F °F gr/lb							ft² (%)			MBh cfm	°F	°F		
Main Clg	0.5	5.4	3.3	97	83.9	69.5	86.6	53.7	51.7	54.7				Main Htg	-2.8	97	53.7	80.0
Aux Clg	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0				Aux Htg	0.0	0	0.0	0.0
Opt Vent	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0				Preheat	-2.9	48	0.0	53.7
														Reheat	-1.7	97	53.7	70.0
														Humidif	0.0	0	0.0	0.0
														Opt Vent	0.0	0	0.0	0.0
Total	0.5	5.4												Total	-5.7			

Room Checksums

By Miller-Remick

Office 02

COOLING COIL PEAK					CLG SPACE PEAK					HEATING COIL PEAK					TEMPERATURES		
Peaked at Time: Mo/Hr: 7 / 14					Mo/Hr: 7 / 9					Mo/Hr: Heating Design							
Outside Air: OADB/WB/HR: 92 / 77 / 115					OADB: 79					OADB: 0							
Space Sens. + Lat.	Plenum Sens. + Lat.	Net Total	Percent Of Total		Space Sensible	Percent Of Total				Space Peak	Coil Peak	Percent					
Btu/h	Btu/h	Btu/h	(%)		Btu/h	(%)				Space Sens	Tot Sens	Of Total	(%)				
Envelope Loads					Envelope Loads					Envelope Loads							
Skylite Solar	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Skylite Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Roof Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Glass Solar	328	0	328	7	883	41	0	0	0	0	0	0.00	0	0.00			
Glass/Door Cond	142	0	142	3	26	1	0	0	0	-688	-688	12.84	0	0.00			
Wall Cond	95	76	172	3	91	4	0	0	0	-368	-675	12.59	0	0.00			
Partition/Door	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Adjacent Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Infiltration	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Sub Total ==>	565	76	642	13	1,000	46	0	0	0	-1,056	-1,363	25.43	0	0.00			
Internal Loads					Internal Loads					Internal Loads							
Lights	405	101	507	10	405	19	0	0	0	0	0	0.00	0	0.00			
People	450	0	450	9	250	12	0	0	0	0	0	0.00	0	0.00			
Misc	461	0	461	9	461	21	0	0	0	0	0	0.00	0	0.00			
Sub Total ==>	1,316	101	1,418	28	1,116	52	0	0	0	0	0	0.00	0	0.00			
Ceiling Load	37	-37	0	0	36	2	0	0	0	-26	0	0.00	0	0.00			
Ventilation Load	0	0	2,622	52	0	0	0	0	0	0	-3,468	64.71	0	0.00			
Adj Air Trans Heat	0	0	0	0	0	0	0	0	0	0	0	0	0	0.00			
Dehumid. Ov Sizing	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Ov/Undr Sizing	264	-43	264	5	0	0	0	0	0	0	30	-0.55	0	0.00			
Exhaust Heat	0	0	-43	-1	0	0	0	0	0	0	0	0.00	0	0.00			
Sup. Fan Heat	0	0	133	3	0	0	0	0	0	0	-780	14.55	0	0.00			
Ret. Fan Heat	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Duct Heat Pkup	0	0	0	0	0	0	0	0	0	0	222	-4.13	0	0.00			
Underflr Sup Ht Pkup	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Supply Air Leakage	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Grand Total ==>	2,182	98	5,035	100.00	2,153	100.00	0	0	0	-1,082	-5,360	100.00	0	0.00			

	Cooling	Heating
SADB	55.0	80.9
Ra Plenum	75.9	69.4
Return	75.9	69.4
Ret/OA	83.9	34.7
Fn MtrTD	0.1	0.0
Fn BldTD	0.3	0.0
Fn Frict	0.9	0.0

AIRFLOWS		
	Cooling	Heating
Diffuser	98	90
Terminal	98	90
Main Fan	98	90
Sec Fan	0	0
Nom Vent	45	45
AHU Vent	45	45
Infil	0	0
MinStop/Rh	90	90
Return	98	90
Exhaust	45	45
Rm Exh	0	0
Auxiliary	0	0
Leakage Dwn	0	0
Leakage Ups	0	0

ENGINEERING CKS		
	Cooling	Heating
% OA	46.0	50.0
cfm/ft²	0.72	0.67
cfm/ton	232.96	
ft²/ton	321.73	
Btu/hr-ft²	37.30	-39.71
No. People	1	

COOLING COIL SELECTION										AREAS				HEATING COIL SELECTION				
Total Capacity	Sens Cap.	Coil Airflow	Enter DB/WB/HR		Leave DB/WB/HR					Gross Total	Glass			Capacity	Coil Airflow	Ent	Lvg	
ton	MBh	MBh	°F	°F	°F	°F	gr/lb	°F	°F	ft²	(%)			MBh	cfm	°F	°F	
Main Clg	0.4	5.0	3.1	90	83.9	69.5	86.6	53.7	51.6	54.3				Main Htg	-2.7	90	53.7	80.9
Aux Clg	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0				Aux Htg	0.0	0	0.0	0.0
Opt Vent	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0				Preheat	-2.7	45	0.0	53.7
														Reheat	-1.6	90	53.7	70.0
														Humidif	0.0	0	0.0	0.0
														Opt Vent	0.0	0	0.0	0.0
Total	0.4	5.0												Total	-5.4			

Room Checksums

By Miller-Remick

Office 03

COOLING COIL PEAK					CLG SPACE PEAK					HEATING COIL PEAK					TEMPERATURES		
Peaked at Time: Mo/Hr: 7 / 9					Mo/Hr: 7 / 9					Mo/Hr: Heating Design							
Outside Air: OADB/WB/HR: 79 / 71 / 100					OADB: 79					OADB: 0							
Space Sens. + Lat.	Plenum Sens. + Lat.	Net Total	Percent Of Total		Space Sensible	Percent Of Total				Space Peak	Coil Peak	Percent					
Btu/h	Btu/h	Btu/h	(%)		Btu/h	(%)				Space Sens	Tot Sens	Of Total	(%)				
Envelope Loads					Envelope Loads					Envelope Loads							
Skylite Solar	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	SADB	Cooling	Heating
Skylite Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	Ra Plenum	55.0	81.8
Roof Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	Return	75.9	69.4
Glass Solar	883	0	883	21	883	42	0	0	0	0	0	0.00	0.00	0.00	Ret/OA	77.5	34.7
Glass/Door Cond	26	0	26	1	26	1	0	0	0	-688	-688	13.65	13.65	13.65	Fn MtrTD	0.1	0.0
Wall Cond	91	73	164	4	91	4	0	0	0	-368	-675	13.38	13.38	13.38	Fn BldTD	0.3	0.0
Partition/Door	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	Fn Frict	0.9	0.0
Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Adjacent Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Infiltration	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Sub Total ==>	1,000	73	1,073	26	1,000	48	0	0	0	-1,056	-1,363	27.03	27.03	27.03			
Internal Loads					Internal Loads					Internal Loads							
Lights	375	94	469	11	375	18	0	0	0	0	0	0.00	0.00	0.00			
People	450	0	450	11	250	12	0	0	0	0	0	0.00	0.00	0.00			
Misc	427	0	427	10	427	20	0	0	0	0	0	0.00	0.00	0.00			
Sub Total ==>	1,252	94	1,346	33	1,052	50	0	0	0	0	0	0.00	0.00	0.00			
Ceiling Load					Ceiling Load					Ceiling Load							
Ventilation Load	0	0	1,420	34	0	0	0	0	0	-24	0	0.00	0.00	0.00			
Adj Air Trans Heat	0	0	0	0	0	0	0	0	0	0	-3,212	63.70	63.70	63.70			
Dehumid. Ov Sizing	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Ov/Undr Sizing	184	0	184	4	0	0	0	0	0	0	0	0.00	0.00	0.00			
Exhaust Heat	0	-39	-39	-1	0	0	0	0	0	0	28	-0.55	-0.55	-0.55			
Sup. Fan Heat	0	0	140	3	0	0	0	0	0	0	0	0.00	0.00	0.00			
Ret. Fan Heat	0	0	0	0	0	0	0	0	0	0	-722	14.33	14.33	14.33			
Duct Heat Pkup	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Underflr Sup Ht Pkup	0	0	0	0	0	0	0	0	0	0	228	-4.52	-4.52	-4.52			
Supply Air Leakage	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Grand Total ==>	2,470	94	4,124	100.00	2,086	100.00	0	0	0	-1,080	-5,042	100.00	100.00	100.00			

TEMPERATURES		
	Cooling	Heating
SADB	55.0	81.8
Ra Plenum	75.9	69.4
Return	75.9	69.4
Ret/OA	77.5	34.7
Fn MtrTD	0.1	0.0
Fn BldTD	0.3	0.0
Fn Frict	0.9	0.0

AIRFLOWS		
	Cooling	Heating
Diffuser	95	83
Terminal	95	83
Main Fan	95	83
Sec Fan	0	0
Nom Vent	42	42
AHU Vent	42	42
Infil	0	0
MinStop/Rh	83	83
Return	95	83
Exhaust	42	42
Rm Exh	0	0
Auxiliary	0	0
Leakage Dwn	0	0
Leakage Ups	0	0

ENGINEERING CKS		
	Cooling	Heating
% OA	44.0	50.0
cfm/ft²	0.76	0.67
cfm/ton	275.62	
ft²/ton	363.75	
Btu/hr-ft²	32.99	-40.33
No. People	1	

COOLING COIL SELECTION										AREAS				HEATING COIL SELECTION				
Total Capacity	Sens Cap.	Coil Airflow	Enter DB/WB/HR		Leave DB/WB/HR					Gross Total	Glass			Capacity	Coil Airflow	Ent	Lvg	
ton	MBh	MBh	°F	°F	°F	°F	gr/lb	gr/lb	gr/lb		ft²	(%)		MBh	cfm	°F	°F	
Main Clg	0.3	4.1	2.7	95	77.5	65.5	76.5	53.7	50.9	51.7	Floor	125		Main Htg	-2.6	83	53.7	81.8
Aux Clg	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0	Part	0		Aux Htg	0.0	0	0.0	0.0
Opt Vent	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0	Int Door	0		Preheat	-2.5	42	0.0	53.7
											ExFlr	0		Reheat	-1.5	83	53.7	70.0
											Roof	0	0	Humidif	0.0	0	0.0	0.0
											Wall	179	18	Opt Vent	0.0	0	0.0	0.0
											Ext Door	0	0	Total	-5.0			
Total	0.3	4.1																

Room Checksums

By Miller-Remick

Office 04

COOLING COIL PEAK					CLG SPACE PEAK					HEATING COIL PEAK					TEMPERATURES		
Peaked at Time: Mo/Hr: 7 / 14					Mo/Hr: 7 / 9					Mo/Hr: Heating Design							
Outside Air: OADB/WB/HR: 92 / 77 / 115					OADB: 79					OADB: 0							
Space Sens. + Lat.	Plenum Sens. + Lat.	Net Total	Percent Of Total		Space Sensible	Percent Of Total				Space Peak	Coil Peak	Percent					
Btu/h	Btu/h	Btu/h	(%)		Btu/h	(%)				Space Sens	Tot Sens	Of Total	(%)				
Envelope Loads					Envelope Loads					Envelope Loads							
Skylite Solar	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Skylite Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Roof Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Glass Solar	328	0	328	7	883	42	0	0	0	0	0	0.00	0	0.00			
Glass/Door Cond	142	0	142	3	26	1	0	0	0	-688	-688	13.23	0	0.00			
Wall Cond	95	76	172	4	91	4	0	0	0	-368	-675	12.97	0	0.00			
Partition/Door	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Adjacent Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Infiltration	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Sub Total ==>	565	76	642	13	1,000	47	0	0	0	-1,056	-1,363	26.21	0	0.00			
Internal Loads					Internal Loads					Internal Loads							
Lights	390	98	488	10	390	18	0	0	0	0	0	0.00	0	0.00			
People	450	0	450	9	250	12	0	0	0	0	0	0.00	0	0.00			
Misc	444	0	444	9	444	21	0	0	0	0	0	0.00	0	0.00			
Sub Total ==>	1,284	98	1,382	28	1,084	51	0	0	0	0	0	0.00	0	0.00			
Ceiling Load	36	-36	0	0	35	2	0	0	0	-25	0	0.00	0	0.00			
Ventilation Load	0	0	2,525	52	0	0	0	0	0	0	-3,340	64.22	0	0.00			
Adj Air Trans Heat	0	0	0	0	0	0	0	0	0	0	0	0	0	0.00			
Dehumid. Ov Sizing	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Ov/Undr Sizing	224	0	224	5	0	0	0	0	0	0	29	-0.55	0	0.00			
Exhaust Heat	0	-41	-41	-1	0	0	0	0	0	0	0	0.00	0	0.00			
Sup. Fan Heat	0	0	128	3	0	0	0	0	0	0	-751	14.45	0	0.00			
Ret. Fan Heat	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Duct Heat Pkup	0	0	0	0	0	0	0	0	0	0	225	-4.32	0	0.00			
Underflr Sup Ht Pkup	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Supply Air Leakage	0	0	0	0	0	0	0	0	0	0	0	0.00	0	0.00			
Grand Total ==>	2,109	97	4,859	100.00	2,119	100.00	0	0	0	-1,081	-5,201	100.00	0	0.00			

	Cooling	Heating
SADB	55.0	81.3
Ra Plenum	75.9	69.4
Return	75.9	69.4
Ret/OA	83.9	34.7
Fn MtrTD	0.1	0.0
Fn BldTD	0.3	0.0
Fn Frict	0.9	0.0

AIRFLOWS		
	Cooling	Heating
Diffuser	96	87
Terminal	96	87
Main Fan	96	87
Sec Fan	0	0
Nom Vent	43	43
AHU Vent	43	43
Infil	0	0
MinStop/Rh	87	87
Return	96	87
Exhaust	43	43
Rm Exh	0	0
Auxiliary	0	0
Leakage Dwn	0	0
Leakage Ups	0	0

ENGINEERING CKS		
	Cooling	Heating
% OA	45.0	50.0
cfm/ft²	0.74	0.67
cfm/ton	237.66	
ft²/ton	321.05	
Btu/hr-ft²	37.38	-40.01
No. People	1	

COOLING COIL SELECTION										AREAS				HEATING COIL SELECTION				
Total Capacity	Sens Cap.	Coil Airflow	Enter DB/WB/HR		Leave DB/WB/HR					Gross Total	Glass			Capacity	Coil Airflow	Ent	Lvg	
ton	MBh	MBh	°F	°F	°F	°F	gr/lb	°F	°F		ft²	(%)		MBh	cfm	°F	°F	
Main Clg	0.4	4.9	2.9	87	83.9	69.5	86.6	53.7	51.5	54.2	Floor	130		Main Htg	-2.6	87	53.7	81.3
Aux Clg	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0	Part	0		Aux Htg	0.0	0	0.0	0.0
Opt Vent	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0	Int Door	0		Preheat	-2.6	43	0.0	53.7
											ExFlr	0		Reheat	-1.6	87	53.7	70.0
Total	0.4	4.9									Roof	0	0	Humidif	0.0	0	0.0	0.0
											Wall	179	18	Opt Vent	0.0	0	0.0	0.0
											Ext Door	0	0	Total	-5.2			

By Miller-Remick

COOLING COIL PEAK

Peaked at Time:	Mo/Hr: 7 / 14
Outside Air:	OADB/WB/HR: 92 / 77 / 115

Mo/Hr: 7 / 23
OADB: 79

Mo/Hr: Heating Design
OADB: 0

TEMPERATURES		
	Cooling	Heating
SADB	55.0	70.3
Ra Plenum	75.9	69.4
Return	75.9	69.4
Ret/OA	83.9	34.7
Fn MtrTD	0.1	0.0
Fn BldTD	0.3	0.0
Fn Frict	0.9	0.0

	Cooling	Heating
Diffuser	77	77
Terminal	77	77
Main Fan	77	77
Sec Fan	0	0
Nom Vent	38	38
AHU Vent	38	38
Infil	0	0
MinStop/Rh	77	77
Return	77	77
Exhaust	38	38
Rm Exh	0	0
Auxiliary	0	0
Leakage Dwn	0	0
Leakage Ups	0	0

ENGINEERING CKS		
	Cooling	Heating
% OA	50.0	50.0
cfm/ft²	0.67	0.67
cfm/ton	216.27	
ft²/ton	324.40	
Btu/hr-ft²	36.99	-31.88
No. People	1	

AREAS			
	Gross Total	Glass	
		ft ²	(%)
Floor	115		
Part	0		
Int Door	0		
ExFlr	0		
Roof	0	0	0
Wall	0	0	0
Ext Door	0	0	0

HEATING COIL SELECTION				
	Capacity MBh	Coil Airflow cfm	Ent °F	Lvg °F
Main Htg	-1.4	77	53.7	70.3
Aux Htg	0.0	0	0.0	0.0
Preheat	-2.3	38	0.0	53.7
Reheat	-1.4	77	53.7	70.0
Humidif	0.0	0	0.0	0.0
Opt Vent	0.0	0	0.0	0.0
Total	-3.7			

By Miller-Remick

COOLING COIL PEAK					CLG SPACE PEAK		HEATING COIL PEAK					TEMPERATURES				
Peaked at Time:		Mo/Hr: 7 / 14			Mo/Hr: 7 / 23		Mo/Hr: Heating Design					Cooling			Heating	
Outside Air:		OADB/WB/HR: 92 / 77 / 115			OADB: 79		OADB: 0					SADB			55.0	70.3
												Ra Plenum			75.9	69.4
												Return			75.9	69.4
												Ret/OA			83.9	34.7
												Fn MtrTD			0.1	0.0
												Fn BldTD			0.3	0.0
												Fn Frict			0.9	0.0
	Space	Plenum	Net	Percent	Space	Percent		Space	Coil	Percent						
	Sens. + Lat.	Sens. + Lat	Total	Of Total	Sensible	Of Total		Space	Peak	Tot	Sens	Of Total				
	Btu/h	Btu/h	Btu/h	(%)	Btu/h	(%)		Space	Peak	Tot	Sens	Of Total				
								Sens								
Envelope Loads					Envelope Loads					Envelope Loads						
Skylite Solar	0	0	0	0	0	0	Skylite Solar	0	0	0	0.00					
Skylite Cond	0	0	0	0	0	0	Skylite Cond	0	0	0	0.00					
Roof Cond	0	0	0	0	0	0	Roof Cond	0	0	0	0.00					
Glass Solar	0	0	0	0	0	0	Glass Solar	0	0	0	0.00					
Glass/Door Cond	0	0	0	0	0	0	Glass/Door Cond	0	0	0	0.00					
Wall Cond	0	0	0	0	0	0	Wall Cond	0	0	0	0.00					
Partition/Door	0		0	0	0	0	Partition/Door	0	0	0	0.00					
Floor	0		0	0	0	0	Floor	0	0	0	0.00					
Adjacent Floor	0	0	0	0	0	0	Adjacent Floor	0	0	0	0.00					
Infiltration	0		0	0	0	0	Infiltration	0	0	0	0.00					
Sub Total ==>	0	0	0	0	0	0	Sub Total ==>	0	0	0	0.00					
Internal Loads					Internal Loads					Internal Loads						
Lights	3,724	931	4,655	10	3,724	20	Lights	0	0	0	0.00					
People	3,600	0	3,600	8	2,000	11	People	0	0	0	0.00					
Misc	4,232	0	4,232	9	4,232	23	Misc	0	0	0	0.00					
Sub Total ==>	11,556	931	12,487	28	9,956	55	Sub Total ==>	0	0	0	0.00					
Ceiling Load					Ceiling Load					Ceiling Load						
Ventilation Load	339	-339	0	0	357	2	Ventilation Load	-236	0	0	0.00					
Adj Air Trans Heat	0	0	24,082	53	0	0	Adj Air Trans Heat	0	-31,858	80.59						
Dehumid. Ov Sizing			0	0	0	0	Ov/Undr Sizing	0	0	0.00						
Ov/Undr Sizing	7,910		7,910	17	7,891	43	Exhaust Heat		273	-0.69						
Exhaust Heat		-392	-392	-1			OA Preheat Diff.		0	0.00						
Sup. Fan Heat			1,225	3			RA Preheat Diff.		-7,166	18.13						
Ret. Fan Heat		0	0	0			Additional Reheat		0	0.00						
Duct Heat Pkup		0	0	0			System Plenum Heat		-781	1.98						
Underflr Sup Ht Pkup			0	0			Underflr Sup Ht Pkup		0	0.00						
Supply Air Leakage		0	0	0			Supply Air Leakage		0	0.00						
Grand Total ==>	19,805	200	45,312	100.00	18,205	100.00	Grand Total ==>	-236	-39,533	100.00						
AIRFLOWS																
		Cooling	Heating													
Diffuser		827	827													
Terminal		827	827													
Main Fan		827	827													
Sec Fan		0	0													
Nom Vent		413	413													
AHU Vent		413	413													
Infil		0	0													
MinStop/Rh</																

COOLING COIL SELECTION										AREAS				HEATING COIL SELECTION					
	Total Capacity		Sens Cap.	Coil Airflow	Enter DB/WB/HR			Leave DB/WB/HR			Gross Total		Glass		Capacity	Coil Airflow	Ent	Lvg	
	ton	MBh	MBh	cfm	°F	°F	gr/lb	°F	°F	gr/lb			ft² (%)	MBh	cfm	°F	°F		
Main Clg	3.8	45.3	27.3	827	83.9	69.5	86.6	53.7	52.0	56.0	Floor	1,240		Main Htg	-15.1	827	53.7	70.3	
Aux Clg	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0	Part	0		Aux Htg	0.0	0	0.0	0.0	
Opt Vent	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0	Int Door	0		Preheat	-24.4	413	0.0	53.7	
											ExFlr	0		Reheat	-14.9	827	53.7	70.0	
											Roof	0	0	0	Humidif	0.0	0	0.0	0.0
											Wall	0	0	0	Opt Vent	0.0	0	0.0	0.0
											Ext Door	0	0	0	Total	-39.5			
Total	3.8	45.3																	

Room Checksums

By Miller-Remick

Office 07

COOLING COIL PEAK					CLG SPACE PEAK					HEATING COIL PEAK					TEMPERATURES		
Peaked at Time: Mo/Hr: 7 / 14					Mo/Hr: 7 / 23					Mo/Hr: Heating Design							
Outside Air: OADB/WB/HR: 92 / 77 / 115					OADB: 79					OADB: 0							
Space Sens. + Lat.	Plenum Sens. + Lat.	Net Total	Percent Of Total		Space Sensible	Percent Of Total				Space Peak	Coil Peak	Percent					
Btu/h	Btu/h	Btu/h	(%)		Btu/h	(%)				Space Sens	Tot Sens	Of Total	(%)				
Envelope Loads					Envelope Loads					Envelope Loads							
Skylite Solar	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	SADB	Cooling	Heating
Skylite Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	Ra Plenum	55.0	70.3
Roof Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	Return	75.9	69.4
Glass Solar	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	Ret/OA	83.9	34.7
Glass/Door Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	Fn MtrTD	0.1	0.0
Wall Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	Fn BldTD	0.3	0.0
Partition/Door	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	Fn Frict	0.9	0.0
Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Adjacent Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Infiltration	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Sub Total ==>	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Internal Loads					Internal Loads					Internal Loads							
Lights	330	83	413	10	330	20	0	0	0	0	0	0.00	0.00	0.00			
People	450	0	450	11	250	15	0	0	0	0	0	0.00	0.00	0.00			
Misc	375	0	375	9	375	23	0	0	0	0	0	0.00	0.00	0.00			
Sub Total ==>	1,156	83	1,238	30	956	59	0	0	0	0	0	0.00	0.00	0.00			
Ceiling Load					Ceiling Load					Ceiling Load							
Ventilation Load	30	-30	0	0	32	2	0	0	0	-21	0	0.00	0.00	0.00			
Adj Air Trans Heat	0	0	2,136	52	0	0	0	0	0	0	-2,826	80.59	0.00	0.00			
Dehumid. Ov Sizing	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Ov/Undr Sizing	629	0	629	15	627	39	0	0	0	0	0	0.00	0.00	0.00			
Exhaust Heat	0	-35	-35	-1	0	0	0	0	0	0	24	-0.69	0.00	0.00			
Sup. Fan Heat	0	0	109	3	0	0	0	0	0	0	-636	18.13	0.00	0.00			
Ret. Fan Heat	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Duct Heat Pkup	0	0	0	0	0	0	0	0	0	0	-69	1.98	0.00	0.00			
Underflr Sup Ht Pkup	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Supply Air Leakage	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Grand Total ==>	1,815	18	4,078	100.00	1,615	100.00	0	0	0	-21	-3,507	100.00	0.00	0.00			

TEMPERATURES		
	Cooling	Heating
SADB	55.0	70.3
Ra Plenum	75.9	69.4
Return	75.9	69.4
Ret/OA	83.9	34.7
Fn MtrTD	0.1	0.0
Fn BldTD	0.3	0.0
Fn Frict	0.9	0.0

AIRFLOWS		
	Cooling	Heating
Diffuser	73	73
Terminal	73	73
Main Fan	73	73
Sec Fan	0	0
Nom Vent	37	37
AHU Vent	37	37
Infil	0	0
MinStop/Rh	73	73
Return	73	73
Exhaust	37	37
Rm Exh	0	0
Auxiliary	0	0
Leakage Dwn	0	0
Leakage Ups	0	0

ENGINEERING CKS		
	Cooling	Heating
% OA	50.0	50.0
cfm/ft²	0.67	0.67
cfm/ton	215.81	
ft²/ton	323.71	
Btu/hr-ft²	37.07	-31.88
No. People	1	

COOLING COIL SELECTION										AREAS			HEATING COIL SELECTION				
Total Capacity	Sens Cap.	Coil Airflow	Enter DB/WB/HR	Leave DB/WB/HR						Gross Total	Glass		Capacity	Coil Airflow	Ent	Lvg	
ton	MBh	MBh	°F °F	°F °F	gr/lb	°F °F	gr/lb				ft²	(%)	MBh	cfm	°F	°F	
Main Clg	0.3	4.1	2.4	73	83.9	69.5	86.6	53.7	51.7	54.8	Floor	110	-1.3	73	53.7	70.3	
Aux Clg	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0	Part	0	0.0	0	0.0	0.0	
Opt Vent	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0	Int Door	0	-2.2	37	0.0	53.7	
											ExFlr	0	-1.3	73	53.7	70.0	
Total	0.3	4.1									Roof	0	0.0	0	0.0	0.0	
											Wall	0	0.0	0	0.0	0.0	
											Ext Door	0	0.0	0	0.0	0.0	
													Total	-3.5			

Room Checksums

By Miller-Remick

Office 08

COOLING COIL PEAK					CLG SPACE PEAK					HEATING COIL PEAK					TEMPERATURES		
Peaked at Time: Mo/Hr: 7 / 14					Mo/Hr: 7 / 23					Mo/Hr: Heating Design							
Outside Air: OADB/WB/HR: 92 / 77 / 115					OADB: 79					OADB: 0							
Space Sens. + Lat.	Plenum Sens. + Lat.	Net Total	Percent Of Total		Space Sensible	Percent Of Total				Space Peak	Coil Peak	Percent					
Btu/h	Btu/h	Btu/h	(%)		Btu/h	(%)				Space Sens	Tot Sens	Of Total	(%)				
Envelope Loads					Envelope Loads					Envelope Loads							
Skylite Solar	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	SADB	Cooling	Heating
Skylite Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	Ra Plenum	55.0	70.3
Roof Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	Return	75.9	69.4
Glass Solar	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	Ret/OA	75.9	69.4
Glass/Door Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	Fn MtrTD	83.9	34.7
Wall Cond	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	Fn BldTD	0.1	0.0
Partition/Door	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00	Fn Frict	0.3	0.0
Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Adjacent Floor	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Infiltration	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Sub Total ==>	0	0	0	0	0	0	0	0	0	0	0	0.00	0.00	0.00			
Internal Loads					Internal Loads					Internal Loads							
Lights	390	98	488	10	390	20	0	0	0	0	0	0.00	0.00	0.00			
People	450	0	450	9	250	13	0	0	0	0	0	0.00	0.00	0.00			
Misc	444	0	444	9	444	23	0	0	0	0	0	0.00	0.00	0.00			
Sub Total ==>	1,284	98	1,382	29	1,084	57	0	0	0	0	0	0.00	0.00	0.00			
Ceiling Load	36	-36	0	0	37	2	0	0	0	-25	0	0.00	0.00	0.00			
Ventilation Load	0	0	2,525	53	0	0	0	0	0	0	-3,340	80.59	80.59	80.59			
Adj Air Trans Heat	0		0	0	0	0	0	0	0	0	0	0	0	0			
Dehumid. Ov Sizing			0	0			0	0	0	0	0	0.00	0.00	0.00			
Ov/Undr Sizing	789		789	16	787	41	0	0	0	0	0	0.00	0.00	0.00			
Exhaust Heat		-41	-41	-1			0	0	0	0	29	-0.69	-0.69	-0.69			
Sup. Fan Heat			128	3			0	0	0	0	-751	18.13	18.13	18.13			
Ret. Fan Heat		0	0	0			0	0	0	0	0	0.00	0.00	0.00			
Duct Heat Pkup		0	0	0			0	0	0	0	-82	1.98	1.98	1.98			
Underflr Sup Ht Pkup			0	0			0	0	0	0	0	0.00	0.00	0.00			
Supply Air Leakage		0	0	0			0	0	0	0	0	0.00	0.00	0.00			
Grand Total ==>	2,109	21	4,783	100.00	1,909	100.00				-25	-4,145	100.00	100.00	100.00			

TEMPERATURES		
	Cooling	Heating
SADB	55.0	70.3
Ra Plenum	75.9	69.4
Return	75.9	69.4
Ret/OA	83.9	34.7
Fn MtrTD	0.1	0.0
Fn BldTD	0.3	0.0
Fn Frict	0.9	0.0

AIRFLOWS		
	Cooling	Heating
Diffuser	87	87
Terminal	87	87
Main Fan	87	87
Sec Fan	0	0
Nom Vent	43	43
AHU Vent	43	43
Infil	0	0
MinStop/Rh	87	87
Return	87	87
Exhaust	43	43
Rm Exh	0	0
Auxiliary	0	0
Leakage Dwn	0	0
Leakage Ups	0	0

ENGINEERING CKS		
	Cooling	Heating
% OA	50.0	50.0
cfm/ft²	0.67	0.67
cfm/ton	217.45	
ft²/ton	326.17	
Btu/hr-ft²	36.79	-31.88
No. People	1	

COOLING COIL SELECTION										AREAS				HEATING COIL SELECTION				
Total Capacity	Sens Cap.	Coil Airflow	Enter DB/WB/HR		Leave DB/WB/HR					Gross Total	Glass			Capacity	Coil Airflow	Ent	Lvg	
ton	MBh	MBh	cfm	°F °F	gr/lb	°F °F	gr/lb				ft² (%)			MBh	cfm	°F	°F	
Main Clg	0.4	4.8	2.9	87	83.9	69.5	86.6	53.7	51.9	55.4				Main Htg	-1.6	87	53.7	70.3
Aux Clg	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0				Aux Htg	0.0	0	0.0	0.0
Opt Vent	0.0	0.0	0.0	0	0.0	0.0	0.0	0.0	0.0	0.0				Preheat	-2.6	43	0.0	53.7
														Reheat	-1.6	87	53.7	70.0
														Humidif	0.0	0	0.0	0.0
														Opt Vent	0.0	0	0.0	0.0
Total	0.4	4.8												Total	-4.1			

Air Filtration Standards for SPD, Sterile Supply Areas, RME Reprocessing Areas -New Facilities/Construction and AHU Replacements-

Functional Area	Pre-Filter Efficiency Pre-Filter Set #1	Pre-Filter Efficiency Pre-Filter Set #2	After/Final-Filter Efficiency	Centralized Monitoring of Filter Loading ¹ (i.e. Building Automation System)	Inspection Frequency ²	Replacement Criteria			
SPD- Soiled/Decontamination	Comply with the VA HVAC Design Manual for Hospitals, Ambulatory Care, Outpatient Clinics, and Laboratories (PG-18-10) dtd. March 2011				Continual monitoring of filter loading. Every six months check for filter integrity.	1. Air filter loading reaches recommended optimum (obtained from filter manufacturer). Or 2. Evidence of damage, media deterioration, microbial growth. Or 3. Minimum space airflow (CFM) and ACH requirements cannot be achieved.			
SPD- Preparation, Assembly, Sterilization Area				Yes	Continual monitoring of filter loading. Every six months check for filter integrity.				
SPD- Sterilizer Equipment Room	N/A- Room supplied by transfer make-up air.								
SPD- Restrooms/Housekeeping	N/A- Room supplied by transfer make-up air.								
SPD- Clean/Sterile Storage	Comply with the VA HVAC Design Manual for Hospitals, Ambulatory Care, Outpatient Clinics, and Laboratories (PG-18-10) dtd. March 2011			Yes	Continual monitoring of filter loading. Every six months check for filter integrity.	1. Air filter loading reaches recommended optimum (obtained from filter manufacturer). Or 2. Evidence of damage, media deterioration, microbial growth. Or 3. Minimum space airflow (CFM) and ACH requirements cannot be achieved.			
Non-SPD- Sterile/Clean Supply Room (e.g. wards, clinics, etc.)				Yes	Continual monitoring of filter loading. Every six months check for filter integrity.				
Non-SPD- RME Reprocessing Room (e.g. wards, clinics, etc.)				Yes	Continual monitoring of filter loading. Every six months check for filter integrity.				

Notes:

¹ Installed manometer or pressure differential device connected to building automation system for monitoring purposes.

² Inspection frequencies listed represent minimums established by VHA and are not intended to preclude more frequent inspections necessitated by local conditions.

10N Guidance
Air Filtration Standards for SPD, Sterile Supply Areas, RME Reprocessing Areas
-Existing Facilities/Construction-

Functional Area	Pre-Filter Efficiency (minimum)	After/Final-Filter Efficiency (minimum)	Centralized monitoring of filter loading ¹ (i.e. Building Automation System)	Inspection Frequency ²	Replacement Criteria	
SPD- Soiled/Decontamination	Existing	VA Grade B (MERV 11)	No	Every three months check for filter loading and filter integrity.	1. Air filter loading reaches recommended optimum (obtained from filter manufacturer). Or 2. Evidence of damage, media deterioration, microbial growth. Or 3. Minimum space airflow (CFM) and ACH requirements cannot be achieved.	
			Yes	Continual monitoring of filter loading. Every six months check for filter integrity.		
			No	Every three months check for filter loading and filter integrity.		
SPD- Preparation, Assembly, Sterilization Area	Existing	VA Grade B (MERV 11)	Yes	Continual monitoring of filter loading. Every six months check for filter integrity.		
				Every three months check for filter loading and filter integrity.		
SPD- Sterilizer Equipment Room				N/A- Room supplied by transfer make-up air.		
SPD- Restrooms/Housekeeping				N/A- Room supplied by transfer make-up air.		
SPD- Clean/Sterile Storage	Existing	VA Grade B (MERV 11)	No	Every three months check for filter loading and filter integrity.	1. Air filter loading reaches recommended optimum (obtained from filter manufacturer). Or 2. Evidence of damage, media deterioration, microbial growth. Or 3. Minimum space airflow (CFM) and ACH requirements cannot be achieved.	
			Yes	Continual monitoring of filter loading. Every six months check for filter integrity.		
			No	Every three months check for filter loading and filter integrity.		
Non-SPD- Sterile/Clean Supply Room (e.g. wards, clinics, etc.)	Existing	VA Grade B/C/D/E ³ (MERV 11/14/15/17)	Yes	Continual monitoring of filter loading. Every six months check for filter integrity.		
				Every three months check for filter loading and filter integrity.		
Non-SPD- RME Reprocessing Room (e.g. wards, clinics, etc.)	Existing	VA Grade B/C/D/E ³ (MERV 11/14/15/17)	No	Every three months check for filter loading and filter integrity.		
			Yes	Continual monitoring of filter loading. Every six months check for filter integrity.		

¹ Installed manometer or pressure differential device connected to building automation system for monitoring purposes.

² Inspection frequencies listed represent minimums established by VHA and are not intended to preclude more frequent inspections necessitated by local conditions.

³ Air filtration efficiency is determined by the most stringent requirement for the space function being served (i.e.- Dental Clinic, ICU, Pharmacy, Nursing Ward, etc.). As a minimum, After/Final-filter efficiency shall be equal or higher than VA Grade B (MERV 11).

Notes:

Performance Climate Changer

1/17/2013



Job Name

Miller Remick VA Lebanon Bldg 101 and Bldg 22

User Name

(T92)Andrew Bees

Address

Philadelphia Main Office

Performance Climate Changer

AHU 22

Quantity

1

Job Comments

Coil performance data is certified in accordance with AHRI standard 410. Propylene glycol and calcium chloride, or mixtures thereof, are not covered under the scope of AHRI 410.

Air-handling performance data is certified in accordance with AHRI standard 430. Air handlers with plenum fans and vertical draw-thru air handlers where the coil is mounted immediately below the fan section are not covered under the scope of AHRI 430.

Performance Climate Changer

1/17/2013

Unit level options

Module Position:

0

<u>Actual airflow</u>	3200 cfm	<u>Installed weight</u>	4222.7 lb
<u>Unit elevation</u>	0.00 ft	<u>Rigging weight</u>	3819.0 lb
<u>Unit size</u>	8	<u>Single or front discharge - 63 Hz</u>	91 dB
<u>Integral base frame</u>	6in. integral base frame	<u>Single or front discharge - 125 Hz</u>	90 dB
<u>UL listed unit</u>	UL listed unit	<u>Single or front discharge - 250 Hz</u>	77 dB
<u>Circuit number 1</u>	Supply fan motor(s)	<u>Single or front discharge - 500 Hz</u>	101 dB
<u>FLA (CV) circuit 1</u>	11.22 A	<u>Single or front discharge - 1K Hz</u>	94 dB
<u>MCA circuit 1</u>	13.97 A	<u>Single or front discharge - 2K Hz</u>	93 dB
<u>MOP circuit 1</u>	24.97 A	<u>Single or front discharge - 4K Hz</u>	84 dB
<u>Fuse size circuit 1</u>	20.00 A	<u>Single or front discharge - 8K Hz</u>	79 dB
<u>Circuit number 2</u>	Return/booster fan motor(s)	<u>Inlet and casing - 63 Hz</u>	94 dB
<u>FLA (CV) circuit 2</u>	5.02 A	<u>Inlet and casing - 125 Hz</u>	96 dB
<u>MCA circuit 2</u>	6.22 A	<u>Inlet and casing - 250 Hz</u>	75 dB
<u>MOP circuit 2</u>	11.02 A	<u>Inlet and casing - 500 Hz</u>	91 dB
<u>Fuse size circuit 2</u>	15.00 A	<u>Inlet and casing - 1K Hz</u>	77 dB
<u>Circuit number 3</u>	Lights + switch	<u>Inlet and casing - 2K Hz</u>	78 dB
<u>FLA (CV) circuit 3</u>	2.61 A	<u>Inlet and casing - 4K Hz</u>	76 dB
<u>MCA circuit 3</u>	3.26 A	<u>Inlet and casing - 8K Hz</u>	67 dB
<u>MOP circuit 3</u>	5.87 A	<u>Ducted inlet - 63 Hz</u>	85 dB
<u>Fuse size circuit 3</u>	15.00 A	<u>Ducted inlet - 125 Hz</u>	87 dB
<u>Circuit number 4</u>	Receptacle	<u>Ducted inlet - 250 Hz</u>	70 dB
<u>FLA (CV) circuit 4</u>	8.00 A	<u>Ducted inlet - 500 Hz</u>	87 dB
<u>MCA circuit 4</u>	10.00 A	<u>Ducted inlet - 1K Hz</u>	73 dB
<u>MOP circuit 4</u>	18.00 A	<u>Ducted inlet - 2K Hz</u>	76 dB
<u>Fuse size circuit 4</u>	15.00 A	<u>Ducted inlet - 4K Hz</u>	61 dB
<u>Product group</u>	Outdoor unit	<u>Ducted inlet - 8K Hz</u>	51 dB
<u>Roof curb type</u>	Standard roof curb	<u>Casing - 63 Hz</u>	86 dB
<u>Modified coil - min face velocity</u>	250 ft/min	<u>Casing - 125 Hz</u>	82 dB
<u>Modified coil - max face velocity</u>	600 ft/min	<u>Casing - 250 Hz</u>	69 dB
<u>HEPA filter - min face velocity</u>	0 ft/min	<u>Casing - 500 Hz</u>	85 dB
<u>HEPA filter - max face velocity</u>	600 ft/min	<u>Casing - 1K Hz</u>	78 dB
<u>High voltage location</u>	Right	<u>Casing - 2K Hz</u>	63 dB
<u>Length</u>	302.875 in	<u>Casing - 4K Hz</u>	55 dB
<u>Width</u>	50.500 in	<u>Casing - 8K Hz</u>	52 dB

Controls and VFD/starter

Module Position:

0

<u>Factory controls package</u>	No factory mount	<u>Design Sequence</u>	C
<u>Automatic Selection</u>	Validation Only	<u>Number of transformers</u>	1 - Transformer
<u>Controller mounting</u>	No mount	<u>Prepackaged solution option used</u>	MP common configuration not used
<u>Controller type</u>	No controller	<u>Prepackaged solution valid unit</u>	Non valid MP common configuration
<u>LCD screen and keypad</u>	No LCD	<u>Total number of control points</u>	2 control points

Warranty

Module Position:

0

<u>Warranty section</u>	Std. warranty only
-------------------------	--------------------

Coil performance data is certified in accordance with AHRI standard 410. Propylene glycol and calcium chloride, or mixtures thereof, are not covered under the scope of AHRI 410.

Air-handling performance data is certified in accordance with AHRI standard 430. Air handlers with plenum fans and vertical draw-thru air handlers where the coil is mounted immediately below the fan section are not covered under the scope of AHRI 430.

Performance Climate Changer

1/17/2013

Pipe cabinet section

Module Position:

0

Pipe cabinet 1 side doors	One side door	
---------------------------	---------------	--

Fan section

Module Position:

1

Fan sec [1]-1		
<u>Section type</u>	Fan	<u>Section width</u> 50.500 in
<u>Fan application</u>	Return fan	<u>Section weight</u> 673.6 lb
<u>Unit size</u>	8	<u>Static pressure origin</u> Program calculated
<u>Inlet location</u>	Bottom inlet	<u>Single or front discharge - 63 Hz</u> 76 dB
<u>Fan orientation</u>	Front-top discharge	<u>Single or front discharge - 125 Hz</u> 65 dB
<u>Fan discharge</u>	Front top	<u>Single or front discharge - 250 Hz</u> 59 dB
<u>Access door location</u>	Right	<u>Single or front discharge - 500 Hz</u> 55 dB
<u>Drive location</u>	Right side drive	<u>Single or front discharge - 1K Hz</u> 59 dB
<u>Design sequence</u>	E	<u>Single or front discharge - 2K Hz</u> 59 dB
<u>Motor horsepower per fan</u>	3 hp	<u>Single or front discharge - 4K Hz</u> 48 dB
<u>NEMA nominal motor efficiency</u>	89.50 %	<u>Single or front discharge - 8K Hz</u> 40 dB
<u>Motor class</u>	NEMA premium compliant	<u>Inlet and casing - 63 Hz</u> 75 dB
	ODP	
<u>Motor voltage</u>	460/3	<u>Inlet and casing - 125 Hz</u> 73 dB
<u>Cycle</u>	60 cycles/sec	<u>Inlet and casing - 250 Hz</u> 66 dB
<u>Drive service factor</u>	1.5 fixed drive	<u>Inlet and casing - 500 Hz</u> 56 dB
<u>Motor RPM</u>	1800	<u>Inlet and casing - 1K Hz</u> 64 dB
<u>Marine light</u>	Marine LED light	<u>Inlet and casing - 2K Hz</u> 66 dB
<u>Fan airflow</u>	3200 cfm	<u>Inlet and casing - 4K Hz</u> 64 dB
<u>Overall ESP</u>	0.500 in H2O	<u>Inlet and casing - 8K Hz</u> 52 dB
<u>Unit entering ESP</u>	0.250 in H2O	<u>Ducted inlet - 63 Hz</u> 71 dB
<u>Unit discharge ESP</u>	0.250 in H2O	<u>Ducted inlet - 125 Hz</u> 64 dB
<u>Elevation</u>	0.00 ft	<u>Ducted inlet - 250 Hz</u> 56 dB
<u>Minimum temperature</u>	40.00 F	<u>Ducted inlet - 500 Hz</u> 50 dB
<u>Design temperature</u>	70.00 F	<u>Ducted inlet - 1K Hz</u> 55 dB
<u>Fan size and type</u>	10in. diameter FC, class 1	<u>Ducted inlet - 2K Hz</u> 56 dB
<u>Total brake horsepower</u>	1.901 hp	<u>Ducted inlet - 4K Hz</u> 54 dB
<u>Total brake horsepower at min temp</u>	2.015 hp	<u>Ducted inlet - 8K Hz</u> 42 dB
<u>Total static pressure</u>	1.276 in H2O	<u>Casing - 63 Hz</u> 73 dB
<u>Speed</u>	1194 rpm	<u>Casing - 125 Hz</u> 68 dB
<u>Outlet area</u>	1.04 sq ft	<u>Casing - 250 Hz</u> 63 dB
<u>Fan outlet velocity</u>	3086 ft/min	<u>Casing - 500 Hz</u> 60 dB
<u>Fan module pressure drop</u>	0.500 in H2O	<u>Casing - 1K Hz</u> 72 dB
<u>Fan discharge loss pressure drop</u>	0.000 in H2O	<u>Casing - 2K Hz</u> 52 dB
<u>Section height</u>	41.250 in	<u>Casing - 4K Hz</u> 33 dB
<u>Section length</u>	44.000 in	<u>Casing - 8K Hz</u> 24 dB

Coil performance data is certified in accordance with AHRI standard 410. Propylene glycol and calcium chloride, or mixtures thereof, are not covered under the scope of AHRI 410.

Air-handling performance data is certified in accordance with AHRI standard 430. Air handlers with plenum fans and vertical draw-thru air handlers where the coil is mounted immediately below the fan section are not covered under the scope of AHRI 430.

Performance Climate Changer

1/17/2013

Access section

Module Position:

2

<u>Section type</u>	Access/blank/turning	<u>Design sequence</u>	B
<u>Unit size</u>	8	<u>Section length</u>	10.000 in
<u>Section size</u>	Small	<u>Section width</u>	50.500 in
<u>Front opening</u>	Full Face	<u>Section height</u>	41.250 in
<u>Back opening</u>	Full Face	<u>Section weight</u>	83.8 lb

Controls section

Module Position:

3

<u>Section type</u>	Starter/VFD only	<u>Ret/Exh fan high voltage door</u>	Right
<u>Unit size</u>	Unit size 8	<u>Design sequence</u>	B
<u>Starter/VFD</u>	Return/exhaust section	<u>Section length</u>	24.500 in
<u>NEMA application type</u>	Internal NEMA	<u>Section width</u>	50.500 in
<u>Access door location</u>	Left	<u>Section height</u>	41.250 in
<u>Access door swing direction</u>	Outward swing	<u>Section weight</u>	280.9 lb

Economizer section

Module Position:

4

<u>Economizer section type</u>	Return fan economizer	<u>Exhaust air damper type</u>	Parallel blade damper
<u>Outside air location</u>	Left	<u>Exhaust air hood type</u>	Exhaust hood w/ bird screen
<u>Outside air damper type</u>	Parallel blade damper	<u>Supply fan total air PD</u>	0.196 in H2O
<u>Outside air hood type</u>	No inlet hood	<u>Exhaust fan total air PD</u>	0.776 in H2O
<u>Return air damper type</u>	Parallel blade damper		

Filter section

Module Position:

5

<u>Section type</u>	Filter	<u>Filter condition</u>	Mid-life
<u>Unit size</u>	8	<u>Filter area</u>	11.11 sq ft
<u>Filter type</u>	Angled filter	<u>Filter face velocity</u>	288 ft/min
<u>Filter frame</u>	2in. filter frame	<u>Filter pressure drop</u>	0.569 in H2O
<u>Access door location</u>	Right	<u>Filter section pressure drop</u>	0.569 in H2O
<u>Primary filter type 1</u>	Pleated media - MERV 8	<u>Section length</u>	26.500 in
<u>Prefilter filter type</u>	No prefilter	<u>Section width</u>	50.500 in
<u>Design sequence</u>	C	<u>Section height</u>	41.250 in
<u>Filter airflow</u>	3200 cfm	<u>Section weight</u>	236.7 lb

Access section

Module Position:

6

<u>Section type</u>	Access/blank/turning	<u>Design sequence</u>	B
<u>Unit size</u>	8	<u>Marine light</u>	Marine LED light
<u>Section size</u>	Medium	<u>Section length</u>	14.000 in
<u>Access door location</u>	Left	<u>Section width</u>	50.500 in
<u>Door swing direction</u>	Outward swing	<u>Section height</u>	41.250 in
<u>Front opening</u>	Full Face	<u>Section weight</u>	113.3 lb
<u>Back opening</u>	Full Face		

Coil performance data is certified in accordance with AHRI standard 410. Propylene glycol and calcium chloride, or mixtures thereof, are not covered under the scope of AHRI 410.

Air-handling performance data is certified in accordance with AHRI standard 430. Air handlers with plenum fans and vertical draw-thru air handlers where the coil is mounted immediately below the fan section are not covered under the scope of AHRI 430.

Performance Climate Changer

1/17/2013

Coil section

Module Position:

7

Coil se [4]-1			
<u>Section type</u>	Horizontal coil	<u>Rows</u>	1 row
<u>Unit size</u>	8	<u>Fin type</u>	Sigma flo fins
<u>Section size</u>	Medium	<u>Fin material</u>	Aluminum fins
<u>Coil application</u>	Heating coil	<u>Tube diameter</u>	1in. tube diameter (25.4 mm)
<u>Changeover coil</u>	No	<u>Tube matl/wall thickness</u>	.031" (0.787mm) copper tubes
<u>System type</u>	Steam	<u>Corrosion resistant coating</u>	None
<u>Coil supply/cabinet side</u>	Right	<u>Coil face velocity</u>	492 ft/min
<u>Coil casing</u>	Galvanized	<u>Air pressure drop</u>	0.147 in H2O
<u>Coil height</u>	Unit coil height	<u>J trap dimension</u>	6.000 in
<u>Drain pan</u>	Stainless steel	<u>H trap dimension</u>	12.000 in
<u>Drain connection location</u>	Right	<u>Fluid volume</u>	1.29 gal
<u>Design sequence</u>	D	<u>Steam pressure drop</u>	11.072 in H2O
<u>Apply AHRI ranges</u>	Yes	<u>Coil condensate</u>	285.97 lb/hr
<u>Coil performance airflow</u>	3200 cfm	<u>Total cap coil #1</u>	270.69 MBh
<u>Coil elevation</u>	0.00 ft	<u>Coil face area</u>	6.50 sq ft
<u>Entering dry bulb</u>	0.00 F	<u>Coil rigging weight</u>	75.8 lb
<u>Leaving dry bulb</u>	78.00 F	<u>Coil section pressure drop</u>	0.147 in H2O
<u>Total capacity</u>	270.69 MBh	<u>Section length</u>	14.000 in
<u>Fin spacing</u>	77 Per Foot	<u>Section height</u>	41.250 in
<u>Steam pressure</u>	15.00 psig	<u>Section width</u>	50.500 in
<u>Coil type</u>	NS	<u>Section weight</u>	286.8 lb

Access section

Module Position:

8

<u>Section type</u>	Access/blank/turning	<u>Design sequence</u>	B
<u>Unit size</u>	8	<u>Marine light</u>	Marine LED light
<u>Section size</u>	Medium	<u>Section length</u>	14.000 in
<u>Access door location</u>	Left	<u>Section width</u>	50.500 in
<u>Door swing direction</u>	Outward swing	<u>Section height</u>	41.250 in
<u>Front opening</u>	Full Face	<u>Section weight</u>	141.5 lb
<u>Back opening</u>	Full Face		

Coil performance data is certified in accordance with AHRI standard 410. Propylene glycol and calcium chloride, or mixtures thereof, are not covered under the scope of AHRI 410.

Air-handling performance data is certified in accordance with AHRI standard 430. Air handlers with plenum fans and vertical draw-thru air handlers where the coil is mounted immediately below the fan section are not covered under the scope of AHRI 430.

Performance Climate Changer

1/17/2013

Coil section

Module Position:

9

Coil se [6]-1			
<u>Section type</u>	Horizontal coil	<u>Fluid type</u>	Water
<u>Unit size</u>	8	<u>Coil fluid percentage</u>	100.00 %
<u>Section size</u>	Extended medium	<u>Target valve pressure drop</u>	4.00 psig
<u>Coil application</u>	Cooling coil	<u>Coil type</u>	UW
<u>Changeover coil</u>	No	<u>Rows</u>	8 rows
<u>System type</u>	Chilled water	<u>Fin type</u>	Delta flo H (Hi efficient)
<u>Coil supply/cabinet side</u>	Right	<u>Fin material</u>	Aluminum fins
<u>Coil casing</u>	Galvanized	<u>Tube diameter</u>	1/2in. tube diameter (12.7 mm)
<u>Coil height</u>	Unit coil height	<u>Tube matl/wall thickness</u>	.016" (0.406mm) copper tubes
<u>Drain pan</u>	Stainless steel	<u>Corrosion resistant coating</u>	None
<u>Drain connection location</u>	Right	<u>Coil face velocity</u>	401 ft/min
<u>Design sequence</u>	D	<u>Air pressure drop</u>	0.758 in H2O
<u>Apply AHRI ranges</u>	Yes	<u>J trap dimension</u>	2.051 in
<u>Coil performance airflow</u>	3200 cfm	<u>H trap dimension</u>	4.101 in
<u>Coil elevation</u>	0.00 ft	<u>Leaving fluid temperature</u>	55.00 F
<u>Entering dry bulb</u>	95.00 F	<u>Fluid pressure drop</u>	8.85 ft H2O
<u>Entering wet bulb</u>	76.00 F	<u>Fluid volume</u>	7.12 gal
<u>Leaving dry bulb</u>	52.00 F	<u>Fluid velocity</u>	4.02 ft/s
<u>Leaving wet bulb</u>	51.90 F	<u>Coil face area</u>	7.99 sq ft
<u>Sensible capacity</u>	152.72 MBh	<u>Coil rigging weight</u>	167.8 lb
<u>Total capacity</u>	258.91 MBh	<u>Coil installed weight</u>	227.4 lb
<u>Fin spacing</u>	120 Per Foot	<u>Coil section pressure drop</u>	0.758 in H2O
<u>Entering fluid temperature</u>	45.00 F	<u>Section length</u>	19.000 in
<u>Fluid temperature rise</u>	10.00 F	<u>Section height</u>	41.250 in
<u>Standard fluid flow rate</u>	51.60 gpm	<u>Section width</u>	50.500 in
<u>Coil fouling factor</u>	0.00000 hr-sq ft-deg F/Btu	<u>Section weight</u>	469.8 lb

Access section

Module Position:

10

<u>Section type</u>	Access/blank/turning	<u>Design sequence</u>	B
<u>Unit size</u>	8	<u>Section length</u>	10.000 in
<u>Section size</u>	Small	<u>Section width</u>	50.500 in
<u>Front opening</u>	Full Face	<u>Section height</u>	41.250 in
<u>Back opening</u>	Full Face	<u>Section weight</u>	83.8 lb

Controls section

Module Position:

11

<u>Section type</u>	Starter/VFD only	<u>Design sequence</u>	B
<u>Unit size</u>	Unit size 8	<u>Section length</u>	24.500 in
<u>Starter/VFD</u>	Supply section	<u>Section width</u>	50.500 in
<u>NEMA application type</u>	Internal NEMA	<u>Section height</u>	41.250 in
<u>Supply fan high voltage door</u>	Right	<u>Section weight</u>	278.0 lb

Coil performance data is certified in accordance with AHRI standard 410. Propylene glycol and calcium chloride, or mixtures thereof, are not covered under the scope of AHRI 410.

Air-handling performance data is certified in accordance with AHRI standard 430. Air handlers with plenum fans and vertical draw-thru air handlers where the coil is mounted immediately below the fan section are not covered under the scope of AHRI 430.

Performance Climate Changer

1/17/2013

Access section

Module Position:

12

<u>Section type</u>	Access/blank/turning	<u>Design sequence</u>	B
<u>Unit size</u>	8	<u>Section length</u>	10.000 in
<u>Section size</u>	Small	<u>Section width</u>	50.500 in
<u>Front opening</u>	Full Face	<u>Section height</u>	41.250 in
<u>Back opening</u>	Full Face	<u>Section weight</u>	91.8 lb

Fan section


Module Position:

13

Fan sec [7]-1			
<u>Section type</u>	Fan	<u>Section weight</u>	787.6 lb
<u>Fan application</u>	Supply fan	<u>Static pressure origin</u>	Program calculated
<u>Unit size</u>	8	<u>Single or front discharge - 63 Hz</u>	91 dB
<u>Inlet location</u>	Back inlet	<u>Single or front discharge - 125 Hz</u>	90 dB
<u>Fan orientation</u>	Plenum fan	<u>Single or front discharge - 250 Hz</u>	77 dB
<u>Fan discharge</u>	Bottom front	<u>Single or front discharge - 500 Hz</u>	101 dB
<u>Access door location</u>	Right	<u>Single or front discharge - 1K Hz</u>	94 dB
<u>Drive location</u>	Right side drive	<u>Single or front discharge - 2K Hz</u>	93 dB
<u>Design sequence</u>	E	<u>Single or front discharge - 4K Hz</u>	84 dB
<u>Motor horsepower per fan</u>	7.5 hp	<u>Single or front discharge - 8K Hz</u>	79 dB
<u>NEMA nominal motor efficiency</u>	91.00 %	<u>Inlet and casing - 63 Hz</u>	94 dB
<u>Motor class</u>	NEMA premium compliant	<u>Inlet and casing - 125 Hz</u>	96 dB
	ODP		
<u>Motor voltage</u>	460/3	<u>Inlet and casing - 250 Hz</u>	75 dB
<u>Cycle</u>	60 cycles/sec	<u>Inlet and casing - 500 Hz</u>	91 dB
<u>Drive service factor</u>	1.5 fixed drive	<u>Inlet and casing - 1K Hz</u>	77 dB
<u>Motor RPM</u>	1800	<u>Inlet and casing - 2K Hz</u>	78 dB
<u>Marine light</u>	Marine LED light	<u>Inlet and casing - 4K Hz</u>	76 dB
<u>Fan airflow</u>	3200 cfm	<u>Inlet and casing - 8K Hz</u>	67 dB
<u>Overall ESP</u>	2.000 in H2O	<u>Ducted inlet - 63 Hz</u>	85 dB
<u>Unit entering ESP</u>	1.000 in H2O	<u>Ducted inlet - 125 Hz</u>	87 dB
<u>Unit discharge ESP</u>	1.000 in H2O	<u>Ducted inlet - 250 Hz</u>	70 dB
<u>Elevation</u>	0.00 ft	<u>Ducted inlet - 500 Hz</u>	87 dB
<u>Minimum temperature</u>	40.00 F	<u>Ducted inlet - 1K Hz</u>	73 dB
<u>Design temperature</u>	70.00 F	<u>Ducted inlet - 2K Hz</u>	76 dB
<u>Fan size and type</u>	14in. belt-drive plenum, class 1	<u>Ducted inlet - 4K Hz</u>	61 dB
<u>Plenum fan bottom discharge</u>	1st bottom rectangular opening	<u>Ducted inlet - 8K Hz</u>	51 dB
<u>Total brake horsepower</u>	3.913 hp	<u>Casing - 63 Hz</u>	86 dB
<u>Total brake horsepower at min temp</u>	4.148 hp	<u>Casing - 125 Hz</u>	82 dB
<u>Total static pressure</u>	3.850 in H2O	<u>Casing - 250 Hz</u>	68 dB
<u>Speed</u>	2876 rpm	<u>Casing - 500 Hz</u>	85 dB
<u>Fan module pressure drop</u>	2.180 in H2O	<u>Casing - 1K Hz</u>	77 dB
<u>Section height</u>	41.250 in	<u>Casing - 2K Hz</u>	63 dB
<u>Section length</u>	44.000 in	<u>Casing - 4K Hz</u>	55 dB
<u>Section width</u>	50.500 in	<u>Casing - 8K Hz</u>	52 dB

Coil performance data is certified in accordance with AHRI standard 410. Propylene glycol and calcium chloride, or mixtures thereof, are not covered under the scope of AHRI 410.

Air-handling performance data is certified in accordance with AHRI standard 430. Air handlers with plenum fans and vertical draw-thru air handlers where the coil is mounted immediately below the fan section are not covered under the scope of AHRI 430.



For maneuvering purposes, include 1.125 inches to each ship split length for overlapping panel flange. Flange will not add to overall installed unit length shown.


OPENING AND DIMENSIONS MAY VARY FROM CONTRACT DOCUMENTS / RETURN OF APPROVED DRAWINGS CONSTITUTES ACCEPTANCE OF THESE VARIANCES / NOT TO SCALE

Unit size: 8	Job Name: Miller Remick VA Lebanon Bldg 101 and Bldg 22	Unit Casing: 2in Double Wall
Product group: Outdoor unit	Actual airflow: 3200 cfm	Proposal Number:
Integral base frame: 6in. integral base frame	Sales Office: Philadelphia Main Office	Tags: AHU 22
Paint: Factory painted - slate gray		Rigging/Installed Weight: 3819.0 lb/ 4222.7 lb



TRANE

Performance Climate Changer™
Air Handlers




Overall Elevation View: Right - Shipping splits indicated by bold outline. - Measurements in inches

VFD

For maneuvering purposes, include 1.125 inches to each ship split length for overlapping panel flange. Flange will not add to overall installed unit length sh


Pos #	Module	Length	Weight	Module	Weight
1	Fan section	44	673.65	Roof Curb	344.15
2	Access section	10	83.78	Installed Unit Weight 4222.70 lbs	
3	Controls section	24 5/8	280.94		
4	Economizer section	48 1/8	350.99		
5	Filter section	26 1/2	236.75		
6	Access section	14 1/8	113.32		
7	Coil section	14 1/8	286.77		
8	Access section	14	141.46		
9	Coil section	19	469.77		
10	Access section	10	83.78		
11	Controls section	24 1/2	277.96		
12	Access section	10 1/8	91.76		
13	Fan section	44 1/8	787.63		



VFD




Basic Overall Plan View: Top - Measurements in inches


OPENING AND DIMENSIONS MAY VARY FROM CONTRACT DOCUMENTS / RETURN OF APPROVED DRAWINGS CONSTITUTES ACCEPTANCE OF THESE VARIANCES / NOT TO SCALE

Unit size: 8	Job Name: Miller Remick VA Lebanon Bldg 101 and Bldg 22	Unit Casing: 2in Double Wall	 TRANE® Performance Climate Changer™ Air Handlers
Product group: Outdoor unit	Actual airflow: 3200 cfm	Proposal Number:	
Integral base frame: 6in. integral base frame	Sales Office: Philadelphia Main Office	Tags: AHU 22	
Paint: Factory painted - slate gray		Rigging/Installed Weight: 3819.0 lb/ 4222.7 lb	




OPENING AND DIMENSIONS MAY VARY FROM CONTRACT DOCUMENTS / RETURN OF APPROVED DRAWINGS CONSTITUTES ACCEPTANCE OF THESE VARIANCES / NOT TO SCALE

Unit size: 8	Job Name: Miller Remick VA Lebanon Bldg 101 and Bldg 22	Unit Casing: 2in Double Wall	 TRANE® Performance Climate Changer™ Air Handlers
Product group: Outdoor unit	Actual airflow: 3200 cfm	Proposal Number:	
Integral base frame: 6in. integral base frame	Sales Office: Philadelphia Main Office	Tags: AHU 22	
Paint: Factory painted - slate gray		Rigging/Installed Weight: 3819.0 lb/ 4222.7 lb	




Detailed Elevation View: Right - Measurements in inches


VFD




Detailed Elevation View: Left - Measurements in inches

OPENING AND DIMENSIONS MAY VARY FROM CONTRACT DOCUMENTS / RETURN OF APPROVED DRAWINGS CONSTITUTES ACCEPTANCE OF THESE VARIANCES / NOT TO SCALE

Unit size: 8	Job Name: Miller Remick VA Lebanon Bldg 101 and Bldg 22	Unit Casing: 2in Double Wall	 TRANE® Performance Climate Changer™ Air Handlers
Product group: Outdoor unit	Actual airflow: 3200 cfm	Proposal Number:	
Integral base frame: 6in. integral base frame	Sales Office: Philadelphia Main Office	Tags: AHU 22	
Paint: Factory painted - slate gray		Rigging/Installed Weight: 3819.0 lb/ 4222.7 lb	





Detailed Elevation View: Front - Measurements in inches



Detailed Elevation View: Back - Measurements in inches

OPENING AND DIMENSIONS MAY VARY FROM CONTRACT DOCUMENTS / RETURN OF APPROVED DRAWINGS CONSTITUTES ACCEPTANCE OF THESE VARIANCES / NOT TO SCALE


Unit size: 8	Job Name: Miller Remick VA Lebanon Bldg 101 and Bldg 22	Unit Casing: 2in Double Wall	 TRANE® Performance Climate Changer™ Air Handlers
Product group: Outdoor unit	Actual airflow: 3200 cfm	Proposal Number:	
Integral base frame: 6in. integral base frame	Sales Office: Philadelphia Main Office	Tags: AHU 22	
Paint: Factory painted - slate gray		Rigging/Installed Weight: 3819.0 lb/ 4222.7 lb	




Coil connection view: Right - Measurements in inches

NPTI : National Pipe Thread Internal Connection
 NPTE : National Pipe Thread External Connection

OPENING AND DIMENSIONS MAY VARY FROM CONTRACT DOCUMENTS / RETURN OF APPROVED DRAWINGS CONSTITUTES ACCEPTANCE OF THESE VARIANCES / NOT TO SCALE


Unit size: 8	Job Name: Miller Remick VA Lebanon Bldg 101 and Bldg 22	Unit Casing: 2in Double Wall	 TRANE Performance Climate Changer™ Air Handlers
Product group: Outdoor unit	Actual airflow: 3200 cfm	Proposal Number:	
Integral base frame: 6in. integral base frame	Sales Office: Philadelphia Main Office	Tags: AHU 22	
Paint: Factory painted - slate gray		Rigging/Installed Weight: 3819.0 lb/ 4222.7 lb	



Coil connection view: Left - Measurements in inches

NPTI : National Pipe Thread Internal Connection
 NPTE : National Pipe Thread External Connection

OPENING AND DIMENSIONS MAY VARY FROM CONTRACT DOCUMENTS / RETURN OF APPROVED DRAWINGS CONSTITUTES ACCEPTANCE OF THESE VARIANCES / NOT TO SCALE

Unit size: 8	Job Name: Miller Remick VA Lebanon Bldg 101 and Bldg 22	Unit Casing: 2in Double Wall	 TRANE® Performance Climate Changer™ Air Handlers
Product group: Outdoor unit	Actual airflow: 3200 cfm	Proposal Number:	
Integral base frame: 6in. integral base frame	Sales Office: Philadelphia Main Office	Tags: AHU 22	
Paint: Factory painted - slate gray		Rigging/Installed Weight: 3819.0 lb/ 4222.7 lb	

Basic Unit with Controls

Single/Dual Duct Terminals



ESV

Available Models:

- | | |
|------|----------------------|
| PESV | • Pneumatic |
| EESV | • Electric |
| AESV | • Analog Electronic |
| DESV | • Digital Electronic |

- Standard AeroCross™ multi-point center averaging velocity sensor (except EESV).

- Standard dual density insulation.
- Standard 22-gauge casing with slip and drive discharge connection.
- Controls supplied by Titus are factory calibrated for a quicker start-up.



INLET SIZE	CFM RANGE	D	F		G	H	L	M	W
			PESV	AESV DESV EESV					
4	0-225	3 7/8	1 7/8	2 1/8	7 3/8	8	15 1/2	5 3/8	12
5	0-350	4 7/8	1 7/8	2 1/8	7 3/8	8	15 1/2	5 3/8	12
6	0-500	5 7/8	1 7/8	2 1/8	7 3/8	8	15 1/2	3 3/8	12
7	0-650	6 7/8	7/8	1 1/8	7 3/8	10	15 1/2	3 3/8	12
8	0-900	7 7/8	7/8	1 1/8	7 3/8	10	15 1/2	3 3/8	12
9	0-1050	8 7/8	-	-	5 3/8	12 1/2	15 1/2	3 3/8	14
10	0-1400	9 7/8	-	-	5 3/8	12 1/2	15 1/2	3 3/8	14
12	0-2000	11 7/8	-	-	5 3/8	15	15 1/2	3 3/8	16
14	0-3000	13 7/8	-	-	3 3/8	17 1/2	15 1/2	3 3/8	20
16	0-4000	15 7/8	-	-	3 3/8	18	15 1/2	3 3/8	24
24X16	0-8000	23 7/8 - 15 7/8	7/8	1 1/8	5 3/8	18	15	3 3/8	38

All dimensions are in inches.

ACCESSORIES

INTEGRAL SOUND ATTENUATOR

Titus' unique integral design minimizes casing leakage and disturbance to airflow with no casing or insulation seams.

INTEGRAL ELECTRIC COIL

With a rigid one piece assembly, Titus locates the heating elements for optimal heat transfer and insets them for protection during shipment and installation.

STANDARD FEATURES:

- Primary automatic reset thermal cutout (one per coil).
- Secondary manual reset thermal cutout.
- Airflow switch (differential pressure).
- Derated nickel chrome heating elements.
- Magnetic or safety contactors (as required).
- Line terminal block.
- Control terminal block.
- ETL listed.
- 80/20 nickel chrome element wire.

OPTIONAL FEATURES:





- Class II, 24 volt control transformer.
- Mercury contactors.
- Door interlock disconnect switch.
- Main supply fuses.
- Dust tight construction.
- Removable flow sensor.

HOT WATER REHEAT COILS

Details on water coil features are shown on performance pages M18-22.

INTEGRAL SOUND ATTENUATOR WITH OPTIONAL HOT WATER REHEAT COIL

Single/Dual Duct Terminals



INLET SIZE	H	M	W	WATER COIL	
				L (1-2 ROW)	L (3-4 ROW)
4, 5	8	$5\frac{3}{8}$	12	5	$7\frac{1}{4}$
6	8	$3\frac{3}{8}$	12	5	$7\frac{1}{4}$
7, 8	10	$3\frac{3}{8}$	12	5	$7\frac{1}{4}$
9, 10	$12\frac{1}{2}$	$3\frac{3}{8}$	14	5	$7\frac{1}{4}$
12	15	$3\frac{3}{8}$	16	5	$7\frac{1}{4}$
14	$17\frac{1}{2}$	$3\frac{3}{8}$	20	$7\frac{1}{2}$	$9\frac{3}{4}$
16	18	$3\frac{3}{8}$	24	$7\frac{1}{2}$	$9\frac{3}{4}$
24X16	18	$3\frac{3}{8}$	38	5	$7\frac{1}{4}$


Note: The total length of the ESV basic unit and accessories (attenuators and coils) is the summation of basic unit length and the accessories length.

All dimensions are in inches.



ACCESSORIES

Single/Dual Duct Terminals

REMOVABLE FLOW SENSOR



ESV WITH ACCESS DOOR OPTION



All dimensions are in inches.

PERFORMANCE DATA

Single/Dual Duct Terminals


RECOMMENDED PRIMARY AIR CFM RANGES / ALL TERMINALS

Control Types:

- | | |
|------|----------------------|
| PESV | • Pneumatic |
| AESV | • Analog Electronic |
| DESV | • Digital Electronic |

QUICK SELECTION PROCEDURE

1. Select unit inlet size based upon acoustic parameters and/or maximum pressure drop requirements, using pages M13.
2. Check inlet size selection against cfm control limits based on control type shown on this page.
3. Select accessories (multi-outlets, attenuators) as required.
4. Select reheat coil, if required. Make your selection using the actual heating flow rate, not cooling.



AESV

Inlet Size	Total cfm Range	cfm Ranges of Minimum and Maximum Settings							
		PESV - Pneumatic Titus II Controller		PESV - Pneumatic Titus I Controller		AESV - Analog Electronic TA1 Controller		DESV - Digital Typical Controller	
		Minimum	Maximum	Minimum	Maximum	MINIMUM	MAXIMUM	MINIMUM	MAXIMUM
4	0-225	45*-170	80-225	55*-170	80-225	45*-225	45-225	45*-225	45-225
5	0-350	65*-270	120-350	85*-270	120-350	65*-350	65-350	65*-350	65-350
6	0-500	80*-330	150-500	105*-330	150-500	80*-500	80-500	80*-500	80-500
7	0-650	105*-425	190-650	135*-425	190-650	105*-650	105-650	105*-650	105-650
8	0-900	145*-590	265-900	190*-590	265-900	145*-900	145-900	145*-900	145-900
9	0-1050	175*-700	315-1050	225*-700	315-1050	175*-1050	175-1050	175*-1050	175-1050
10	0-1400	230*-925	415-1400	300*-925	415-1400	230*-1400	230-1400	230*-1400	230-1400
12	0-2000	325*-1330	600-2000	425*-1330	600-2000	325*-2000	325-2000	325*-2000	325-2000
14	0-3000	450*-1800	810-3000	575*-1800	810-3000	450*-3000	450-3000	450*-3000	450-3000
16	0-4000	580*-2350	1100-4000	750*-2350	1100-4000	580*-4000	580-4000	580*-4000	580-4000
24X16	0-8000	1400*-5200	2600-8000	1800*-5200	2600-8000	1400*-7500	1400-7500	1400*-7500	1400-7500

*Factory cfm settings (except zero) will not be made below this range because control accuracy is reduced. On pressure dependent units, minimum cfm is always zero and there is no maximum.

Note: On controls mounted by Titus but supplied by others (FMA or Factory Mounting Authorization), these values are guidelines only. Controls mounted on an FMA basis are calibrated in the field.

PERFORMANCE DATA

Single/Dual Duct Terminals

PESV, AESV, DESV / RADIATED SOUND PERFORMANCE

Size	CFM	Min ΔPs	Octave Band Sound Power, Lw																											
			0.5" ΔPs							1.0" ΔPs							1.5" ΔPs							2.0" ΔPs						
			2	3	4	5	6	7	NC	2	3	4	5	6	7	NC	2	3	4	5	6	7	NC	2	3	4	5	6	7	NC
4	100	0.02	49	45	36	33	31	26	11	52	48	39	36	35	31	15	53	50	41	37	37	34	17	55	51	43	38	39	36	18
	125	0.03	52	49	39	36	32	27	16	55	52	42	38	36	32	20	57	54	44	39	39	36	22	58	55	45	41	40	38	23
	150	0.04	55	52	41	37	34	28	20	58	55	44	40	38	34	23	60	57	46	41	40	37	25	61	58	47	42	42	39	27
	175	0.06	58	55	42	39	35	29	23	61	58	46	42	39	34	27	63	59	48	43	41	38	28	64	61	49	44	43	40	30
	200	0.08	60	57	44	40	36	30	25	63	60	47	43	40	35	29	65	62	49	44	42	38	31	66	63	51	45	44	41	33
5	150	0.01	49	44	36	32	31	25	10	53	49	41	36	35	30	16	55	51	43	38	37	33	18	57	53	45	39	39	35	21
	200	0.02	53	48	39	35	34	27	15	56	53	44	38	37	32	21	59	55	46	40	40	35	23	60	57	48	42	41	37	25
	250	0.03	55	52	41	37	35	29	20	59	56	46	40	39	34	24	62	59	49	42	41	37	28	63	61	51	44	43	39	30
	300	0.04	58	54	43	39	37	30	22	62	59	48	42	41	35	28	64	61	50	44	43	38	30	65	63	52	45	44	40	33
	350	0.06	60	56	45	40	38	31	24	63	61	49	43	42	36	30	66	63	52	45	44	39	33	67	65	54	47	45	41	35
6	300	0.07	55	49	40	35	32	28	16	59	54	45	39	37	33	22	61	57	48	41	39	36	25	63	59	50	42	41	38	28
	350	0.10	57	52	42	37	34	29	20	60	57	47	41	38	34	25	62	59	50	43	40	37	28	64	62	52	44	42	39	31
	400	0.13	58	53	44	39	35	30	21	61	58	49	42	39	35	27	63	61	52	44	42	38	30	65	63	54	46	43	40	33
	450	0.16	59	55	45	40	36	31	23	62	60	50	44	40	36	29	64	63	53	46	43	39	33	66	65	55	47	45	41	35
	500	0.20	59	56	47	42	37	32	24	63	61	51	45	41	37	30	65	64	54	47	44	40	34	67	67	56	49	46	42	37
7	450	0.07	59	48	42	38	33	24	20	61	54	48	42	38	30	23	62	57	51	45	41	33	25	63	59	53	46	43	35	28
	500	0.09	60	50	43	39	34	24	22	62	55	49	43	39	30	24	63	58	52	46	42	34	27	64	60	54	48	44	36	29
	550	0.10	60	51	44	40	35	25	22	63	57	50	45	40	31	25	64	59	53	47	43	34	28	66	62	55	49	45	37	31
	600	0.12	61	53	45	42	35	25	23	63	58	51	46	41	31	27	65	61	54	48	44	35	30	66	63	56	50	46	37	33
	650	0.15	62	54	46	43	36	26	24	64	59	52	47	41	32	28	65	62	55	49	44	35	31	66	64	57	51	46	38	34
8	600	0.02	59	50	44	40	38	32	20	62	55	49	43	43	39	24	64	58	52	46	45	44	27	65	60	54	47	47	47	29
	650	0.02	60	51	44	41	39	32	22	63	56	50	44	44	40	25	65	59	53	47	46	45	28	66	61	55	48	48	48	30
	700	0.02	60	52	45	42	40	33	22	63	57	50	45	44	41	25	65	60	53	47	47	45	29	67	62	56	49	49	48	31
	750	0.02	61	53	46	43	40	34	23	64	58	51	46	45	41	27	66	61	54	48	48	46	30	67	63	56	50	50	49	33
	800	0.03	62	54	47	43	41	34	24	65	59	52	47	46	42	28	66	62	55	49	48	47	31	68	64	57	51	50	50	34
9	800	0.04	58	47	43	36	34	30	19	61	53	49	42	40	35	23	62	57	52	46	44	38	26	63	59	55	48	47	40	29
	850	0.04	58	48	43	37	34	31	19	61	54	49	43	41	35	23	63	58	53	46	45	38	27	64	60	55	49	47	40	29
	900	0.05	59	49	44	37	35	31	20	62	55	50	43	41	35	24	64	58	53	47	45	38	27	65	61	56	49	48	40	30
	950	0.06	59	50	44	37	35	31	20	62	56	50	43	42	36	24	64	59	54	47	45	38	28	65	62	56	49	48	40	31
	1000	0.06	60	50	44	38	36	31	22	63	56	50	44	42	36	25	65	60	54	47	46	39	29	66	62	57	50	48	40	31
10	900	0.01	60	50	47	45	42	29	22	63	57	53	50	48	37	27	65	60	57	53	52	41	31	67	63	59	56	54	44	34
	1000	0.01	60	51	48	46	43	30	22	64	58	54	51	49	38	28	66	61	57	54	53	42	31	67	64	59	56	55	45	34
	1100	0.01	61	52	48	47	44	32	23	65	58	54	52	50	39	28	67	62	57	55	54	43	31	68	64	60	57	56	46	35
	1200	0.01	62	53	48	47	45	32	24	65	59	54	53	51	40	28	67	63	58	56	55	44	33	69	65	60	58	57	47	35
	1300	0.01	63	54	49	48	45	33	25	66	60	55	53	52	41	29	68	63	58	56	55	45	33	69	66	61	58	58	48	36
12	1200	0.01	58	50	47	41	37	30	20	62	56	52	47	43	37	26	64	59	56	50	46	41	30	66	61	58	53	49	43	32
	1400	0.01	60	52	48	42	38	32	22	63	57	54	48	45	39	28	65	60	57	52	48	42	31	67	63	60	54	51	45	35
	1600	0.01	61	53	50	43	40	34	24	64	59	55	49	46	40	29	66	62	59	53	50	44	34	68	64	61	55	52	47	36
	1800	0.01	61	55	51	44	41	35	25	65	60	56	50	48	41	30	67	63	60	54	51	45	35	69	65	62	56	54	48	37
	2000	0.01	62	56	52	45	43	36	26	66	61	57	51	49	43	31	68	64	61	55	52	47	36	69	67	63	57	55	49	38
14	1500	0.02	56	51	45	43	40	36	18	60	56	50	48	45	41	24	62	59	53	51	48	45	28	64	61	55	53	50	47	30
	1800	0.03	58	53	46	44	41	36	21	62	58	51	49	46	42	27	64	60	54	52	49	45	29	66	63	56	54	51	48	33
	2100	0.04	59	54	47	45	42	37	22	63	59	52	50	47	43	28	66	62	55	53	50	46	31	67	64	58	55	52	49	34
	2400	0.05	60	55	48	46	43	38	23	64	60	53	51	48	43	29	67	63	56	54	51	47	33	69	65	58	56	53	49	35
	2700	0.06	62	56	49	47	44	38	24	66	61	54	52	49	44	30	68	64	57	55	52	47	34	70	66	59	57	54	50	36
16	2000	0.02	55	48	43	41	39	31	36	59	53	47	45	44	38	21	61	56	50	47	47	41	24	63	58	52	49	49	44	27
	2400	0.02	57	51	45	43	41	33	18	61	56	49	47	46	39	24	64	59	52	49	49	43	28	65	61	54	51	51	46	30
	2800	0.03	59	53	46	44	42	34	21	63	58	51	48	47	41	27	66	61	54	50	50	45	30	67	63	55	52	52	48	33
	3200	0.04	61	55	48	46	44	36	23	65	60	52	50	49	42	29	67	62	55	52	52	46	31	69	64	57	53	54	49	34
	3600	0.05	62	56	49	47	45	37	24	66	61	54	51	50	44	30	69	64	56	53	53	48	34	71	66	58	55	55	50	36
40	3900	0.03	70	65	63	59	57	54	38	72	68	66	62	61	58	41	74	69	67	63	63	61	42	75	70	68	64	65	63	43
	4600	0.04	73	68	66	62	59	55	41	75	71	68	64	63	60</															

PESV, AESV, DESV / DISCHARGE SOUND PERFORMANCE

Size	CFM	Min ΔPs	Octave Band Sound Power, Lw																											
			0.5" ΔPs							1.0" ΔPs							1.5" ΔPs							2.0" ΔPs						
			2	3	4	5	6	7	NC	2	3	4	5	6	7	NC	2	3	4	5	6	7	NC	2	3	4	5	6	7	NC
4	100	0.02	62	53	46	42	40	33	17	63	56	50	46	47	41	18	64	58	53	49	50	46	19	65	59	55	51	53	49	20
	125	0.03	64	57	49	44	42	35	19	65	60	53	49	49	43	20	66	61	56	52	52	47	22	67	62	58	54	55	51	23
	150	0.04	65	60	51	47	44	36	20	67	62	56	51	50	44	23	68	64	59	54	54	49	24	68	65	60	56	57	52	24
	175	0.06	67	62	53	48	45	37	23	68	65	58	53	51	45	24	69	66	61	56	55	50	25	70	68	63	58	58	53	28
	200	0.08	68	64	55	50	46	38	24	69	67	60	55	53	46	27	70	69	62	58	56	51	29	71	70	64	60	59	54	30
5	150	0.01	60	50	46	43	41	34	14	62	55	51	47	47	42	17	64	57	54	50	51	46	19	65	59	57	52	53	49	20
	200	0.02	63	54	49	46	43	36	18	65	58	55	51	49	44	20	67	61	58	53	53	48	23	68	63	60	55	55	51	24
	250	0.03	65	57	52	49	45	38	20	67	62	57	53	51	45	23	69	64	60	56	55	50	25	70	66	62	58	57	53	27
	300	0.04	66	59	54	51	47	39	18	69	64	59	55	53	46	22	70	67	62	58	56	51	25	71	69	65	60	59	54	28
	350	0.06	68	61	56	52	48	40	20	70	66	61	57	54	47	24	72	69	64	60	57	52	28	73	71	66	61	60	55	30
6	300	0.07	60	57	53	50	45	39	14	64	62	58	54	51	46	20	67	65	61	57	54	50	23	69	67	63	58	56	53	25
	350	0.10	61	59	54	52	47	40	16	66	64	60	56	52	47	22	68	67	63	59	55	51	25	70	69	65	60	58	54	28
	400	0.13	63	60	56	54	48	41	17	67	66	61	58	53	48	24	70	69	64	60	57	52	28	71	71	66	62	59	55	30
	450	0.16	64	62	57	55	49	42	20	68	67	63	59	54	49	25	71	70	66	62	58	53	29	73	73	68	63	60	56	33
	500	0.20	65	63	59	56	50	43	21	69	69	64	61	55	50	28	72	72	67	63	59	54	31	74	74	69	65	61	57	34
7	450	0.07	64	58	53	51	47	40	15	67	63	58	54	51	46	21	68	67	60	56	54	49	25	70	69	62	58	56	52	28
	500	0.09	64	59	54	52	48	40	16	67	65	59	56	52	47	23	69	68	62	58	55	50	27	70	71	63	59	57	53	30
	550	0.1	65	61	55	54	49	41	18	68	66	60	57	53	48	24	69	70	63	59	56	51	29	71	72	64	60	58	54	31
	600	0.12	65	62	56	55	49	42	20	68	67	61	58	54	48	25	70	71	63	60	57	52	30	71	73	65	61	59	55	33
	650	0.15	65	63	57	56	50	43	21	68	69	62	59	55	49	28	70	72	64	61	58	53	31	72	74	66	62	59	55	34
8	600	0.02	66	60	55	52	48	40	18	69	66	59	55	52	47	24	71	69	61	56	55	51	28	72	72	63	57	57	54	31
	650	0.02	67	61	56	53	48	41	19	70	67	60	56	53	47	25	71	70	62	57	55	51	29	72	73	64	58	57	54	33
	700	0.02	67	62	56	54	49	41	20	70	68	60	56	53	48	27	72	71	63	58	56	52	30	73	74	64	59	58	55	34
	750	0.02	68	63	57	54	49	42	20	70	69	61	57	54	48	27	72	72	63	58	56	52	30	73	75	65	60	58	55	34
	800	0.03	68	64	57	55	50	42	21	71	70	62	58	54	49	28	72	73	64	59	57	53	31	74	75	66	60	59	56	34
9	800	0.04	67	59	56	53	49	43	17	70	64	60	57	54	49	21	71	67	62	59	57	53	24	72	69	64	60	59	56	27
	850	0.04	68	60	56	53	49	43	18	70	65	60	57	54	50	22	72	68	62	59	57	54	25	73	70	64	61	59	56	28
	900	0.05	68	61	57	54	50	43	18	71	66	61	57	55	50	23	73	68	63	59	57	54	25	74	70	65	61	59	57	28
	950	0.06	69	61	57	54	50	44	19	72	66	61	58	55	50	23	73	69	63	60	58	54	27	74	71	65	61	60	57	29
	1000	0.06	69	62	58	55	50	44	19	72	67	61	58	55	50	24	74	70	64	60	58	54	28	75	72	65	62	60	57	30
10	900	0.01	69	60	57	55	50	44	19	71	65	61	59	55	50	22	72	68	64	61	58	54	25	73	71	66	63	61	57	29
	1000	0.01	70	61	58	56	50	44	20	72	66	62	60	56	51	23	73	69	65	62	59	55	27	74	72	67	64	61	57	30
	1100	0.01	70	61	58	57	51	45	20	73	67	63	61	56	51	24	74	70	65	63	60	55	28	75	72	67	65	62	58	30
	1200	0.01	71	62	59	57	52	45	22	73	68	63	61	57	52	25	75	71	66	64	60	56	29	76	73	68	66	63	59	31
	1300	0.01	72	63	60	58	52	46	23	74	68	64	62	58	53	25	75	72	67	65	61	56	30	76	74	68	66	63	59	33
12	1200	0.01	68	62	59	55	53	46	18	71	67	63	59	57	52	24	73	70	65	62	60	56	28	74	72	67	64	62	59	30
	1400	0.01	69	63	61	56	54	47	20	72	69	65	61	59	53	27	74	72	67	63	61	57	30	75	74	69	65	63	60	33
	1600	0.01	70	64	62	57	55	48	21	73	70	66	62	59	55	28	75	73	68	64	62	58	31	76	75	70	66	64	61	34
	1800	0.01	71	66	63	58	55	49	23	74	71	67	63	60	56	29	75	74	70	65	63	59	33	76	76	71	67	65	62	35
	2000	0.01	71	67	64	59	56	50	24	74	72	68	64	61	56	30	76	75	71	66	64	60	34	77	77	72	68	66	63	36
14	1500	0.02	65	56	56	53	50	44	14	68	62	61	59	57	53	18	70	66	63	62	62	59	23	72	68	65	65	65	62	25
	1800	0.03	66	58	58	53	50	44	15	69	64	62	59	58	53	21	71	67	65	63	62	59	24	73	70	67	65	65	63	28
	2100	0.04	67	59	59	54	51	44	17	70	65	64	60	58	54	22	72	68	66	63	63	59	25	74	71	68	66	66	63	29
	2400	0.05	68	60	60	54	51	44	18	71	66	65	60	59	54	23	73	69	68	64	63	59	27	74	72	69	66	66	63	30
	2700	0.06	68	61	61	54	51	45	18	72	67	66	61	59	54	24	74	70	69	64	63	60	28	75	73	70	67	66	63	31
16	2000	0.02	65	58	57	54	52	45	14	68	62	60	58	56	51	18	70	65	62	61	59	54	22	71	67	63	63	61	57	24
	2400	0.02	67	61	59	55	53	46	17	70	65	63	60	58	52	22	72	67	64	62	61	56	24	73	69	66	64	62	58	27
	2800	0.03	68	63	61	57	55	48	20	72	67	65	61	59	54	24	74	69	66	64	62	57	27	75	71	68	66	64	60	29
	3200	0.04	70	64	63	58	56	49	21	73	68	66	62	60	55	25	75	71	68	65	63	59	29	76	72	70	67	65	61	30
	3600	0.05	71	66	65	59	57	50	23	74	70	68	63	61	56	28	76	72	70	66	64	60	30	78	74	71	68	66	62	33
40	3900	0.03	74	69	66	62	61	56	27	79	74	71	67	67	62	33	82	77	74	69	70	66	36	84	79	76	71	72	68	34
	4600	0.04	75	70	67	63	63	58	28	80	76	73	68	68	64	35	83	79												

PESV, AESV, DESV / HOT WATER COIL CAPACITY, MBH / 1- AND 2-ROW

	Rows/ Circuits	gpm	Head Loss	Airflow, cfm								
				50	100	150	200	250	300	350	400	450
Sizes 4-5-6	One-Row Single Circuit	1.0	0.50	4.2	5.9	7.0	7.7	8.6	9.4	10.1	10.6	11.2
		2.0	1.69	4.4	6.3	7.5	8.3	9.4	10.3	11.1	11.8	12.5
		4.0	5.77	4.4	6.5	7.8	8.7	9.8	10.9	11.8	12.6	13.4
		5.0	8.59	4.5	6.5	7.8	8.8	9.9	11.0	11.9	12.8	13.6
		Airside Δ Ps		0.01	0.01	0.02	0.03	0.05	0.07	0.09	0.12	0.14
	Two-Row Multi- Circuit	1.0	0.24	5.3	8.6	11.0	12.9	14.4	15.6	16.7	17.6	18.4
		3.0	1.66	5.5	9.4	12.5	15.0	17.1	19.0	20.7	22.2	23.5
		5.0	4.06	5.6	9.6	12.8	15.5	17.9	19.9	21.8	23.5	25.0
		7.0	7.39	5.6	9.7	13.0	15.8	18.2	20.4	22.3	24.1	25.7
		Airside ΔPs		0.01	0.02	0.04	0.07	0.10	0.13	0.18	0.22	0.27
Sizes 7-8	One-Row Single Circuit	1.0	0.69	6.9	9.2	10.7	12.2	13.4	14.5	15.3	16.1	16.8
		2.0	2.34	7.2	9.9	11.7	13.6	15.1	16.4	17.6	18.6	19.5
		3.0	4.77	7.4	10.2	12.1	14.1	15.8	17.2	18.5	19.6	20.7
		4.0	7.96	7.4	10.3	12.3	14.4	16.1	17.7	19.0	20.2	21.3
		Airside ΔPs		0.01	0.02	0.04	0.07	0.10	0.14	0.19	0.24	0.30
	Two-Row Multi- Circuit	1.0	0.33	9.4	14.3	17.6	20.1	21.9	23.4	24.7	25.7	26.6
		3.0	2.32	10.1	16.5	21.2	25.0	28.1	30.8	33.1	35.1	37.0
		5.0	5.66	10.3	17.0	22.2	26.3	29.9	32.9	35.6	38.0	40.2
		7.0	10.28	10.3	17.2	22.6	27.0	30.7	34.0	36.9	39.5	41.8
		Airside ΔPs		0.01	0.04	0.08	0.13	0.20	0.27	0.36	0.46	0.56
Sizes 9-10	One-Row Multi- Circuit	2.0	0.68	11.7	13.8	15.3	17.0	18.5	19.8	21.0	22.0	23.0
		3.0	1.40	12.1	14.4	16.0	18.0	19.7	21.2	22.5	23.7	24.8
		5.0	3.41	12.5	15.0	16.7	18.9	20.8	22.4	23.9	25.3	26.6
		6.0	4.72	12.6	15.1	16.9	19.1	21.1	22.8	24.3	25.8	27.1
		Airside ΔPs		0.01	0.02	0.04	0.05	0.07	0.10	0.12	0.15	0.18
	Two-Row Multi- Circuit	2.0	0.65	17.4	22.4	26.3	29.5	32.1	34.4	36.3	38.1	39.6
		4.0	2.19	18.5	24.3	29.0	33.0	36.5	39.6	42.3	44.7	46.9
		6.0	4.43	18.8	25.0	30.1	34.5	38.3	41.7	44.8	47.6	50.1
		8.0	7.35	19.0	25.4	30.7	35.3	39.3	42.9	46.2	49.2	51.9
		Airside ΔPs		0.02	0.04	0.07	0.10	0.14	0.18	0.23	0.29	0.35
Size 12	One-Row Multi- Circuit	2.0	0.88	14.7	17.3	19.6	21.4	22.9	24.1	25.2	26.0	26.8
		3.0	1.81	16.4	19.9	23.0	25.7	28.0	29.9	31.5	32.9	34.2
		5.0	4.40	17.5	21.6	25.4	28.7	31.6	34.0	36.2	38.1	39.9
		6.0	6.08	17.9	22.3	26.3	29.9	33.0	35.8	38.2	40.3	42.3
		Airside ΔPs		0.01	0.03	0.06	0.09	0.12	0.17	0.21	0.27	0.33
	Two-Row Multi- Circuit	2.0	0.84	21.7	27.5	31.1	33.7	35.6	37.1	38.3	39.3	40.2
		4.0	2.79	26.0	35.7	42.8	48.5	53.0	56.9	60.2	63.1	65.6
		6.0	5.63	27.1	37.9	46.3	53.0	58.7	63.6	67.8	71.6	75.0
		8.0	9.33	27.6	39.0	47.9	55.3	61.6	67.0	71.8	76.1	79.9
		Airside ΔPs		0.02	0.06	0.11	0.16	0.23	0.32	0.41	0.51	0.62

ELECTRIC COILS

Single/Dual Duct Terminals

SELECTION AND CAPACITIES

Recommended Coil Selection Data

The table at the right describes the maximum recommended kW capacities and number of stages available for Titus single duct terminals.

To make a coil selection:

1. Check the desired kW is available in desired unit size and number of stages. (Required to prevent excessive watt density and current draw, while taking into account unit size limitations.)
2. Check the desired minimum airflow limit is within recommended operating range. (Ensures velocity pressure will be sufficient to close airflow sensing switch.)
3. Multiply desired minimum airflow limit by a factor of 0.0142 and check the result is equal to or greater than desired kW. (Limits temperature rise across the coil to 45°F.)

$$\text{kW} \leq \text{cfm} \times 0.0142$$

These requirements established to prevent excessive temperature rise caused by low airflow and/or oversized coils. Minimum airflow limits must be within recommended ranges to ensure proper operation and long service life. For optimum diffuser performance and maximum thermal comfort, coil discharge temperatures should not be more than 15°F above desired room temperatures. For proper coil operation it is recommended that coil discharge temperatures do not to exceed 100°F.



PESV, AESV, DESV / APPLICATION DATA (LYNERGY HEAT)

Inlet Size	Heating cfm Range	208V 1 Phase kW Range		240V 1 Phase kW Range		277V 1 Phase kW Range		208V 3 Phase kW Range		480V 3 Phase kW Range	
		Min	Max	Min	Max	Min	Max	Min	Max	Min	Max
4	55-225	0.5	3.0	1.0	3.0	1.0	3.0	1.5	3.0	2.5	3.0
5	85-350	0.5	5.0	1.0	5.0	1.0	5.0	1.5	5.0	2.5	5.0
6	105-500	0.5	7.5	1.0	7.5	1.0	7.5	1.5	7.5	2.5	7.5
7	135-650	0.5	9.5	1.0	9.5	1.0	9.5	1.5	9.5	2.5	9.5
8	190-900	0.5	9.5	1.0	11.0	1.0	13.0	1.5	10.5	2.5	13.0
9	225-1050	0.5	9.5	1.0	11.0	1.0	13.0	1.5	10.5	2.5	16.0
10	300-1400	0.5	9.5	1.0	11.0	1.0	13.0	1.5	10.5	2.5	21.0
12	425-2000	0.5	9.5	1.0	11.0	1.0	13.0	1.5	10.5	2.5	25.0
14	575-3000	1.0	9.5	1.0	11.0	1.5	13.0	1.5	10.5	3.0	25.0
16	750-4000	1.0	9.5	1.0	11.0	1.5	13.0	1.5	10.5	3.0	25.0
24x16	1800-8000	1.0	9.5	1.0	11.0	1.5	13.0	1.5	10.5	4.0	25.0

Note: The Titus 480V, 3-phase electric heat configuration is 4-wire wye. Contact your Titus representative for other configuration options.

Useful formulas:

$$\text{kW} = \frac{\text{cfm} \times \Delta T}{3160} \quad \text{or} \quad \Delta T = \frac{\text{kW} \times 3160}{\text{cfm}} \quad \text{or} \quad \text{cfm} = \frac{\text{kW} \times 3160}{\Delta T}$$

Where ΔT = air temperature rise.

APPENDIX D

HAZARDOUS MATERIALS

HOMOGENEOUS AREAS

REPORT DATE: 9/6/2010

ASBESTOS CONTENT: C - Chrysotile, A - Amosite, CR - Crocidolite, TR - Tremolite, AC - Actinolite, AN - Anthophyllite, ASMD - Assumed, NAD - None Detected

Building Number: 022

Client Number: 100152

Building Name: Building 22 - Education Building

Client Name: Lebanon VA Medical Center

HOMO AREA	MATERIAL	LOCATION	APPROX AMOUNT	CLASSIFICATION	FRIABILITY	ASBESTOS CONTENT	SAMPLE NUMBERS	INSPECTION DATE
01	Pipe Insulation	1st Floor Kitchen Storage Room	25 Lineal Feet	THERMAL SYSTEM INSULATION	FRIABLE	Assumed	-	8/19/2010
02	Pipe Fitting Insulation	1st Floor Kitchen Storage Room	8 Fittings	THERMAL SYSTEM INSULATION	FRIABLE	Assumed	-	8/19/2010
03	Transite Wall Panels	3rd Floor Mechanical Chase	50 Square Feet	MISCELLANEOUS MATERIAL	NON-FRIABLE	Assumed	-	8/19/2010
04	9x9 Floor Tile	1st Floor Storage Room	220 Square Feet	MISCELLANEOUS MATERIAL	NON-FRIABLE	Assumed	-	8/19/2010
05	9x9 Floor Tile Mastic	1st Floor Storage Room	220 Square Feet	MISCELLANEOUS MATERIAL	NON-FRIABLE	Assumed	-	8/19/2010

HOMOGENEOUS AREAS

REPORT DATE: 9/5/2010

ASBESTOS CONTENT: C - Chrysotile, A - Amosite, CR - Crocidolite, TR - Tremolite, AC - Actinolite, AN - Anthophyllite, ASMD - Assumed, NAD - None Detected

Building Number: 019

Client Number: 100152

Building Name: Building 19- Office Building


Client Name: Lebanon VA Medical Center

HOMO AREA	MATERIAL	LOCATION	APPROX AMOUNT	CLASSIFICATION	FRIABILITY	ASBESTOS CONTENT	SAMPLE NUMBERS	INSPECTION DATE
01	Pipe Insulation	1st Floor Storage Closet & 3rd Floor Pipe Chase Area	25 Lineal Feet	THERMAL SYSTEM INSULATION	FRIABLE	Assumed	-	8/19/2010
02	Pipe Fitting Insulation	1st Floor Storage Closet & 3rd Floor Pipe Chase Areas	5 Fittings	THERMAL SYSTEM INSULATION	FRIABLE	Assumed	-	8/19/2010
03	9"x9" Floor Tile (Miscellaneous Colors)	Miscellaneous Areas Throughout Building	9900 Square Feet	MISCELLANEOUS MATERIAL	NON-FRIABLE	Assumed	-	8/19/2010
04	Floor Tile Mastic (Under 9x9 Floor Tile)	1st Floor Offices 136A & 137A	10200 Square Feet	MISCELLANEOUS MATERIAL	NON-FRIABLE	Assumed	-	8/19/2010

ASBESTOS HAZARD ASSESSMENT REPORT

IMPROVE EMERGENCY CACHE

VAMC LEBANON, PA



CONTRACT NO. VA24412R0058
PROJECT NO. 595-11-127

Prepared for:

Department of Veterans Affairs Medical Center
Lebanon, PA

Prepared By:

Environmental Solutions Group, Inc.
4142 Ogletown-Stanton Road, Suite 226
Newark, DE 19713



August 2012

1.0 INTRODUCTION

Environmental Solutions Group, Inc. (ESG) was contracted by Miller-Remick, LLC to provide asbestos investigation and abatement oversight services in connection with Contract No. VA244-12-R-0058, Project No. 595-11-127, Improve Emergency Cache. This project involves renovations in portions of two buildings. The two buildings are building 19, having approximately 6,600 square feet of space and building 22, having approximately 14,000 square feet of space.

Specific SOW items that deal with these services are:

- Review VA-provided sampling data and interview station personnel regarding asbestos containing materials
- Perform a visual site inspection and collect potential bulk samples as per USEPA guidance
- Have potential samples analyzed using USEPA-approved analysis
- Prepare an Assessment Report that identifies the types and location of ACM found
- Provide quantity and cost estimates for all asbestos to be abated
- Provide CAD drawings showing critical sample locations and containment to be constructed during abatement
- Prepare Asbestos Abatement Specifications using the VA Master Specifications
- Assist the VA in selection of an ACM abatement Company
- Provide construction period services

2.0 SCOPE OF WORK

As part of contractual requirements described in Section One, this report describes:

1. The methodology used for the collection of potential ACM samples within the spaces in the project area
2. The results of ACM laboratory analyses of the collected samples
3. A description of the impacted areas within the project area
4. A summary of the amount of ACM in each impacted space
5. An estimate of the cost for ACM abatement

2.1 ACM Bulk Sampling

Potential ACM samples were collected in accordance with USEPA guidelines and by a Pennsylvania-AHERA certified technician. Once homogeneous materials are identified, the USEPA recommends the following sampling from these materials:

- three (3) samples from less than 1,000 square feet
- five (5) samples from 1,000 to 5,000 square feet
- seven (7) samples from greater than 5,000 square feet
- three (3) samples from homogeneous thermal materials
- at least one sample from miscellaneous materials

If it is determined that additional potential ACM samples must be collected, they will be collected in accordance with 40 CFR Part 61, National Emission Standards for Hazardous Air Pollutants; (HESHAPS) Asbestos.

2.2 Segregation of the Project Area

There were minimal historical ACM sampling data available, therefore the entire project area was sampled for potential ACM using USEPA guidelines. However, ESG representatives did not perform destructive sampling.

In building 19, eight (8) different Homogeneous Areas (suspect ACM) were identified and in building 22, fourteen (14) were identified. A total of forty seven (47) bulk samples were collected from various building materials in the two buildings. Figures (not to scale) showing the sampling locations are included in Attachment A, and the Homogeneous Identification Reports are shown in Attachment B.

3.0 ASBESTOS CONTAINING MATERIAL SAMPLING ANALYSIS

A total of forty seven (47) potential ACM samples were collected during the July 2012, site visit and sampling event. The sample Chain of Custody and Laboratory Analytical Data is included in Attachment C. These samples were transported to a NVLAP qualified laboratory for analysis. USEPA Analysis Method EPA: 600/M4-82-020 was used to analyze the samples. By definition, any material containing more than 1% by volume of asbestos fibers is classified as ACM and has been included for abatement. The Certificate of Analysis for the samples is included in Attachment D.

Asbestos insulated pipes may exist within wall cavities specifically in bathroom, kitchen and heater pipe riser areas. Wall block demolition will be needed to access these areas.

3.1 Homogeneous Identification Reports

The Homogeneous Identification Report (HIR) shows the homogeneous identification, corresponding room number, the type of potential ACM sampled, the percent of asbestos in the sample (if any) and the amount of each material in square feet (sf) or linear feet (lf).

3.2 Chain of Custody and Laboratory Data

The Chain of Custody includes the sample number for each sample, the homogeneous area of the sample, and whether the sample was analyzed as positive (>1%) asbestos fibers.

4.0 QUANTITIES TO BE ABATED

A total of forty seven (47) samples were collected as part of this investigation and the quantities of materials which have greater than 1% asbestos are shown in the table below.

	Building No. 19	
Homogeneous Area	Description	Length/Volume
C2-1	Floor Tile, 9X9", black w/off white & green swirls	64 sf

Notes:

sf= square feet

6.0 PRELIMINARY ABATEMENT SCHEDULE

6.1 Pre-Abatement Activities


Asbestos Containing Material abatement cannot proceed until each area is prepared for abatement activities. This means that all stored or other materials are removed from each abatement area and wherever necessary and temporary lighting is installed.

6.2 Building Sub-Systems Impact

Since the only building system to be abated is the floor tile in Room 132A of Building 19, the abatement is not anticipated to impact any other building systems.

ATTACHMENT A
FIGURES WITH SAMPLE LOCATIONS

FIRST FLOOR PLAN / SAMPLE LOCATION MAP




Drawing Not to Scale - For Reference Only

The floor plan shows the second floor of a building. The central feature is a large rectangular area labeled "BOARDING ALLEY 109". To the left of this area is a "CORRIDOR 116" and a "STAIR HALL NO. 2 105". To the right is a "CORRIDOR 122" and a "DOWN STAIR HALL NO. 3 110". Below the boarding alley is a "LOBBY 110" with an "ELEVATOR" and "STAIR HALL NO. 1 117". To the left of the lobby are "VISITOR'S TOILET WOMEN 103", "ENTRY 102", "CLUBSET 102", and "CLOSET 116". To the right of the lobby are "VISITOR'S TOILET WOMEN 112", "ENTRY 114", "PATENTS TOILET WOMEN 114", and "STORAGE 113". The plan also includes a "CAGE ROOM 114" and a "SUPERVISOR OFFICE 112A". Callouts point to various areas: B22-01, 02, 03, 04 (top right); B22-07, 07M, 08, 08M (top center); B22-05 (top right); B22-06 (left side); B22-16, 17, 17M (bottom left); B22-15, 18, 18M (bottom left); B22-14 (bottom center); B22-09, 09M, 10, 10M, 11, 12 (bottom center); B22-13 (bottom right); and B22-19, 20 (bottom right).

Drawing Not to Scale - For Reference Only

BASEMENT FLOOR PLAN / SAMPLE LOCATION MAP



Drawing Not to Scale - For Reference Only

ATTACHMENT B
HOMOGENEOUS AREA IDENTIFICATION

HOMOGENEOUS AREA IDENTIFICATION

[illegible]

LEGEND: F—FRIABLE NF—NON-FRIABLE POS—TESTED/ASSUMED POSITIVE
grv — GRAVIMETRIC SAMPLE

HOMOGENEOUS AREA IDENTIFICATION

[illegible]

LEGEND: F—FRIABLE NF—NON-FRIABLE POS—TESTED/ASSUMED POSITIVE
grv — GRAVIMETRIC SAMPLE

ATTACHMENT C
CHAIN OF CUSTODY
AND
ANALYTICAL DATA

CHAIN OF CUSTODY

JOB NUMBER 12-036-1

LABORATORY: NAME

EMSL Analytical, Inc.

LAB # 101048-0

ANALYSIS: ☒ PLM ☐ SEM

SAMPLES COLLECTED BY (Signature)

Christa Krown

#035177

SAMPLES DISPATCHED TO LAB BY

EAA

DATE 07/19/12 TIME 1720

SAMPLES RECEIVED BY

EMSL Analytical, Inc.

DATE 07/20/12 TIME 0940

SAMPLES ANALYSIS BY

C. Walker / N. Stalter

DATE 07/20/12 TIME 1915

ANALYSIS RESULTS TO

EAA

DATE 07/20/12 TIME 0810

SAMPLES STORED BY

EMSL Analytical, Inc.

DATE 07/20/12 TIME 0830

BULK SAMPLE LOG

SAMPLE #	HOMOGENEOUS AREA I. D.	FUNCTIONAL SPACE	SAMPLE LOCATION	FRIABLE		ASBESTOS	
				Yes	No	Yes	No
B19-01	C1-1	132A1	Ceiling	X			X
B19-02	C1-1	131L	Ceiling	X			X
B19-03	C3-1	132A1	Wall	X			X
B19-04	C3-1	131L	Wall	X			X
B19-05	C3-2	132	Cove base		X		X
B19-05M	C3-2M	132	Cove base		X		X
B19-06	C3-2	131L	Cove base		X		X
B19-06M	C3-2M	131L	Cove base		X		X
B19-07	A5-1S	132A1	Above window	X			X
B19-08	A5-1S	132A1	Above window	X			X
B19-09	A5-1S	132A1	Above window	X			X
B19-10	A5-1R	132A1	Above window		X		X
B19-11	A5-1R	132A1	Above window		X		X
B19-12	A5-1R	132A1	Above window		X		X
B19-13	C2-1	132A	Floor		X	X	
B19-13M	C2-1M	132A	Floor		X		X
B19-14	C2-1	132A	Floor		X	X	
B19-14M	C2-1M	132A	Floor		X		X

**EMSL Analytical, Inc.**

200 Route 130 North, Cinnaminson, NJ 08077

Phone/Fax: (800) 220-3675 / (856) 786-5974

<http://www.emsl.com>cinnaslab@EMSL.com

EMSL Order: 041219103

CustomerID: ENV55

CustomerPO: CK #10915

ProjectID:

Attn: **Christa Knorr**
Environmental Abatement Associates, Inc.
143 West Main Street

Plymouth, PA 18651

Phone: (570) 779-4242
 Fax: (570) 779-0929
 Received: 07/20/12 9:40 AM
 Analysis Date: 7/20/2012
 Collected: 7/18/2012

Project: 12-036-1/ Lebanon VA Medical Center-Bldg 19 Improve Emergency Cache

Test Report: Asbestos Analysis of Bulk Materials via EPA 600/R-93/116 and/or EPA 600/M4-82-020 Method(s) using Polarized Light Microscopy

Sample	Description	Appearance	Non-Asbestos		Asbestos
			% Fibrous	% Non-Fibrous	% Type
B19-01 041219103-0001	132A1 - ceiling tile	Gray/White Fibrous Heterogeneous	45% Cellulose 35% Min. Wool	20% Non-fibrous (other)	None Detected
B19-02 041219103-0002	131L - ceiling tile	Gray/White Fibrous Heterogeneous	45% Cellulose 35% Min. Wool	20% Non-fibrous (other)	None Detected
B19-03 041219103-0003	132A1 - drywall	Brown/White Fibrous Heterogeneous	15% Cellulose	85% Non-fibrous (other)	None Detected
B19-04 041219103-0004	131L - drywall	Brown/White Fibrous Heterogeneous	15% Cellulose	85% Non-fibrous (other)	None Detected
B19-05-Cove Base 041219103-0005	132 - covebase	Brown Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B19-05-Mastic 041219103-0005A	132 - covebase	Beige Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B19-06-Cove Base 041219103-0006	131L - covebase	Brown Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B19-06-Mastic 041219103-0006A	131L - covebase	Beige Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected

Analyst(s)

Christina Walker (10)
 Nancy Stalker (8)

Stephen Siegel, CIH, Laboratory Manager
 or other approved signatory

EMSL maintains liability limited to cost of analysis. This report relates only to the samples reported and may not be reproduced, except in full, without written approval by EMSL. EMSL bears no responsibility for sample collection activities or analytical method limitations. Interpretation and use of test results are the responsibility of the client. This report must not be used by the client to claim product certification, approval, or endorsement by NVLAP, NIST or any agency of the federal government. Non-friable organically bound materials present a problem matrix and therefore EMSL recommends gravimetric reduction prior to analysis. Samples received in good condition unless otherwise noted. Estimated accuracy, precision and uncertainty data available upon request. Unless requested by the client, building materials manufactured with multiple layers (i.e. linoleum, wallboard, etc.) are reported as a single sample.

Samples analyzed by EMSL Analytical, Inc. Cinnaminson, NJ NVLAP Lab Code 101048-0, AIHA-LAP, LLC-IHLAP Lab 100194, NYS ELAP 10872, NJ DEP 03036

Initial report from 07/20/2012 23:43:42

**EMSL Analytical, Inc.**

200 Route 130 North, Cinnaminson, NJ 08077

Phone/Fax: (800) 220-3675 / (856) 786-5974

<http://www.emsl.com>cinnasblab@EMSL.com

EMSL Order: 041219103

CustomerID: ENVA55

CustomerPO: CK #10915

ProjectID:

Attn: **Christa Knorr**
Environmental Abatement Associates, Inc.
143 West Main Street

Plymouth, PA 18651

Phone: (570) 779-4242
Fax: (570) 779-0929
Received: 07/20/12 9:40 AM
Analysis Date: 7/20/2012
Collected: 7/18/2012

Project: 12-036-1/ Lebanon VA Medical Center-Bldg 19 Improve Emergency Cache

Test Report: Asbestos Analysis of Bulk Materials via EPA 600/R-93/116 and/or EPA 600/M4-82-020 Method(s) using Polarized Light Microscopy

Sample	Description	Appearance	Non-Asbestos		Asbestos
			% Fibrous	% Non-Fibrous	% Type
B19-07 041219103-0007	132A1 - skim coat plaster	White Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B19-08 041219103-0008	132A1 - skim coat plaster	White Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B19-09 041219103-0009	132A1 - skim coat plaster	White Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B19-10 041219103-0010	132A1 - rough coat plaster	Tan Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B19-11 041219103-0011	132A1 - rough coat plaster	Tan Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B19-12 041219103-0012	132A1 - rough coat plaster	Tan Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B19-13-Floor Tile 041219103-0013	132A - floor tile	Black Non-Fibrous Heterogeneous		95% Non-fibrous (other)	5% Chrysotile
B19-13-Mastic 041219103-0013A	132A - floor tile	Black Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected

Analyst(s)

Christina Walker (10)

Nancy Stalter (8)

Stephen Siegel, CIH, Laboratory Manager
or other approved signatory

EMSL maintains liability limited to cost of analysis. This report relates only to the samples reported and may not be reproduced, except in full, without written approval by EMSL. EMSL bears no responsibility for sample collection activities or analytical method limitations. Interpretation and use of test results are the responsibility of the client. This report must not be used by the client to claim product certification, approval, or endorsement by NVLAP, NIST or any agency of the federal government. Non-friable organically bound materials present a problem matrix and therefore EMSL recommends gravimetric reduction prior to analysis. Samples received in good condition unless otherwise noted. Estimated accuracy, precision and uncertainty data available upon request. Unless requested by the client, building materials manufactured with multiple layers (i.e. linoleum, wallboard, etc.) are reported as a single sample.

Samples analyzed by EMSL Analytical, Inc. Cinnaminson, NJ NVLAP Lab Code 101048-0, AIHA-LAP, LLC-IHLAP Lab 100194, NYS ELAP 10872, NJ DEP 03036

Initial report from 07/20/2012 23:43:42

**EMSL Analytical, Inc.**

200 Route 130 North, Cinnaminson, NJ 08077

Phone/Fax: (800) 220-3675 / (856) 786-5974

<http://www.emsl.com>cinnasbiab@EMSL.com

EMSL Order: 041219103

CustomerID: ENVA55

CustomerPO: CK #10915

ProjectID:

Attn: **Christa Knorr**
Environmental Abatement Associates, Inc.
143 West Main Street

Plymouth, PA 18651

Phone: (570) 779-4242
Fax: (570) 779-0929
Received: 07/20/12 9:40 AM
Analysis Date: 7/20/2012
Collected: 7/18/2012

Project: 12-036-1/ Lebanon VA Medical Center-Bldg 19 Improve Emergency Cache

**Test Report: Asbestos Analysis of Bulk Materials via EPA 600/R-93/116 and/or EPA
600/M4-82-020 Method(s) using Polarized Light Microscopy**

Sample	Description	Appearance	Non-Asbestos		Asbestos
			% Fibrous	% Non-Fibrous	% Type
B19-14-Floor Tile 041219103-0014	132A - floor tile	Black Fibrous Heterogeneous		95% Non-fibrous (other)	5% Chrysotile
B19-14-Mastic 041219103-0014A	132A - floor tile	Black Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected

Analyst(s)

Christina Walker (10)

Nancy Stalter (8)

Stephen Siegel, CIH, Laboratory Manager
or other approved signatory

EMSL maintains liability limited to cost of analysis. This report relates only to the samples reported and may not be reproduced, except in full, without written approval by EMSL. EMSL bears no responsibility for sample collection activities or analytical method limitations. Interpretation and use of test results are the responsibility of the client. This report must not be used by the client to claim product certification, approval, or endorsement by NVLAP, NIST or any agency of the federal government. Non-friable organically bound materials present a problem matrix and therefore EMSL recommends gravimetric reduction prior to analysis. Samples received in good condition unless otherwise noted. Estimated accuracy, precision and uncertainty data available upon request. Unless requested by the client, building materials manufactured with multiple layers (i.e. linoleum, wallboard, etc.) are reported as a single sample.

Samples analyzed by EMSL Analytical, Inc. Cinnaminson, NJ NVLAP Lab Code 101048-0, AIHA-LAP, LLC-IHLAP Lab 100194, NYS ELAP 10872, NJ DEP 03036

Initial report from 07/20/2012 23:43:42

CHAIN OF CUSTODY

JOB NUMBER 12-036-1

LABORATORY: NAME EMSL Analytical, Inc.

LAB # 101048-0

ANALYSIS: ☒ PLM ☐ SEM

SAMPLES COLLECTED BY (Signature) Christa Krown

#035177

SAMPLES DISPATCHED TO LAB BY EAA DATE 07/19/12 TIME 1720

SAMPLES RECEIVED BY EMSL Analytical, Inc. DATE 07/20/12 TIME 0940

SAMPLES ANALYSIS BY C. Walker / N. Stalter DATE 07/20/12 TIME 1600

ANALYSIS RESULTS TO EAA DATE 07/21/12 TIME 0805

SAMPLES STORED BY EMSL Analytical, Inc. DATE 07/21/12 TIME 0830

BULK SAMPLE LOG

SAMPLE #	HOMOGENEOUS AREA I. D.	FUNCTIONAL SPACE	SAMPLE LOCATION	FRIABLE		ASBESTOS	
				Yes	No	Yes	No
B22-01	C2-1	109 – Maintenance Storage	Floor		X		X
B22-02	C2-1	109 – Maintenance Storage	Floor		X		X
B22-03	C2-1M	109 – Maintenance Storage	Floor		X		X
B22-04	C2-1M	109 – Maintenance Storage	Floor		X		X
B22-05	C1-1	109 – Bowling Alleys	Ceiling	X			X
B22-06	C1-1	109 – Bowling Alleys	Ceiling	X			X
B22-07	C3-1	109 – Bowling Alleys	Cove base		X		X
B22-07M	C3-1M	109 – Bowling Alleys	Cove base		X		X
B22-08	C3-1	109 – Bowling Alleys	Cove base		X		X
B22-08M	C3-1M	109 – Bowling Alleys	Cove base		X		X
B22-09	C2-2	Lobby 118	Floor		X		X
B22-09M	C2-M	Lobby 118	Floor		X		X
B22-10	C2-2	Lobby 118	Floor		X		X
B22-10M	C2-M	Lobby 118	Floor		X		X
B22-11	C2-3	Lobby 118	Floor		X		X
B22-12	C2-3	Lobby 118	Floor		X		X
B22-13	C1-2	Corridor 121	Ceiling	X			X
B22-14	C1-2	Lobby 118	Ceiling	X			X
B22-15	C3-2	Lobby 118	Wall		X		X
B22-16	C3-2	Corridor 121	Wall		X		X

**LEBANON VA MEDICAL CENTER
BUILDING 22 – IMPROVE EMERGENCY CACHE**

ACM Page 2 of 2

**EMSL Analytical, Inc.**

200 Route 130 North, Cinnaminson, NJ 08077

Phone/Fax: (800) 220-3675 / (856) 786-5974

<http://www.emsl.com>cinnaslab@EMSL.com

EMSL Order: 041219104
 CustomerID: ENV55
 CustomerPO: CK #10915
 ProjectID:

Attn: **Christa Knorr**
Environmental Abatement Associates, Inc.
143 West Main Street

Plymouth, PA 18651

Phone: (570) 779-4242
 Fax: (570) 779-0929
 Received: 07/20/12 9:40 AM
 Analysis Date: 7/20/2012
 Collected: 7/18/2012

Project: **12-036-1/ Lebanon VA Medical Center-Bldg 22 Improve Emergency Cache**

Test Report: Asbestos Analysis of Bulk Materials via EPA 600/R-93/116 and/or EPA 600/M4-82-020 Method(s) using Polarized Light Microscopy

Sample	Description	Appearance	Non-Asbestos		Asbestos
			% Fibrous	% Non-Fibrous	% Type
B22-01 041219104-0001	109 maintenance storage - floor tile	Gray Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
Recommend TEM					
B22-02 041219104-0002	109 maintenance storage - floor tile	Gray Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
Recommend TEM					
B22-03 041219104-0003	109 maintenance storage - floor tile mastic	Yellow Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B22-04 041219104-0004	109 maintenance storage - floor tile mastic	Yellow Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B22-05 041219104-0005	109 bowling alleys - ceiling tile	Gray/White Fibrous Heterogeneous	45% Cellulose 35% Min. Wool	20% Non-fibrous (other)	None Detected
B22-06 041219104-0006	109 bowling alleys - ceiling tile	Gray/White Non-Fibrous Heterogeneous	45% Cellulose 35% Min. Wool	20% Non-fibrous (other)	None Detected
B22-07-Cove Base 041219104-0007	109 bowling alleys - covebase	Beige Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B22-07-Mastic 041219104-0007A	109 bowling alleys - covebase	Yellow Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected

Analyst(s)

Christina Walker (15)

Nancy Stalker (14)

Stephen Siegel, CIH, Laboratory Manager
or other approved signatory

EMSL maintains liability limited to cost of analysis. This report relates only to the samples reported and may not be reproduced, except in full, without written approval by EMSL. EMSL bears no responsibility for sample collection activities or analytical method limitations. Interpretation and use of test results are the responsibility of the client. This report must not be used by the client to claim product certification, approval, or endorsement by NVLAP, NIST or any agency of the federal government. Non-friable organically bound materials present a problem matrix and therefore EMSL recommends gravimetric reduction prior to analysis. Samples received in good condition unless otherwise noted. Estimated accuracy, precision and uncertainty data available upon request. Unless requested by the client, building materials manufactured with multiple layers (i.e. linoleum, wallboard, etc.) are reported as a single sample.

Samples analyzed by EMSL Analytical, Inc. Cinnaminson, NJ NVLAP Lab Code 101048-0, AIHA-LAP, LLC-IHLAP Lab 100194, NYS ELAP 10872, NJ DEP 03036

Initial report from 07/20/2012 23:41:25

**EMSL Analytical, Inc.**

200 Route 130 North, Cinnaminson, NJ 08077

Phone/Fax: (800) 220-3675 / (856) 786-5974

<http://www.emsl.com>cinnaslab@EMSL.com

EMSL Order: 041219104
CustomerID: ENVA55
CustomerPO: CK #10915
ProjectID:

Attn: **Christa Knorr**
Environmental Abatement Associates, Inc.
143 West Main Street

Plymouth, PA 18651

Phone: (570) 779-4242
Fax: (570) 779-0929
Received: 07/20/12 9:40 AM
Analysis Date: 7/20/2012
Collected: 7/18/2012

Project: 12-036-1/ Lebanon VA Medical Center-Bldg 22 Improve Emergency Cache

Test Report: Asbestos Analysis of Bulk Materials via EPA 600/R-93/116 and/or EPA 600/M4-82-020 Method(s) using Polarized Light Microscopy

Sample	Description	Appearance	Non-Asbestos		Asbestos
			% Fibrous	% Non-Fibrous	% Type
B22-08-Cove Base 041219104-0008	109 bowling alleys - covebase	Beige Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B22-08-Mastic 041219104-0008A	109 bowling alleys - covebase	Yellow Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B22-09-Floor Tile 041219104-0009	Lobby 118 - beige floor tile	Beige Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B22-09-Mastic 041219104-0009A	Lobby 118 - beige floor tile	Yellow Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B22-10-Floor Tile 041219104-0010	Lobby 118 - beige floor tile	Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B22-10-Mastic 041219104-0010A	Lobby 118 - beige floor tile	Yellow Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B22-11 041219104-0011	Lobby 118 - green floor tile	Green Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected
B22-12 041219104-0012	Lobby 118 - green floor tile	Green Non-Fibrous Heterogeneous		100% Non-fibrous (other)	None Detected

Analyst(s)

Christina Walker (15)

Nancy Stalter (14)

Stephen Siegel, CIH, Laboratory Manager
or other approved signatory

EMSL maintains liability limited to cost of analysis. This report relates only to the samples reported and may not be reproduced, except in full, without written approval by EMSL. EMSL bears no responsibility for sample collection activities or analytical method limitations. Interpretation and use of test results are the responsibility of the client. This report must not be used by the client to claim product certification, approval, or endorsement by NVLAP, NIST or any agency of the federal government. Non-friable organically bound materials present a problem matrix and therefore EMSL recommends gravimetric reduction prior to analysis. Samples received in good condition unless otherwise noted. Estimated accuracy, precision and uncertainty data available upon request. Unless requested by the client, building materials manufactured with multiple layers (i.e. linoleum, wallboard, etc.) are reported as a single sample.

Samples analyzed by EMSL Analytical, Inc. Cinnaminson, NJ NVLAP Lab Code 101048-0, AIHA-LAP, LLC-IHLAP Lab 100194, NYS ELAP 10872, NJ DEP 03036

Initial report from 07/20/2012 23:41:25

**EMSL Analytical, Inc.**

200 Route 130 North, Cinnaminson, NJ 08077

Phone/Fax: (800) 220-3675 / (856) 786-5974

<http://www.emsl.com>cinnaslab@EMSL.com

EMSL Order: 041219104

CustomerID: ENVA55

CustomerPO: CK #10915

ProjectID:

Attn: **Christa Knorr**
Environmental Abatement Associates, Inc.
143 West Main Street

Plymouth, PA 18651

Phone: (570) 779-4242

Fax: (570) 779-0929

Received: 07/20/12 9:40 AM

Analysis Date: 7/20/2012

Collected: 7/18/2012

Project: **12-036-1/ Lebanon VA Medical Center-Bldg 22 Improve Emergency Cache**

Test Report: Asbestos Analysis of Bulk Materials via EPA 600/R-93/116 and/or EPA 600/M4-82-020 Method(s) using Polarized Light Microscopy

Sample	Description	Appearance	Non-Asbestos		Asbestos	
			% Fibrous	% Non-Fibrous	% Type	
B22-13 041219104-0013	Corridor 121 - ceiling tile	Gray/White Fibrous Heterogeneous	45% Cellulose 35% Min. Wool	20% Non-fibrous (other)		None Detected
B22-14 041219104-0014	Lobby 118 - ceiling tile	Gray Fibrous Heterogeneous	45% Cellulose 35% Min. Wool	20% Non-fibrous (other)		None Detected
B22-15 041219104-0015	Lobby 118 - wallpaper	White Fibrous Heterogeneous	85% Cellulose	15% Non-fibrous (other)		None Detected
B22-16 041219104-0016	Corridor 121 - wallpaper	White Fibrous Heterogeneous	85% Cellulose	15% Non-fibrous (other)		None Detected
B22-17-Cove Base 041219104-0017	Corridor 121 - covebase	Gray Non-Fibrous Heterogeneous		100% Non-fibrous (other)		None Detected
B22-17-Mastic 041219104-0017A	Corridor 121 - covebase	Yellow Non-Fibrous Heterogeneous		100% Non-fibrous (other)		None Detected
B22-18-Cove Base 041219104-0018	Lobby 118 - covebase	Gray Non-Fibrous Heterogeneous		100% Non-fibrous (other)		None Detected
B22-18-Mastic 041219104-0018A	Lobby 118 - covebase	Yellow Non-Fibrous Heterogeneous		100% Non-fibrous (other)		None Detected

Analyst(s)

Christina Walker (15)

Nancy Stalter (14)

Stephen Siegel, CIH, Laboratory Manager
or other approved signatory

EMSL maintains liability limited to cost of analysis. This report relates only to the samples reported and may not be reproduced, except in full, without written approval by EMSL. EMSL bears no responsibility for sample collection activities or analytical method limitations. Interpretation and use of test results are the responsibility of the client. This report must not be used by the client to claim product certification, approval, or endorsement by NVLAP, NIST or any agency of the federal government. Non-friable organically bound materials present a problem matrix and therefore EMSL recommends gravimetric reduction prior to analysis. Samples received in good condition unless otherwise noted. Estimated accuracy, precision and uncertainty data available upon request. Unless requested by the client, building materials manufactured with multiple layers (i.e. linoleum, wallboard, etc.) are reported as a single sample.

Samples analyzed by EMSL Analytical, Inc. Cinnaminson, NJ NVLAP Lab Code 101048-0, AIHA-LAP, LLC-IHLAP Lab 100194, NYS ELAP 10872, NJ DEP 03036

Initial report from 07/20/2012 23:41:25

**EMSL Analytical, Inc.**

200 Route 130 North, Cinnaminson, NJ 08077

Phone/Fax: (800) 220-3675 / (856) 786-5974

<http://www.emsl.com>cinnaslab@EMSL.com

EMSL Order: 041219104

CustomerID: ENVA55

CustomerPO: CK #10915

ProjectID:

Attn: **Christa Knorr**
Environmental Abatement Associates, Inc.
143 West Main Street

Plymouth, PA 18651

Phone: (570) 779-4242
Fax: (570) 779-0929
Received: 07/20/12 9:40 AM
Analysis Date: 7/20/2012
Collected: 7/18/2012

Project: **12-036-1/ Lebanon VA Medical Center-Bldg 22 Improve Emergency Cache**

**Test Report: Asbestos Analysis of Bulk Materials via EPA 600/R-93/116 and/or EPA
600/M4-82-020 Method(s) using Polarized Light Microscopy**

Sample	Description	Appearance	Non-Asbestos		Asbestos
			% Fibrous	% Non-Fibrous	% Type
B22-19 041219104-0019	Corridor 121 - drywall	Tan/White Fibrous Heterogeneous	15% Cellulose 2% Glass	83% Non-fibrous (other)	None Detected
B22-20 041219104-0020	Corridor 121 - drywall	Tan/White Fibrous Heterogeneous	15% Cellulose 2% Glass	83% Non-fibrous (other)	None Detected
B22-21 041219104-0021	Electrical room - sprayed on	Brown Fibrous Heterogeneous	20% Cellulose	80% Non-fibrous (other)	None Detected
B22-22 041219104-0022	Electrical room - sprayed on	Brown Fibrous Heterogeneous	25% Cellulose	75% Non-fibrous (other)	None Detected
B22-23 041219104-0023	Compressor room - sprayed on	Brown Fibrous Heterogeneous	25% Cellulose	75% Non-fibrous (other)	None Detected

Analyst(s)

Christina Walker (15)

Nancy Stalter (14)

Stephen Siegel, CIH, Laboratory Manager
or other approved signatory

EMSL maintains liability limited to cost of analysis. This report relates only to the samples reported and may not be reproduced, except in full, without written approval by EMSL. EMSL bears no responsibility for sample collection activities or analytical method limitations. Interpretation and use of test results are the responsibility of the client. This report must not be used by the client to claim product certification, approval, or endorsement by NVLAP, NIST or any agency of the federal government. Non-friable organically bound materials present a problem matrix and therefore EMSL recommends gravimetric reduction prior to analysis. Samples received in good condition unless otherwise noted. Estimated accuracy, precision and uncertainty data available upon request. Unless requested by the client, building materials manufactured with multiple layers (i.e. linoleum, wallboard, etc.) are reported as a single sample.

Samples analyzed by EMSL Analytical, Inc. Cinnaminson, NJ NVLAP Lab Code 101048-0, AIHA-LAP, LLC-IHLAP Lab 100194, NYS ELAP 10872, NJ DEP 03036

Initial report from 07/20/2012 23:41:25

ATTACHMENT D
CERTIFICATE OF ANALYSIS

United States Department of Commerce
National Institute of Standards and Technology



Certificate of Accreditation to ISO/IEC 17025:2005

NVLAP LAB CODE: 101048-0

EMSL Analytical, Inc.
Cinnaminson, NJ

*is accredited by the National Voluntary Laboratory Accreditation Program for specific services,
listed on the Scope of Accreditation, for:*

BULK ASBESTOS FIBER ANALYSIS

*This laboratory is accredited in accordance with the recognized International Standard ISO/IEC 17025:2005.
This accreditation demonstrates technical competence for a defined scope and the operation of a laboratory quality
management system (refer to joint ISO-ILAC-IAF Communique dated January 2009).*

2012-07-01 through 2013-06-30

Effective dates



A handwritten signature in black ink, appearing to read "Michael R. Mello".

For the National Institute of Standards and Technology



**National Voluntary
Laboratory Accreditation Program**



SCOPE OF ACCREDITATION TO ISO/IEC 17025:2005

EMSL Analytical, Inc.
200 Route 130 North
Cinnaminson, NJ 08077
Mr. Stephen Siegel, CIH
Phone: 800-220-3675 Fax: 856-786-5973
E-Mail: ssiegel@emsl.com
URL: <http://www.emsl.com>

BULK ASBESTOS FIBER ANALYSIS (PLM)

NVLAP LAB CODE 101048-0

NVLAP Code Designation / Description


18/A01	EPA-600/M4-82-020: Interim Method for the Determination of Asbestos in Bulk Insulation Samples
--------	------------------------------------------------------------------------------------------------

2012-07-01 through 2013-06-30

Effective dates

For the National Institute of Standards and Technology

APPENDIX E
ELECTRICAL



FEATURES

- Wet label housing troffer
- Gasketed to provide additional seal between door, lens, and housing
- Mitered corners standard on door frame
- Mechanical light trap
- All metal parts are white powder coat, painted after fabrication
- UL listed 1598 for wet location covered ceiling applications
- Rotary action cam latches. Smooth operating for secure shielding retention
- Corner hinging for easy insertion and removal of shielding frame
- Housing ends are secured by unique corner interlock and screws
- Metal to metal light leak protection on all four sides of shielding frame
- Rotary lock lampholders for positive lamp contact
- Heat sink embossments behind ballasts for cooler operation and longer life

PROJECT INFORMATION

Project Name _____

Catalog No. _____

A1 _____

Type _____

Date _____

FLANGED FEATURES

Four adjustable Uni-Lugs for quick easy installation. Optional plaster frames available for individual or row mounting.

HOUSING

Heavy gauge steel. Die formed for extra rigidity. Designed for installation in standard inverted tee grid ceilings.

BALLASTS

Thermally protected, automatic resetting, Class P, high power factor, sound rated A, unless otherwise specified. CEE NEMA Premium compliant.

ELECTRICAL

Standard class "P," thermally protected, autoresetting HPF ballast, sound rated A. CEE NEMA Premium compliant. All ballast leads extend a minimum of 6" through access location. NEC/CEC-compliant ballast disconnect is standard.

FINISH

All metal parts are processed with a five phase phosphate bonding treatment. Grid units are pre-painted with high glass baked white enamel, 86% reflective. Flanged units are painted after

fabrication with a polyester powder coat, reflectance of 90%.

SHIELDING

100% prismatic acrylic, extruded and roll-embossed, diagonally oriented female prisms, unless otherwise specified.

FLANGED UNIT INSTALLATION

Fixtures are installed from below the ceiling and have overlapping trim flanges. Adjustable Uni-Lugs secure the fixture to the ceiling structure. Plaster frames are available if required.

CERTIFICATION

All luminaires are built to UL 1598 standards and bear appropriate UL and cUL or CSA labels. Wet location labeling is standard.

ORDERING INFORMATION


EXAMPLE WT22-417G-FAA12-EU

WT	22	-	-	-	-	-	-
MODEL	NO. OF LAMPS	CEILING TYPE	SHIELDING	VOLTAGE	OPTIONS	SIZE	LAMP TYPE
WT Wet Location Lensed Troffer	2 Two 3 Three 4 Four	G Inverted T-bar F Overlap Flange	A12 Pattern 12 Acrylic 0.100" Nominal (Standard) A12.125 Pattern 12 Acrylic 0.125" Nominal A19 Pattern 19 Acrylic 0.156" Male Prism DR12 High Impact Acrylic Pattern 12, .140" (Std.)	U 120V-277V 347 347V	F0730 T8, 70CRI, 3000K Lamps, Furn/Inst. F0735 T8, 70CRI, 3500K Lamps, Furn/Inst. F0741 T8, 70CRI, 4100K Lamps, Furn/Inst. SLL Spring Loaded Latches GMF Slow Blow Fuse GLR Fast Blow Fuse C388 3/8" Flex with 3 No. 18 Wires C384 3/8" Flex with 3 No. 14 Wires C488 3/8" Flex with 4 No. 18 Wires C424 1/2" Flex with 4 No. 14 Wires NYC NYC Compliant NYCU NYC Compliant, Union Label	22 2' x 2'	14 2', T5: 14 Watt 17 2', T8: 17 Watt 24 2', T5HO: 24 Watt 40TT Twin Tube Compact, 2G11 Base: 40 Watt 31U1 U-Bent, 1 1/2" Leg Spacing T8: 31 Watt 32U6 U-Bent, 6" Leg Spacing T8: 32 Watt
DOOR STYLE	BALLAST	For a complete set of options, see options and accessories section.					
FA White Flush Aluminum RA White Regressed Aluminum	E Electronic T8, Instant Start 3E 3-lamp Electronic Instant Start (T8) 4E 4-Lamp Electronic T8, Instant Start EP Electronic T5 or T8, Programmed Start 3EP 3-lamp Electronic Programmed Start (T8, T5HO) Others available. 4EP 4-Lamp Electronic T5HO (N/A 347V) or T8, Programmed Start EPTT Electronic Programmed Start (40TT)						


For a specific ballast vendor, show as option.

PHOTOMETRIC DATA – CONTACT FACTORY

DIMENSIONAL DATA



NOTE: All dimensions are in inches; dimensions and specifications are subject to change without notice. Please consult factory or check sample for verification.



FEATURES

- Wet label shallow housing troffer
- Gasketed to provide additional seal between door, lens, and housing
- Mitered corners standard on door frame
- Rolled or hemmed housing edges
- Mechanical light trap
- All metal parts are white powder coat, painted after fabrication
- UL listed 1598 for wet location covered ceiling applications
- Integral T-bar clips quickly secure fixture to the grid system without the need for time-consuming loose parts
- Snap-in ballast covers can be removed when lamps are installed
- Corner hinging for easy insertion and removal of shielding frame
- Flush steel shielding frame, screw assembled for easy diffuser replacement
- Housing ends are secured by unique corner interlock and screws
- Heat sink embossments behind ballasts for cooler operation and longer life
- Metal to metal light leak protection on all four sides of shielding frame

PROJECT INFORMATION

Project Name _____

Type _____

Catalog No. _____

Date _____

FLANGED FEATURES

Four adjustable Uni-Lugs for quick easy installation. Optional plaster frames available for individual or row mounting. Fixture end flanges are removable for row mounting. Joiner channels are included.

HOUSING

Heavy gauge steel. Die formed for extra rigidity. Designed for installation in standard inverted tee grid ceilings.

BALLASTS

Energy efficient, thermally protected, automatic resetting, Class P, high power factor, sound rated A, unless otherwise specified. CEE NEMA Premium compliant.

ELECTRICAL

Standard class "P," thermally protected, autoresetting HPF ballast, sound rated A. CEE NEMA Premium compliant. All ballast leads extend a minimum of 6" through access location. NEC/CEC-compliant ballast disconnect is standard.

FINISH

All metal parts are processed with a five phase phosphate bonding treatment. Grid units are pre-painted with high glass baked white enamel, 86% reflective. Flanged units are painted after fabrication with a polyester powder coat, reflectance of 90%.

SHIELDING

100% prismatic acrylic, extruded and roll-embossed, diagonally oriented female prisms, unless otherwise specified.

FLANGED UNIT INSTALLATION

Fixtures are installed from below the ceiling and have overlapping trim flanges. Adjustable Uni-Lugs secure the fixture to the ceiling structure. Plaster frames are available if required.

CERTIFICATION

All luminaires are built to UL 1598 standards and bear appropriate UL and cUL or CSA labels. Wet location labeling is standard.

ORDERING INFORMATION

EXAMPLE WT24-332G-FAA12-EU-C488-GLR

WT	24	-	-	-	-	-	-
MODEL	NO. OF LAMPS	CEILING TYPE	SHIELDING	VOLTAGE	BALLAST	OPTIONS	
WT Wet Location Lensed Troffer	2 Two 3 Three 4 Four 6 Six	G Inverted T-bar F Overlap Flange	A12 Pattern 12 Acrylic 0.100" Nominal (Standard) A12.125 Pattern 12 Acrylic 0.125" Nominal A19 Pattern 19 Acrylic 0.156" Male Prism DR12 High Impact Acrylic Pattern 12, .140" (Std.)	U 120V-277V 347 347V	E Electronic T8, Instant Start 3E 3-Lamp Electronic T8, Instant Start 4E 4-Lamp Electronic T8, Instant Start 24E (1) 2-Lamp and (1) 4-Lamp Electronic T8, Instant Start EP Electronic T5 or T8, Programmed Start 3EP 3-Lamp Electronic T5HO or T8, Programmed Start 4EP 4-Lamp Electronic T5HO (N/A 347V) or T8, Programmed Start 24EP (1) 2-Lamp and (1) 4-Lamp Electronic T5HO (N/A 347V) or T8, Programmed Start	F0730 T8, 70CRI, 3000K Lamps, Furn/Inst. F0735 T8, 70CRI, 3500K Lamps, Furn/Inst. F0741 T8, 70CRI, 4100K Lamps, Furn/Inst. SLL Spring Loaded Latches GMF Slow Blow Fuse GLR Fast Blow Fuse C388 3/8" Flex with 3 No. 18 Wires C384 3/8" Flex with 3 No. 14 Wires C488 3/8" Flex with 4 No. 18 Wires C424 1/2" Flex with 4 No. 14 Wires NYC NYC Compliant NYCU NYC Compliant, Union Label	
SIZE	LAMP TYPE	DOOR STYLE	For complete list of lenses and louvers, see options and accessories.				
24 2' x 4'	28 4', T5: 28 Watt 32 4', T8: 32, 30, 28 or 25 Watt 54 4', T5HO: 54 or 51 Watt	FA White Flush Aluminum RA White Regressed Aluminum					

For a specific ballast vendor show as option.

For a complete set of options, see options and accessories section.

PHOTOMETRIC DATA

Test 13747 Test Date 12/3/04

LUMINAIRE DATA

Luminaire	WT24-332G-FSA12-3E-PAF WT Lensed Troffer 2' x 4' 3-Lamp with A12 Pattern Acrylic Prisms Lens
Ballast	B2321120RH-A
Ballast Factor	0.88
Lamp	F32T8
Lumens per Lamp	2900
Total Input Watts	87
Mounting	Recessed
Shielding Angle	0° = 90 90° = 90
Spacing Criterion	0° = 1.25 90° = 1.37
Luminous Opening in Feet	Length: 3.82 Width: 1.82 Height: 0.00


ZONAL LUMEN SUMMARY

Zone	Lumens	% Lamp	% Fixt.
0-30	2086	24.0	29.5
0-40	3448	39.6	48.8
0-60	5916	68.0	83.8
0-90	7064	81.2	100.0
0-180	7064	81.2	100.0

ENERGY DATA

Total Luminaire Efficiency	81.2%
Luminaire Efficacy Rating (LER)	FL - 71
ANSI/IESNA RP-1-2004 Compliance	Noncompliant
Comparative Yearly Lighting Energy Cost per 1000 Lumens	\$3.38 based on 3000 hrs. and \$0.08 per KWH

INDOOR CANDELA PLOT



AVG. LUMINANCE (Candela/Sq. M.)

Average Luminance Angle	0.0	22.5	45.0	67.5	90.0
0	4056	4056	4056	4056	4056
30	3903	3992	4160	4287	4321
40	3705	3846	4091	4271	4333
45	3525	3689	3946	4143	4208
50	3249	3430	3702	3890	3945
55	2888	3096	3374	3523	3579
60	2524	2731	2973	3100	3196
65	2235	2370	2517	2641	2795
70	2023	2073	2069	2200	2381
75	1956	1956	1741	1896	2070
80	2095	2015	1658	1783	1863
85	2327	2221	1830	1759	1794


COEFFICIENTS OF UTILIZATION (%)

RCR	RC	80					70					50					0
	RW	70	50	30	10	70	50	30	10	50	30	10	0				
	1	89	85	82	79	87	83	80	78	80	78	75	69				
	2	81	75	70	65	79	73	69	64	71	66	63	58				
	3	74	66	60	55	72	65	59	54	63	58	53	50				
	4	68	59	52	47	66	58	51	46	56	50	46	43				
	5	63	53	46	41	61	52	45	40	50	44	40	37				
	6	58	48	41	36	57	47	40	35	45	39	35	33				
	7	54	43	36	31	53	43	36	31	41	35	31	29				
	8	50	40	33	28	49	39	32	28	38	32	28	26				
9	47	36	30	25	46	36	30	25	35	29	25	23					
10	44	33	27	23	43	33	27	23	32	27	23	21					

RCR = Room Cavity Ratio

RC = Effective Ceiling Cavity Reflectance RW = Wall Reflectance

DIMENSIONAL DATA



NOTE: All dimensions are in inches; dimensions and specifications are subject to change without notice. Please consult factory or check sample for verification.

DESIGNER WALL PACK – ROUND

WPRD

CFL

SUBMITTAL:

JOB:

TYPE: B

VOLTAGE:

EXAMPLE:

WPRD - 1 42T - GX24q-4 - WD - OPTIONS - UNV

SERIES


OF WATTAGE
LAMPS

LAMP
BASE

DISTRIBUTION

OPTIONS


VOLTAGE



SERIES

FEATURES

- ▶ Overall dimensions: 18" x 9-3/16" x 9-1/16".
- ▶ Heat and impact-resistant tempered glass lens.
- ▶ Heavy-duty die-cast aluminum construction.
- ▶ Fully gasketed for wet locations.
- ▶ Provides full cutoff.
- ▶ Dark bronze finish only.



WPRD SERIES

HOUSING — Die-cast aluminum.

REFLECTIVE SURFACES — Aluminum reflector.

LENS — Tempered, flat, clear glass.

LAMP OPTIONS (Must specify)

COMPACT FLUORESCENT

# LAMPS	WATTAGE	LAMP BASE
1	26Q	G24q-3
1	32T	GX24q-3
1	42T	GX24q-4

DISTRIBUTION (Must specify)

WD	Wide Distribution
FD	Forward Throw Distribution

OPTIONS

SF	Single Fuse (120V or 277V only; must specify voltage)
DF	Double Fuse (208V or 240V only; must specify voltage)
GMF	HLR-GMF Style Slow Blow Fuse (Factory installed inside of unit. 120V and 277V only; must specify voltage)

VOLTAGE (Must specify)

120	120V	208	208V
240	240V	277	277V
UNV	120-277V		


ELECTRICAL

4-pin socket, electronic ballast standard.
Prewired at factory for easy field installation.
Rated 0°F minimum starting temperature.


FINISH

Powder coated finish on heavy-duty die-cast housing. Dark bronze finish only.

MOUNTING



BACK VIEW




BOLT CIRCLE PATTERN DETAIL

MOUNTING

Wall mounts directly over a 4" maximum recessed outlet box.

FOOTCANDLE ESTIMATOR



FIXTURE: **WPRD-142T-GX24q-4-FD**

Footcandle calculations based on standard building reflectance of .10 with a ground reflectance of .0 and a light loss factor of .75.

Fixture installed at 15' mounting height.

LABELS

cCSAus certified as
luminaire suitable
for wet location.



LED EXIT SIGN

EXIT

SUBMITTAL:

JOB:

TYPE: X

VOLTAGE:

EXAMPLE: **EXIT - R - EM - WHT - OPTIONS**

SERIES

LETTER
COLOR

POWER
OPTIONS



HOUSING
COLOR

OPTIONS/
ACCESSORIES

SERIES

FEATURES

- ▶ Available as full-time AC powered unit or emergency unit with battery backup.
- ▶ LED lamp life of 25 years.
- ▶ Provided as universal single face/double face unit.
- ▶ Ni-Cad battery on emergency (EM) units provides 90 minutes of emergency operation.
- ▶ Automatic, low voltage disconnect (LVD) activates EM unit in event of partial power failure or brownout.
- ▶ Universal mounting canopy for top or side installation.
- ▶ Energy consumption of 3.2 watts for red letters and 3.8 watts for green letters.
- ▶ Charge rate/power on LED indicator light.
- ▶ Removable directional indicators.
- ▶ Available with industry-standard white or black housing.
- ▶ Custom messages available, consult factory for details.



EXIT SERIES

HOUSING — Injection-molded, V0 flame retardant, high-impact thermoplastic housing.

ELECTRICAL — Universal transformer for 120 or 277 VAC operation.

MOUNTING — Universal mounting canopy included for top or side installation.

LETTER COLOR (Must specify)

R	Red	G	Green
----------	-----	----------	-------

POWER OPTIONS (Must specify)

AC	AC operation	EM	AC operation with emergency battery backup
-----------	--------------	-----------	--------------------------------------------


HOUSING COLOR (Must specify)

BLK	Black	WHT	Industry-standard white
------------	-------	------------	-------------------------

OPTIONS

COPY	Consult factory for custom message	SALIDA	Salida faceplate (industry-standard white only)
DC	Dual circuit	SDT	Self-diagnostic test

ACCESSORIES



PC1
Polycarbonate shield



WG
Wireguard

LABELS

Listed to UL 924 standard as an exit light suitable for dry or damp location.

EXIT

LED EXIT SIGN

