



- ① REMOVE EXISTING AREA DRAINS. PLUG EXISTING PIPES WITH AN EPOXY PRODUCT.
- ② CUT EXISTING CONCRETE TO FLOOR OF WINDOW WELL. FORM AND POUR CONCRETE TROUGH AND NEW 6" STORM DRAIN OUTLET.
- ③ EXCAVATE AREA FOR BORING PIT. INSTALL GRATE OR LARGE SCREEN TO PREVENT LEAVES OR DEBRIS FROM PLUGGING THIS NEW STORM PLUGGING THIS NEW STORM DRAIN SYSTEM.
- ④ DIRECTIONAL BORE 6" CONTINUOUS STORM DAYLIGHT OUTLET AT CURB HEIGHT BY MRI/CT DOCK. VERIFY EXACT LOCATION WITH RESIDENT ENGINEER.

1" = 50'

4
F

1
: