



- SHEET NOTES**
- ① REMOVE EXISTING TEMPORARY FEEDERS FROM CONDUIT WHEN NEW FEEDERS ARE INSTALLED AND OPERATIONAL.

- 3) EXISTING AS PART OF SPECIALTY CLINIC PROJECT.
- 4) PROVIDE 48" X 48" DEEP RECESSED CONCRETE VALT WITH SPRING ASSISTED BALANCED FLANGE PLATE FLOOR WITH LOCKING LATCH PROVIDE EXTENSION RISERS AS REQUIRED. SEE DETAIL SECTION.
- 5) DISCONNECT AND REMOVE (E) JOINTS CIRCUIT TO SHED FROM PANEL 6.
- 6) VERIFY EXACT LOCATION OF CONDUIT SHEDDERS IN FIELD. EXTEND TO GROUND AND CONTROL POINT AS REQUIRED. SEE DETAIL SECTION.
- 7) (E) GSA 8" SURFACE MOUNTED RAIL BOX 3" ABOVE GRADE WITH CONE RAILS THROUGH WALL TO CONNECT TO NDB-HALL. SEE SHEET ABOVE.
- 8) (E) CONDUIT TO BE ABANDONED AND CAPPED AT EACH END.
- 9) (E) CONDUIT TO BE REMOVED.
- 10) (E) CONDUIT RUNNING TO THE NORTH ON WALL SHALL BE REMOVED AND REROUTED AROUND NEM IN FIELD.
- 11) EXTEND REEFER CONDUITS UP WALL AND OVER HEAD AND DOWN TO AIS5 AS REQUIRED. SEE SHEET ABOVE.

- ## GENERAL NOTES
1. COORDINATE ALL NEW INTERCROSS UTILITIES WITH EXISTING CONDITIONS. CALL BEFORE YOU DIG.
 2. SEE DETAILED DIAGRAM FOR CONDUITS IN CONDUITS.
 3. VARY EXACT ROUTING OF EXISTING CONDUITS IN FIELD.