

**SECTION 07 01 50.19
PREPARATION FOR RE-ROOFING**

PART 1 - GENERAL

1.1 DESCRIPTION

- A. Roof tear-off, temporary roofing membrane, roof re-cover preparation, removal of base flashings on existing construction in preparation to receive new roofing membrane.
- B. Existing Membrane Roofing System: EPDM, with related insulation, surfacing, and components and accessories between deck and roofing membrane.

1.2 RELATED WORK

- A. Use of the premises and phasing requirements: Section 01 00 00 GENERAL REQUIREMENTS.
- B. Temporary construction and environmental-protection measures for reroofing preparation: Section 01 00 00 GENERAL REQUIREMENTS
- C. Electrical equipment disconnection and reconnection: Division 26 sections.

1.3 APPLICABLE PUBLICATIONS

- A. Publications listed below form a part of this specification to the extent referenced. Publications are referenced in the text by the basic designation only. Editions of applicable publications current on date of issue of bidding documents apply unless otherwise indicated.
- B. American National Standards Institute/Single-Ply Roofing Institute (ANSI/SPRI):
 - ANSI/SPRI FX-1-01(R2006) Standard Field Test Procedure for
Determining the Withdrawal Resistance of
Roofing Fasteners.
- C. ASTM International (ASTM):
 - C208-08.....Cellulosic Fiber Insulating Board
 - C728-05.....Perlite Thermal Insulation Board
 - C1177/C1177M-08.....Standard Specification for Glass Mat Gypsum
Substrate for Use as Sheathing
 - C1278/C1278M-07.....Standard Specification for Fiber-Reinforced
Gypsum Panel
 - D1079-09.....Standard Terminology Relating to Roofing and
Waterproofing
- D. FM Approvals: RoofNav Approved Roofing Assemblies and Products.

4450-89.....Approved Standard for Class 1 Insulated Steel
Deck Roofs

4470-10.....Approved Standard for Class 1 Roof Coverings

1-28-09.....Loss Prevention Data Sheet: Design Wind Loads.

1-29-09.....Loss Prevention Data Sheet: Above-Deck Roof
Components

1-49-09.....Loss Prevention Data Sheet: Perimeter Flashing

E. National Roofing Contractors Association: Roofing and Waterproofing
Manual

1.4 MATERIALS COTRSHIP

A. Assume COTRship of demolished materials and remove from Project site
and dispose of legally, unless indicated to be reused, reinstalled, or
otherwise to remain COTR's property.

1.5 DEFINITIONS

A. Refer to ASTM D1079 and NRCA "The NRCA Roofing and Waterproofing
Manual" for definition of terms.

1.6 QUALITY CONTROL

A. Requirements of Division 07 roofing section for qualifications of
roofing system and roofing insulation Installer; work of this section
shall be performed by same Installer.

B. Regulatory Requirements: Comply with governing EPA notification
regulations. Comply with hauling and disposal regulations of
authorities having jurisdiction.

C. Reroofing Conference: Conduct conference at Project site.

1. Meet with COTR; Architect-Engineer; testing and inspecting agency
representative; roofing system manufacturer's representative;
roofing Installer including project manager, superintendent, and
foreman; and installers whose work interfaces with or affects
reroofing.

2. Review methods and procedures related to roofing system tear-off and
replacement

1.7 SUBMITTALS

A. Submit in accordance with Section 01 33 23, SHOP DRAWINGS, PRODUCT
DATA, AND SAMPLES.

B. Manufacturer's Literature and Data:

1. Recover boards.

C. List of proposed infill materials.

- D. List of proposed temporary roofing materials.
- E. Fastener pull-out test report.
- F. Photographs or Videotape: Document existing conditions of adjacent construction including site improvements.
- G. Landfill Records: Indicate receipt and acceptance of hazardous wastes by a licensed landfill facility.
- H. Qualification Data: For Installer.
 - 1. Certificate indicating Installer is licensed to perform asbestos abatement.
 - 2. Certificate indicating Installer is approved by warrantor of existing roofing system.

1.8 PROJECT CONDITIONS

- A. COTR will occupy portions of building below reroofing area. Conduct reroofing so COTR's operations will not be disrupted.
 - 1. Coordinate work activities daily with COTR.
 - 2. Provide COTR with not less than 72 hours' notice of activities that may affect COTR's operations.
- B. Protect building and landscaping from damage.
- C. Maintain access to existing walkways and adjacent occupied facilities.
- E. Weather Limitations: Proceed with reroofing preparation only when weather conditions permit Work to proceed without water entering existing roofing system or building.
- F. Hazardous Materials: It is not expected that Contractor will encounter hazardous materials such as asbestos-containing materials.
 - 1. COTR will remove hazardous materials before start of the Work.
 - 2. Do not disturb materials suspected of containing hazardous materials. Notify Architect-Engineer and COTR. Hazardous materials will be removed by COTR under a separate contract.

1.9 WARRANTY

- A. Existing Warranties: Remove, replace, patch, and repair materials and surfaces affected by reroofing, by methods and with materials acceptable to warrantor.
 - 1. Notify warrantor of existing roofing system before proceeding, and upon completion of reroofing.
 - 2. Obtain documentation verifying that existing roofing system has been inspected by warrantor and warranty remains in effect. Submit documentation at Project closeout.

PART 2 - PRODUCTS

2.1 INFILL MATERIALS

- A. Use infill materials matching existing membrane roofing system materials.

2.2 TEMPORARY ROOFING MATERIALS

- A. Design of temporary roofing and selection of materials are responsibilities of Contractor.

2.3 RECOVER BOARDS

- A. Insulation Serving as Recover Board: Requirements are specified in Section 07 22 00 ROOF AND DECK INSULATION.
- B. Fasteners: Factory-coated steel fasteners, No. 12 or 14, and metal or plastic plates listed in FM Approval's "RoofNav."

2.4 AUXILIARY REROOFING MATERIALS

- A. General: Auxiliary reroofing preparation materials recommended by roofing system manufacturer and compatible with components of existing and new membrane roofing system.
- B. Base Sheet Fasteners: Capped head, factory-coated steel fasteners, listed in FM Approval's "RoofNav."
- C. Metal Flashing Sheet: Metal flashing sheet is specified in Section 07 60 00 SHEET METAL FLASHING AND TRIM.

PART 3 - EXECUTION

3.1 PREPARATION

- A. Protect existing membrane roofing system that is indicated not to be reroofed.
 - 1. Limit traffic and material storage to areas of existing roofing membrane that have been protected.
 - 2. Maintain temporary protection and leave in place until replacement roofing has been completed. Remove temporary protection on completion of reroofing.
- B. Coordinate with COTR to shut down air-intake equipment in the vicinity of the Work. Cover air-intake louvers before proceeding with reroofing work that could affect indoor air quality or activate smoke detectors in the ductwork.
 - 1. Comply with COTR's requirements for maintaining fire watch when temporarily disabling smoke detectors.

- C. During removal operations, have sufficient and suitable materials on-site to facilitate rapid installation of temporary protection in the event of unexpected rain.
- D. Maintain roof drains in functioning condition to ensure roof drainage at end of each workday. Prevent debris from entering or blocking roof drains and conductors. Use roof-drain plugs specifically designed for this purpose. Remove roof-drain plugs at end of each workday, when no work is taking place, or when rain is forecast.
 - 1. If roof drains are temporarily blocked or unserviceable due to roofing system removal or partial installation of new membrane roofing system, provide alternative drainage method to remove water and eliminate ponding.
 - 2. Do not permit water to enter into or under existing membrane roofing system components that are to remain.
- E. Verify that rooftop utilities and service piping have been shut off before beginning the Work.

3.2 ROOF TEAR-OFF

- A. General: Notify COTR each day of extent of roof tear-off proposed for that day and obtain authorization to proceed.
- B. Remove aggregate ballast from roofing membrane. Store aggregate ballast for reuse
- C. Remove loose aggregate from aggregate-surfaced built-up bituminous roofing using a power broom.
- D. Remove pavers and accessories from roofing membrane. Store and protect pavers and accessories for reuse. Discard cracked pavers.
- E. Remove protection mat and insulation from protected roofing membrane.
 - 1. Discard insulation that is wet and exceeds 8 lb/cu. ft.
 - 2. Store insulation for reuse and protect from physical damage.
- F. Roof Tear-Off: Remove existing roofing membrane and other membrane roofing system components down to the deck.
 - 1. Dry bitumen and felts that are firmly bonded to concrete decks may remain. Remove wet or unadhered bitumen and felts.
 - 2. Remove fasteners from deck or cut fasteners off slightly above deck surface and apply recover board prior to installing roof membrane.

3.3 DECK PREPARATION

- A. Inspect deck after tear-off or partial tear-off of membrane roofing system.

- B. Verify that concrete substrate is visibly dry and free of moisture.
Test for capillary moisture by plastic sheet method according to ASTM D 4263. Do not proceed with roofing work if moisture condenses under the plastic sheet.
- C. If broken or loose fasteners that secure deck panels to one another or to structure are observed or if deck appears or feels inadequately attached, immediately notify Architect-Engineer. Do not proceed with installation until directed by Architect-Engineer.
- D. If deck surface is not suitable for receiving new roofing or if structural integrity of deck is suspect, immediately notify Architect-Engineer. Do not proceed with installation until directed by Architect-Engineer.
- E. Provide additional deck securement as indicated on Drawings.
- F. Replace deck as indicated on Drawings.

3.4 INFILL MATERIALS INSTALLATION

- A. Immediately after removal of selected portions of existing membrane roofing system, and inspection and repair, if needed, of deck, fill in the tear-off areas to match existing membrane roofing system construction.
 - 1. Install new roofing membrane patch over roof infill area. If new roofing membrane is installed the same day tear-off is made, roofing membrane patch is not required.

3.5 TEMPORARY ROOFING MEMBRANE

- A. Install approved temporary roofing membrane over area to be reroofed.
- B. Remove temporary roofing membrane before installing new roofing membrane.
- C. Prepare the temporary roof to receive new roofing membrane according to approved temporary roofing membrane proposal. Restore temporary roofing membrane to watertight condition. Obtain approval for temporary roof substrate from roofing membrane manufacturer and Architect-Engineer before installing new roof.

3.6 ROOF RE-COVER PREPARATION

- 1. Remove loose aggregate from aggregate-surfaced built-up bituminous roofing with a power broom.
- 2. Broom clean existing substrate.
- 3. Coordinate with COTR's inspector to schedule times for tests and inspections before proceeding with installation of recover boards.

4. Remove materials that are wet or damp. Removal will be paid for by adjusting the Contract Sum according to unit prices included in the Contract Documents.
- B. Remove blisters, ridges, buckles, and other substrate irregularities from existing roofing membrane that inhibit new roofing membrane from conforming to substrate.
 1. Remove loose aggregate from aggregate-surfaced built-up bituminous roofing with a power broom.
 2. Broom clean existing substrate.
 3. Coordinate with COTR's inspector to schedule times for tests and inspections.
 4. Remove materials that are wet and damp. Removal will be paid for by adjusting the Contract Sum according to unit prices included in the Contract Documents.
 5. Remove loose aggregate from aggregate-surfaced built-up bituminous roofing with a power broom.
 6. Power vacuum the existing roof surface. If recommended by manufacturer, prime dried surface at recommended rate with recommended primer.

3.7 EXISTING BASE FLASHINGS

- A. Remove existing base flashings around parapets, curbs, walls, and penetrations.
 1. Clean substrates of contaminants such as asphalt, sheet materials, dirt, and debris.
- B. Do not damage metal counterflashings that are to remain. Replace metal counterflashings damaged during removal with counterflashings specified in Section 07 60 00 SHEET METAL FLASHING AND TRIM.

3.8 FASTENER PULL-OUT TESTING

- A. Retain independent testing and inspecting agency to conduct fastener pull-out tests according to SPRI FX-1, and submit test report to Architect-Engineer before installing new membrane roofing system.
 1. Obtain Architect-Engineer's approval to proceed with specified fastening pattern. Architect-Engineer may furnish revised fastening pattern commensurate with pull-out test results.

3.9 RECOVER BOARD INSTALLATION

- A. Install recover boards over roof insulation with long joints in continuous straight lines and end joints staggered between rows. Loosely butt recover boards together and fasten to deck.
 - 1. Fasten recover boards to resist wind-uplift pressure at corners, perimeter, and field of roof as required.
 - 2. Install additional fasteners near board corners and edges as necessary to conform boards to substrate and to adjacent boards.

3.10 DISPOSAL

- A. Collect demolished materials and place in containers. Promptly dispose of demolished materials. Do not allow demolished materials to accumulate on-site.
 - 1. Storage or sale of demolished items or materials on-site is not permitted.
- B. Transport and legally dispose of demolished materials off COTR's property.

--- END OF SECTION ---