



- ## GENERAL NOTES
1. DETAILS SHOWN ARE TYPICAL, AND BASED ON ASCO EQUIPMENT. CONSULT WIRING AND TERMINATION DETAILS FROM SUPPLIED SWITCHES FOR ACTUAL TERMINATIONS, RACEWAY ENTRIES, SIZES AND CONFIGURATIONS.
 2. MAINTAIN A MINIMUM OF 48" CLEARANCE IN FRONT OF SWITCHES.
 3. THE CONTRACTOR SHALL FIELD VERIFY ACTUAL EXISTING POWER AND CONTROL CABLE LENGTHS PRIOR TO BEGINNING SWITCH CHANGE-OUT. IF EXISTING LENGTHS ARE NOT ADEQUATE, CONTACT ARCHITECT AND ENGINEER PRIOR TO BEGINNING ANY WORK.
 4. FIELD VERIFY EXACT LOCATIONS FOR TERMINAL BLOCK LOCATIONS.

2 TYPICAL FRONT CONNECTED 600A ATS OPEN TYPE
NTS



3 600A OPEN TYPE - TYPICAL COMPONENT LOCATIONS

[illegible]