

**SECTION 09 65 13  
RESILIENT BASE AND ACCESSORIES**

**PART 1 - GENERAL****1.1 DESCRIPTION**

This section specifies the installation rubber base, resilient stair treads, and resilient molding accessories

**1.2 RELATED WORK**

- A. Color and texture: See drawings Refer to Finish Legend for Basis of Design products
- Approved manufacturers: Johnsonite, Nora and Armstrong, OR APPROVED EQUAL

**1.3 SUBMITTALS**

- A. Submit in accordance with Section 01 33 23, SHOP DRAWINGS, PRODUCT DATA, AND SAMPLES.
- B. Manufacturer's Literature and Data:
1. Description of each product.
  2. Base and stair material manufacturer's recommendations for adhesives.
  3. Application and installation instructions.
- C. Samples:
1. Base: 150 mm (6 inches) long, each type and color.
  2. Resilient Stair Treads: 150 mm (6 inches) long.
  3. Sheet Rubber Flooring: 300 mm (12 inches) square.
  4. Adhesive: Literature indicating each type.

**1.4 DELIVERY**

- A. Deliver materials to the site in original sealed packages or containers, clearly marked with the manufacturer's name or brand, type and color, production run number and date of manufacture.
- B. Materials from containers which have been distorted, damaged or opened prior to installation will be rejected.

**1.5 STORAGE**

- A. Store materials in weather tight and dry storage facility.
- B. Protect material from damage by handling and construction operations before, during, and after installation.

**1.6 APPLICABLE PUBLICATIONS**

- A. The publication listed below form a part of this specification to the extent referenced. The publications are referenced in the text by the basic designation only.
- B. American Society for Testing and Materials (ASTM):
  - F1344-10.....Rubber Floor Tile
  - F1859-10.....Rubber Sheet Floor Covering without Backing
  - F1860-10.....Rubber Sheet Floor Covering with Backing
  - F1861-08.....Resilient Wall Base
- C. Federal Specifications (Fed. Spec.):
  - RR-T-650E.....Treads, Metallic and Non-Metallic, Nonskid

**PART 2 - PRODUCTS****2.1 GENERAL**

Use only products by the same manufacturer and from the same production run.

**2.2 RESILIENT BASE**

- A. ASTM F1861, 3 mm (1/8 inch) thick, 100 mm (4 inches) high, Thermoplastics, Group 2-layered. Style B-cove.
- B. Where carpet occurs, use Style A-straight.
- C. Use only one type of base throughout.

Manufacturers: Subject to compliance with requirements, provide products by one of the following

- a. Armstrong World Industries, Inc.
- b. Johnsonite.
- c. Nora Rubber Flooring; Freudenberg Building Systems, Inc.
- d. Roppe Corporation, USA.
- e. OR EQUAL

- 2. Material Requirement: Type TP (rubber, thermoplastic)
- 3. Manufacturing Method: Group I (solid, homogeneous)

- B. Minimum Thickness: 0.125 inch
- C. Height: 4 inches
- D. Lengths: Coils in manufacturer's standard length
- E. Finish: Matte

**2.3 RESILIENT TREADS**

- A. Fed. Spec. RR-T-650, Composition A, Type 2, 5 mm (3/16 inch) thick on wear surface tapering to 3 mm (1/8 inch) thick at riser end.

B. Nosing shape to conform to sub-tread nosing shape.

1. Material Requirement: Type TP (rubber, thermoplastic)
2. Surface Design: hammered
3. Manufacturing Method: Group 2, tread with contrasting color for the visually impaired.

F. Nosing Style, Height and Thickness: as specified by product designation indicated in Finish Schedule

G. Risers: Produced by the same manufacturer as treads and recommended by manufacturer for installation with treads.

H. Stringers: Of same thickness as risers, height and length after cutting to fit risers and treads and to cover stair stringers; produced by same manufacturer as treads and recommended by manufacturer for installation with treads.

I. Size: Lengths and depths to fit each stair tread in one piece or, for treads exceeding maximum lengths manufactured, in equal-length units.

#### **2.4 RESILIENT MOLDING ACCESSORY**

- A. Manufacturers: Subject to compliance with requirements, provide products by one of the following
- a. Johnsonite.
  - b. R.C.A. Rubber Company (The).
  - c. Roppe Corporation, USA.
  - d. OR APPROVED EQUAL

B. Description: Cap for cove carpet, Cap for cove resilient floor covering, Carpet edge for glue-down applications, Nosing for carpet, Nosing for resilient floor covering, Reducer strip for resilient floor covering, Joiner for tile and carpet, Transition strips

C. Material: Rubber.

D. Profile and Dimensions: As recommended per manufacturer for intended applications

#### **2.5 PRIMER (FOR CONCRETE FLOORS)**

As recommended by the adhesive and tile manufacturer.

#### **2.6 LEVELING COMPOUND (FOR CONCRETE FLOORS)**

Provide products with latex or polyvinyl acetate resins in the mix.

#### **2.7 ADHESIVES**

- A. Use products recommended by the material manufacturer for the conditions of use.
- B. Use low-VOC adhesive during installation. Water based adhesive with low VOC is preferred over solvent based adhesive.

**PART 3 - EXECUTION****3.1 PROJECT CONDITIONS**

- A. Maintain temperature of materials above 21° C (70 °F), for 48 hours before installation.
- B. Maintain temperature of rooms where work occurs, between 21° C and 27° C (70°F and 80°F) for at least 48 hours, before, during, and after installation.
- C. Do not install materials until building is permanently enclosed and wet construction is complete, dry, and cured.

**3.2 INSTALLATION REQUIREMENTS**

- A. The respective manufacturer's instructions for application and installation will be considered for use when approved by the Resident Engineer.
- B. Submit proposed installation deviation from this specification to the Resident Engineer indicating the differences in the method of installation.
- C. The Resident Engineer reserves the right to have test portions of material installation removed to check for non-uniform adhesion and spotty adhesive coverage.

**3.3 PREPARATION**

- A. Examine surfaces on which material is to be installed.
- B. Fill cracks, pits, and dents with leveling compound.
- C. Level to 3 mm (1/8 inch) maximum variations.
- D. Do not use adhesive for leveling or filling.
- E. Grind, sand, or cut away protrusions; grind high spots.
- F. Clean substrate area of oil, grease, dust, paint, and deleterious substances.
- G. Substrate area dry and cured. Perform manufacturer's recommended bond and moisture test.
- H. Preparation of existing installation:
  - 1. Remove existing base and stair treads including adhesive.
  - 2. Do not use solvents to remove adhesives.
  - 3. Prepare substrate as specified.

**3.4 BASE INSTALLATION**

- A. Location:
  - 1. Unless otherwise specified or shown, where base is scheduled, install base over toe space of base of casework, lockers,

laboratory, pharmacy furniture island cabinets and where other equipment occurs.

2. Extend base scheduled for room into adjacent closet, alcoves, and around columns.

B. Application:

1. Apply adhesive uniformly with no bare spots.
2. Set base with joints aligned and butted to touch for entire height.
3. Before starting installation, layout base material to provide the minimum number of joints with no strip less than 600 mm (24 inches) length.
  - a. Short pieces to save material will not be permitted.
  - b. Locate joints as remote from corners as the material lengths or the wall configuration will permit.

C. Form corners and end stops as follows:

1. Score back of outside corner.
2. Score face of inside corner and notch cove.

D. Roll base for complete adhesion.

### **3.5 STAIR TREAD INSTALLATION**

- A. Prepare surfaces to receive the treads in accordance with applicable portions of paragraph, preparation.

B. Layout of Treads.

1. No joints will be accepted in treads.,
2. Set full treads on intermediate and floor landings.

C. Application:

1. Apply adhesive uniformly with no bare spots.
2. Roll and pound treads to assure adhesion.

### **3.6 RESILIENT ACCESSORY INSTALLATION**

- A. Resilient Molding Accessories: Butt to adjacent materials and tightly adhere to substrates throughout length of each piece. Install reducer strips at edges of carpet and /or resilient floor covering that would otherwise be exposed.

### **3.7 CLEANING AND PROTECTION**

- A. Clean all exposed surfaces of base and adjoining areas of adhesive spatter before it sets.
- B. Keep traffic off resilient material for at least 72 hours after installation.
- C. Clean and polish materials in the following order:

1. After two weeks, scrub resilient base, sheet rubber and treads materials with a minimum amount of water and a mild detergent. Leave surfaces clean and free of detergent residue. Polish resilient base to a gloss finish.
  2. Do not polish tread and sheet rubber materials.
- D. When construction traffic is anticipated, cover tread materials with reinforced kraft paper and plywood or hardboard properly secured and maintained until removal is directed by the Resident Engineer.
- E. Where protective materials are removed and immediately prior to acceptance, replace damaged materials and re-clean resilient materials. Damaged materials are defined as having cuts, gouges, scrapes or tears and not fully adhered.

- - - E N D - - -