

GENERAL SHEET NOTES:

1. REFER TO DWG E-001 FOR NOTES, SYMBOLS, AND ABBREVIATIONS

2. COMMISSIONING START UP SHALL OCCUR ONLY DURING OFF PEAK HOURS

3. ELECTRICAL CONTRACTOR SHALL VERIFY DIMENSIONS WITH MECHANICAL ENGINEER BEFORE FIELD AND COORDINATE WITH OTHER TRADES BEFORE FIELD INSTALLATION

SHEET KEYNOTES:

1. BURIED CABLE AND CONDUIT SHALL BE BURIED AT A DEPTH OF 4 FEET AND ENCASED IN CONCRETE.
2. PLASTIC IDENTIFICATION TAPE SHALL BE BURIED AT A DEPTH OF 4 FEET AND ENCASED IN CONCRETE. IDENTIFY EVERY 100' FROM SWITCH S18 TO TUNNEL PENETRATION. SEE DETAIL 1 ON DWG EP-504
3. CONTRACTOR SHALL PROTECT AND INSTALL PULL BOXES EVERY 100' FROM SWITCH S18 TO TUNNEL PENETRATION. SEE DETAIL 1 ON DWG EP-504
4. TWO (2) - FOUR (4) INCH CONDUITS ENCASED IN CONCRETE. ONE (1) CONDUIT SHALL CARRY CABLE. THE SECOND SHALL BE A SPARE. SEE DWG EP-601
5. FOUR (4) - FOUR (4) INCH CONDUITS ENCASED IN CONCRETE. THREE (3) CONDUITS SHALL CARRY CABLES. THE FOURTH SHALL BE A SPARE. SEE DWG EP-601
6. REFER TO DWG EP-401 FOR EXISTING SWITCH S18 DETAILS

