

**NOTES:**

1. EXPANSION JOINTS SHALL BE LOCATED WHERE SIDEWALK ABUTS CONCRETE CURB; EXISTING SIDEWALK; AS SHOWN. SPACING BETWEEN EXPANSION JOINTS SHALL NOT EXCEED 60 FEET.
2. ONE-QUARTER INCH BITUMINOUS JOINT FILLER SHALL BE INSTALLED AT EXPANSION JOINT LOCATIONS AND SHALL EXTEND THE FULL DEPTH OF THE CONCRETE. CAULK ALL EXPANSION JOINTS.
3. NEW SIDEWALK SHALL HAVE 4x4-W1.4xW1.4 STEEL REINFORCEMENT MESH. USE ONLY FLAT SHEETS PLACED ON CHAIRS. CUT OR INTERRUPT AT EXPANSION JOINTS.
4. CONCRETE SHALL BE FINISHED BY MEANS OF A FLOAT, STEEL TROWELLED AND BROOMED WITH A FINE BRUSH IN A TRANSVERSE DIRECTION.
5. 1" DEEP SCORED JOINTS (TYP) SPACED AT 4' ON 48" WIDE WALK WIDTH; 3' ON 36" WIDE WALK. FILL WITH POLYURETHANE SEALANT TO MEET LEVEL OF SLAB.