

## DRAWING NOTES:

1. CONNECT TO NEW FIRE ALARM CONTROL PANEL.
2. TO TELECOM RACK.
3. PROVIDE 110 BLOCK AND TERMINATE EXISTING RELOCATED 50 PAIR TELEPHONE LINE.
4. PROVIDE CONNECTIONS TO INTERACTIVE WHITEBOARD.
5. PROVIDE WEATHER-PROOF BOX AND COVER.
6. PROVIDE BOX COVER PLATE AND 1" CONDUIT WITH PULLSTRING TO CABLE TRAY IN ATTIC SPACE FOR FUTURE OUTLET.
7. RE-INSTALL EXISTING CCTV FIBER CABLES AND CALL BOX COPPER CABLES.
8. REFER TO DETAIL # 1 ON SHEET #T-402.

---

PDG 110105.01